


ABB Procontic CS 31

Intelligent decentralized
automation system

FPTN 440 004 R2001 - d



This technical documentation supplied in a loose-leaf file can be easily up-dated.

In order to be registered in our revision and up-dating service, the enclosed Original Registration Form⁽¹⁾ should be filled-in and addressed to your local ABB contact engineer.

The supplements contain either new sections of the documentation or replacement pages for existing sections. Instructions for these supplements are enclosed in the corresponding parcel.

All rights reserved to change design, size, weight of the equipment described in our documentation.

(1) Copy is not suitable.

ABB Procontic CS31

Intelligent decentralized
automation system

Main summary

General **1**

Hardware **2**

Central processing unit **3**
– 07 KR 31/ 07 KT 31

Central processing units **4**
– 07 KR 91
– 07 KT 92
– 07 KT 93

Central processing units **5**
– UCZA/UCZB
– PCZB /CS 20

6

Programming **7**
– Handheld terminal TCZ
– Monitor
– Software PC 29

Networking **8**

Temporary documents **9**

10

Reply – Card

Please fill-in with the address of your local ABB contact engineer.



Date :

ABB Procontic CS 31

Ref.: Technical documentation **FPTN 440 004 R2001-d**

Dear Sirs,

I want to keep my technical documentation updated, which is why I would like to have my name to your list for distribution of revised documentation. The returned original reply card contains all relevant information.

I am interested in detailed information about modifications on existing devices as well as technical details of novel devices forming part of the control system used in my installation.

My address :

Company :

Department :

Surname, first name :

Street, No, or P.O. Box :

Post code : City : Country :

Yours sincerely

(Visa)

ABB CS31

Intelligent decentralized automation system

General



ABB Control



Contents

FPTC 404 364 P2001-e

Chapter	Description	Page
1	General	1-1
2	System description	2-1
2.1	CS 31 benefits	2-4
2.2	Modular system	2-4
2.3	Versatile range	2-4
2.4	Diagnosis	2-4
2.5	Use of the CS 31 system	2-4
2.6	Emergency operation	2-4
2.7	ABB Procontic CS 31 equipment	2-5
2.8	General characteristics	2-13
3	General operation	
3.1	CPU communication with remote units	3-1
3.2	Addressing of the remote units	3-1
3.3	System bus	3-1
3.4	Transmission format	3-6
3.5	Bus refresh time	3-6
	3.5.1 Bus refresh time	3-7
	3.5.2 Response time to energize an output from the activation of an input	3-7
4	Programming and testing	
4.1	TCZ handheld terminal	4-1
4.2	Programming Software	4-1
	4.2.1 Software for 07 KR 91 central unit	4-1

Machines and plant equipment, for reasons of competitiveness are becoming even more complex, the amount of information required from sensors and actuating devices is constantly expanding, causing heavier implementation and higher wiring costs.

The ABB Procontic CS 31 is designed to simplify implementation and wiring.

The CS 31 is a decentralized automation system.

The system is ideally suited to applications where modularity and cost reduction are key factors.

The CS 31 system comprises of the following :

- a central unit, enclosed within a compact case which can be screw or DIN rail mounted,
- remote input/output plug-in units, which are easily removeable. The plug-in base can be screw or DIN rail mounted,
- a simple twisted pair wire arrangement (RS 485), which is utilized for connection of the central unit to the I/O units.


2 System description

The decentralized architecture of the ABB Procontic CS 31 system offers a superior solution to control system requirements:

- The central unit can be mounted within the control panel.
- The input/output units can be mounted local to the sensors and actuators.

As an example the central unit may be connected to remote units distributed along a process line.



A cost reduction in wiring is possible upto 80% with the implementation of the CS 31 system.



Conventional wiring

Simplified wiring with
the ABB Procontic CS 31 system

Example of configuration



2.1 CS 31 benefits

- decentralized architecture as opposed to centralized system,
- reduction of wiring costs (design, materials and commissioning time),
- configurable input/output units,
- extensive diagnosis functions,
- freely expandable network. Additional units can be connected whilst the installation is operational,
- simple transparent programming. All remote I/O channels are handled as though they were centralized,
- remote I/O facility is integral feature and not an additional unit,
- programmable serial communications (RS 232) connection to modem, printer, operator display etc...

2.2 Modular system

The comprehensive range of units enhances the modularity of the system.

For example :

The low profile 16 channel user configurable input/output unit can be mounted on the control panel door, with inputs and outputs connected to pushbuttons and pilot lamps.

2.3 Versatile range

The CS 31 is based upon two types of central units, 07 KR 91, 07 KT 92/07 KT 93 and 07 KR 31/07 KT 31.

The system can be configured to comply with most control system requirements (See previous configuration examples).

- 07 KR 91, 07 KT 92/07 KT 93 is designed for complex applications with an higher level of functionality (Data manipulation, PID regulation, etc...).
- 07 KR 31/07 KT 31 incorporates all of the functions required for smaller decentralized applications, thus providing an excellent Price/Performance ratio.

2.4 Diagnosis

The CS 31 system incorporates extensive diagnosis functions.

All of the remote units contain a microprocessor which is dedicated to the management of inputs/outputs and diagnosis facilities.

The diagnosis are accessed using the "test" button on the front of each remote unit, the results are displayed on the I/O status led's.

The diagnosis results can be incorporated with the user program thus enabling effective fault management.

2.5 Use of the CS 31 system

All of the remote units are easily interchangeable, even with the process in operation, as they are plug-in base mounted.

The screw terminals of the plug-in bases are used for connection to the process inputs and outputs.

Bases are screw or DIN rail mounted.

The DIL switches on the bases are used for coding the address of units.

Any additional connected units are automatically recognized by the central unit.

NOTE : The system may comprise of remote units of varying supply and input voltages.

2.6 Emergency operation

A system may comprise of many central units, however one single master and the remainders slaves.

If the bus communication is interrupted or the master unit fails the individual slave units continue with their own operation.

Central processing units - CPU		
Type	Description	Order code
07 KR 31	CPU - 2 K word user memory (EEPROM), twelve 24 VDC inputs Eight 2A relay outputs Programmable RS 232 port RS 485 system bus real time clock high speed counter 10 kHz high order functions PI data handling, etc... Master/Slave MODBUS built-in 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 360 0227 R1202 FPR 360 0227 R0204 FPR 360 0227 R0206
07 KT 31	CPU - 2 K word user program (EEPROM), twelve 24 VDC inputs Eight 24 VDC/0.5A transistor outputs Programmable RS 232 port RS 485 system bus real time clock high speed counter 10 kHz high order functions PI data handling, etc... Master/Slave MODBUS built-in 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 360 0228 R1202 FPR 360 0228 R0204 FPR 360 0228 R0206
07 KR 91	CPU - 7 K FLASH EPROM, twenty 24 VDC inputs Twelve 2A relay outputs Programmable RS 232 port RS 485 system bus real time clock high speed counter 10 kHz high order functions PID data handling, etc... 24 VDC power supply 120 or 230 VAC power supply	GJR 525 0000 R0252 GJR 525 0000 R0202
07 KT 92	CPU - 14 K FLASH EPROM, twelve 24 VDC inputs Eight 24 VDC/ 0.5A transistor outputs 4 analogue inputs 12 bits resolution 2 analogue output 12 bits resolution 2 programmable RS 232 port RS 485 system bus real time clock high speed counter 50 kHz high order functions PID data handling, etc... 24 VDC power supply	GJR 525 0500 R0202
07 KT 92	CPU - 14 K FLASH EPROM, twelve 24 VDC inputs Eight 24 VDC/ 0.5A transistor outputs 4 analogue inputs 12 bits resolution 2 analogue output 12 bits resolution 2 programmable RS 232 port RS 485 system bus real time clock high speed counter 50 kHz high order functions PID data handling, etc... ARCNET built-in 24 VDC power supply	GJR 525 0500 R0262

Central processing units - CPU (cont.)

Type	Description	Order code
07 KT 93	CPU - 14 K flash EPROM, twenty four 24 VDC inputs Sixteen 24 VDC/ 0.5A transistor outputs 2 programmable RS 232 port RS 485 system bus real time clock high speed counter 10 kHz high order functions PID data handling, etc... 24 VDC power supply	GJR 525 1300 R0101
07 KT 93	CPU - 14 K flash EPROM, twenty four 24 VDC inputs Sixteen 24 VDC/ 0.5A transistor outputs 2 programmable RS 232 port RS 485 system bus real time clock high speed counter 10 kHz high order functions PID data handling, etc... ARCNET built-in 24 VDC power supply	GJR 525 1300 R0171
Plug-in base		
Type	Description	Order code
ECZ	Plug-in base for I/O units 07 KR 31/07 KT 31 DIN rail or screw fixing	FPR 370 0001 R0001

Binary input units

Type	Description	Order code
ICSI 08 D1	Input unit, eight 24 VDC inputs non-isolated configurable input delay: 2...32ms 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 331 5101 R1012 FPR 331 5101 R0014 FPR 331 5101 R0016
ICSI 08 E1	Input unit, eight 24 V d.c. inputs isolated configurable input delay: 2...32ms 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 331 6101 R1012 FPR 331 6101 R0014 FPR 331 6101 R0016
ICSI 16 D1	Input unit, sixteen 24 V d.c. inputs non-isolated configurable input delay: 2...32ms 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 331 5101 R1032 FPR 331 5101 R0034 FPR 331 5101 R0036
ICSI 16 E1	Input unit, sixteen 24 VDC inputs isolated configurable input delay: 2...32ms 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 331 6101 R1032 FPR 331 6101 R0034 FPR 331 6101 R0036
ICSI 08 E3	Input unit, eight 110 VAC isolated inputs 110 VAC power supply	FPR 331 6301 R0014
ICSI 08 E4	Input unit, eight 230 VAC isolated inputs 230 VAC power supply	FPR 331 6401 R0016

Binary output units

ICSO 08 R1	Output unit, eight relay outputs 250 VAC / 2A 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 331 2101 R1022 FPR 331 2101 R0024 FPR 331 2101 R0026
ICSO 08 Y1	Output unit, eight transistor outputs 24 VDC / 2A max. 8A for eight outputs isolated short-circuit proof 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 331 1101 R1022 FPR 331 1101 R0024 FPR 331 1101 R0026
ICSO 16 N1	Output unit, sixteen transistor outputs 24 VDC / 0.5A 24 VDC power supply 120 VDC power supply 230 VDC power supply	FPR 331 3101 R1052 FPR 331 3101 R1054 FPR 331 3101 R1056

Binary input/output units

Type	Description	Order code
ICSK 20 F1	Input/output unit, twelve 24 VDC inputs non-isolated inputs eight relay outputs 250 VAC / 2A 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 332 7101 R1202 FPR 332 7101 R0204 FPR 332 7101 R0206
ICSK 20 N1	Input/output unit, twelve 24 VDC inputs non-isolated inputs eight transistor outputs 24 V ; 0.5 A 24 VDC power supply 120 VDC power supply 230 VDC power supply	FPR 333 1001 R1202 FPR 333 1001 R1204 FPR 333 1001 R1206
ICSC 08 L1	Input/output unit, eight user configurable channels for 24 VDC input signals or for 24 VDC / 0.5A output signals max. 2A for eight outputs short-circuit proof, non-isolated configurable input delay : 2...32ms 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 331 9101 R1082 FPR 331 9101 R0084 FPR 331 9101 R0086
ICFC 16 L1	Input/output unit, sixteen user configurable channels for 24 VDC input signals or for 24 VDC / 0.5A output signals max. 4A for sixteen outputs short-circuit proof, non-isolated configurable input delay : 2...32ms low profile units 2 ECZ mounting bases are required 24 VDC power supply	FPR 331 9101 R1162
ICBG 32 L1	Input/output unit 16 inputs for 24 VDC input channels 8 transistor outputs 24 VDC 250 mA 8 user configurable input/output channels 24 VDC overload and short-circuit proof input signal delay : 7 ms 24 VDC power supply	GJR 525 1400 R0101

IP 65 remote units

Type	Description	Order code
ICPI 08 D1	Input unit, eight 24 VDC inputs Degree of protection IP 65 Protection against short circuit and overload 24 VDC power supply	GJV 307 5614 R0101
ICPI 16 D1	Input unit, sixteen 24 VDC inputs Degree of protection IP 65 Protection against short circuit and overload 24 VDC power supply	GJV 307 5613 R0101
ICPO 08 H1	Output unit, eight transistor outputs 24 VDC / 2A Degree of protection IP 65 Protection against short circuit and overload 24 VDC power supply	GJV 307 5611 R0101
ICPO 16 H1	Output unit, sixteen transistor outputs 24 VDC / 2A Degree of protection IP 65 Protection against short circuit and overload 24 VDC power supply	GJV 307 5610 R0101

Analogue input units

Type	Description	Order code
ICSE 08 A6	<p>Eight analogue inputs 0 ...+ 10V, 0 ...20mA, 4 ...20mA 8 bits resolution 24 VDC power supply 120 VAC power supply 230 VAC power supply</p>	<p>FPR 334 5601 R1012 FPR 334 5601 R0014 FPR 334 5601 R0016</p>
ICST 08 A8	<p>Eight analogue inputs PT100 8 bits resolution range of temperature : -50 °C ... +150 °C (-58 °F ... +302 °F) 24 VDC power supply 120 VAC power supply 230 VAC power supply</p>	<p>FPR 333 5801 R1012 FPR 333 5801 R0014 FPR 333 5801 R0016</p>
ICST 08 A9	<p>Eight analogue inputs PT100 8 bits resolution range of temperature : 0 °C ... +300 °C (-32 °F ... +572 °F) 24 VDC power supply 120 VAC power supply 230 VAC power supply</p>	<p>FPR 333 5901 R1012 FPR 333 5901 R0014 FPR 333 5901 R0016</p>
ICSE 08 B5	<p>Eight analogue inputs -10V ...+10V, -20 ...+20mA, 4 ...20mA 12 bits resolution 24 VDC power supply 120 VAC power supply 230 VAC power supply</p>	<p>FPR 334 6501 R1012 FPR 334 6501 R0014 FPR 334 6501 R0016</p>
ICDT 08 B5	<p>Eight analogue inputs -10V ...+10 V, -5 ...+5 V, -500... + 500 mV, -50 ...+50 mV 0...20 mA, 4 ...20 mA 12 bits resolution configurable for temperature sensors or as voltage inputs 24 VDC power supply</p>	<p>GJR 525 1666 R1001</p>

Analogue output unit

ICSA 04 B5	<p>Four analogue outputs -10V ...+10V, 0 ...+20mA, 4 ...20mA 12 bits resolution 24 VDC power supply 120 VAC power supply 230 VAC power supply</p>	<p>FPR 334 1501 R1042 FPR 334 1501 R0044 FPR 334 1501 R0046</p>
-------------------	---	--

Analogue input/output units

ICSM 06 A6	<p>Input/output unit, four inputs for 0 ...+ 10V, 0...20mA, 4...20mA signals 8 bits resolution, non-isolated two outputs for -10V ...+10V, 0...20mA, 4 ...20mA signals 8 bits resolution, non-isolated 24 VDC power supply 120 VAC power supply 230 VAC power supply</p>	<p>FPR 335 0601 R1062 FPR 335 0601 R0064 FPR 335 0601 R0066</p>
-------------------	--	--

High speed counter unit

Type	Description	Order code
ICSF 08 D1	encoder unit or 3 independant up/counter 2 threshold detections counter preset Max. frequency 50kHz 7 transistor outputs 24 V d.c. 300mA 4 binary inputs 24 V d.c. Integral 5V, 15V, 24V power supply for encoder 24 VDC power supply 120 VAC power supply 230 VAC power supply	FPR 332 3101 R1012 FPR 332 3101 R0014 FPR 332 3101 R0016

Remote display unit

TCAD	Display unit 2 lines, 32 characters 127 messages programmable + 1 background message buzzer (programmable) key function embedded variables 24 VDC power supply	FPR 320 3526 R1002
-------------	--	--------------------

CS31 Bus units

NCB	CS31 bus amplifier up to 2km 24 VDC power supply	FPR 347 1200 R0006
NCBR	CS31 bus amplifier with redundancy amplification up to 2km 24 VDC power supply	FPR 347 1300 R0006

Robot coupler unit

ICBG 32 L7	Robot coupler connect ABB S3 robot to CS 31 bus 16 inputs, 16 outputs for communication supply from robot rack	FPR 333 0705 R0321
ICBG 64 L7	Robot coupler connect ABB S3 robot to CS 31 bus 32 inputs, 32 outputs for communication supply from robot rack	FPR 333 0705 R0641

Communication units

Type	Description	Order code
07 KP 90	CS 31 RCOM coupler used with 07 KT 92, 07 KR 91 R 0252, 07 KT 93 1 serial interface EIA RS232 24 VDC power supply	GJR 525 1000 R0202
07 KP 92	CS 31 coupler used with 07 KT 92, 07 KR 91 R 0252, 07 KT 93 Freely programmable in C language, stored in flash EPROM 2 serial interfaces EIA R232, EJA RS422 or EIA RS485 24 VDC power supply	GJR 525 1500 R101

Accessories

Type	Description	Order code
NCC 232	RS 232/RS 232 isolated converter 24 VDC power supply	FPR 347 1000 R0006
NCC 485	RS 232/RS 485 isolated converter 24 VDC power supply	FPR 347 1100 R0006
TCZ	Handheld terminal	FPR 320 0002 R1001
TCZ - adapter	Adaptor "Off-line"	FPTN 404 958 R0002
Cable Sub D9	For programming and test	FPTN 404 948 R0002
Cable Sub D25	For programming and test	FPTN 404 948 R0005
Cable Sub D9	For ASCII or MODBUS communication	FPTN 404 948 R0006
Cable Sub D25	For ASCII or MODBUS communication	FPTN 404 948 R0001
Cable for communication	TCZ adaptor/printer 07 DR 12	FPTN 404 948 R0004

Spare parts

Lithium battery for UCZA	FPTN 404 949 R0001
Lithium battery for TCZ	FPTN 404 949 R0002
5V battery for external power supply of TCZ	FPTN 404 949 R0003
Spare cable to connect TCZ to 07 KR 91 or UCZA/UCZB or PCZB or CS 20	FPTN 404 975 R0001

2.8 General characteristics

The CS 31 system is developed according to the international standard IEC 1131-2.

● Operating conditions

- Temperature :
 - operation 0 °C ... + 55 °C 32 ... 131 °F
 - storage - 40 °C ... + 75 °C - 40 ... 167 °F
 - transport - 25 °C ... + 75 °C - 13 ... 167 °F
- Humidity acc. to DIN 40040 class F without condensation :
 - average over the year 75 %
 - up to 30 days of a year 95 %
 - on the other days with regard to the average of the year, occasionally 85 %
- Air pressure :
 - operation 800 hPa (2000 m)
 - storage 660 hPa (3500 m)

● Mechanical data

- degree of protection IP 20
- housing UL94 V0
UL94 V1 for central units serie 90, coupler 07KPxx and units ICDxx
- vibration each of three mutually perpendicular axes 10 Hz ... 57 Hz
continuous : 0.0375 mm amplitude
occasional : 0.075 mm amplitude
57 Hz ... 150 Hz
continuous : 0.5 g acceleration
occasional : 1.0 g acceleration
- shocks occasional excursion to 15 g, 11 ms, halfsine in each of three mutually perpendicular axes
- impact withstand test for units with a power supply > 30 VAC. According to IEC 950 : a steel sphere with a mass of 500 g is to fall freely from a height of 1300 mm

● Mounting

- DIN rail 35 mm
- Screw mounting screws Ø 4 mm (M4)

● Serial interfaces

- for connection of the central unit to the remote units RS485, using screw terminals
- for programming and setting parameter RS232-C 9 pole D connector (female)

● Termination

- on the plug-in base ECZ use 60 °C copper conductor only
- Cross section :
 - bus wiring terminal : twisted pair AWG 24 (0.22 mm²) to AWG 18 (0.8 mm²)
 - earth terminal : rigid or stranded connector AWG 10 (5.2 mm²)
 - Others terminals :
 - inputs : stranded connector AWG 18 (0.8 mm²) to AWG 14 (2.1 mm²)
 - outputs : stranded connector AWG 14 (2.1 mm²)
 - power supply AWG 14 (2.1 mm²)
- on removable terminal block (small section) 2.5 mm² (copper No. AWG14)
- on removable terminal block (small section) 1.5 mm² (copper No. AWG16)
- screws tightening torque (for guidance only) 7 lbs. inch (0.8 Nm)

● Supply connections

- 24 VDC (process and power supply) 24 VDC (-20 %, +25 %, i.e. 19.2 ... 30V) incl. ripple
ripple factor < 5 %
- 120 VAC power supply 120 VAC (-15%, +10%, i.e. 102 ... 132V) 50 Hz or 60 Hz (± 5 %)
- 230 VAC power supply 230 VAC (-15%, +10%, i.e. 195.5 ... 253V) 50 Hz or 60 Hz (± 5 %)

● Voltage drops and interruptions

- DC power supply interruption time 10 ms
time interval between two drops 1s
- AC power supply interruption time 0.5 period
time interval between two drops 1s

● Creepage distances and clearances

according to EN 61131-2 / IEC1131-2

● Insulation test voltages

the insulation test voltages are according to IEC 1131-2

● Electromagnetic compatibility (EMC)

– electrostatic discharge (ESD)	according to IEC 1000-4-2 (severity level 3)
test peak voltage :	
• at discharge thru air	8 kV
• at discharge thru relay's contact	6 kV
time between two discharges	> 1s
number of discharges on each selected point	10

– radiated electromagnetic field immunity test	according to IEC 1000-4-3
field strength	10 V/m (severity level 3)
frequency range	27 MHz to 1000 MHz
sweep speed	1.5 x 10E-3 decade/s

– fast transient burst test (FTT)	according to IEC 1000-4-4
interference voltage for :	
mains terminals 115/230 V	2 kV
mains terminals 24 V	2 kV
output terminals 24 V	1 kV
output terminals 115/230 V	2 kV
input terminals 24 V	1 kV
input terminals 115/230 V	2 kV
analogue input/output terminals	1 kV
CS 31 bus	2 kV
programming interface	0.5 kV

– surge immunity	according to IEC 1000-4-5
test voltage for assymetric coupling	common mode
power supply (115/230 VAC)	2 kV
power supply (24 VDC)	1 kV
digital inputs/outputs	1 kV
test voltage for symetric coupling	differential mode
power supply (115/230 VAC)	1 kV
power supply (24 VDC)	1 kV
digital inputs/outputs	1 kV

– impedance characteristic	100 to 150
– capacitance	< 150 nF/km
– shield	
– termination	120 , 1/4 Watt resistor connected at the end of the bus
– number of points of connections	31 slaves + 1 master

● ABB Procontic CS 31 system bus

The CS 31 bus is a shield twisted pair RS485


– cross	0.22 ... 0.8 mm ² (N _o AWG 24 ... N _o AWG 18)
– twists	> 10 per metre
– resistance	100 /km

3 General operation

3.1 CPU communication with remote units

Communication between the central units and the remote units requires no user intervention as it is carried out by a dedicated serial interface.

The dual port RAM of the central unit enables data transfer between the user program processor and the dedicated serial interface.



In the read cycle, data is taken from the remote unit and stored within the dual port RAM via the bus and dedicated serial interface, the user program processor then reads the data from the dual port RAM.

Similarly, data is transferred from the dual port RAM to the remote units via the dedicated serial interface and bus for the write cycle.

3.2 Addressing of the remote units

All system bus request telegrams have an address. The remote unit which has the same address as the telegram receives and responds to the data.

The address of the remote unit is set using the DIL switches of the plug-in base.

The inputs and outputs have the following address structure: yy, xx

yy represents the remote unit number,
xx represents the channel number.

Example

Address setting of DIL-switches : 03
Number of channels on remote unit : 08

The I/O channels are simply addressed from 03, 00 to 03, 07 within the user program of the central unit, as though they were centralized.

3.3 System bus

This is a simple 2-wire serial connection (RS 485).

Connection type	Serial RS 485
Mode	Half-Duplex
Baud rate	187.5 k bauds
Maximum length	500 metres
Isolation	opto-couplers
Material	twisted pair

NOTE : For the wiring precautions and characteristics see the "hardware" chapter.

● Installation of CS 31 system

Generalities

Some installation rules have to be respected. These rules concern the ground concept, the connection of the CS 31 bus and the different power supplies installations.

The following main principles must be applied :

Each type of signal has to be mounted separately

- power supply 230 VAC
- analogue and low voltage signals

The ground and power supply wires must be connected in star

● Refer to the description of each remote unit for connection of inputs and outputs.

● Installation of the bus

The CS 31 bus is a RS 485 serial line and a shield twisted pair.

The CS 31 bus is a master slave bus. Only one master can be present on the bus.

The maximum length between the both extremities is 500 metres.

The master should be :

- a central unit : 07 KR 31, 07 KT 31, 07 KR 91, 07 KT 92, 07 KT 93, PCZB, UCZA/UCZB
- a PLC coupler : 07 CS 61 and 07 CS 91 for the ABB Procontic T 200 and T 300
- a PC board : 07 CM 90

● Characteristics of the bus' cable


The CS 31 bus is a shield twisted pair RS 485

- cross 0.22 ... 0.8 mm²
- twists > 10 per metre
- resistance 100/km
- impedance
- characteristics 100 to 150
- capacitance < 150 nF/km
- shield
- termination 120 Ω, 1/4 Watt resistor connected at the ends of the bus

Example of supplier :

- ALCATEL MCX-T
- DRAKKA dracoda 2903

The twisted pair has to be symmetric





● Connections

The same type of cable should be used throughout the installation for the system bus (RS 485).



Avoid interruption of the bus, for example, when connecting cables at the marshalling cabinet.

Whenever interruption of the bus is absolutely necessary, it must be wired to the same side of the terminals.


Example :




"Star connection of the bus is forbidden !"




● Bus topology



The bus must be terminated with a 120 Ω, 1/4 Watt resistor, this must be connected at the ends of the bus.
 The central units UCZA/UCZB, the couplers 07 CS 61 and 35 CS 91 have to be connected at an end of the bus.
 The resistor 120 Ω is integrated.
 The other central units and the PC board should be connected everywhere on the bus.
 The shield of the bus must be connected to the earth near the master.



When noisy elements are in the area of the cabinet, it is better to connect the bus' shield to the ground via a capacitor 1 nF class Y directly at the access of the cabinet according the following diagram.



The system bus CS 31 is opto-isolated from all units.
 The shield is connected to the earth through a capacitor 1 nF class Y, mounted in the plug-in base.
 The maximum bus length is 500 metres.
 In case of use of a bus amplifier or redondy amplifier refer to their own descriptions.



● **Ground concept and power supplies**

Ground concept


All CS31 products in a cabinet must be connected to the same earth.

When the remote units are outside the cabinet, they must be connected to the nearest earth.


The connection to the earth has to be as short as possible (shorter than 25 cm).




Example of connection with a 24 VDC power supply



Example of connection with a 230 VAC power supply





● **Ground concept with different cabinets**




The capacitor is integrated in the plug-in base. When the cabinets are close from each others, the different earths have to be connected together with a cable with a cross section of at least 16 mm².

The noisy elements (drives, motors, ...) haven't to be connected to the earth between two cabinets. The connection to the earth has to be near the noisier element.



Power supply I-T

- The neutral is isolated from the earth
- The metallic parts are connected to the earth



In a noisy environment, an isolated transformer with a shield has used in each cabinet (even for 24 VDC version).


Types of power supplies

Different types of power supplies are available.

The main difference is the connection of the neutral and the metallic parts to the earth.

Power supply T-T

- The neutral is connected to the earth. All metallic parts are connected to the earth



3.4 Transmission format

One single CPU is the master on the bus, all of the other remote units or CPU are considered to be slaves. The master CPU manages up to a maximum of 31 remote units on one bus. All messages are terminated with an error check (CRC8).

The format of the messages :

- request from the master CPU



- response from the remote units



During initialization, the central unit interrogates all of the remote units in succession, thus building an image of the system configuration.

On each cycle of the bus all of the remote units are interrogated.


This updates all diagnosis information and recognizes additional remote units.

If the CPU or one of the remote units receives a message with a (CRC8) error, it is ignored. After ten consecutive transmission errors, an error "Bus error" is generated on the remote units and within the diagnostics of the central unit.


3.5 Bus refresh time

The refresh time depends on the configuration of the system, number and type of remote units.

The example below is for a system of remote units type ICSC 08 L1.



The user program and the bus refresh cycle are executed in serie with the 07 KR/KT 31, 07 KR 91 and 07 KT 92/93 central units. The time event diagram is shown below :



The bus transmission time is easily calculated from the configuration of the installation.

Communication time	
offset time Master CPU	2000 µs
Slave central units	
07 KR 31*	750 µs
07 KT 31*	750 µs
07 KR 91*	750 µs
07 KT 92*	750 µs
07 KT 93*	750 µs
* with factory setting	
time following the configuration :	
2 bytes in transmission	
2 bytes in receiving	516 µs
4 bytes in transmission	
4 bytes in receiving	750 µs
8 bytes in transmission	
8 bytes in receiving	1300 µs
12 bytes in transmission	
12 bytes in receiving	1850 µs
8 words in transmission	
8 words in receiving	2500 µs
Binary input units	
ICSI 08 D1	323 µs
ICSI 08 E1	323 µs
ICSI 08 E3/E4	323 µs
ICSI 16 D1	387 µs
ICSI 16 E1	387 µs
Binary output units	
ICSO 08 R1	260 µs
ICSO 08 Y1	260 µs
ISCO 16 N1	340 µs
Binary input/output units	
ICSC 08 L1	387 µs
ICFC 16 L1	516 µs
ICSK 20 F1	452 µs
ICSK 20 N1	452 µs
ICDG 32 L1	516/590 µs
	following the configuration
IP65 binary input/output units	
ICPI 08 D1	323 µs
ICPI 16 D1	387 µs
ICPO 08 H1	260 µs
ICPO 16 H1	340 µs

Analogue units	
ICSM 06 A6 (input/output)	1162 µs
ICSE 08 A6 (input)	1355 µs
ICSE 08 B5 (input)	1355 µs
ICST 08 A7 (input)	1355 µs
ICST 08 A8 (input)	1355 µs
ICST 08 A9 (input)	1355 µs
ICDT 08 B5 (input)	1355 µs
ICSA 04 B5 (output)	700 µs
Robot coupler card	
ICBG 32 L7	516 µs
ICBG 64 L7	750 µs
High speed counter	
ICSF 08 D1	1300 µs

3.5.1 Bus refresh time (T_{rb})

This time is equal to :

– with a master central unit serie 90 :

$$T_{rb} = T_{\text{offset}} + T_{\text{communication time}}$$

– with a master central unit serie 30 :

$$T_{rb} = T_{\text{offset}} + T_{\text{communication time}} + n * 100 (\mu\text{s})$$

with :

– T_{offset} = 2 000 μs

– T_{communication time} : see table

– n = number of slaves on the bus

Example of calculation

Configuration :

1 "Master" CPU 2 000 μs

1 ICSK 20 F1 452 μs

1 ICSO 08 R1 260 μs

1 ICSI 16 E1 387 μs

1 ICFC 16 L1 516 μs

1 ICSC 08 L1 387 μs

– with a master central unit serie 90

$$T_{rb} = 4\,002 \mu\text{s} = 4 \text{ ms}$$

– with a master central unit serie 30

$$T_{rb} = 4\,502 \mu\text{s} = 4,5 \text{ ms}$$

3.5.2 Response time to energize an output from the activation of an input

See Part 3 page 5.3-1 for a master central unit serie 30.

See Part 4 pages 1-22 or 2-25 or 3-21 for a master central unit serie 90.

4 Programming and testing

There are 2 types of central units available for the CS 31 system :

- 07 KR 31, 07 KT 31/07 KR 91, 07 KT 92 and 07 KT 93.

Central units can be programmed by two methods :

- TCZ handheld terminal
- Software package (on IBM PC)

4.1 TCZ handheld terminal

The TCZ terminal can be used for the programming and testing of 07 KR 31 / 07 KT 31, 07 KR 91 /07 KT 92 / 07 KT 93, units.

The TCZ is powered from the central unit (9 PIN D - CONNECTOR).

An external power supply is available which allows "off line" editing of the program.

4.2 Programming software

All programming packages are used with an IBM AT compatible personal computer.

Expensive dedicated programming units are therefore not necessary as the computer is connected directly to the integral programming port of the central unit.

4.2.1 Software for 07 KR 91/07 KR 31 central unit

The higher level functions (data manipulation, communication and PID regulation etc...) of the 07 KR 91 central unit are programmed using the 907 PC 331 Package.

ABB CS31

Hardware



ABB Control



FPTC 404 365 P2001-e

Chapter	Description	Page
1	Installation requirements	
1.1	General characteristics	1.1-1
1.1.1	Technical data system	1.1-1
1.1.2	Installation of CS 31 System	1.1.2-1
1.2	Transmission format	1.2-1
1.3	Bus refresh time	1.3-1
1.4	Dimensions	1.4-1
1.5	Approvals and classification societies agreements	1.5-1
2	Central units	
2.1	07 KR 31	2.1-1
2.2	07 KT 31	2.2-1
2.3	07 KR 91	2.3-1
2.4	07 KT 92	2.4-1
2.5	07 KT 93	2.5-1
2.6	07 GV 93	2.6-1
2.7	UCZA/UCZB	2.7-1
2.8	PCZB	2.8-1
2.9	CS20	2.9-1
3	Plug-in base	
3.1	ECZ Plug-in base for : I/O remote units Central units 07 KR 31, 07 KT 31, PCZB, CS 20	3.1-1
4	Binary remote units	
4.1	Binary Input remote units	
4.1.1	ICSI 08 D1 : 8 Inputs 24 VDC	4.1.1-1
4.1.2	ICSI 08 E1 : 8 opto-isolated Inputs 24 VDC	4.1.2-1
4.1.3	ICSI 08 E3/4 : 8 Inputs 115/230 VAC	4.1.3-1
4.1.4	ICSI 16 D1 : 16 Inputs 24 VDC	4.1.4-1
4.1.5	ICSI 16 E1 : 16 opto-isolated Inputs 24 VDC	4.1.5-1

4.2	Binary Output remote units	
4.2.1	ICSO 08 R1 : 8 relay Outputs	4.2.1-1
4.2.2	ISCO 08 Y1 : 8 Outputs 24 VDC 2A	4.2.2-1
4.2.3	ICSO 16 N1 : 16 Outputs 24 VDC 0.5A	4.2.3-1
4.3	Binary Input/Output remote units	
4.3.1	ICSK 20 F1 : 12 Inputs 24 VDC/8 relay Outputs	4.3.1-1
4.3.2	ICSC 08 L1 : 8 user configurable Inputs/Outputs	4.3.2-1
4.3.3	ICFC 16 L1 : 16 user configurable Inputs/Outputs	4.3.3-1
4.3.4	ICDG 32 L1 : 16 Inputs 24 VDC/8 Outputs 24 VDC 0.25A 8 user configurable Inputs/Outputs	4.3.4-1
4.3.5	ICSK 20 N1 : 12 Inputs 24 VDC/8 transistor outputs	4.3.5-1
4.4	Binary Input/Output remote units, degree of protection IP65	
4.4.1	ICPO 16 H1 : 16 Outputs 24 VDC 2A	4.4-1
4.4.2	ICPO 08 H1 : 8 Outputs 24 VDC 2A	4.4-9
4.4.3	ICPI 16 D1 : 16 Inputs 24 VDC	4.4-17
4.4.4	ICPI 08 D1 : 8 Inputs 24 VDC	4.4-25
5	Analog remote units	
5.1	General	5.1-1
5.2	Analog Input remote units	
5.2.1	ICSE 08 A6 : 8 current/voltage Inputs, 8 bits	5.2.1-1
5.2.2	ICSE 08 B5 : 8 current/voltage Inputs, 12 bits	5.2.2-1
5.2.3	ICST 08 A8 : 8 Inputs PT 100 (Temperature range $-50\text{ }^{\circ}\text{C} \dots +150\text{ }^{\circ}\text{C}$ $+58\text{ }^{\circ}\text{F} \dots +302\text{ }^{\circ}\text{F}$) 8 bits	5.2.3-1
5.2.4	ICST 08 A9 : 8 Inputs PT 100 (Temperature range $0\text{ }^{\circ}\text{C} \dots +300\text{ }^{\circ}\text{C}$ $+32\text{ }^{\circ}\text{F} \dots +572\text{ }^{\circ}\text{F}$) 8 bits	5.2.4-1
5.2.5	ICDT 08 B5 : 8 configurable Inputs for temperature sensors or as voltage inputs	5.2.5-1
5.2.6	ICST 08 A7 : 8 Inputs PT 100 (Temperature range $-30\text{ }^{\circ}\text{C} \dots +20\text{ }^{\circ}\text{C}$ $-22\text{ }^{\circ}\text{F} \dots +68\text{ }^{\circ}\text{F}$) 8 bits	5.2.6-1
5.3	Analog Output remote units	
5.3.1	ICSA 04 B5 : 4 current/voltage Outputs, 12 bits	5.3.1-1
5.4	Analog Input/Output remote units	
5.4.1	ICSM 06 A6 : 4 current/voltage Inputs, 2 current/voltage Outputs, 8 bits	5.4.1-1
6	Special remote units	
6.1	ICSF 08 D1 : high speed counter	6.1-1
6.2	TCAD : Remote display	6.2-1
6.3	CS31 Bus units	
6.3.1	NCB : CS31 Bus Amplifier	6.3.1-1
6.3.2	NCBR : CS31 Bus Amplifier with redundancy	6.3.2-1
7	Couplers	
7.1	Robot card	
7.1.1	ICBG 32 L7 : 32 binary inputs/outputs	7.1.1-1
7.1.2	ICBG 64 L7 : 64 binary inputs/outputs	7.1.2-1

8	Accessories	
8.1	Serial line converters	
8.1.1	NCC 232 : RS232/RS232 isolated converter	8.1.1-1
8.1.2	NCC 485 : RS232/RS485 isolated converter	8.1.2-1
8.2	TCZ handheld terminal	8.2-1
8.3	TCZ adaptor "off-line"	8.3-1
8.4	System cables	
8.4.1	FPTN404948R00002 : Programmation and test (sub D9)	8.4.1-1
8.4.2	FPTN404948R00005 : Programmation and test (sub D25)	8.4.2-1
8.4.3	FPTN404948R00006 : ASCII and MODBUS communication (sub D9)	8.4.3-1
8.4.4	FPTN404948R00001 : ASCII and MODBUS communication (sub D25)	8.4.4-1
8.4.5	FPTN404948R00004 : communication TCZ adaptor printer 07DR12	8.4.5-1
8.5	Batteries	8.5-1
9	In case of failure	
9.1	Internal diagnosis	9.1
9.1.1	General	9.1
9.1.2	Use of "TEST" push-button	9.1
9.1.3	Sum up the diagnosis	9.2
9.2	Open circuit detection	9.4
9.2.1	Detection for inputs	9.4
9.2.2	Detection for outputs	9.4
9.3	Overload and short-circuit	9.4
9.4	Diagnosis of the various central units	9.4

Chapter	Description	Page
1.1	General characteristics	1.1-1
1.1.1	Technical data system	1.1-1
1.1.2	Installation of CS 31 System	1.1.2-1
1.2	Transmission format	1.2-1
1.3	Bus refresh time	1.3-1
1.4	Dimensions	1.4-1
1.5	Approvals and classification societies	1.5-1

1.1 General characteristics

Installation requirements

1.1.1 Technical data system

The CS 31 system is developed according to the international standard IEC 1131-2.

● Operating conditions

- Temperature :
 - operation 0 °C ... + 55 °C 32 ... 131 °F
 - storage - 40 °C ... + 75 °C - 40 ... 167 °F
 - transport - 25 °C ... + 75 °C - 13 ... 167 °F
- Humidity acc. to DIN 40040 class F without condensation :
 - average over the year ≤ 75 %
 - up to 30 days of a year 95 %
 - on the other days with regard to the average of the year, occasionally 85 %
- Air pressure :
 - operation ≥ 800 hPa (≤ 2000 m)
 - storage ≥ 660 hPa (≤ 3500 m)

● Mechanical data

- degree of protection IP 20
- housing UL94 V0
UL94 V1 for central units serie 90, coupler 07KPxx and units ICDxx
- vibration each of three mutually perpendicular axes 10 Hz ... 57 Hz
continuous : 0.0375 mm amplitude
occasional : 0.075 mm amplitude
57 Hz ... 150 Hz
continuous : 0.5 g acceleration
occasional : 1.0 g acceleration
- shocks occasional excursion to 15 g, 11 ms, halfsine in each of three mutually perpendicular axes
- impact withstand test for units with a power supply > 30 VAC. According to IEC 950 : a steel sphere with a mass of 500 g is to fall freely from a height of 1300 mm

● Mounting

- DIN rail 35 mm
- Screw mounting screws Ø 4 mm (M4)

● Serial interfaces

- for connection of the central unit to the remote units RS485, using screw terminals
- for programming and setting parameter RS232-C
9 pole D connector (female)

● Termination

- on the plug-in base ECZ use 60 °C copper conductor only
- Cross section :
 - bus wiring terminal : twisted pair
AWG 24 (0.22 mm²) to AWG 18 (0.8 mm²)
 - earth terminal : rigid or stranded connector
AWG 10 (5.2 mm²)
 - Others terminals :
 - inputs : stranded connector
AWG 18 (0.8 mm²) to AWG 14 (2.1 mm²)
 - outputs : stranded connector
AWG 14 (2.1 mm²)
 - power supply
AWG 14 (2.1 mm²)

- on removable terminal block (small section) 2.5 mm² (copper No. AWG14)
- on removable terminal block (small section) 1.5 mm² (copper No. AWG16)
- screws tightening torque (for guidance only) 7 lbs. inch (0.8 Nm)

● Supply connections

- 24 VDC (process and power supply) 24 VDC
(-20 %, +25 %, i.e. 19.2 ... 30V)
incl. ripple
ripple factor < 5 %
- 120 VAC power supply 120 VAC
(-15%, +10%, i.e. 102 ... 132V)
50 Hz or 60 Hz (± 5 %)
- 230 VAC power supply 230 VAC
(-15%, +10%, i.e. 195.5 ... 253V)
50 Hz or 60 Hz (± 5 %)

● Voltage drops and interruptions

- DC power supply interruption time ≤ 10 ms
time interval between two drops ≥ 1s

– AC power supply	interruption time ≤ 0.5 period time interval between two drops ≥ 1 s	power supply (24 VDC)	1 kV
		digital inputs/outputs	1 kV
		test voltage for symetric coupling	differential mode
● Creepage distances and clearances		power supply (115/230 VAC)	1 kV
	according to EN 61131-2 / IEC1131-2	power supply (24 VDC)	1 kV
		digital inputs/outputs	1 kV
● Insulation test voltages		● ABB Procontic CS 31 system bus	
	the insulation test voltages are according to IEC 1131-2	The CS 31 bus is a shield twisted pair RS485	
● Electromagnetic compatibility (EMC)		– cross	0.22 ... 0.8 mm ² (N _o AWG 24 ... N _o AWG 18)
– electrostatic discharge (ESD)	according to IEC 1000-4-2 (severity level 3)	– twists	> 10 per metre
test peak voltage :		– resistance	$\leq 100 \Omega/\text{km}$
• at discharge thru air	8 kV	– impedance	characteristic 100 to 150 Ω
• at discharge thru relay's contact	6 kV	– capacitance	< 150 nF/km
time between two discharges	> 1s	– shield	
number of discharges on each selected point	10	– termination	120 Ω , 1/4 Watt resistor connected at the end of the bus
– radiated electromagnetic field immunity test	according to IEC 1000-4-3	– number of points of connections	31 slaves + 1 master
field strength	10 V/m (severity level 3)		
frequency range	27 MHz to 1000 MHz		
sweep speed	1.5 x 10E-3 decade/s		
– fast transient burst test (FTT)	according to IEC 1000-4-4		
interference voltage for :			
mains terminals 115/230 V	2 kV		
mains terminals 24 V	2 kV		
output terminals 24 V	1 kV		
output terminals 115/230 V	2 kV		
input terminals 24 V	1 kV		
input terminals 115/230 V	2 kV		
analogue input/output terminals	1 kV		
CS 31 bus	2 kV		
programming interface	0.5 kV		
– surge immunity	according to IEC 1000-4-5		
test voltage for assymetric coupling	common mode		
power supply (115/230 VAC)	2 kV		

1.1.2 Installation of CS 31 system

Generalities

Some installation rules have to be respected. These rules concern the ground concept, the connection of the CS 31 bus and the different power supplies installations. The following main principles must be applied :

Each type of signal has to be mounted separately

- power supply 230 VAC
- analogue and low voltage signals

The ground and power supply wires must be connected in star

- Refer to the description of each remote unit for connection of inputs and outputs.

● Installation of the bus

The CS 31 bus is a RS 485 serial line and a shield twisted pair.

The CS 31 bus is a master slave bus. Only one master can be present on the bus.

The maximum length between the both extremities is 500 metres.

The master should be :

- a central unit : 07 KR 31, 07 KR 91, 07 KT 92, 07 KT 93, PCZB, UCZA/UCZB
- a PLC coupler : 07 CS 61 and 07 CS 91 for the ABB Procontic T 200 and T 300
- a PC board : 07 CM 90

● Characteristics of the bus' cable

The CS 31 bus is a shield twisted pair RS 485

- cross 0.22 ... 0.8 mm²
- twists > 10 per metre
- resistance ≤ 100/km
- impedance


● Characteristics 100 to 150 Ω

- capacitance < 150 nF/km
- shield
- termination 120 Ω, 1/4 Watt resistor connected at the ends of the bus

Example of supplier :

- ALCATEL MCX-T
- DRAKKA dracoda 2903

The twisted pair has to be symetric





● Connections

The same type of cable should be used throughout the installation for the system bus (RS 485).



Avoid interruption of the bus, for example, when connecting cables at the marshalling cabinet.

Whenever interruption of the bus is absolutely necessary, it must be wired to the same side of the terminals.


Example :




"Star connection of the bus is forbidden !"




● Bus topology



The bus must be terminated with a 120 Ω, 1/4 Watt resistor, this must be connected at the ends of the bus.
 The central units UCZA/UCZB, the couplers 07 CS 61 and 35 CS 91 have to be connected at an end of the bus.
 The resistor 120 Ω is integrated.
 The other central units and the PC board should be connected everywhere on the bus.
 The shield of the bus must be connected to the earth near the master.



When noisy elements are in the area of the cabinet, it is better to connect the bus' shield to the ground via a capacitor 1 nF class Y directly at the access of the cabinet according the following diagram.



The system bus CS 31 is opto-isolated from all units.
 The shield is connected to the earth through a capacitor 1 nF class Y, mounted in the plug-in base.
 The maximum bus length is 500 metres.
 In case of use of a bus amplifier or redondy amplifier refer to their own descriptions.



● **Ground concept and power supplies**

Ground concept


All CS 31 products in a cabinet must be connected to the same earth.

When the remote units are outside the cabinet, they must be connected to the nearest earth.


The connection to the earth has to be as short as possible (shorter than 25 cm).




Example of connection with a 24 VDC power supply



Example of connection with a 230 VAC power supply





● **Ground concept with different cabinets**



The capacitor is integrated in the plug-in base. When the cabinets are close from each others, the different earths have to be connected together with a cable with a cross section of at least 16 mm².

The noisy elements (drives, motors, ...) haven't to be connected to the earth between two cabinets. The connection to the earth has to be near the noisier element.




• **Types of power supplies**

Different types of power supplies are available.

The main difference is the connection of the neutral and the metallic parts to the earth.


Power supply T-T

– The neutral is connected to the earth. All metallic parts are connected to the earth



Power supply I-T

- The neutral is isolated from the earth
- The metallic parts are connected to the earth



In a noisy environment, an isolated transformer with a shield has used in each cabinet (even for 24 VDC version).

1.2 Transmission format

One single CPU is the master on the bus, all of the other remote units or CPU are considered to be slaves.

The master CPU manages up to a maximum of 31 remote units on one bus.

All messages are terminated with an error check (CRC8).

The format of the messages :

- request from the master CPU

Address	Data	CRC8
---------	------	------

- response from the remote units

Start	Data	CRC8
-------	------	------

During initialization, the central unit interrogates all of the remote units in succession, thus building an image of the system configuration.

On each cycle of the bus all of the remote units are interrogated.

This updates all diagnosis information and recognizes additional remote units.


If the CPU or one of the remote units receives a message with a (CRC8) error, it is ignored.

After ten consecutive transmission errors, an error "Bus error" is generated on the remote units and within the diagnosis of the central unit.


1.3 Bus refresh time

The refresh time depends on the configuration of the system, number and type of remote units.

The example below is for a system of remote units type ICSC 08 L1 :



The user program and the bus refresh cycle are executed in serie with the 07 KR/KT 31, 07 KR 91 and 07 KT 92/93 central units. The time event diagram is shown below :



● Bus refresh time (T_{rb})

The bus transmission time is easily calculated from the configuration of the installation.

This time is equal to :

– with a master central unit serie 90 :

$$T_{rb} = T_{\text{offset}} + T_{\text{communication time}}$$

– with a master central unit serie 30 :

$$T_{rb} = T_{\text{offset}} + T_{\text{communication time}} + n * 100 (\mu\text{s})$$

with :

– T_{offset} = 2 000 μs

– T_{communication time} : see table on the next page

– n = number of slaves on the bus

Example of calculation

Configuration :

1 "Master" CPU	2 000 μs
1 ICSK 20 F1	452 μs
1 ICSO 08 R1	260 μs
1 ICSI 16 E1	387 μs
1 ICFC 16 L1	516 μs
1 ICSC 08 L1	387 μs

– with a master central unit serie 90

$$T_{rb} = 4\,002 \mu\text{s} = 4 \text{ ms}$$

– with a master central unit serie 30

$$T_{rb} = 4\,502 \mu\text{s} = 4,5 \text{ ms}$$

● Response time to energize an output from the activation of an input












See Part 3 page 5.3-1 for a master central unit serie 30.

See Part 4 pages 1-22 or 2-25 or 3-21 for a master central unit serie 90.

Communication time	
offset time Master CPU	2000 µs
Slave central units	
07 KR 31 *	750 µs
07 KT 31 *	750 µs
07 KR 91 *	750 µs
07 KT 92 *	750 µs
07 KT 93 *	750 µs
* with factory setting	
time following the configuration :	
2 bytes in transmission	
2 bytes in receiving	516 µs
4 bytes in transmission	
4 bytes in receiving	750 µs
8 bytes in transmission	
8 bytes in receiving	1300 µs
12 bytes in transmission	
12 bytes in receiving	1850 µs
8 words in transmission	
8 words in receiving	2500 µs
Binary input units	
ICSI 08 D1	323 µs
ICSI 08 E1	323 µs
ICSI 08 E3/E4	323 µs
ICSI 16 D1	387 µs
ICSI 16 E1	387 µs
Binary output units	
ICSO 08 R1	260 µs
ICSO 08 Y1	260 µs
ISCO 16 N1	340 µs
Binary input/output units	
ICSC 08 L1	387 µs
ICFC 16 L1	516 µs
ICSK 20 F1	452 µs
ICSK 20 N1	452 µs
ICDG 32 L1	516/590 µs
	following the configuration
IP65 binary input/output units	
ICPI 08 D1	323 µs
ICPI 16 D1	387 µs
ICPO 08 H1	260 µs
ICPO 16 H1	340 µs

Analogue units	
ICSM 06 A6 (input/output)	1162 µs
ICSE 08 A6 (input)	1355 µs
ICSE 08 B5 (input)	1355 µs
ICST 08 A7 (input)	1355 µs
ICST 08 A8 (input)	1355 µs
ICST 08 A9 (input)	1355 µs
ICDT 08 B5 (input)	1355 µs
ICSA 04 B5 (output)	700 µs
Robot coupler card	
ICBG 32 L7	516 µs
ICBG 64 L7	750 µs
High speed counter	
ICSF 08 D1	1300 µs

1.4 Dimensions

Types	Short description		Dimensions in mm with unit carrier/terminal		
			W	H	D
			W1	H1	D1
07 KR 91 07 KT 92 07 KT 93 07 SA 93	Central processing units Positioning unit		240	140	85
07 KR 31 07 KT 31	Central processing units		120 123	60 64	115
ICS..	Binary or analog units Input - Output - Input/Output High speed counter unit		120 123	60 64	115
ICFC 16 L1	Binary Input/Output unit		244 246	60 64	80
ECZ	Plug-in base		123	64	30
ICD..	Binary or analog remote units		120	140	85
ICPI 16 D1 ICPO 16 H1	Binary remote units (IP 65 protection)		367	78	78.5
ICPI 08 D1 ICPO 08 H1	Binary remote units (IP 65 protection)		247	78	78.5
07 KP 90 07 KP 92 07 MK 92	Communication couplers		120	140	85
NCC 232 NCC 485 NCB NCBR	Communication accessories		120	80	85
TCAD	Text display		230 198	80 67	47 42

The other products (type ICBG 32 L7, type ICBG 64 L7, type 07 CS 61, type 07 CM 90) are mounted in a rack.
Their dimensions depend on their ranges (Robot S3, ABB Procontic T 200 and PC).

1.5 Approvals and classification societies

The product listed in the catalogue is designed according to the relevant standards; it is manufactured and tested under our own responsibility.

The table below indicates for each unit the situation regarding the approvals for those countries or with regard to the classification societies where an approval is mandatory and confirms that products in standard version can be used worldwide thus avoiding double stocking.

All following units are developed, tested and produced according to the standard IEC 1131-2.

UL : only for 24 VDC and 120 VAC versions.
Ships classification societies agreements for : 24 VDC, 120 and 230 VAC versions.

■ : approved
△ : applied in 1996

Unit type	Approvals		Ships classification societies agreements						
Test mark									
Abbreviation	UL	CSA	BV	GL	LRS	MRS	RINa	DNV	ABS
Approved in	USA	Canada	France	German.	Gr.Brit.	Russia	Italy	Norway	USA

Unit type	Approvals		Ships classification societies agreements						
Test mark									
Abbreviation	UL	CSA	BV	GL	LRS	MRS	RINa	DNV	ABS
Approved in	USA	Canada	France	German.	Gr.Brit.	Russia	Italy	Norway	USA

CS 31 CPU

07 KR 31	■		■	■	■	■	■	■	■
07 KT 31	△		■	■	■	■	■	■	■
07 KR 91	■	■	■	■	■	■	■	■	■
07 KT 92	■	■	■	■	■	■	■	■	■
07 KT 93	■	■	■	■	■	■	■	■	■

CS 31 remote units

ICSI 08 D1	■		■	■	■	■	■	■	■
ICSI 08 E1	■		■	■	■	■	■	■	■
ICSI 16 D1	■		■	■	■	■	■	■	■
ICSI 16 E1	■		■	■	■	■	■	■	■
ICSI 08 E3	■		■	■	■	■	■	■	■
ICSI 08 E4			■	■	■	■	■	■	■
ICSO 08 R1	■		■	■	■	■	■	■	■
ICSO 08 Y1									
ICSO 16 N1	△		■	■	■	■	■	■	■
ICSC 08 L1	△		■	■	■	■	■	■	■
ICFC 16 L1	△		■	■	■	■	■	■	■
ICSK 20 F1	■		■	■	■	■	■	■	■
ICSK 20 N1	△		■	■	■	■	■	■	■
ICDG 32 L1	■	■	■	■	■	■	■	■	■
ICSF 08 D1	■		■	■	■	■	■	■	■
ICPI 08 D1			■	■	■		■		
ICPI 16 D1			■	■	■		■		
ICPO 08 H1			■	■	■		■		
ICPO 16 H1			■	■	■		■		

All products have CE marking.

CS 31 remote units

ICSE 08 A6	■		■	■	■	■	■	■	■
ICSE 08 B5	■		■	■	■	■	■	■	■
ICST 08 A7									
ICST 08 A8	■		■	■	■	■	■	■	■
ICST 08 A9	■		■	■	■	■	■	■	■
ICSA 04 B5	■		■	■	■	■	■	■	■
ICSM 06 A6	■		■	■	■	■	■	■	■
ICDT 08 B5	■	■	■	■	■	■	■	■	■


CS31 other units and accessories

TCAD	△		■	■	■	■	■	■	■
NCB	△		■	■	■	■	■	■	■
NCBR	△		■	■	■	■	■	■	■
ICBG 32 L7									
ICBG 64 L7									
07 KP 90	■	■	■	■	■	■	■	■	■
07 KP 92	■	■	■	■	■	■	■	■	■
NCC 232	△		■	■	■	■	■	■	■
NCC 485	△		■	■	■	■	■	■	■
ECZ	■		■	■	■	■	■	■	■

CS 31 coupler for T200

07 CS 61	■	■	■	■	■	■	■	■	■
----------	---	---	---	---	---	---	---	---	---

Chapter	Description	Page
2.1	07 KR 31	2.1-1
2.2	07 KT 31	2.2-1
2.3	07 KR 91	2.3-1
2.4	07 KT 92	2.4-1
2.5	07 KT 93	2.5-1
2.6	07 GV 93	2.6-1
2.7	UCZA/UCZB	2.7-1
2.8	PCZB	2.8-1
2.9	CS20	2.9-1



The comprehensive description for this central unit is located in part 3 of this volume.

Brief description

The central unit 07 KR 31 works either as


- Bus master in the decentralized automation system ABB Procontic CS31 or as
- Slave (remote processor) in the decentralized automation system ABB Procontic CS 31 or as
- Stand-alone central unit.

The unit is provided in three versions with supply voltages of 24 V DC, 120 V AC or 230 V AC :

The central unit versions have the following main features :

- 12 binary inputs
- 8 binary relay outputs
- 1 counting input for counting frequencies up to 10 kHz
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
 - can be set as MODBUS interface

- has a built-in MODBUS protocol (master and slave)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Fastening by inserting in the plug-in base ECZ. The plug-in base can either be snapped on a DIN rail or fastened by screws.
- Built-in lithium battery for back-up of the RAM contents, its lifetime is 10 years.
- Reading and writing program protection by password
- Programming with the programming software 907 PC 331
- "On-Line" programming
- User program containing max. 2 k of instructions
- RUN/STOP switch for starting and aborting the program execution
- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected units



The comprehensive description for this central unit is located in part 3 of this volume.

Brief description

The central unit 07 KT 31 works either as


- Bus master in the decentralized automation system ABB Procontic CS31 or as
- Slave (remote processor) in the decentralized automation system ABB Procontic CS 31 or as
- Stand-alone central unit.

The unit is provided in three versions with supply voltages of 24 V DC, 120 V AC or 230 V AC :

The central unit versions have the following main features :

- 12 binary inputs
- 8 binary transistor 24VDC/0.5A outputs
- 1 counting input for counting frequencies up to 10 kHz
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
 - can be set as MODBUS interface

- has a built-in MODBUS protocol (master and slave)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Fastening by inserting in the plug-in base ECZ. The plug-in base can either be snapped on a DIN rail or fastened by screws.
- Built-in lithium battery for back-up of the RAM contents, its lifetime is 10 years.
- Reading and writing program protection by password
- Programming with the programming software 907 PC 331
- "On-Line" programming
- User program containing max. 2 k of instructions
- RUN/STOP switch for starting and aborting the program execution
- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected units



The comprehensive description for this central unit is located in part 4 of this volume. The same description is available as an operating manual, order No. GATS 1316 01 R2001.

Brief description

The central unit 07 KR 91 works either as

- Bus master in the decentralized automation system ABB Procontic CS31 or as
- Slave (remote processor) in the decentralized automation system ABB Procontic CS 31 or as
- Stand-alone central unit.

The module is provided in two versions with supply voltages of 24 V DC and 115/230 V AC :

07 KR 91 R101 :

The device has a 115/230 V AC power supply voltage. It provides a 24 V output voltage for the supply of its own binary inputs.


07 KR 91 R151 :

The device has a 24 V DC power supply voltage. It is provided with an additional interface for connecting communication modules (e.g. 07 KP 90).

Both module versions have the following main features :

- 20 binary inputs
- 12 binary relay outputs
- 1 counting input for counting frequencies up to 10 kHz

- Central unit for an user program containing ma. 7 k of instructions
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device ; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device on a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution
- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Proncontic CS31 system bus and the connected modules



The comprehensive description for this central unit is located in part 4 of this volume. The same description is available as an operating manual, order No. GATS 1316 02 R2001.

Brief description

The central unit 07 KT 92 works either as


- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit.

Main features

- Power supply 24 V DC
- 12 binary inputs
- 8 binary transistor outputs
- 4 analog inputs
- 1 analog output
- 1 calibrated 10 V output
- 1 counting input for counting frequencies up to 10 kHz
- Central unit for a user program containing max. 7 k of instructions
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface

– can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)

- Serial interface COM2 as an MMC interface
- Additional interface for connecting communication modules (e.g. 07 KP 90)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device ; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device on a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution
- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules



The comprehensive description for this central unit is located in part 4 of this volume. The same description is available as an operating manual, order No GATS 1316 12 R2001

Brief description


The central unit 07 KT 93 works either as

- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit

Main features

- Power supply 24 V DC
- 24 binary inputs
- 16 binary transistor outputs
- 1 counting input for counting frequencies up to 10 kHz
- Central unit for a user program containing max. 7 k of instructions
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)

- Serial interface COM2 as an MMC interface
- Additional interface for connecting communication modules (e.g. 07 KP 90)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device ; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device on a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution
- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules



The comprehensive description for the positioning module is located in the 07 GV 93 operating manual in DIN A5 format, order No. GATS 1316 07 R2001.

Brief description

The positioning module 07 GV 93 is a subsystem within the decentralized automation system ABB Procontic CS31. It moves and positions three independent axes. The move sequences are programmed in a simple way by means of sets. Machine parameters which can be freely chosen adapt the positioning module to the mechanical units of the machines or the installation.

When used as a stand-alone module, the 07 GV 93 positioning module automatically moves and positions the axes on the basis of the programmed positioning sets. Additional input/output modules, connected via the CS31 system bus, allow the external control of the positioning sets and positioning sequences programmed in 07 GV 93.

The positioning module 07 GV 93 can also be used as a slave on the CS31 system bus. In the case, the positioning sets and sequences programmed in 07 GV 93 are controlled by a central unit 07 KR 91/07 KT 92/07 KT 93. This configuration allows the connection of additional positioning modules, slave central units as well as input and output modules.

The main features of the 07 GV 93 positioning module are :


- 1...3 axes
- Speed setpoint ± 10 V DC
- Connection to incremental encoders
- High traversing speed of up to 100 m/min
- Position control cycle 4 ms
- Internal numerical representation 32 bits
- Adjustable ramps per axis for both traverse directions
- Encoder error detection
- Power supply 24 DC
- LEDs for displaying the input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device ; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail
- RUN/STOP switch for starting and aborting the program execution
- Diagnosis functions

Operating and programming

A means for operating and programming the positioning module 07 GV 93 is the operating station 35 BS 40. It is configured as a simple terminal when the power is switched on and no further programming is to be done. The control of the display which includes 2 lines of 40 characters each is performed completely by the module 07 GV 93. Entry is done via function keys and a numerical keypad.

The following functions are available for programming :

- Absolute and incremental dimensions
- Override 0...125 %
- 300 positioning sets per axis
- Machine data set for machine-specific parameters
- Software limit switches
- 1-, 2- and 4 - fold evaluation of the positioning encoders
- Metric system
- Reference point drive
- Automatic single set and automatic next set
- Manual control (Feed, Jog, Pos)
- Error detection, diagnosis



The comprehensive description for these central units is located in the part 5 of this volume.

Brief description

The central unit UCZA and UCZB work as bus master in the decentralized automation system ABB Procontic CS 31.

The units are provided in three versions with supply voltages of 24 VDC, 120 VAC or 230 VAC.

The central unit versions have the following main features :

- 1 CS 31 system bus interface for system expansion.
A coupler SCZ allows an expansion to another CS 31 bus.
- 1 serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)

- 1 serial interface COM2
For diagnosis and configuration

Real time clock

Leds for displaying the operating and error messages.


Programming with the programming software 907 PC 32.

User program containing max. 8 k instructions for UCZA and 16 k instructions for UCZB.

Fastening by screws or by snapping for starting or aborting the program execution.

Extensive diagnosis functions
– self-diagnosis of the central unit

– diagnosis of the ABB Procontic CS 31 and connected remote units.



C 149 D

The comprehensive description for this central unit is located in volume 5.

Brief description


The central unit PCZB works either as

- Bus master in the decentralized automation system ABB Procontic CS 31 or as
- Slave (remote processor) in the decentralized automation system ABB Procontic CS 31 or as
- Stand-alone central unit.

Main features :

- Power supply
24 VDC or 120 VAC or 230 VAC (3 versions)
- 12 binary inputs (one of them is a high-speed input)
- 8 binary relay outputs
- 1 integrated high-speed counter
- 1 CS 31 system bus interface for system expansion

- Serial interface COM1, EIA-232, for programming
- Real-time clock
- LEDs for displaying of the input and output signals as well as error messages and the RUN operating condition.
- Fastening by inserting in the plug-in base ECZ. The plug-in base can either be snapped on a DIN rail or fastened by screws.
- Built-in lithium battery for back-up of the RAM contents, its lifetime is 10 years.
- RUN/STOP switch for starting and aborting the program execution.
- Diagnosis functions.
- Programming with the programming software : 907 PC 29
- User program containing max. 2 k instructions.



The comprehensive description for this central unit is located in volume 5.

Brief description

The central unit CS 20 works as a

- Stand-alone central unit.

Main features :

- Power supply
24 VDC or 120 VAC or 230 VAC (3 versions)
- 12 binary inputs (one of them is a high-speed input)
- 8 binary relay outputs
- 1 integrated high-speed counter
- Serial interface COM1, EIA-232, for programming
- Real-time clock
- LEDs for displaying of the input and output signals as well as error messages and the RUN operating condition.
- Fastening by inserting in the plug-in base ECZ. The plug-in base can either be snapped on a DIN rail or fastened by screws.
- Built-in lithium battery for back-up of the RAM contents, its lifetime is 10 years.
- RUN/STOP switch for starting and aborting the program execution.
- Diagnosis functions.
- Programming with the programming software : 907 PC 29
- User program containing max. 2 k instructions.

Chapter	Description	Page
3.1	ECZ Plug-in base for : I/O remote units Central units 07 KR 31, PCZB, CS 20	3.1-1

3.1

ECZ

Plug-in base ECZ

The central units 07 KR 31, PCZB/CS20 and all of the remote units must be mounted on a plug-in base ECZ, with screw termination.

The plug-in base is suitable for rail mounting : (35 mm EN 50 022).

It consist of :

- 30 screw terminals for the connecting cables ①
- 8 dip switches to set the address of the unit ②
- 2 holes to allow screw fixing ③
- One 96 way connector for connection to the plug-in unit ④
- 1 voltage selector 24 VDC, 120 and 230 VAC ⑤
- Rail fixing ⑥

The following terminals are :

- Terminal 1 : bus 2
- Terminal 2 : bus 1
- Terminal 3 : shield of bus
- Terminal 16 : power supply 24 VDC or 120 VAC or 230 VAC
- Terminal 17 : power supply 0 VDC or 120 VAC or 230 VAC
- Terminal 18 : functional earth

● Termination


– on the plug-in base ECZ use 60 °C copper conductor only

Cross section :

- bus wiring terminal : twisted pair
AWG 24 (0.22 mm²) to AWG 18 (0.8 mm²)
- earth terminal : rigid or stranded connector
AWG 10 (5.2 mm²)
- Others terminals :
- inputs : stranded connector
AWG 18 (0.8 mm²) to AWG 14 (2.1 mm²)
- outputs : stranded connector
AWG 14 (2.1 mm²)
- power supply
AWG 14 (2.1 mm²)


Screws tightening torque (for guidance only)
7 Lbs. in (0.8 N.m).

An LC filter is built into the base.




C : capacitor 1 nF class Y
L : self 3 , 330 μH

The insertion of a unit with the incorrect power supply is prevented by the voltage selector.



Dimensions in mm


Details quoted in **heavy types** refer to screw fixing (2 x M4) dimensions.



Order number : FPR 370 0001 R0001
Weight (kg) : 0.200

3.2 Addressing

The address of the remote units is set by the dip switch on the plug-in base.




Dip switch	2	3	4	5	6	7
Decimal value	32	16	8	4	2	1


Dip switches 2 to 7 are used to set the address of the remote units on the bus.

The address of the unit is obtained by the addition of the binary values of the dip switches 2 to 7 when in the "ON position". The result obtained is the decimal address of the unit.

Example 1 : address 07



Example 2 : address 19



Dip switch N. 1 :

– For the user configurable I/O units
Examples : ICSC 08 L1, ICFC 16 L1

Position «**ON**» : All channels are set on outputs only.

Position «**OFF**» : The function of each of the channels is configured by the user's programme.

– For the PCZB

Position «**ON**» : PCZB MASTER

Position «**OFF**» : PCZB SLAVE

Dip switch N. 8 :

This switch is used to set the address of the channels of I/O units.

xx = address of the remote unit

● Position «**OFF**» :

xx, 00 to xx, 07 (channels 00 to 07)

xx, 00 to xx, 15 (channels 00 to 15) with the central units 07 KR 31, 07 KR 91, 07 KT 92.

xx, 00 to xx, 07 and xx+1, 00 to xx+1,07 with the central units UCZA/UCZB.

● Position «**ON**» :

xx, 08 to xx, 15 (channels 08 to 15)

xx, 08 to xx, 15 and xx+1,00 to xx+1,07 (channels 08 to 15 and channels 00 to 07) with the central units 07 KR 31, 07 KR 91, 07 KT 92.

xx, 08 to xx, 15 and xx+1,08 to xx+1,15 with the central units UCZA/UCZB.

Chapter	Description	Page
4.1	Binary Input remote units	
4.1.1	ICSI 08 D1 : 8 Inputs 24 VDC	4.1.1-1
4.1.2	ICSI 08 E1 : 8 opto-isolated Inputs 24 VDC	4.1.2-1
4.1.3	ICSI 08 E3/4 : 8 Inputs 115/230 VAC	4.1.3-1
4.1.4	ICSI 16 D1 : 16 Inputs 24 VDC	4.1.4-1
4.1.5	ICSI 16 E1 : 16 opto-isolated Inputs 24 VDC	4.1.5-1
4.2	Binary Output remote units	
4.2.1	ICSO 08 R1 : 8 relay Outputs	4.2.1-1
4.2.2	ISCO 08 Y1 : 8 Outputs 24 VDC 2A	4.2.2-1
4.2.3	ICSO 16 N1 : 16 Outputs 24 VDC 0.5A	4.2.3-1
4.3	Binary Input/Output remote units	
4.3.1	ICSK 20 F1 : 12 Inputs 24 VDC/8 relay Outputs	4.3.1-1
4.3.2	ICSC 08 L1 : 8 user configurable Inputs/Outputs	4.3.2-1
4.3.3	ICFC 16 L1 : 16 user configurable Inputs/Outputs	4.3.3-1
4.3.4	ICDG 32 L1 : 16 Inputs 24 VDC/8 Outputs 24 VDC 0.25A 8 user configurable Inputs/Outputs	4.3.4-1
4.3.5	ICSK 20 N1 : 12 Inputs 24 VDC/8 transistors Outputs	4.3.5-1
4.4	Binary Input/Output remote units, degree of protection IP65	
4.4.1	ICPO 16 H1 : 16 Outputs 24 VDC 2A	4.4-1
4.4.2	ICPO 08 H1 : 8 Outputs 24 VDC 2A	4.4-9
4.4.3	ICPI 16 D1 : 16 Inputs 24 VDC	4.4-17
4.4.4	ICPI 08 D1 : 8 Inputs 24 VDC	4.4-25

4.1.1

ICSI 08 D1

Binary Input remote unit


8 non isolated inputs 24 VDC

Binary non isolated input unit with 8 input channels for 24 VDC.

Description of the unit front :

- Eight yellow input status led's «0» to «7»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ



8 inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	no	no
Supply output regulated 24 VDC (± 5 %)	-	100 mA
Signal level of the input, nominal value	24 VDC	24 VDC
Signal level of the input :		
0 signal	-3 to +5V	-3 to +5V
1 signal	+15 to +30V	+15 to +30V
Open circuit detection	yes (**)	yes (**)
Input current for 24 VDC	6 mA	6 mA
Input delay (*)	2 to 32 ms	2 to 32 ms
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.5 W	8 W
Order number : FPR 331 5101	R1012	R0016/R0014
Weight (kg)	0.25	0.43

(*) This time can be changed, factory setting 8 ms.
 (**) Open circuit will not be detected with factory setting.
 Enable with TCZ terminal (see Chapter 9, Volume 2
 «In case of failure»).

● **Electrical connection**



The common "+" terminals are connected together.

Power supply 24 VDC

The common "+" must not be used.

Power supply 230 VAC and 120 VAC

The common "+" can supply the inputs with 24 VDC.



Note : In case of use of an external power supply 24 VDC for inputs, the "0" VDC has to be connected to the common "-".

Caution : The 24 VDC must never be connected to common "+".

● **Initialization**

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 8 inputs is displayed on the 8 led's.

● **Utilization**

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 61		00 ... 63		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	ON	OFF	ON	OFF
Input	A	Exx, 00	Exx,08	Exx, 00	Exx, 08	Ixx00
	B	Exx, 01	Exx,09	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx,10	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx,11	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx,12	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx,13	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx,14	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx,15	Exx, 07	Exx, 15	Ixx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

The available configuration for each input :

- delay
- open circuit detection

● **Fault indication**

The led's indicate the following :

- Led 0 : "**Unit error**"
- Led 1 : "**Bus error**"
- Led 3 : "**Cut wire**"

The status of an input channel is shown by :

- Led 7 : "**Input**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.1.2 ICSI 08 E1 8 isolated inputs 24 VDC


Binary Input remote unit

Binary isolated input unit with 8 input channels for 24 VDC.

Description of the unit front :

- Eight yellow input status led's «0» to «7»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ



8 inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	yes (1500VAC)	yes (1500 VAC)
Supply output regulated 24 VDC ($\pm 5\%$)	-	-
Signal level of the input, nominal value	24 VDC	24 VDC
Signal level of the input :		
0 signal	-3 to +5V	-3 to +5V
1 signal	+15 to +30V	+15 to +30V
Open circuit detection	-	-
Input current for 24 VDC	12 mA	12 mA
Input delay (*)	2 to 32 ms	2 to 32 ms
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.5 W	8 W
Order number : FPR 331 6101	R1012	R0016/R0014
Weight (kg)	0.25	0.43


(*) This time can be changed, factory setting 8 ms.

Note : After the input delay, the effective value is 5 ms higher than the selected value.


● Electrical connection

Power supply 24 VDC

Power supply 230 VAC and 120 VAC



94.C.132.D



94.C.131.D

Note : In case of use of only one external power supply 24 VDC for inputs, the different commons have to be connected together and to the 0 VDC of the power supply.

● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 8 inputs is displayed on the 8 led's.

● **Utilization**

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 62		00 ... 63		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	ON	OFF	ON	OFF
Input	A	Exx, 00	Exx,08	Exx, 00	Exx, 08	Ixx00
	B	Exx, 01	Exx,09	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx,10	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx,11	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx,12	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx,13	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx,14	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx,15	Exx, 07	Exx, 15	Ixx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 07 CS 91, refer to their own description

The available configuration for each input :
– delay

● **Fault indication**

The led's indicate the following :

Led 0 : "**Unit error**"
Led 1 : "**Bus error**"

The status of an input channel is shown by :

Led 7 : "**Input**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.1.3 ICSI 08 E3/E4 8 isolated inputs 120/230 VAC


Binary Input remote unit

Binary isolated input unit with 8 input channels for 120 VAC or 230 VAC.
 Type E3 : isolated inputs 120 VAC
 Type E4 : isolated inputs 230VAC

Description of the unit front :

- Eight yellow input status led's «0» to «7»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ



8 inputs per unit

TECHNICAL CHARACTERISTICS		
	120 VAC	230 VAC
Power supply	120 VAC	230 VAC
Number of inputs per unit	8	8
Power supply isolation	yes(1500 VAC)	yes (1500 VAC)
Inputs opto-isolated	yes(1500 VAC)	yes(1500 VAC)
Supply output regulated 24 VDC (± 5 %)	-	-
Signal level of the input, nominal value	120 VAC	230 VAC
Signal level of the input :		
0 signal	0 to 20 V	0 to 40 V
1 signal	79 to 132 V	159 to 242 V
Open circuit detection	no	no
Input current	3.2 mA	6.5 mA
Input delay (*)	2 to 32 ms	2 to 32 ms
Maximum power consumption	5 VA	5VA
Maximum power dissipation	6 W	6W
Order number : FPR 331 6301 FPR 331 6401	R0014	R0016
Weight (kg)	0.43	0.43


(*) This time can be changed, factory setting 10ms.

Note : After the input delay,the effective value is 10 ms higher than the selected value.

● Electrical connection

Power supply 120 VAC

Power supply 230 VAC



● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 8 inputs is displayed on the 8 led's.

● **Utilization**

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 62		00 ... 63		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	ON	OFF	ON	OFF
Input	A	Exx, 00	Exx,08	Exx, 00	Exx, 08	Ixx00
	B	Exx, 01	Exx,09	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx,10	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx,11	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx,12	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx,13	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx,14	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx,15	Exx, 07	Exx, 15	Ixx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

The available configuration for each input :

– delay

● **Fault indication**

The led's indicate the following :

Led 0 : "**Unit error**"

Led 1 : "**Bus error**"

The status of an input channel is shown by :

Led 7 : "**Input**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.1.4 ICSI 16 D1 16 non isolated inputs 24 VDC


Binary Input remote unit

Binary non isolated input unit with 16 input channels for 24 VDC.

Description of the unit front :

- Sixteen yellow input status led's «0» to «15»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ



16 inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	16	16
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	no	no
Supply output regulated 24 VDC (± 5 %)	-	100 mA
Signal level of the input, nominal value	24 VDC	24 VDC
Signal level of the input :		
0 signal	-3 to +5V	-3 to +5V
1 signal	+15 to +30V	+15 to +30V
Open circuit detection	yes (**)	yes (**)
Input current for 24 VDC	6 mA	6 mA
Input delay (*)	2 to 32 ms	2 to 32 ms
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.5 W	8 W
Order number : FPR 331 5101	R1032	R0036/R0034
Weight (kg)	0.25	0.43

(*) This time can be changed, factory setting 8 ms.

(**) Open circuit will not be detected with factory setting.

Enable with TCZ terminal (see Chapter 9, Volume 2


«In case of failure»).

● Electrical connection

The common "+" terminals are connected together and never have to be connected to the 24 VDC.

Power supply 24 VDC


The common "+" must not be used.



94.C.087.D

Power supply 230 VAC and 120 VAC

The common "+" can supply the inputs with 24 VDC.



94.C.086.D

Note : In case of use of an external power supply 24 VDC for inputs, the "0" VDC has to be connected to the common "-".

Caution : the 24 VDC must never be connected to the common "+".

● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 16 inputs is displayed on the 16 led's.

● Utilization

VARIABLES USED IN THE CENTRAL UNIT					
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 61	00 ... 62		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	OFF	ON	OFF
Input	A	Exx, 00	Exx, 00	Exx, 08	Ixx00
	B	Exx, 01	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx, 07	Exx, 15	Ixx07
	I	Exx, 08	Exx+1, 00	Exx+1, 08	Ixx08
	J	Exx, 09	Exx+1, 01	Exx+1, 09	Ixx09
	K	Exx, 10	Exx+1, 02	Exx+1, 10	Ixx10
	L	Exx, 11	Exx+1, 03	Exx+1, 11	Ixx11
	M	Exx, 12	Exx+1, 04	Exx+1, 12	Ixx12
	N	Exx, 13	Exx+1, 05	Exx+1, 13	Ixx13
	O	Exx, 14	Exx+1, 06	Exx+1, 14	Ixx14
	P	Exx, 15	Exx+1, 07	Exx+1, 15	Ixx15

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 07 CS 91, refer to their own description

The available configuration for each input :

- delay
- open circuit detection

● Fault indication

The led's indicate the following :

Led 0 : "**Unit error**"

Led 1 : "**Bus error**"

Led 3 : "**Cut wire**"

The status of an input channel is shown by :

Led 7 : "**Input**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.1.5 ICSI 16 E1 16 isolated inputs 24 VDC


Binary Input remote unit

Binary isolated input unit with 16 input channels for 24 VDC.

Description of the unit front :

- Sixteen yellow input status led's «0» to «15»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ



16 inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	16	16
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	yes(1500VAC)	yes(1500VAC)
Supply output regulated 24 VDC ($\pm 5\%$)	-	-
Signal level of the input, nominal value	24 VDC	24 VDC
Signal level of the input :		
0 signal	-3 to +5V	-3 to +5V
1 signal	+15 to +30V	+15 to +30V
Open circuit detection	-	-
Input current for 24 VDC	6 mA	6 mA
Input delay (*)	2 to 32 ms	2 to 32 ms
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.5 W	8 W
Order number : FPR 331 6101	R1032	R0036/R0034
Weight (kg)	0.25	0.43


(*) This time can be changed, factory setting 8 ms.

Note : After setting the input delay, the effective value is 5 ms higher than the selected value.


● Electrical connection

Power supply 24 VDC

Power supply 230 VAC and 120 VAC



C 133D/GB



C 134D/GB

Note : In case of use of only one external power supply 24 VDC for inputs, the different commons have to be connected together and to the 0 VDC of the power supply.

● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 16 inputs is displayed on the 16 led's.

● Utilization

VARIABLES USED IN THE CENTRAL UNIT					
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 61	00 ... 62		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	OFF	ON	OFF
Input	A	Exx, 00	Exx, 00	Exx, 08	Ixx00
	B	Exx, 01	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx, 07	Exx, 15	Ixx07
	I	Exx, 08	Exx+1, 00	Exx+1, 08	Ixx08
	J	Exx, 09	Exx+1, 01	Exx+1, 09	Ixx09
	K	Exx, 10	Exx+1, 02	Exx+1, 10	Ixx10
	L	Exx, 11	Exx+1, 03	Exx+1, 11	Ixx11
	M	Exx, 12	Exx+1, 04	Exx+1, 12	Ixx12
	N	Exx, 13	Exx+1, 05	Exx+1, 13	Ixx13
	O	Exx, 14	Exx+1, 06	Exx+1, 14	Ixx14
	P	Exx, 15	Exx+1, 07	Exx+1, 15	Ixx15

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

The available configuration for each input :

– delay

● Fault indication

The led's indicate the following :

Led 0 : "**Unit error**"

Led 1 : "**Bus error**"

The status of an input channel is shown by :

Led 7 : "**Input**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.2.1 ICSO 08 R1 8 relay outputs 2A


Binary Output remote unit

Binary output unit with 8 relay output channels 2 A.

Description of the unit front :

- Eight yellow output status led's «0» to «7»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ




8 outputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of outputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Outputs isolated	yes (1500 VAC)	yes (1500 VAC)
Switching capacity 120/230 AC DC	2 A 60 W (2A)	2 A 60 W (2A)
Load current,nominal value	2 A AC-1 1 A AC-3	2 A AC-1 1 A AC-3
Minimum values	12 VDC 10 mA	12 VDC 10 mA
Total current for 8 outputs	16 A	16 A
Short circuit shutdown	no	no
Limit of the inductive shutdown voltage	Varistor	Varistor
Maximum power consumption	0.2 A	6VA
Maximum power dissipation	5 W	5 W
Order number : FPR 331 2101	R1012	R0016/R0014
Weight (kg)	0.25	0.43


● Electrical connection

Power supply 24 VDC

Power supply 230 VAC and 120 VAC




94 C 137D



94 C 138D

Note : In case of inductive load with a DC current, a free wheel diode Has to be mounted in parallel of the load according the following example for the output A :



94 C 139D

● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 8 outputs is displayed on the 8 led's.

● **Utilization**

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 62		00 ... 63		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	ON	OFF	ON	OFF
Output	A	Axx, 00	Axx,08	Axx, 00	Axx, 08	Oxx00
	B	Axx, 01	Axx,09	Axx, 01	Axx, 09	Oxx01
	C	Axx, 02	Axx,10	Axx, 02	Axx, 10	Oxx02
	D	Axx, 03	Axx,11	Axx, 03	Axx, 11	Oxx03
	E	Axx, 04	Axx,12	Axx, 04	Axx, 12	Oxx04
	F	Axx, 05	Axx,13	Axx, 05	Axx, 13	Oxx05
	G	Axx, 06	Axx,14	Axx, 06	Axx, 14	Oxx06
	H	Axx, 07	Axx,15	Axx, 07	Axx, 15	Oxx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

● **Fault indication**

The led's indicate the following :

Led 0 : "**Unit error**"

Led 1 : "**Bus error**"

The status of an output channel is shown by :

Led 6 : "**Output**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.2.2 ICSO 08 Y1
8 outputs 24 VDC 2A


Binary Output remote unit

Binary output unit with 8 transistor output channels 24 VDC 2 A.

Description of the unit front :

- Eight yellow output status led's «0» to «7»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ





8 outputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of outputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Outputs opto-isolated	yes(1500VAC)	yes(1500 VAC)
Maximum current	2 A AC1	2 A AC1
Leackage current	4 mA	4 mA
Total current for the 8 outputs	8 A	8 A
Short circuit protection for each output	yes	yes
Overload thermal protection for each output	yes	yes
Maximum power consumption	0.2 A	6VA
Maximum power dissipation	6 W	8 W
Order number : FPR 331 1101	R1022	R0026/R0024
Weight (kg)	0.25	0.43

● Electrical connection

Power supply 24 VDC

Power supply 230 VAC and 120 VAC



● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 8 outputs is displayed on the 8 led's.

● **Utilization**

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 62		00 ... 63		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	ON	OFF	ON	OFF
Output	A	Axx, 00	Axx,08	Axx, 00	Axx, 08	Oxx00
	B	Axx, 01	Axx,09	Axx, 01	Axx, 09	Oxx01
	C	Axx, 02	Axx,10	Axx, 02	Axx, 10	Oxx02
	D	Axx, 03	Axx,11	Axx, 03	Axx, 11	Oxx03
	E	Axx, 04	Axx,12	Axx, 04	Axx, 12	Oxx04
	F	Axx, 05	Axx,13	Axx, 05	Axx, 13	Oxx05
	G	Axx, 06	Axx,14	Axx, 06	Axx, 14	Oxx06
	H	Axx, 07	Axx,15	Axx, 07	Axx, 15	Oxx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

● **Fault indication**

The led's indicate the following :

Led 0 : "**Unit error**"

Led 1 : "**Bus error**"

Led 3 : "**Power off**"

Led 4 : "**Overload**"

Led 5 : "**Short-circuit**"

The status of an output channel is shown by :

Led 6 : "**Output**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.2.3 ICSO 16 N1 16 outputs 24 VDC 0.5A


Binary Output remote unit

Binary output unit with 16 transistor output channels 24 VDC 0.5A.

Description of the unit front :

- Sixteen yellow output status led's «0» to «15»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ




16 outputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of outputs per unit	16	16
Power supply isolation	no	yes (1500 VAC)
Outputs opto-isolated	no	no
Maximum current	0.5 A	0.5 A
Total current for the 16 outputs	8 A	8 A
Short circuit protection for each output	yes	yes
Overload thermal protection for each output 2 A with 25 °C ambient 1.5 A with 55 °C ambient	yes	yes
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	6 W	8 W
Order number : FPR 331 3101	R1052	R0056/R0054
Weight (kg)	0.25	0.43


● Electrical connection

Power supply 24 VDC

Power supply 230 VAC and 120 VAC




C.207 D



C.208 D

Electric schema for a transistor output



C.209 D

Note :

The both commun + terminals have to be connected to garanty a right diagnosis function.

If the common + terminals are not connected to an external power supply 24 VDC, the corresponding outputs are reset to 0.

- A free wheel diode is not necessary because the protection is integrated into the transistor component.
- An external thermal fuse max. 10 A has to be connected between the common + terminals and the 24 VDC to avoid damage in case of use of a lot of overload outputs.

● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 16 outputs is displayed on the 16 led's.

● Utilization

VARIABLES USED IN THE CENTRAL UNIT					
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 61	00 ... 63		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	OFF	ON	OFF
Output	A	Axx, 00	Axx, 00	Axx, 08	Oxx00
	B	Axx, 01	Axx, 01	Axx, 09	Oxx01
	C	Axx, 02	Axx, 02	Axx, 10	Oxx02
	D	Axx, 03	Axx, 03	Axx, 11	Oxx03
	E	Axx, 04	Axx, 04	Axx, 12	Oxx04
	F	Axx, 05	Axx, 05	Axx, 13	Oxx05
	G	Axx, 06	Axx, 06	Axx, 14	Oxx06
	H	Axx, 07	Axx, 07	Axx, 15	Oxx07
	I	Axx, 08	Axx + 1, 00	Axx + 1, 08	Oxx08
	J	Axx, 09	Axx + 1, 01	Axx + 1, 09	Oxx09
	K	Axx, 10	Axx + 1, 02	Axx + 1, 10	Oxx10
	L	Axx, 11	Axx + 1, 03	Axx + 1, 11	Oxx11
	M	Axx, 12	Axx + 1, 04	Axx + 1, 12	Oxx12
	N	Axx, 13	Axx + 1, 05	Axx + 1, 13	Oxx13
	O	Axx, 14	Axx + 1, 06	Axx + 1, 14	Oxx14
	P	Axx, 15	Axx + 1, 07	Axx + 1, 15	Oxx15

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

● Fault indication

The led's indicate the following :

Led 0 : "Unit error"

Led 1 : "Bus error"

Led 3 : "Power off"

Led 5 : "Short-circuit or Overload"

The status of an output channel is shown by :

Led 6 : "Output"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «In case of failure»).

4.3.1

ICSK 20 F1

Binary Input/Output remote unit


12 inputs 24 VDC / 8 relay outputs

Binary input/output unit with 12 input channels for 24 VDC and 8 relay output channels..

Description of the unit front :

- Twelve yellow input status led's «0» to «11»①
- Eight yellow output status led's «0» to «7»②
- One green led labelled "Supply" to indicate the presence of the supply ③
- «TEST» push-button④
- Red error led ⑤
- List of error codes ⑥

The unit has to be mounted on a plug-in base ECZ



12 inputs/8 relay outputs per unit

GENERAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	12	12
Number of outputs per unit	8	8
Isolated power supply	no	yes (1500 VAC)
Maximum consumption	0.3 A	10 VA
Order number FPR 3327101	R 1202	R 0206/R 0204
Weight (kg)	0.25	0.43

INPUT CHARACTERISTICS		
Signal level of the input, nominal value	24 VDC	24 VDC
Opto isolated inputs	no	no
Signal level of the inputs, nominal value	24 VDC	24 VDC
Signal level of the input		
0 signal	-3 to +5V	-3 to +5V
1 signal	+15 to +30V	+15 to +30V
Input current for 24 VDC	5 mA	5 mA
Input delay (*)	5 ms	5 ms


(*) This delay can't be modified

OUTPUT CHARACTERISTICS


Isolated	yes	yes
Switching capacity under 2 A (resistive or inductive load) 120/230 VAC 50/60Hz DC	2 A 60 W (2A)	2 A 60 W (2A)
Nominal current	2 A AC-1 1 A AC-3	2 A AC-1 1 A AC-3
Minimum power for the contacts 10 mA	12 VDC 10 mA	12 VDC
Supply output 24 VDC 100 mA	no	yes
Total current		
Common M-Q 120/230 VAC 50/60Hz 24 VDC	6 A 6 A	6 A 6 A
Common R-T 120/230 VAC 50/60Hz 24 VDC	4 A 4 A	4 A 4 A
Short-circuit protection	no	no
Over voltage protection	Varistor	Varistor

● **Electrical connection**

Power supply 24 VDC



Power supply 230 VAC and 120 VAC



Note :

The internal 24 VDC (100 mA) power supply is only available for the 230 VAC/120 VAC versions. This power is used to power the inputs.

In case of the 24 VDC version, the 0 V of the second external power supply has to be connected to the common "-".

● **Initialization**

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of inputs/outputs is displayed on the 20 led's.

● Utilization

VARIABLES USED IN THE CENTRAL UNIT				
CENTRAL UNITS	07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ	00 ... 61	00 ... 62		1 ... 31
Switch N° 8 on the plug-in base ECZ	OFF	OFF	ON	OFF
Input				
A	Exx, 00	Exx, 00	Exx, 08	Ixx00
B	Exx, 01	Exx, 01	Exx, 09	Ixx01
C	Exx, 02	Exx, 02	Exx, 10	Ixx02
D	Exx, 03	Exx, 03	Exx, 11	Ixx03
E	Exx, 04	Exx, 04	Exx, 12	Ixx04
F	Exx, 05	Exx, 05	Exx, 13	Ixx05
G	Exx, 06	Exx, 06	Exx, 14	Ixx06
H	Exx, 07	Exx, 07	Exx, 15	Ixx07
I	Exx, 08	Exx+1, 00	Exx+1, 08	Ixx08
J	Exx, 09	Exx+1, 01	Exx+1, 09	Ixx09
K	Exx, 10	Exx+1, 02	Exx+1, 10	Ixx10
L	Exx, 11	Exx+1, 03	Exx+1, 11	Ixx11
Output				
M	Axx, 00	Axx, 00	Axx, 08	Oxx00
N	Axx, 01	Axx, 01	Axx, 09	Oxx01
O	Axx, 02	Axx, 02	Axx, 10	Oxx02
P	Axx, 03	Axx, 03	Axx, 11	Oxx03
Q	Axx, 04	Axx, 04	Axx, 12	Oxx04
R	Axx, 05	Axx, 05	Axx, 13	Oxx05
S	Axx, 06	Axx, 06	Axx, 14	Oxx06
T	Axx, 07	Axx, 07	Axx, 15	Oxx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

The available configuration for each channel :

– none

● Fault indication

The led's indicate the following :

Led 0 : "Unit error"

Led 1 : "Bus error"

The status of an input channel is shown by :

Led 7 : "Input"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «In case of failure»).

4.3.2 ICSC 08 L1

Binary Input/Output remote unit

8 user configurable inputs/outputs

Binary input/output unit with 8 channels.


The function of each channel can be selected :

- as a 24 VDC input or
- as a 24 VDC 500 mA transistor output

Description of the unit front :

- Eight yellow input/output status led's «0» to «7»①
- «TEST» push-button②
- Red error led③
- List of error codes④

The unit has to be mounted on a plug-in base ECZ



8 inputs/outputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8 max.	8 max.
Number of outputs per unit	8 max.	8 max.
Power supply isolation	no	1500 VAC
Maximum power consumption without load on the outputs	0.2 A	10 VA
Maximum power dissipation	6 W	8 W
Order number : FPR 331 9101	R1082	R0086/R0084
Weight (kg)	0.25	0.43

SPECIFICATIONS

Specifications of the inputs

Signal level, nominale value	24 VDC	24 VDC
Input opto-isolated	no	no
Signal level of the input		
0 signal	- 3 V to + 5 V	- 3 V to + 5 V
1 signal	+ 15 V to + 30 V	+ 15 V to + 30 V
Open circuit detection	yes (**)	yes (**)
Input current, nominal value (under 24 VDC)	6 mA	6 mA
Input delay (*)	2 to 32 ms	2 to 32 ms

Specifications of outputs

Process supply	24 VDC	24 VDC
Output opto-isolated	no	no
Maximum voltage drop under nominal load	3 V	3 V
Residual current for 0 signal	< 1 mA	< 1 mA
Switching frequency with inductive loads	max. 0.1 Hz	max. 0.1 Hz
Maximum current	0.5 A	0.5 A
Lamp loads	5 W	5 W
Total current for 8 outputs	max. 2 A	max. 2 A
Short-circuit protection ($I > 2 \text{ A}$)	yes	yes
Overload protection ($I > 0.6 \text{ A}$, $t > 250 \text{ ms}$)	yes	yes
Open circuit detection ($I < 50 \text{ mA}$)	yes (**)	yes (**)

(*) This time can be changed, factory setting 8 ms.

(**) By factory setting, open circuit will not be detected.


Enable with TCZ terminal (see chapter 9, volume 2 «**In case of failure**»).

● Electrical connection

An external power supply is necessary if the outputs are used and in this case the **common + terminal musn't be disconnected** to the 24 VDC power supply.


Power supply 24 VDC

Example of electrical connections with 5 inputs and 3 outputs.



Power supply 230 VAC and 120 VAC


Example of electrical connections with 5 inputs and 3 outputs.



Note : Almost one common + has to be connected to the power supply. When switching high current loads, use many common + terminal to avoid damage to the base.

Warning : For a version dated before 01/92, the terminals 4 and 5 have not be used.

Internal connection



Note : In case of use of an external power supply 24 V DC for inputs, the "24" V DC has to be connected to the common "+".

Caution : if the 24 V DC is connected to common "+", the remote unit can be supplied by the external power supply even if the main power supply is **OFF**.

● Initialization

- After configured and wired the unit :
- the unit initializes itself after power **On**.
 - the error led goes out after initialization.
 - the status of 8 inputs is displayed on the 8 led's.

● Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 61		00 ... 62		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	OFF	OFF	ON	OFF
Input	A	Exx, 00	Exx,08	Exx, 00	Exx, 08	Ixx08
	B	Exx, 01	Exx,09	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx,10	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx,11	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx,12	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx,13	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx,14	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx,15	Exx, 07	Exx, 15	Ixx07
Output	A	Axx, 00	Axx,08	Axx, 00	Axx, 08	Oxx08
	B	Axx, 01	Axx,09	Axx, 01	Axx, 09	Oxx01
	C	Axx, 02	Axx,10	Axx, 02	Axx, 10	Oxx02
	D	Axx, 03	Axx,11	Axx, 03	Axx, 11	Oxx03
	A	Axx, 04	Axx,12	Axx, 04	Axx, 12	Oxx04
	F	Axx, 05	Axx,13	Axx, 05	Axx, 13	Oxx05
	G	Axx, 06	Axx,14	Axx, 06	Axx, 14	Oxx06
	H	Axx, 07	Axx,15	Axx, 07	Axx, 15	Oxx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

The available configuration for each input :

- delay
- open circuit detection

A channel can be used for an input or an output, depending upon the user program.

Note :

The inputs/outputs are configured in outputs when the DIP switch N° 1 on the plug-in base ECZ is ON. This allows to use again the address coded for an input unit.

● **Fault indication**

The led's indicate the following :

- Led 0 : "**Unit error**"
- Led 1 : "**Bus error**"
- Led 3 : "**Cut wire**"
- Led 4 : "**Overload**"
- Led 5 : "**Short Circuit**"

The status of an input channel is shown by :

- Led 6 : "**Output**"
- Led 7 : "**Input**"


If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.3.3

ICFC 16 L1

Binary Input/Output remote unit

16 user configurable inputs/outputs



Binary input/output unit with 16 channels.

The function of each channel can be selected :

- as a 24 VDC input or
- as a 24 VDC 500 mA transistor output

Description of the unit front :

- Sixteen yellow input/output status led's «0» to «15» ①
- «TEST» push-button ②
- Red error led ③
- List of error codes ④

The unit has to be mounted on two plug-in bases ECZ

The unit has a special low-profile housing.

TECHNICAL CHARACTERISTICS	
Power supply	24 VDC
Number of inputs per unit	16 max.
Number of outputs per unit	16 max.
Power supply isolation	no
Maximum power consumption without load on the outputs	4 W
Maximum power dissipation	0.2 A
Order number : FPR 331 9101	R1162
Weight (kg)	0.37

SPECIFICATIONS

Specifications of the inputs

Signal level, nominale value	24 VDC
Input opto-isolated	no
Signal level of the input	
0 signal	- 3 V to + 5 V
1 signal	+ 15 V to + 30 V
Open circuit detection	yes (**)
Input current, nominal value	6 mA
Input delay (*)	2 to 32 ms

Specifications of outputs

Process supply	24 V
Output opto-isolated	no
Maximum voltage drop under nominal load	3 V
Residual current for 0 signal	< 1 mA
Switching frequency with inductive loads	max. 0.1 Hz
Maximum current	0.5 A
Lamp loads	5 W
Total current for 16 outputs	max. 4 A
Short-circuit protection ($I > 2 \text{ A}$)	yes
Overload protection ($I > 0.6 \text{ A}$, $t > 250 \text{ ms}$)	yes
Open circuit detection ($I < 50 \text{ mA}$)	yes (**)

(*) This time can be changed, factory setting 8 ms.

(**) By factory setting, open circuit will not be detected.


Enable with TCZ terminal (see chapter 9, volume 2 «**In case of failure**»).

● Electrical connection

An external power supply is necessary if the outputs are used and in this case the **common + terminal musn't be disconnected** to the 24 VDC power supply.

Power supply 24 VDC

Example of electrical connections with 10 inputs and 6 outputs.



Note : Almost one common + and one common - on each plug-in base ECZ have to be connected to the power supply.

When switching high current loads, use many common + terminal to avoid damage to the base.

CAUTION : The common - is internally connected to the earth terminal.

Note : In case of use of an external power supply 24 VDC for inputs, the "24" VDC has to be connected to the common "+".


Caution : if the 24 VDC is connected to common "+", the remote unit can be supplied by the external power supply even if the main power supply is **OFF**.

● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the status of 8 inputs is displayed on the 16 led's.

Internal connection



C-167 D

● Utilization

VARIABLES USED IN THE CENTRAL UNIT					
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ on the left side		00 ... 61	00 ... 63		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	OFF	ON	OFF
Input	A	Exx, 00	Exx, 00	Exx, 08	Ixx08
	B	Exx, 01	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx, 07	Exx, 15	Ixx07
	I	Exx, 08	Exx+1,00	Exx+1,08	Ixx08
	J	Exx, 09	Exx+1,01	Exx+1,09	Ixx09
	K	Exx, 10	Exx+1,02	Exx+1,10	Ixx10
	L	Exx, 11	Exx+1,03	Exx+1,11	Ixx11
	M	Exx, 12	Exx+1,04	Exx+1,12	Ixx12
	N	Exx, 13	Exx+1,05	Exx+1,13	Ixx13
	O	Exx, 14	Exx+1,06	Exx+1,14	Ixx14
	P	Exx, 15	Exx+1,07	Exx+1,15	Ixx15
Output	A	Axx, 00	Axx, 00	Axx, 08	Oxx08
	B	Axx, 01	Axx, 01	Axx, 09	Oxx01
	C	Axx, 02	Axx, 02	Axx, 10	Oxx02
	D	Axx, 03	Axx, 03	Axx, 11	Oxx03
	A	Axx, 04	Axx, 04	Axx, 12	Oxx04
	F	Axx, 05	Axx, 05	Axx, 13	Oxx05
	G	Axx, 06	Axx, 06	Axx, 14	Oxx06
	H	Axx, 07	Axx, 07	Axx, 15	Oxx07
	I	Axx, 08	Axx, 08	Axx+1,08	Oxx08
	J	Axx, 09	Axx, 09	Axx+1,09	Oxx01
	K	Axx, 10	Axx, 10	Axx+1,10	Oxx02
	L	Axx, 11	Axx, 11	Axx+1,11	Oxx03
	M	Axx, 12	Axx, 12	Axx+1,12	Oxx04
	N	Axx, 13	Axx, 13	Axx+1,13	Oxx05
	O	Axx, 14	Axx, 14	Axx+1,14	Oxx06
	P	Axx, 15	Axx, 15	Axx+1,15	Oxx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

The available configuration for each input :

- delay
- open circuit detection

The available configuration for each output :

- open circuit detection

A channel can be used for an input or an output, depending upon the user program.

Note :

The inputs/outputs are configured in outputs when the DIP switch N° 1 on the plug-in base ECZ is ON. This allows to use again the address coded for an input unit.

● **Fault indication**

The led's indicate the following :

Led 0 : "**Unit error**"

Led 1 : "**Bus error**"

Led 3 : "**Cut wire**"

Led 4 : "**Overload**"

Led 5 : "**Short Circuit**"

The status of an input channel is shown by :

Led 6 : "**Output**"

Led 7 : "**Input**"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «**In case of failure**»).

4.3.4 Binary input/output module ICDG 32 L1

16 binary inputs, 8 binary outputs, 8 configurable inputs/outputs,
24 V DC, CS31 system bus connection electrically isolated




Fig. 4.3.4–1: Binary input/output module ICDG 32 L1

Contents

Intended purpose	4.3.4–1
Display and operating elements on the front panel	4.3.4–1
Electrical connection	4.3.4–1
Addressing	4.3.4–3
I/O configuration	4.3.4–4
Normal operation	4.3.4–4
Diagnosis and displays	4.3.4–4
Technical data	4.3.4–5
Dimensioned drawing (for mounting)	4.3.4–8

Intended purpose

The binary input/output module ICDG 32 L1 is a remote module on the CS31 system bus. It has 32 binary channels with the following features:

- 16 inputs, 24 V DC, in 2 groups
- 8 outputs, 24 V DC, in 1 group. The outputs
 - employ switching transistors,
 - have a rated load capability of 0.25 A and
 - are overload and short-circuit proof.
- 8 inputs/outputs, of which each can be addressed
 - as an input,
 - as an output
 - as a readable output (combined input/output).

In this case the technical data are equal to the data of the other inputs and outputs.

The module is supplied with 24 V DC.

The CS31 system bus connection is electrically isolated from the remaining module components.

The module offers a number of diagnosis functions (see chapter "Diagnosis and displays").

Display and operating elements on the front panel

- 16 green LEDs for displaying the signal statuses of the inputs,
16 yellow LEDs for displaying the signal statuses of the outputs or of the combined inputs/outputs
- ⊖ List of diagnosis information belonging to the LEDs, if they are used for diagnosis
- Red LED for error message
- Test button

Electrical connection

The module is mounted on a 15-mm-high DIN rail or fastened with 4 screws. The following figure shows the electrical connection of the input/output module.




Fig. 4.3.4-2: Electrical connection of the binary input/output module ICDG 32 L1 R0101, the example shows 19 channels as inputs and 13 channels as outputs

Addressing

An address has to be set on each module, so that the central unit can access the inputs and outputs correctly.

A detailed description concerning the item "Addressing" is contained in the chapters "Addressing" of the central units and couplers.

The module address is set on the DIL switch located under the slide on the right side of the module.

If the central units 07 KR 91, 07 KT 92 and 07 KT 93 are used as bus masters, the following **operating modes** (address allocations) are valid, dependent on the position of the address DIL switch No. 1:

Central units 07 KR 91 / 07 KT 92 / 07 KT 93	
For address DIL switch No. 8 see separate description (this page, top right).	
The address DIL switch No. 1 set to ON means, that 16 inputs and 16 outputs are unchangeably allocated. All of the combined inputs/outputs are outputs only (see below).	
Terminal/Input	Terminal/Output
5 E n,00	28 A n,00
6 E n,01	29 A n,01
7 E n,02	30 A n,02
8 E n,03	31 A n,03
9 E n,04	32 A n,04
10 E n,05	33 A n,05
11 E n,06	34 A n,06
12 E n,07	35 A n,07
13 E n,08	36 A n,08
14 E n,09	37 A n,09
15 E n,10	38 A n,10
16 E n,11	39 A n,11
17 E n,12	40 A n,12
18 E n,13	41 A n,13
19 E n,14	42 A n,14
20 E n,15	43 A n,15

n: module address, is set on the address DIL switches No. 2...7.
Recommended module addresses with 07 KR 91 / 07 KT 92/93 as bus masters: 08, 10, 12.....60 (even addresses)

With this setting, the module uses only **one** address on the CS31 system bus.
16 inputs and 16 outputs are available.

Fig. 4.3.4-3: Addresses of the channels, if DIL switch No. 1 is set to ON

Setting the address DIL switch No. 8

The address DIL switch is used to define whether the outputs should switch on again after overload or short-circuit automatically or by acknowledgement. Meaning of the switch positions:

OFF (factory setting): After the error has been eliminated, the outputs switch on again automatically.

ON: After the error has been eliminated, the outputs switch on again by pressing the test button or by acknowledgement via the PLC program (connection element CS31QU) or via the serial interface on the central unit.

Central units 07 KR 91 / 07 KT 92 / 07 KT 93		
For address DIL switch No. 8 see separate description (this page, top right).		
The address DIL switch No. 1 set to OFF (factory setting) means, that 16 inputs and 8 outputs are unchangeably allocated. The 8 combined inputs/outputs can be addressed individually as inputs or outputs (see below).		
Term./Input	Term./Output	Input
5 E n,00	28 A n,00	
6 E n,01	29 A n,01	
7 E n,02	30 A n,02	
8 E n,03	31 A n,03	
9 E n,04	32 A n,04	
10 E n,05	33 A n,05	
11 E n,06	34 A n,06	
12 E n,07	35 A n,07	
13 E n,08	36 A n,08	E n+1,00
14 E n,09	37 A n,09	E n+1,01
15 E n,10	38 A n,10	E n+1,02
16 E n,11	39 A n,11	E n+1,03
17 E n,12	40 A n,12	E n+1,04
18 E n,13	41 A n,13	E n+1,05
19 E n,14	42 A n,14	E n+1,06
20 E n,15	43 A n,15	E n+1,07

n: module address, is set on the address DIL switches No. 2...7.
Recommended module addresses with 07 KR 91 / 07 KT 92/93 as bus masters: 08, 10, 12.....60 (even addresses)

With this setting, the module uses **two** addresses on the CS31 system bus. 24 binary input and 16 binary output channels are occupied. The module has 16 inputs, 8 outputs and 8 combined inputs/outputs now. An+1,00...15 and En+1,08...15 are not used. If needed, these addresses can be used for other modules.

Fig. 4.3.4-4: Addresses of the channels, if DIL switch No. 1 is set to OFF

Remark:

The module ICDG 32 L1 reads the positions of the DIL switches only once during initialization after power ON. If switch positions are changed during operation of the module, these alterations become effective not before the next initialization. Exception: The position of DIL switch No. 8 (defining whether the outputs should switch on again after overload or short-circuit automatically or by acknowledgement) is currently updated.

I/O configuration

The module ICDG 32 L1 does not store any configuration data. The 8 combined input/output channels are defined as inputs or outputs by the user program.

That means, that each of the combined inputs/outputs can be used as an input or an output (or readable output) by reading data from it or sending data to it, respectively. If used as an input, no signal "1" may be sent to the respective output. For setting the DIL switches and address allocation see also figures 4.3.4–3 and 4.3.4–4 (one page above).

Normal operation

- The module initializes itself after power ON. During initialization all LEDs are ON.
- If the CS31 system bus does not run, the LED ③ flashes.
- The LED ③ goes out again, when the bus operation runs correctly and the module does not detect an error.
- The 16 green and the 16 yellow LEDs ① show the signal statuses of the 32 channels.

Diagnosis and display

Diagnosis functions:

- Output short-circuit/overload ($I > 0.7 \text{ A}$)
- Message of a short-circuit/overload to the central unit
- After storing this information, holding it ready for reading (error class and error location)
- Error in the module (Unit error)
- Error on the CS31 system bus (Bus error)

If one of these errors occurs, the red LED ③ lights up. **The error message is sent to the central unit (or coupler).** For more information see the chapters "Diagnosis" in the descriptions of the central units and couplers.

By means of the test button ④ and the LEDs ① the user is enabled to call diagnosis information directly from the module.

Pressing the test button the first time the channel En,00 is selected: The LED of the selected channel flashes, all of

the other LEDs are switched off during this test. When releasing the test button, the error information belonging to this channel is displayed by the green LEDs 00 to 07 for a period of ca. 3 seconds.

Meaning of the LEDs if lighting up:

- 00 Error in the module (Unit error)
- 01 Error on the CS31 system bus (Bus error)
- 02 not used
- 03 not used
- 04 Overload or short circuit, outputs only
- 05 not used
- 06 Configuration as an output
- 07 Configuration as an input

The meaning of the diagnosis LEDs ② is labelled on the front panel of the module in English.

Pressing the test button further times, the test procedure repeats for all of the other inputs and outputs (and combined inputs/outputs).

After calling information from the last channel, a lamp test is carried out by pressing the test button the next time. All LEDs light up. After that, the positions of the address DIL switches stored during the initialization are displayed on the LEDs 00 to 07 for a period of ca. 3 seconds. LED 00 shows the position of switch No. 1 (LEDs 00 to 07 belong to the switches 1 to 8).

The error messages in the I/O module and in the central unit are reset again, when the errors have been eliminated, no new errors have occurred **and** the error elimination has been acknowledged. This also applies for the overload message independent of the position of the DIL switch No. 8.

Acknowledging an error after error elimination:

- by pressing the test button for a period of ca. 5 seconds
- or
- by means of the TCZ or a PC (see TCZ description in volume 7.3, Terminal mode, Mail command "Acknowledging errors on remote modules")
- or
- via the PLC program in the central unit, connection element CS31QU, software 907 PC 331.

Remarks:

Using the LED display for overload/short-circuit, the user can find out which channels are involved.

The LEDs 06 and 07 indicate for the 8 configurable channels whether the selected channel is configured as output or as input/output. The unchangeable channels are indicated in the same way.

When the calling of the diagnosis information has been terminated, the 32 green and yellow LEDs show the binary signal statuses of the channels again.

Technical data ICDG 32 L1

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

General data of the module

Admissible temperature range, module in operation	0...65 °C
Rated supply voltage	24 V DC
Rated signal voltage at inputs and outputs	24 V DC
Max. current consumption, outputs unloaded	0.15 A
Max. total output current	4.0 A
Max. rated loadability for the supply terminals	4.0 A
Max. power dissipation in the module, outputs unloaded	5 W
Max. power dissipation in the module outputs under load	10 W
Overvoltage category	II according to IEC 65 A
Buffered voltage interruption time for the processor part	> 10 ms
for the outputs	none
Protection against reversed connection of supply voltage	yes
Conductor cross section for the removable terminal blocks supply voltage max. 2.5 mm ² CS31 system bus input/output terminals	max. 2.5 mm ² max. 1.5 mm ²
Number of binary inputs	16
Number of binary transistor outputs	8
Number of combined inputs/outputs	8
Reference potential for all inputs and outputs	terminals 24/25 (minus pole of the supply voltage, signal name M)
Number of interfaces	1 CS31 system bus interface
Electrical isolation	CS31 system bus interface versus the remaining module parts
Address setting	with a DIL switch located under the slide on the right side of the module
Diagnosis	see chapter "Diagnosis and display"
Indication of operating statuses and errors	33 LEDs altogether
Mechanical dimensions	120 x 140 x 85 mm
Weight	450 g
Order number	GJR5 2514 00 R0101
Technical data for the binary inputs	
Number of channels per module	16
Distribution of channels into groups	2 groups of 8 channels each, channels En,00...En,07 and En,08...En,15
Reference potential for all inputs	terminals 24/25 (minus pole of the supply voltage, signal name M)

Electrical isolation	versus the CS31 system bus interface
Input signal delay	typ. 7 ms
Signalling of input statuses	one green LED per channel, the LEDs correspond functionally to the input signals
Input signal voltage	
signal 0	–30 V...+ 5 V
signal 1	+13 V...+30 V
ripple when signal 0 within –30 V...+ 5 V	
when signal 1	within +13 V...+30 V
Allowed input overvoltage	± 36 V, for 100 ms only
Input current per channel	
input voltage = +24 V	typ. 7.0 mA
input voltage = + 5 V	≥ 1.0 mA
input voltage = +13 V	≥ 2.0 mA
input voltage = +30 V	≤ 10.0 mA
Labelling for the inputs	Symbol names or short signal designations can be labelled on the front panel foil. The foil is not removeable .
Conductor cross section of the removable terminal blocks	max. 1.5 mm ² , terminal-to-terminal distance 3.81 mm
Technical data for the binary outputs	
Number of channels per module	8 transistor outputs
Distribution of channels into groups	1 groups of 8 channels, channels An,00...An,07
Reference potential for all outputs	terminals 24/25 (minus pole of the supply voltage, signal name M)
Common voltage supply for all outputs	terminals 22/23 (plus pole of the supply voltage, signal name L+)
Electrical isolation	versus the CS31 system bus interface
Signalling of output statuses	one yellow LED per channel, the LEDs correspond functionally to the output signals
Output current	
rated value	250 mA with L+ = 24 V
maximum value	312 mA with L+ = 24 V + 25 %
leakage current with signal 0	< 0.5 mA
Demagnetization of inductive loads	internally with free-wheeling diode and Z-diode (Z-diode voltage is 12 V)
Switching frequency with inductive loads	max. 0.5 Hz
Switching frequency with lamp load	max. 11 Hz with max. 5 W
Short-circuit-proof/overload-proof	yes
Overload message ($I \geq 0,7$ A)	yes, after ca. 100 ms
Limitation of output current	yes
Output is switched on again	after acknowledgement, if DIL switch No. 8 = ON automatically, if DIL switch No. 8 = OFF
Total load (together with the output currents of the combined inputs/outputs)	max. 4 A
Labelling for the outputs	Symbol names or short signal designations can be labelled on the front panel foil. The foil is not removeable .

Conductor cross section of the removable terminal blocks max. 1.5 mm², terminal-to-terminal distance 3.81 mm

Technical data of the configurable inputs/outputs

The 8 combined input/output channels are defined individually as inputs or outputs by the user program. This is done by reading from or writing to the corresponding channel.

Number of channels per module	8 inputs/transistor outputs
Distribution of channels into groups if the channels used as inputs if the channels used as outputs	1 group of 8 channels channels En+1,00...En+1,07 channels An,08...An,15
Signalling of input/output statuses	one yellow LED per channel, the LEDs correspond functionally to the binary signals
Other technical data	see binary inputs, see binary outputs

Connection to the ABB Procontic CS31 system bus

Interface standard	EIA RS-485
Electrical isolation	versus supply voltage, inputs/outputs
Conductor cross section of the removable terminal block	max. 2.5 mm ² , terminal-to-terminal distance 5.08 mm

Mechanical data


Mounting on DIN rail	according to DIN EN 50022-35, 15 mm deep. The DIN rail is located in the middle between the upper and the lower edges of the module.
Fastening by screws	using 4 M4 screws.
Width x height x depth	120 x 140 x 85 mm
Wiring method conductor cross section	by removable terminal blocks with screw-type terminals, max. 2.5 mm ² , terminal-to-terminal distance 5.08 mm max. 1.5 mm ² , terminal-to-terminal distance 3.81 mm
Weight	450 g
Outline dimensions (for mounting)	see the drawing on the next page

Mounting hints

Mounting position	vertical, terminals above and below
Cooling	The natural convection cooling must not hindered by cable ducts or other material mounted in the switch cabinet.

Ordering data

Module ICDG 32 L1 R0101	Order No. GJR5 2514 00 R0101
Scope of delivery	Binary input/output module ICDG 32 L1 1 5-pole terminal blocks (5.08 mm) 1 3-pole terminal block (5.08 mm) 4 9-pole terminal blocks (3.81 mm)



All dimensions in mm.

The module is 85 mm deep.

If a DIN rail is used, the mounting depth is increased by the overall depth of the rail.

Fig. 4.3.4-5:

ICDG 32 L1, outline dimensions, **the dimensions for assembly bore holes are printed in bold.**

4.3.5

ICSK 20 N1


Binary Input/Output remote unit

12 inputs 24 VDC / 8 transistor outputs

Binary input/output unit with 12 input channels for 24 VDC and 8 transistor output 24VDC 0.5A channels.

Description of the unit front :

- Twelve yellow input status led's «0» to «11»①
- Eight yellow output status led's «0» to «7»②
- One green led labelled "Supply" to indicate the presence of the supply ③
- «TEST» push-button④
- Red error led⑤
- List of error codes ⑥



The unit has to be mounted on a plug-in base ECZ

12 inputs/8 transistor outputs per unit

GENERAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	12	12
Number of outputs per unit	8	8
Isolated power supply	no	yes (1500 VAC)
Maximum consumption	0.3 A	10 VA
Order number FPR 3331001	R 1202	R 0206/R 0204
Weight (kg)	0.25	0.43

INPUT CHARACTERISTICS		
Signal level of the input, nominal value	24 VDC	24 VDC
Opto isolated inputs	no	no
Signal level of the inputs, nominal value	24 VDC	24 VDC
Signal level of the input		
0 signal	-3 to +5V	-3 to +5V
1 signal	+15 to +30V	+15 to +30V
Input current for 24 VDC	5 mA	5 mA
Input delay (*)	5 ms	5 ms

(*) This delay can't be modified

OUTPUT CHARACTERISTICS

Isolated	no	no
Switching capacity under 0.5 A (resistive or inductive load) DC	15W (0.5A)	15 W (0.5A)
Nominal current	0.5 A	0.5 A
Supply output 24 VDC 100 mA	no	yes
Total current for 8 outputs	4A	4A
Short-circuit protection for each output	yes	yes
Thermal protection for each output 2 A with 25 °C ambient 1.5 A with 55 °C ambient	yes	yes
Over voltage protection	yes	yes

● Utilization

VARIABLES USED IN THE CENTRAL UNIT					
CENTRAL UNITS		07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 61	00 ... 62		1 ... 31
Switch N° 8 on the plug-in base ECZ		OFF	OFF	ON	OFF
Input	A	Exx, 00	Exx, 00	Exx, 08	Ixx00
	B	Exx, 01	Exx, 01	Exx, 09	Ixx01
	C	Exx, 02	Exx, 02	Exx, 10	Ixx02
	D	Exx, 03	Exx, 03	Exx, 11	Ixx03
	E	Exx, 04	Exx, 04	Exx, 12	Ixx04
	F	Exx, 05	Exx, 05	Exx, 13	Ixx05
	G	Exx, 06	Exx, 06	Exx, 14	Ixx06
	H	Exx, 07	Exx, 07	Exx, 15	Ixx07
	I	Exx, 08	Exx+1, 00	Exx+1, 08	Ixx08
	J	Exx, 09	Exx+1, 01	Exx+1, 09	Ixx09
	K	Exx, 10	Exx+1, 02	Exx+1, 10	Ixx10
	L	Exx, 11	Exx+1, 03	Exx+1, 11	Ixx11
Output	M	Axx, 00	Axx, 00	Axx, 08	Oxx00
	N	Axx, 01	Axx, 01	Axx, 09	Oxx01
	O	Axx, 02	Axx, 02	Axx, 10	Oxx02
	P	Axx, 03	Axx, 03	Axx, 11	Oxx03
	Q	Axx, 04	Axx, 04	Axx, 12	Oxx04
	R	Axx, 05	Axx, 05	Axx, 13	Oxx05
	S	Axx, 06	Axx, 06	Axx, 14	Oxx06
	T	Axx, 07	Axx, 07	Axx, 15	Oxx07

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

The available configuration for each channel :

– none

● Fault indication

The led's indicate the following :

Led 0 : "Unit error"

Led 1 : "Bus error"

Led 5 : "Short-circuit or overload"

The status of an input channel is shown by :

Led 7 : "Input"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «In case of failure»).

4.4.1 Binary Output Module ICPO 16 H1

16 output channels 24 V DC/2A, Degree of Protection IP65

CS31 system bus connection electrically isolated




Fig. 4.4.1-1: Binary output module ICPO 16 H1

Contents

Intended purpose	4.4.1-1
Displays and connections at the module housing	4.4.1-1
Electrical connection	4.4.1-1
Addressing	4.4.1-3
I/O configuration	4.4.1-3
Normal operation	4.4.1-3
Diagnosis and displays	4.4.1-4
Technical data	4.4.1-5
Dimensioned drawing (for mounting)	4.4.1-7

Intended purpose

The binary output module ICPO 16 H1 is a remote module on the CS31 system bus. It has 16 binary channels with the following features:

- Housing and termination system according to IP65 degree of protection
- The CS31 bus line is looped through from module to module. For this purpose, the module has two bus connectors as bus input and bus output.
- Each output has its own connector and thus can be unplugged individually.
- The 24 V DC supply voltage is connected via screw-type terminals inside the module housing.
- The outputs
 - employ switching transistors,
 - have a rated load capability of 2 A and
 - are overload and short-circuit proof.

The module is mounted with screws. There are bore holes available for both mounting on a rear wall or on a horizontal surface.

The CS31 system bus connection is electrically isolated from remaining module components.


The module offers diagnosis functions (see chapter "Diagnosis and displays").

Displays and connections at module housing

- ① 16 yellow LEDs for displaying the signal statuses of the outputs
- ② LEDs "Bus Error", "Overload" and "Supply" indicating of operating conditions and errors (see section "Diagnosis and displays")
- ③ CS31 bus connector (input)
- ④ CS31 bus connector (output)
- ⑤ 16 connectors for the outputs
- ⑥ PG11 cable gland for the 24 V DC power supply
- ⑦ The terminals for 24 V DC and PE are located under a removable cover. It is accessible from the top of the module. The DIL switch for setting the module address is also under the cover.
- ⑧ Labelling fields
- ⑨ Bore holes for mounting (see also "Dimensioned drawing" at the end of this description)

Electrical connection

The following figure shows all details necessary for the electrical connection.



24 V DC power supply
L+
M (0V)
PE

not used


With this module, switch 8 must be set to OFF

Bit significance 1 }
Bit significance 2 } Module address;
Bit significance 4 } bit significances
Bit significance 8 }
Bit significance 16 }
Bit significance 32 }

Setting of the module address

The module address is calculated by the sum of significances of those switches which are set to ON.
Example: Switches 3 and 6 ON
Module address: 16 + 2 = 18

PG11 cable gland for 24 V DC power supply




Top view


LED indicators of the outputs
0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
Output channels

Labelling fields

Front view




Bus connector



1 = BUS1
2 = BUS2
3 = SHIELD
4 = not used

CS31 system bus interface, bus input
CS31 system bus interface, bus output

If the module is located at one end of the bus line, the plug at the bus output connector must contain a 120 Ohm resistor for bus termination.



1 = not used
2 = not used
3 = 0 V
4 = output
5 = Protective Earth (PE)


In order to fulfill the IP65 degree of protection, unused output connectors must be sealed with M12 filler plugs (see Accessories)

Indication of operating conditions

LED red Bus Error
 LED red Overload
 LED green Supply

see chapter "Diagnosis"

Side view



This additional earthing terminal is bonded to PE inside the module and should be connected to the machine earth with a short conductor as a EMC measure.

Fig. 4.4.1-2: Details for the electrical connection of the output module ICPO 16 H1



Addressing

An address has to be set on each module, so that the central unit can access the inputs and outputs correctly.

A detailed description concerning the item "Addressing" is contained in the chapters "Addressing" of the central units and couplers.

The module address is set on the DIL switch located under the cover at the top side of the module.

Meaning of the address switches:



When using the central units 07 KR 91, 07 KT 92 or 07 KT 93, the possible module addresses range from 0...61.

In connection with the central units 07 KR 91 and 07 KT 92/KT93 as bus masters, the following address allocations are valid:

Central units 07 KR 91 / 07 KT 92 / 93			
The DIL switch No. 8 must be set to OFF.			
Chan.		Chan.	
A0	A xx,00	A8	A xx,08
A1	A xx,01	A9	A xx,09
A2	A xx,02	A10	A xx,10
A3	A xx,03	A11	A xx,11
A4	A xx,04	A12	A xx,12
A5	A xx,05	A13	A xx,13
A6	A xx,06	A14	A xx,14
A7	A xx,07	A15	A xx,15

xx: Group number of the address, set on the DIL switch with the switches 2...7.

The module uses 16 outputs on the CS31 system bus.

I/O configuration

With this module, an I/O configuration is not necessary.

Normal operation

- The module initializes itself after power ON. During initialization all LEDs \ominus are ON.
- After the initialization, the two red LEDs \ominus go out again, if the bus is running correctly and the module does not detect any error. The green LED "Supply" lights up.
- The 16 yellow LEDs \bigcirc indicate the signal statuses of the channels A0...A15.

Diagnosis and displays

Diagnosis functions:

- Bus Error (on the CS31 system bus)
- Overload (or short-circuit)
- Supply (power)

Diagnosis error table:

Bus Error	Overload	Supply	<input checked="" type="checkbox"/> LED flashes Explanation	<input type="checkbox"/> LED ON	<input type="checkbox"/> LED OFF
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	The module is not connected at all, or the 24 V DC power supply is OFF.		
<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, the bus is running, no error.		
<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, the bus is running, there is a short-circuit/overload on at least one output.		
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, there is a short-circuit/overload on at least one output, the bus does not run.		
<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, the bus does not run.		
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Initialization phase after power ON.		

Behaviour in case of short-circuit or overload:

If a short-circuit or an overload has occurred on an output channel, the involved channel will be switched off as a reaction on a high temperature of the switching transistor. In certain intervals, the module then tries to switch on the channel again. Before every switching-on trial, the signal at all channels will be interrupted for a period of ca. 20 µs. This is also valid for those channels which are not involved in the overload or short-circuit event.

After the short-circuit or overload has been eliminated, the involved channel can operate immediately again. The red LED "Overload" goes out.

Error message to the master:

In case of a short-circuit or an overload, an error message is sent to the master, along with the error code No. 4. In each case, the channel No. 0 is given as faulty, independent of the really involved channel. The error message is kept up for a period of at least 5 seconds, even if the short-circuit or overload has been remedied in a shorter time.

For further information concerning diagnosis, see the descriptions of the central units and couplers used as bus masters.

Technical data

ICPO 16 H1

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

Connectors and terminals

Power supply 24 V DC	Screw-type terminals 2.5 mm ² inside the housing, PG11 gland for cable
CS31 bus line	2 x 4-pole M12 connector (female)
Outputs	16 x 5-pole M12 connector (female)

Power supply

Rated supply voltage	L+	24 V DC
Current consumption, without output loads		max. 0.1 A
Max. supply current (incl. output loads)		20 A
Conductor cross section		max. 2.5 mm ²
Internal fuse (under the cover)		32 A, slow, 6 x 32 mm

Outputs

Number of outputs per module		16 (overload and short-circuit proof, electrically not isolated)
Signal level of the outputs, signal 1		like L+, max. transistor saturation voltage 0.5 V
Leakage current, signal 0		≤ 10 μA
Output load capability		
max. current per output		2 A continuously
lamp load per output		max. 50 W
total output current (all outputs together)		max. 20 A
Switching frequency	with inductive load	max. 2 Hz
	with resistive load	max. 100 Hz
Short-circuit and overload protection		electronically
Switch-off delay in case of a short-circuit		ca. 150 μs
Short-circuit indication		yes, with a red LED
Limitation of output voltage, if an inductive load is switched off		by an integrated suppressor diode
switch-off peak		max. -10 V

Interfaces

Transmission standard		
between the central unit		
and input/output modules		EIA RS-485 (ABB Procontic CS31 system bus)
Bus transmission time		387 μs

LED indicators

Output signals	1 yellow LED per channel
Bus Error	1 red LED
Overload (and short-circuit)	1 red LED (lights up, if at least one output is short-circuited or overloaded)
Supply	1 green LED (lights up, if the supply voltage is ≥ 18 V)

Mechanical data

Degree of protection according to DIN 40040, IEC 529	IP 65
Dimensions (length x width x height)	367.5 x 78.5 x 78.06 mm
Mounting dimensions	356.5 x 49 mm or 356.5 x 43 mm
Weight	ca. 1.15 kg

Ordering data

Output module	ICPO 16 H1	Order No.	GJV 307 56 10 R0101
---------------	------------	-----------	---------------------


Accessories:

5-pole M12 plug, male, "straight"	GJV 307 56 17 R1
5-pole M12 plug, male, "bended"	GJV 307 56 18 R1
4-pole M12 plug, male, "straight"	GJV 307 56 21 R1
4-pole M12 plug, male, "bended"	GJV 307 56 22 R1
M12 filler plug	GJV 307 56 19 R1


Note:

In order to meet the Degree of Protection IP65, suitable cables with certain diameters must be used at the cable glands (bus, I/O connectors, supply voltage): cable diameters for bus and I/O 4.5 mm to 6.5 mm, for supply voltage 5 mm to 10 mm. The electrical specifications for the bus cables can be found under the CS31 system data.


Front view



Top view



Side view




The dimensions for **assembly holes** are printed in **bold**, all dimensions are given in mm.

Fig. 4.4.1-3: Outline dimensions of the 16-channel output module ICPO 16 H1

4.4.2 Binary Output Module ICPO 08 H1

8 output channels 24 V DC/2A, Degree of Protection IP65

CS31 system bus connection electrically isolated



Front view

Fig. 4.4.2-1: Binary output module ICPO 08 H1

Contents

Intended purpose	4.4.2-1
Displays and connections at the module housing	4.4.2-1
Electrical connection	4.4.2-1
Addressing	4.4.2-3
I/O configuration	4.4.2-3
Normal operation	4.4.2-3
Diagnosis and displays	4.4.2-4
Technical data	4.4.2-5
Dimensioned drawing (for mounting)	4.4.2-7

Intended purpose

The binary output module ICPO 08 H1 is a remote module on the CS31 system bus. It has 16 binary channels with the following features:

- Housing and termination system according to IP65 degree of protection
- The CS31 bus line is looped through from module to module. For this purpose, the module has two bus connectors as bus input and bus output.
- Each output has its own connector and thus can be unplugged individually.
- The 24 V DC supply voltage is connected via screw-type terminals inside the module housing.
- The outputs
 - employ switching transistors,
 - have a rated load capability of 2 A and
 - are overload and short-circuit proof.

The module is mounted with screws. There are bore holes available for both mounting on a rear wall or on a horizontal surface.

The CS31 system bus connection is electrically isolated from remaining module components.


The module offers diagnosis functions (see chapter "Diagnosis and displays").

Displays and connections at module housing

- ① 8 yellow LEDs for displaying the signal statuses of the outputs
- ② LEDs "Bus Error", "Overload" and "Supply" indicating of operating conditions and errors (see section "Diagnosis and displays")
- ③ CS31 bus connector (input)
- ④ CS31 bus connector (output)
- ⑤ 8 connectors for the outputs
- ⑥ PG11 cable gland for the 24 V DC power supply
- ⑦ The terminals for 24 V DC and PE are located under a removable cover. It is accessible from the top of the module. The DIL switch for setting the module address is also under the cover.
- ⑧ Labelling fields
- ⑨ Bore holes for mounting (see also "Dimensioned drawing" at the end of this description)

Electrical connection

The following figure shows all details necessary for the electrical connection.



24 V DC power supply
L+
M (0V)
PE

not used


OFF: channel No. ≤ 7
ON: channel No. > 7

Bit significance 1 }
Bit significance 2 } Module
Bit significance 4 } address;
Bit significance 8 } bit signifi-
Bit significance 16 } cances
Bit significance 32 }

Setting of the module address

The module address is calculated by the sum of significances of those switches which are set to ON.
Example: Switches 3 and 6 ON
Module address: 16 + 2 = 18

PG11 cable gland for 24 V DC power supply




Top view


LED indicators of the outputs
0 1 2 3 4 5 6 7
— Output channels —

Labelling fields

Front view




Bus connector



1 = BUS1
2 = BUS2
3 = SHIELD
4 = not used

CS31 system bus interface, bus input
CS31 system bus interface, bus output

If the module is located at one end of the bus line, the plug at the bus output connector must contain a 120 Ohm resistor for bus termination.



1 = not used
2 = not used
3 = 0 V
4 = output
5 = Protective Earth (PE)


In order to fulfill the IP65 degree of protection, unused output connectors must be sealed with M12 filler plugs (see Accessories)

Indication of operating conditions

<input type="checkbox"/>	LED red	Bus Error
<input type="checkbox"/>	LED red	Overload
<input type="checkbox"/>	LED green	Supply

see chapter "Diagnosis"

Side view



This additional earthing terminal is bonded to PE inside the module and should be connected to the machine earth with a short conductor as a EMC measure.

Fig. 4.4.2-2: Details for the electrical connection of the output module ICPO 08 H1



Addressing

An address has to be set on each module, so that the central unit can access the inputs and outputs correctly.

A detailed description concerning the item "Addressing" is contained in the chapters "Addressing" of the central units and couplers.

The module address is set on the DIL switch located under the cover at the top side of the module.

Meaning of the address switches:



When using the central units 07 KR 91, 07 KT 92 or 07 KT 93, the possible module addresses range from 0...61.

In connection with the central units 07 KR 91 and 07 KT 92/KT93 as bus masters, the following address allocations are valid:

Central units 07 KR 91 / 07 KT 92 / 93			
The DIL switch No. 8 is set to:			
Chan.	OFF	Chan.	ON
A0	A xx,00	A0	A xx,08
A1	A xx,01	A1	A xx,09
A2	A xx,02	A2	A xx,10
A3	A xx,03	A3	A xx,11
A4	A xx,04	A4	A xx,12
A5	A xx,05	A5	A xx,13
A6	A xx,06	A6	A xx,14
A7	A xx,07	A7	A xx,15

xx: Group number of the address, set on the DIL switch with the switches 2...7.

The module uses 8 outputs on the CS31 system bus.

I/O configuration

With this module, an I/O configuration is not necessary.

Normal operation

- The module initializes itself after power ON. During initialization all LEDs ② are ON.
- After the initialization, the two red LEDs ② go out again, if the bus is running correctly and the module does not detect any error. The green LED "Supply" lights up.
- The 8 yellow LEDs ① indicate the signal statuses of the channels A0...A7.

Diagnosis and displays

Diagnosis functions:

- Bus Error (on the CS31 system bus)
- Overload (or short-circuit)
- Supply (power)

Diagnosis error table:

Bus Error	Overload	Supply	<input checked="" type="checkbox"/> LED flashes Explanation	<input type="checkbox"/> LED ON	<input type="checkbox"/> LED OFF
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	The module is not connected at all, or the 24 V DC power supply is OFF.		
<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, the bus is running, no error.		
<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, the bus is running, there is a short-circuit/overload on at least one output.		
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, there is a short-circuit/overload on at least one output, the bus does not run.		
<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Power is ON, the bus does not run.		
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Initialization phase after power ON.		

Behaviour in case of short-circuit or overload:

If a short-circuit or an overload has occurred on an output channel, the involved channel will be switched off as a reaction on a high temperature of the switching transistor. In certain intervals, the module then tries to switch on the channel again. Before every switching-on trial, the signal at all channels will be interrupted for a period of ca. 20 µs. This is also valid for those channels which are not involved in the overload or short-circuit event.

After the short-circuit or overload has been eliminated, the involved channel can operate immediately again. The red LED "Overload" goes out.

Error message to the master:

In case of a short-circuit or an overload, an error message is sent to the master, along with the error code No. 4. In each case, the channel No. 0 is given as faulty, independent of the really involved channel. The error message is kept up for a period of at least 5 seconds, even if the short-circuit or overload has been remedied in a shorter time.

For further information concerning diagnosis, see the descriptions of the central units and couplers used as bus masters.

Technical data

ICPO 08 H1

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

Connectors and terminals

Power supply 24 V DC	Screw-type terminals 2.5 mm ² inside the housing, PG11 gland for cable
CS31 bus line	2 x 4-pole M12 connector (female)
Outputs	8 x 5-pole M12 connector (female)

Power supply

Rated supply voltage	L+	24 V DC
Current consumption, without output loads		max. 0.1 A
Max. supply current (incl. output loads)		16 A
Conductor cross section		max. 2.5 mm ²
Internal fuse (under the cover)		20 A, slow, 6 x 32 mm

Outputs

Number of outputs per module		8 (overload and short-circuit proof, electrically not isolated)
Signal level of the outputs, signal 1		like L+, max. transistor saturation voltage 0.5 V
Leakage current, signal 0		≤ 10 μA
Output load capability		
max. current per output		2 A continuously
lamp load per output		max. 50 W
total output current (all outputs together)		max. 16 A
Switching frequency	with inductive load with resistive load	max. 2 Hz max. 100 Hz
Short-circuit and overload protection		electronically
Switch-off delay in case of a short-circuit		ca. 150 μs
Short-circuit indication		yes, with a red LED
Limitation of output voltage, if an inductive load is switched off switch-off peak		by an integrated suppressor diode max. -10 V

Interfaces

Transmission standard between the central unit and input/output modules	EIA RS-485 (ABB Procontic CS31 system bus)
Bus transmission time	323 μs

LED indicators

Output signals	1 yellow LED per channel
Bus Error	1 red LED
Overload (and short-circuit)	1 red LED (lights up, if at least one output is short-circuited or overloaded)
Supply	1 green LED (lights up, if the supply voltage is ≥ 18 V)

Mechanical data

Degree of protection according to DIN 40040, IEC 529	IP 65
Dimensions (length x width x height)	247.5 x 78.5 x 78.06 mm
Mounting dimensions	236.5 x 49 mm or 236.5 x 43 mm
Weight	ca. 0.75 kg

Ordering data




Output module	ICPO 08 H1	Order No.	GJV 307 56 11 R0101
---------------	------------	-----------	---------------------

Accessories:

5-pole M12 plug, male, "straight"	GJV 307 56 17 R1
5-pole M12 plug, male, "bended"	GJV 307 56 18 R1
4-pole M12 plug, male, "straight"	GJV 307 56 21 R1
4-pole M12 plug, male, "bended"	GJV 307 56 22 R1
M12 filler plug	GJV 307 56 19 R1

Note:

In order to meet the Degree of Protection IP65, suitable cables with certain diameters must be used at the cable glands (bus, I/O connectors, supply voltage): cable diameters for bus and I/O 4.5 mm to 6.5 mm, for supply voltage 5 mm to 10 mm. The electrical specifications for the bus cables can be found under the CS31 system data.



The dimensions for **assembly holes** are printed in **bold**, all dimensions are given in mm.

Fig. 4.4.2-3: Outline dimensions of the 8-channel output module ICPO 08 H1

4.4.3 Binary Input Module ICPI 16 D1

16 input channels 24 V DC, **Degree of Protection IP65**

CS31 system bus connection electrically isolated




Fig. 4.4.3–1: Binary input module ICPI 16 D1

Contents

Intended purpose	4.4.3–1
Displays and connections at the module housing	4.4.3–1
Electrical connection	4.4.3–1
Addressing	4.4.3–3
I/O configuration	4.4.3–3
Normal operation	4.4.3–3
Diagnosis and displays	4.4.3–4
Technical data	4.4.3–5
Dimensioned drawing (for mounting)	4.4.3–7

Intended purpose

The binary input module ICPI 16 D1 is a remote module on the CS31 system bus. It has 16 binary channels with the following features:

- Housing and termination system according to IP65 degree of protection
- The CS31 bus line is looped through from module to module. For this purpose, the module has two bus connectors as bus input and bus output.
- Each input has its own connector and thus can be unplugged individually.
- The 24 V DC supply voltage is connected via screw-type terminals inside the module housing.
- The inputs
 - allow you to connect sensors with 2-pole and 3-pole technique (switching contacts, initiators etc.)
 - provide a short-circuit/overload-proof supply voltage for the sensors, with can be loaded with 100 mA by each sensor
 - have a rated signal current of 15 mA each

The module is mounted with screws. There are bore holes available for both mounting on a rear wall or on a horizontal surface.

The CS31 system bus connection is electrically isolated from remaining module components.


The module offers diagnosis functions (see chapter "Diagnosis and displays").

Displays and connections at module housing

- ① 16 yellow LEDs for displaying the signal statuses of the inputs
- ② LEDs "Bus Error", "Overload" and "Supply" indicating of operating conditions and errors (see section "Diagnosis and displays")
- ③ CS31 bus connector (input)
- ④ CS31 bus connector (output)
- ⑤ 16 connectors for the inputs
- ⑥ PG11 cable gland for the 24 V DC power supply
- ⑦ The terminals for 24 V DC and PE are located under a removable cover. It is accessible from the top of the module. The DIL switch for setting the module address is also under the cover.
- ⑧ Labelling fields
- ⑨ Bore holes for mounting (see also "Dimensioned drawing" at the end of this description)

Electrical connection

The following figure shows all details necessary for the electrical connection.



24 V DC power supply
L+
M (0V)
PE

not used


With this module, switch 8 must be set to OFF

Bit significance 1 }
Bit significance 2 } Module address;
Bit significance 4 } bit significances
Bit significance 8 }
Bit significance 16 }
Bit significance 32 }

Setting of the module address

The module address is calculated by the sum of significances of those switches which are set to ON.
Example: Switches 3 and 6 ON
Module address: 16 + 2 = 18

PG11 cable gland for 24 V DC power supply




Top view


LED indicators of the inputs
0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
Input channels

Labelling fields

Front view




Bus connector



1 = BUS1
2 = BUS2
3 = SHIELD
4 = not used

CS31 system bus interface, bus input
CS31 system bus interface, bus output

If the module is located at one end of the bus line, the plug at the bus output connector must contain a 120 Ohm resistor for bus termination.



1 = + 24 V
2 = not used
3 = 0 V
4 = Input
5 = Protective Earth (PE)


In order to fulfill the IP65 degree of protection, unused input connectors must be sealed with M12 filler plugs (see Accessories)

Indication of operating conditions

- LED red Bus Error
- LED red Overload
- LED green Supply

see chapter "Diagnosis"

Side view



This additional earthing terminal is bonded to PE inside the module and should be connected to the machine earth with a short conductor as a EMC measure.

Fig. 4.4.3-2: Details for the electrical connection of the input module ICPI 16 D1



Addressing

An address has to be set on each module, so that the central unit can access the inputs and outputs correctly.

A detailed description concerning the item "Addressing" is contained in the chapters "Addressing" of the central units and couplers.

The module address is set on the DIL switch located under the cover at the top side of the module.

Meaning of the address switches:



When using the central units 07 KR 91, 07 KT 92 or 07 KT 93, the possible module addresses range from 0...61.

In connection with the central units 07 KR 91 and 07 KT 92/KT93 as bus masters, the following address allocations are valid:

Central units 07 KR 91 / 07 KT 92 / 93			
The DIL switch No. 8 must be set to OFF.			
Chan.		Chan.	
E0	E xx,00	E8	E xx,08
E1	E xx,01	E9	E xx,09
E2	E xx,02	E10	E xx,10
E3	E xx,03	E11	E xx,11
E4	E xx,04	E12	E xx,12
E5	E xx,05	E13	E xx,13
E6	E xx,06	E14	E xx,14
E7	E xx,07	E15	E xx,15

xx: Group number of the address, set on the DIL switch with the switches 2...7.

The module uses 16 inputs on the CS31 system bus.

I/O configuration

With this module, an I/O configuration is not necessary.

Normal operation

- The module initializes itself after power ON. During initialization all LEDs ② are ON.
- After the initialization, the two red LEDs ② go out again, if the bus is running correctly and the module does not detect any error. The green LED "Supply" lights up.
- The 16 yellow LEDs ① indicate the signal statuses of the channels E0...E15.

Diagnosis and displays

Diagnosis functions:

- Bus Error (on the CS31 system bus)
- Overload (or short-circuit)
- Supply (power)


Diagnosis error table:

Bus Error	Overload	Supply	LED flashes	LED ON	LED OFF	Explanation
☐	☐	☐	☐	☐	☐	The module is not connected at all, or the 24 V DC power supply is OFF.
☐	☐	■	☐	☐	☐	Power is ON, the bus is running, no error.
☐	■	■	☐	☐	☐	Power is ON, there is a short-circuit/overload on at least one +24 V DC power supply connection of an input, the bus is running.
▣	■	■	▣	▣	▣	Power is ON, there is a short-circuit/overload on at least one +24 V DC power supply connection of an input, the bus is not running.
▣	☐	■	▣	☐	▣	Power is ON, the bus does not run.
■	■	■	■	■	■	Initialization phase after power ON.

Behaviour in case of short-circuit or overload at sensors:

The supply connections at the sensor input connectors are connected via a temperature-dependent resistor (PTC thermistor) to the +24 V DC input of the screw-type terminals. If an overload or a short-circuit occurs with a

sensor, the PTC will work as an overload protection. A voltage monitoring circuitry generates an error message in case of undervoltage (the LED "Overload" lights up). The following figure demonstrates the function.



After the short-circuit or overload has been eliminated, the module can operate correctly again. The red LED "Overload" goes out.

Error message to the master:

In case of a short-circuit or an overload, an error message is sent to the master, along with the error code No. 4. In each case, the channel No. 0 is given as faulty, independent of the really involved channel. The error message is kept up for a period of at least 5 seconds, even if the short-circuit or overload has been remedied in a shorter time.

For further information concerning diagnosis, see the descriptions of the central units and couplers used as bus masters.

Technical data

ICPI 16 D1

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

Connectors and terminals

Power supply 24 V DC	Screw-type terminals 2.5 mm ² inside the housing, PG11 gland for cable
CS31 bus line	2 x 4-pole M12 connector (female)
Inputs	16 x 5-pole M12 connector (female)

Power supply

Rated supply voltage	L+	24 V DC
Current consumption, without sensor loads		max. 50 mA
Supply voltage for the sensors		$\geq (L+ - 0.5 \text{ V})$
Supply current for the sensors		max. 100 mA per sensor
Short-circuit protection		PTC thermistor, $I_{sc} \geq 1.6 \text{ A}$
Short-circuit indication		yes, with a red LED
Conductor cross section		max. 2.5 mm ²

Inputs

Number of inputs per module		16
Signal level of the inputs	with signal 1	$\geq 13 \text{ V}$
	with signal 0	$\leq 7 \text{ V}$
Signal input current	with signal 1	ca. 15 mA
Input signal delay		ca. 6 ms

Interfaces

Transmission standard between the central unit and input/output modules	EIA RS-485 (ABB Procontic CS31 system bus)
Bus transmission time	387 μs

LED indicators

Input signals	1 yellow LED per channel
Bus Error	1 red LED
Overload (and short-circuit)	1 red LED (lights up, if there is an overload or a short-circuit at the supply voltage on at least at one input channel)
Supply	1 green LED (lights up, if the supply voltage is $\geq 18 \text{ V}$)

Mechanical data

Degree of protection according to DIN 40040, IEC 529	IP 65
Dimensions (length x width x height)	367.5 x 78.5 x 78.06 mm
Mounting dimensions	356.5 x 49 mm or 356.5 x 43 mm
Weight	ca. 1.15 kg

Ordering data

Input module	ICPI 16 D1	Order No.	GJV 307 56 13 R0101
--------------	------------	-----------	---------------------


Accessories:

5-pole M12 plug, male, "straight"	GJV 307 56 17 R1
5-pole M12 plug, male, "bended"	GJV 307 56 18 R1
4-pole M12 plug, male, "straight"	GJV 307 56 21 R1
4-pole M12 plug, male, "bended"	GJV 307 56 22 R1
M12 filler plug	GJV 307 56 19 R1


Note:

In order to meet the Degree of Protection IP65, suitable cables with certain diameters must be used at the cable glands (bus, I/O connectors, supply voltage): cable diameters for bus and I/O 4.5 mm to 6.5 mm, for supply voltage 5 mm to 10 mm. The electrical specifications for the bus cables can be found under the CS31 system data.


Front view



Top view



Side view




The dimensions for **assembly holes** are printed in **bold**, all dimensions are given in mm.

Fig. 4.4.3-3: Outline dimensions of the 16-channel input module ICPI 16 D1

4.4.4 Binary Input Module ICPI 08 D1

8 input channels 24 V DC, Degree of Protection IP65

CS31 system bus connection electrically isolated



Front view

Fig. 4.4.4-1: Binary input module ICPI 08 D1

Contents

Intended purpose	4.4.4-1
Displays and connections at the module housing	4.4.4-1
Electrical connection	4.4.4-1
Addressing	4.4.4-3
I/O configuration	4.4.4-3
Normal operation	4.4.4-3
Diagnosis and displays	4.4.4-4
Technical data	4.4.4-5
Dimensioned drawing (for mounting)	4.4.4-7

Intended purpose

The binary input module ICPI 08 D1 is a remote module on the CS31 system bus. It has 16 binary channels with the following features:

- Housing and termination system according to IP65 degree of protection
- The CS31 bus line is looped through from module to module. For this purpose, the module has two bus connectors as bus input and bus output.
- Each input has its own connector and thus can be unplugged individually.
- The 24 V DC supply voltage is connected via screw-type terminals inside the module housing.
- The inputs
 - allow you to connect sensors with 2-pole and 3-pole technique (switching contacts, initiators etc.)
 - provide a short-circuit/overload-proof supply voltage for the sensors, with can be loaded with 100 mA by each sensor
 - have a rated signal current of 15 mA each

The module is mounted with screws. There are bore holes available for both mounting on a rear wall or on a horizontal surface.

The CS31 system bus connection is electrically isolated from remaining module components.


The module offers diagnosis functions (see chapter "Diagnosis and displays").

Displays and connections at module housing

- ① 8 yellow LEDs for displaying the signal statuses of the inputs
- ② LEDs "Bus Error", "Overload" and "Supply" indicating of operating conditions and errors (see section "Diagnosis and displays")
- ③ CS31 bus connector (input)
- ④ CS31 bus connector (output)
- ⑤ 8 connectors for the inputs
- ⑥ PG11 cable gland for the 24 V DC power supply
- ⑦ The terminals for 24 V DC and PE are located under a removable cover. It is accessible from the top of the module. The DIL switch for setting the module address is also under the cover.
- ⑧ Labelling fields
- ⑨ Bore holes for mounting (see also "Dimensioned drawing" at the end of this description)

Electrical connection

The following figure shows all details necessary for the electrical connection.



24 V DC power supply

not used


OFF: channel No. ≤ 7
ON: channel No. > 7

Bit significance 1 }
Bit significance 2 } Module address;
Bit significance 4 } bit significances
Bit significance 8 }
Bit significance 16 }
Bit significance 32 }

Setting of the module address

The module address is calculated by the sum of significances of those switches which are set to ON.
Example: Switches 3 and 6 ON
Module address: $16 + 2 = 18$

PG11 cable gland for 24 V DC power supply



Top view


LED indicators of the inputs

0 1 2 3 4 5 6 7


— Input channels —

Labelling fields

Front view



Bus connector




1 = BUS1
2 = BUS2
3 = SHIELD
4 = not used

CS31 system bus interface, bus input

CS31 system bus interface, bus output

If the module is located at one end of the bus line, the plug at the bus output connector must contain a 120 Ohm resistor for bus termination.



1 = + 24 V
2 = not used
3 = 0 V
4 = Input
5 = Protective Earth (PE)


In order to fulfill the IP65 degree of protection, unused input connectors must be sealed with M12 filler plugs (see Accessories)

Indication of operating conditions

- LED red Bus Error
- LED red Overload
- LED green Supply

see chapter "Diagnosis"

Side view



This additional earthing terminal is bonded to PE inside the module and should be connected to the machine earth with a short conductor as a EMC measure.

Fig. 4.4.4-2: Details for the electrical connection of the input module ICPI 08 D1



Addressing

An address has to be set on each module, so that the central unit can access the inputs and outputs correctly.

A detailed description concerning the item "Addressing" is contained in the chapters "Addressing" of the central units and couplers.

The module address is set on the DIL switch located under the cover at the top side of the module.

Meaning of the address switches:



When using the central units 07 KR 91, 07 KT 92 or 07 KT 93, the possible module addresses range from 0...61.

In connection with the central units 07 KR 91 and 07 KT 92/KT93 as bus masters, the following address allocations are valid:

Central units 07 KR 91 / 07 KT 92 / 93			
The DIL switch No. 8 is set to:			
Chan.	OFF	Chan.	ON
E0	E xx,00	E0	E xx,08
E1	E xx,01	E1	E xx,09
E2	E xx,02	E2	E xx,10
E3	E xx,03	E3	E xx,11
E4	E xx,04	E4	E xx,12
E5	E xx,05	E5	E xx,13
E6	E xx,06	E6	E xx,14
E7	E xx,07	E7	E xx,15

xx: Group number of the address, set on the DIL switch with the switches 2...7.

The module uses 8 inputs on the CS31 system bus.

I/O configuration

With this module, an I/O configuration is not necessary.

Normal operation

- The module initializes itself after power ON. During initialization all LEDs ② are ON.
- After the initialization, the two red LEDs ② go out again, if the bus is running correctly and the module does not detect any error. The green LED "Supply" lights up.
- The 8 yellow LEDs ① indicate the signal statuses of the channels E0...E7.

Diagnosis and displays

Diagnosis functions:

- Bus Error (on the CS31 system bus)
- Overload (or short-circuit)
- Supply (power)


Diagnosis error table:

Bus Error	Overload	Supply	LED flashes	LED ON	LED OFF	Explanation
☐	☐	☐	☐	☐	☐	The module is not connected at all, or the 24 V DC power supply is OFF.
☐	☐	■	☐	☐	■	Power is ON, the bus is running, no error.
☐	■	■	☐	■	■	Power is ON, there is a short-circuit/overload on at least one +24 V DC power supply connection of an input, the bus is running.
▣	■	■	▣	■	■	Power is ON, there is a short-circuit/overload on at least one +24 V DC power supply connection of an input, the bus is not running.
▣	☐	■	▣	☐	■	Power is ON, the bus does not run.
■	■	■	■	■	■	Initialization phase after power ON.

Behaviour in case of short-circuit or overload at sensors:

The supply connections at the sensor input connectors are connected via a temperature-dependent resistor (PTC thermistor) to the +24 V DC input of the screw-type terminals. If an overload or a short-circuit occurs with a

sensor, the PTC will work as an overload protection. A voltage monitoring circuitry generates an error message in case of undervoltage (the LED "Overload" lights up). The following figure demonstrates the function.



After the short-circuit or overload has been eliminated, the module can operate correctly again. The red LED "Overload" goes out.

Error message to the master:

In case of a short-circuit or an overload, an error message is sent to the master, along with the error code No. 4. In each case, the channel No. 0 is given as faulty, independent of the really involved channel. The error message is kept up for a period of at least 5 seconds, even if the short-circuit or overload has been remedied in a shorter time.

For further information concerning diagnosis, see the descriptions of the central units and couplers used as bus masters.

Technical data

ICPI 08 D1

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

Connectors and terminals

Power supply 24 V DC	Screw-type terminals 2.5 mm ² inside the housing, PG11 gland for cable
CS31 bus line	2 x 4-pole M12 connector (female)
Inputs	8 x 5-pole M12 connector (female)

Power supply

Rated supply voltage	L+	24 V DC
Current consumption, without sensor loads		max. 50 mA
Supply voltage for the sensors		$\geq (L+ - 0.5 \text{ V})$
Supply current for the sensors		max. 100 mA per sensor
Short-circuit protection		PTC thermistor, $I_{sc} \geq 1.6 \text{ A}$
Short-circuit indication		yes, with a red LED
Conductor cross section		max. 2.5 mm ²

Inputs

Number of inputs per module		8
Signal level of the inputs	with signal 1	$\geq 13 \text{ V}$
	with signal 0	$\leq 7 \text{ V}$
Signal input current	with signal 1	ca. 15 mA
Input signal delay		ca. 6 ms

Interfaces

Transmission standard between the central unit and input/output modules	EIA RS-485 (ABB Procontic CS31 system bus)
Bus transmission time	323 μs

LED indicators

Input signals	1 yellow LED per channel
Bus Error	1 red LED
Overload (and short-circuit)	1 red LED (lights up, if there is an overload or a short-circuit at the supply voltage on at least at one input channel)
Supply	1 green LED (lights up, if the supply voltage is $\geq 18 \text{ V}$)

Mechanical data

Degree of protection according to DIN 40040, IEC 529	IP 65
Dimensions (length x width x height)	247.5 x 78.5 x 78.06 mm
Mounting dimensions	236.5 x 49 mm or 236.5 x 43 mm
Weight	ca. 0.75 kg

Ordering data




Input module	ICPI 08 D1	Order No.	GJV 307 56 14 R0101
--------------	------------	-----------	---------------------

Accessories:

5-pole M12 plug, male, "straight"	GJV 307 56 17 R1
5-pole M12 plug, male, "bended"	GJV 307 56 18 R1
4-pole M12 plug, male, "straight"	GJV 307 56 21 R1
4-pole M12 plug, male, "bended"	GJV 307 56 22 R1
M12 filler plug	GJV 307 56 19 R1

Note:

In order to meet the Degree of Protection IP65, suitable cables with certain diameters must be used at the cable glands (bus, I/O connectors, supply voltage): cable diameters for bus and I/O 4.5 mm to 6.5 mm, for supply voltage 5 mm to 10 mm. The electrical specifications for the bus cables can be found under the CS31 system data.



The dimensions for **assembly holes** are printed in **bold**, all dimensions are given in mm.

Fig. 4.4.4-3: Outline dimensions of the 8-channel input module ICPI 08 D1

Chapter	Description	Page
5.1	General	5.1-1
5.2	Analog Input remote units	
5.2.1	ICSE 08 A6 : 8 current/voltage Inputs, 8 bits	5.2.1-1
5.2.2	ICSE 08 B5 : 8 current/voltage Inputs, 12 bits	5.2.2-1
5.2.3	ICST 08 A8 : 8 Inputs PT 100 (Temperature range $-50\text{ }^{\circ}\text{C} \dots +150\text{ }^{\circ}\text{C}$ $58\text{ }^{\circ}\text{F} \dots +302\text{ }^{\circ}\text{F}$) 8 bits	5.2.3-1
5.2.4	ICST 08 A9 : 8 Inputs PT 100 (Temperature range $0\text{ }^{\circ}\text{C} \dots +300\text{ }^{\circ}\text{C}$ $+32\text{ }^{\circ}\text{F} \dots +572\text{ }^{\circ}\text{F}$) 8 bits	5.2.4-1
5.2.5	ICDT 08 B5 : 8 Inputs configurable for temperature sensors or as voltages inputs	5.2.5-1
5.2.6	ICST 08 A7 : 8 Inputs PT 100 (Temperature range $-30\text{ }^{\circ}\text{C} \dots +20\text{ }^{\circ}\text{C}$ $-22\text{ }^{\circ}\text{F} \dots +68\text{ }^{\circ}\text{F}$) 8 bits	5.2.6-1
5.3	Analog Output remote units	
5.3.1	ICSA 04 B5 : 4 current/voltage Outputs, 12 bits	5.3.1-1
5.4	Analog Input/Output remote units	
5.4.1	ICSM 06 A6 : 4 current/voltage Inputs, 2 current/voltage Outputs, 8 bits	5.4.1-1

The remote analogue input/output units are used to measure physical process values. These units can convert analog values to numeric values for inputs or numeric values to analog values for outputs.

There are two available resolutions :

- 8 bits units:
 - ICSM 06 A6, 4 inputs, 2 outputs
 - ICSE 08 A6, 8 inputs
 - ICST 08 A8, 8 inputs PT 100
 - ICST 08 A9, 8 inputs PT 100

- 12 bits units :
 - ICSE 08 B5, 8 inputs
 - ICSA 04 B5, 4 outputs

It is possible to use each channel of a unit for current or voltage processing. The PT 100 channels are only used for temperature measurement.


	Inputs		Outputs	
	Voltage	Current	Voltage	Current
ICSM 06 A6	0...10 V 0...5 V	0...20 mA 4...20 mA	± 10 V	0...20 mA 4...20 mA
ICSE 08 A6	0...10 V 0...5 V	0...20 mA 4...20 mA		
ICSE 08 B5	± 10 V ± 5 V	± 20 mA 4...20 mA		
ICSA 04 B5			± 10 V ± 12.5 V	0...20 mA 4...20 mA

There are three possible configurations for the range of bits used within a word.

The range of bits used within a word is determined by the position of dip switches N.2 and N.3 of the plug-in base.


● Configuration for UCZA/UCZB

	2	3
ON		
OFF	X	X




● Configuration most significant byte (07 KT92)

	2	3
ON	X	
OFF		X



● Configuration least significant byte range

	2	3
ON		X
OFF	X	



NOTE : Dip switch N.1 is inoperational for the analog units.

Addresses allowed for the central units :

- UCZA/UCZB : even addresses.
- PCZB : addresses 1 to 8.
- 07 KR91/07 KT92/07 KT93 : addresses 0 to 5.
- 07 KR31 : addresses 0 to 5 and 8 to 15 (only for input units)

ANALOG INPUTS 8 BITS

Input range	0...10 V	0...5 V	0...20mA	4...20 mA
Resolution	39 mV	+ 20 mV	+ 0.08 mA	+ 0.062 mA
Maximum	+ 9.96 V	+ 4.98 V	+ 19.92 mA	+ 19.94 mA
Minimum	0 V	0 V	0 mA	+ 4 mA
Offset	0 V	0 V	0 mA	+ 4 mA

RANGE FOR UCZA/UCZB

Bits of analog word

B15	0 V	0 V	0 mA	0 mA (*)
B14	0 V	0 V	0 mA	0 mA (*)
B13	0 V	0 V	0 mA	0 mA (*)
B12	0 V	0 V	0 mA	0 mA (*)
B11	+ 5 V	+ 2.5 V	+ 10 mA	+ 8 mA
B10	+ 2.5 V	+ 1.25 V	+ 5 mA	+ 4 mA
B9	+ 1.25 V	+ 0.62 V	+ 2.5 mA	+ 2 mA
B8	+ 0.62 V	+ 0.31 V	+ 1.25 mA	+ 1 mA
B7	+ 0.31 V	+ 0.15 V	+ 0.62 mA	+ 0.5 mA
B6	+ 0.15 V	+ 0.08 V	+ 0.31 mA	+ 0.25 mA
B5	+ 0.08 V	+ 0.04 V	+ 0.15 mA	+ 0.125 mA
B4	+ 0.04 V	+ 0.02 V	+ 0.08 mA	+ 0.062 mA
B3	0 V	0 V	0 mA	0 mA
B2	0 V	0 V	0 mA	0 mA
B1	0 V	0 V	0 mA	0 mA
B0	0 V	0 V	0 mA	0 mA

RANGE FOR MOST SIGNIFICANT BYTE – 07 KT92

Bits of analog word

B15	0 V	0 V	0 mA	0 mA (*)
B14	+ 5 V	+ 2.5 V	+ 10 mA	+ 8 mA
B13	+ 2.5 V	+ 1.25 V	+ 5 mA	+ 4 mA
B12	+ 1.25 V	+ 0.62 V	+ 2.5 mA	+ 2 mA
B11	+ 0.62 V	+ 0.31 V	+ 1.25 mA	+ 1 mA
B10	+ 0.31 V	+ 0.15 V	+ 0.62 mA	+ 0.5 mA
B9	+ 0.15 V	+ 0.08 V	+ 0.31 mA	+ 0.25 mA
B8	+ 0.08 V	+ 0.04 V	+ 0.15 mA	+ 0.125 mA
B7	+ 0.04 V	+ 0.02 V	+ 0.08 mA	+ 0.062 mA
B6	0 V	0 V	0 mA	0 mA
B5	0 V	0 V	0 mA	0 mA
B4	0 V	0 V	0 mA	0 mA
B3	0 V	0 V	0 mA	0 mA
B2	0 V	0 V	0 mA	0 mA
B1	0 V	0 V	0 mA	0 mA
B0	0 V	0 V	0 mA	0 mA

RANGE FOR LEAST SIGNIFICANT BYTE

B15	0 V	0 V	0 mA	0 mA (*)
B14	0 V	0 V	0 mA	0 mA (*)
B13	0 V	0 V	0 mA	0 mA (*)
B12	0 V	0 V	0 mA	0 mA (*)
B11	0 V	0 V	0 mA	0 mA (*)
B10	0 V	0 V	0 mA	0 mA (*)
B9	0 V	0 V	0 mA	0 mA (*)
B8	0 V	0 V	0 mA	0 mA (*)
B7	+ 5 V	+ 2.5 V	+ 10 mA	+ 8 mA
B6	+ 2.5 V	+ 1.25 V	+ 5 mA	+ 4 mA
B5	+ 1.25 V	+ 0.62 V	+ 2.5 mA	+ 2 mA
B4	+ 0.62 V	+ 0.31 V	+ 1.25 mA	+ 1 mA
B3	+ 0.31 V	+ 0.15 V	+ 0.62 mA	+ 0.5 mA
B2	+ 0.15 V	+ 0.08 V	+ 0.31 mA	+ 0.25 mA
B1	+ 0.08 V	+ 0.04 V	+ 0.15 mA	+ 0.125 mA
B0	+ 0.04 V	+ 0.02 V	+ 0.08 mA	+ 0.062 mA

(*) For input 4 ... 20 mA :

- no significant bits = 0 if input current > 4 mA.
- no significant bits = 1 if input current < 4 mA.

ANALOG OUTPUTS 8 BITS

Output range	$\pm 10 \text{ V}$	0...20mA	4...20 mA
Resolution	+ 78 mV	+ 0.08 mA	+ 0.062 mA
Maximum	+ 9.92 V	+ 19.92 mA	+ 19.94 mA
Minimum	- 10V	0 mA	+ 4 mA
Offset	0 V	0 mA	+ 4 mA

RANGE FOR UCZA/UCZB (see diagram "a")

Bits of analog word	$\pm 10 \text{ V}$	0...20 mA	4...20 mA
B15	- 80 V ⁽¹⁾	- 160 mA ⁽²⁾	- 128 mA ⁽³⁾
B14	+ 40 V ⁽¹⁾	+ 80 mA ⁽²⁾	+ 64 mA ⁽³⁾
B13	+ 20 V ⁽¹⁾	+ 40 mA ⁽²⁾	+ 32 mA ⁽³⁾
B12	+ 10 V ⁽¹⁾	+ 20 mA ⁽²⁾	+ 16 mA ⁽³⁾
B11	+ 5 V	+ 10 mA	+ 8 mA
B10	+ 2.5 V	+ 5 mA	+ 4 mA
B9	+ 1.25 V	+ 2.5 mA	+ 2 mA
B8	+ 0.62 V	+ 1.25 mA	+ 1 mA
B7	+ 0.31 V	+ 0.62 mA	+ 0.5 mA
B6	+ 0.15 V	+ 0.31 mA	+ 0.25 mA
B5	+ 0.08 V	+ 0.15 mA	+ 0.125 mA
B4	0 V	+ 0.08 mA	+ 0.062 mA
B3	0 V	0 mA	0 mA
B2	0 V	0 mA	0 mA
B1	0 V	0 mA	0 mA
B0	0 V	0 mA	0 mA

RANGE FOR MOST SIGNIFICANT BYTE – 07 KT92 (see diagram "b")

Bits of analog word	$\pm 10 \text{ V}$	0...20 mA	4...20 mA
B15	- 10 V	- 20 mA	- 16 mA
B14	+ 5 V	+ 10 mA	+ 8 mA
B13	+ 2.5 V	+ 5 mA	+ 4 mA
B12	+ 1.25 V	+ 2.5 mA	+ 2 mA
B11	+ 0.62 V	+ 1.25 mA	+ 1 mA
B10	+ 0.31 V	+ 0.62 mA	+ 0.5 mA
B9	+ 0.15 V	+ 0.31 mA	+ 0.25 mA
B8	+ 0.08 V	+ 0.15 mA	+ 0.125 mA
B7	+ 0.04 V	+ 0.08 mA	+ 0.062 mA
B6	0 V	0 mA	0 mA
B5	0 V	0 mA	0 mA
B4	0 V	0 mA	0 mA
B3	0 V	0 mA	0 mA
B2	0 V	0 mA	0 mA
B1	0 V	0 mA	0 mA
B0	0 V	0 mA	0 mA

For UCZA/UCZB bits B12 to B15 represent the sign and the overflow outputs word of the analog outputs.

⁽¹⁾ If B15 = 1 and B12, B13 or B14 = 0 the analog output is forced at the minimum value (-10 V).

⁽²⁾ If B15 = 1 the output is 0 mA
If B15 = 0 and B12, B13 or B14 = 1 the output is forced at + 20 mA

⁽³⁾ If B15 = 1 the output is forced at 4 mA
If B15 = 0 and B12, B13 or B14 = 1 the output is forced at + 20 mA

RANGE FOR LEAST SIGNIFICANT BYTE (see diagram "c")

Bits of analog word	± 10 V	0...20 mA	4...20 mA
B15	- 1280 V ⁽⁴⁾	- 2560 mA ⁽⁵⁾	- 2048 mA ⁽⁶⁾
B14	+ 640 V ⁽⁴⁾	+ 1280 mA ⁽⁵⁾	+ 1024 mA ⁽⁶⁾
B13	+ 320 V ⁽⁴⁾	+ 640 mA ⁽⁵⁾	+ 512 mA ⁽⁶⁾
B12	+ 160 V ⁽⁴⁾	+ 320 mA ⁽⁵⁾	+ 256 mA ⁽⁶⁾
B11	+ 80 V ⁽⁴⁾	+ 160 mA ⁽⁵⁾	+ 128 mA ⁽⁶⁾
B10	+ 40 V ⁽⁴⁾	+ 80 mA ⁽⁵⁾	+ 64 mA ⁽⁶⁾
B9	+ 20 V ⁽⁴⁾	+ 40 mA ⁽⁵⁾	+ 32 mA ⁽⁶⁾
B8	+ 10 V ⁽⁴⁾	+ 20 mA ⁽⁵⁾	+ 16 mA ⁽⁶⁾
B7	+ 5 V	+ 10 mA	+ 8 mA
B6	+ 2.5 V	+ 5 mA	+ 4 mA
B5	+ 1.25 V	+ 2.5 mA	+ 2 mA
B4	+ 0.62 V	+ 1.25 mA	+ 1.25 mA
B3	+ 0.31 V	+ 0.62 mA	+ 1 mA
B2	+ 0.15 V	+ 0.31 mA	+ 0.5 mA
B1	+ 0.08 V	+ 0.15 mA	+ 0.025 mA
B0	+ 0.04 V	+ 0.08 mA	+ 0.062 mA

⁽⁴⁾ If B15 = 1 and B8, B9, B10, B11, B12, B13 or B14 = 0 the output is forced at -10V.
If B15=0 and B12, B13 or B14=1 the output is forced at +10V.



⁽⁵⁾ If B15 = 1 the output is forced at 0 mA.
If B15 = 0 and B8, B9, B10, B11, B12, B13 or B14 = 1 the output is forced at +20 mA.

⁽⁶⁾ If B15 = 1 the output is forced at 4 mA.
If B15 = 0 and B8, B9, B10, B11, B12, B13 or B14 = 1 the output is forced at + 20 mA.



ANALOG OUTPUTS DIAGRAMS 8 BITS

- a** Analog unit dip switches are formatted for using an UCZA/UCZB Central Unit
- b** Analog unit dip switches are formatted for most significant byte
- c** Analog unit dip switches are formatted for least significant byte



Voltage (± 10 V)



Current (0 ... 20 mA)



Current (4 ... 20 mA)



ANALOG INPUTS 12 BITS

	$\pm 10\text{ V}$	$\pm 5\text{ V}$	$\pm 20\text{ mA}$	4...20 mA
Input range	$\pm 10\text{ V}$	$\pm 5\text{ V}$	$\pm 20\text{ mA}$	4...20 mA
Resolution	+ 5 mV	+2.5 mV	+ 0.010 mA	+ 0.008 mA
Maximum	+10 V	+ 5 V	+ 20 mA	+ 20 mA
Minimum	- 10 V	- 5 V	- 20 mA	+ 4 mA
Offset	0 V	0 V	0 mA	+ 4 mA

RANGE FOR UCZA/UCZB

Bits of analog word	$\pm 10\text{ V}$	$\pm 5\text{ V}$	$\pm 20\text{ mA}$	4...20mA
B15	- 10 V	- 5 V	- 20 mA	0 mA (*)
B14	x	x	x	0 mA (*)
B13	x	x	x	0 mA (*)
B12	x	x	x	0 mA (*)
B11	+ 5 V	+ 2.5 V	+ 10 mA	+ 8 mA
B10	+ 2.5 V	+ 1.25 V	+ 5 mA	+ 4 mA
B9	+ 1.25 V	+ 0.62 V	+ 2.5 mA	+ 2 mA
B8	+ 0.62 V	+ 0.31 V	+ 1.25 mA	+ 1 mA
B7	+ 0.31 V	+ 0.15 V	+ 0.62 mA	+ 0.5 mA
B6	+ 0.15 V	+ 0.08 V	+ 0.31 mA	+ 0.25 mA
B5	+ 0.08 V	+ 0.04 V	+ 0.15 mA	+ 0.125 mA
B4	+ 0.04 V	+ 0.02 V	+ 0.08 mA	+ 0.062 mA
B3	+ 0.02 V	+ 0.01 V	+ 0.04 mA	+ 0.031 mA
B2	+ 0.01 V	+ 0.005 V	+ 0.02 mA	+ 0.015 mA
B1	+ 0.005 V	+ 0.0025 V	+ 0.01 mA	+ 0.008 mA
B0	0 V	0 V	0 mA	0 mA

x = 0 positive value

x = 1 negative value

RANGE FOR MOST SIGNIFICANT BYTE – 07 KT92

Bits of analog word	$\pm 10\text{ V}$	$\pm 5\text{ V}$	$\pm 20\text{ mA}$	4...20mA
B15	- 10 V	- 5 V	- 20 mA	0 mA (*)
B14	+ 5 V	+ 2.5 V	+ 10 mA	+ 8 mA
B13	+ 2.5 V	+ 1.25 V	+ 5 mA	+ 4 mA
B12	+ 1.25 V	+ 0.62 V	+ 2.5 mA	+ 2 mA
B11	+ 0.62 V	+ 0.31 V	+ 1.25 mA	+ 1 mA
B10	+ 0.31 V	+ 0.15 V	+ 0.62 mA	+ 0.5 mA
B9	+ 0.15 V	+ 0.08 V	+ 0.31 mA	+ 0.25 mA
B8	+ 0.08 V	+ 0.04 V	+ 0.15 mA	+ 0.125 mA
B7	+ 0.04 V	+ 0.02 V	+ 0.08 mA	+ 0.062 mA
B6	+ 0.02 V	+ 0.01 V	+ 0.04 mA	+ 0.031 mA
B5	+ 0.01 V	+ 0.005 V	+ 0.02 mA	+ 0.015 mA
B4	+ 0.005 V	+ 0.0025 V	+ 0.01 mA	+ 0.008 mA
B3	0 V	0 V	0 mA	0 mA
B2	0 V	0 V	0 mA	0 mA
B1	0 V	0 V	0 mA	0 mA
B0	0 V	0 V	0 mA	0 mA

RANGE FOR LEAST SIGNIFICANT BYTE

Bits of analog word	$\pm 10\text{ V}$	$\pm 5\text{ V}$	$\pm 20\text{ mA}$	4...20mA
B15	- 10 V	- 5 V	- 20 mA	0 mA (*)
B14	x	x	x	0 mA (*)
B13	x	x	x	0 mA (*)
B12	x	x	x	0 mA (*)
B11	x	x	x	0 mA (*)
B10	+ 5 V	+ 2.5 V	+ 10 mA	+ 8 mA
B9	+ 2.5 V	+ 1.25 V	+ 5 mA	+ 4 mA
B8	+ 1.25 V	+ 0.62 V	+ 2.5 mA	+ 2 mA
B7	+ 0.62 V	+ 0.31 V	+ 1.25 mA	+ 1 mA
B6	+ 0.31 V	+ 0.15 V	+ 0.62 mA	+ 0.5 mA
B5	+ 0.15 V	+ 0.08 V	+ 0.31 mA	+ 0.25 mA
B4	+ 0.08 V	+ 0.04 V	+ 0.15 mA	+ 0.125 mA
B3	+ 0.04 V	+ 0.02 V	+ 0.08 mA	+ 0.062 mA
B2	+ 0.02 V	+ 0.01 V	+ 0.04 mA	+ 0.031 mA
B1	+ 0.01 V	+ 0.005 V	+ 0.02 mA	+ 0.015 mA
B0	+ 0.005 V	+ 0.0025 V	+ 0.01 mA	+ 0.008 mA

x = 0 positive value
x = 1 negative value

(*) For input 4 ... 20 mA :

- No significant bits = 0 if input current > 4 mA
- No significant bits = 1 if input current < 4 mA

Bits (x) have the same status as 15.

ANALOG OUTPUTS 12 BITS

Output range	$\pm 10\text{ V}$	$\pm 12.5\text{ V}$	0...20mA	4...20 mA
Resolution	+ 5 mV	+ 5 mV	+ 0.01 mA	+ 0.008 mA
V maximum	+ 9.99 V	+ 12.49 V	+ 19.99 mA	+ 19.99 mA
V minimum	- 10V	- 12.5 V	0 mA	+ 4 mA
Offset	0 V	0 V	0 mA	+ 4 mA

RANGE FOR UCZA/UCZB (see diagram "a")

Bits of analog word	$\pm 10\text{ V}$	$\pm 12.5\text{ V}$	0...20 mA	4...20 mA
B15	(⁰)	(⁰)	(¹)	(¹)
B14	(⁰)	(⁰)	(¹)	(¹)
B13	(⁰)	(⁰)	(¹)	(¹)
B12	(⁰)	(⁰)	(¹)	(¹)
B11	+ 5 V	+ 6.25 V	+ 10 mA	+ 8 mA
B10	+ 2.5 V	+ 3.12 V	+ 5 mA	+ 4 mA
B9	+ 1.25 V	+ 1.56 V	+ 2.5 mA	+ 2 mA
B8	+ 0.62 V	+ 0.77 V	+ 1.25 mA	+ 1 mA
B7	+ 0.31 V	+ 0.39 V	+ 0.62 mA	+ 0.5 mA
B6	+ 0.15 V	+ 0.19 V	+ 0.31 mA	+ 0.25 mA
B5	+ 0.08 V	+ 0.1 V	+ 0.15 mA	+ 0.125 mA
B4	+ 0.04 V	+ 0.05 V	+ 0.08 mA	+ 0.062 mA
B3	+ 0.02 V	+ 0.025 V	+ 0.04 mA	+ 0.031 mA
B2	+ 0.01 V	+ 0.012 V	+ 0.02 mA	+ 0.015 mA
B1	+ 0.005 V	+ 0.006 V	+ 0.01 mA	+ 0.008 mA
B0	0 V	0 V	0 mA	0 mA

RANGE FOR MOST SIGNIFICANT BYTE – 07 KT92 (see diagram "b")

Bits of analog word	$\pm 10\text{ V}$	$\pm 12.5\text{ V}$	0...20 mA	4...20 mA
B15	- 10 V	- 12,5 V	0 mA (²)	0 mA
B14	+ 5 V	+ 6.25 V	+ 10 mA	+ 8 mA
B13	+ 2.5 V	+ 3.12 V	+ 5 mA	+ 4 mA
B12	+ 1.25 V	+ 1.56 V	+ 2.5 mA	+ 2 mA
B11	+ 0.62 V	+ 0.77 V	+ 1.25 mA	+ 1 mA
B10	+ 0.31 V	+ 0.39 V	+ 0.62 mA	+ 0.5 mA
B9	+ 0.15 V	+ 0.19 V	+ 0.31 mA	+ 0.25 mA
B8	+ 0.08 V	+ 0.1 V	+ 0.15 mA	+ 0.125 mA
B7	+ 0.04 V	+ 0.05 V	+ 0.08 mA	+ 0.062 mA
B6	+ 0.02 V	+ 0.025 V	+ 0.04 mA	+ 0.031 mA
B5	+ 0.01 V	+ 0.012 V	+ 0.02 mA	+ 0.015 mA
B4	+ 0.005 V	+ 0.006 V	+ 0.01 mA	+ 0.008 mA
B3	0 V	0 V	0 mA	0 mA
B2	0 V	0 V	0 mA	0 mA
B1	0 V	0 V	0 mA	0 mA
B0	0 V	0 V	0 mA	0 mA

RANGE LEAST SIGNIFICANT BYTE (see diagram "c")

Bits of analog word	± 10 V	± 5 V	± 20 mA	4...20mA
B15	(³)	(³)	(⁴)	(⁴)
B14	(³)	(³)	(⁴)	(⁴)
B13	(³)	(³)	(⁴)	(⁴)
B12	(³)	(³)	(⁴)	(⁴)
B11	(³)	(³)	(⁴)	(⁴)
B10	+ 5 V	+ 6.25 V	+ 10 mA	+ 8 mA
B9	+ 2.5 V	+ 3.12 V	+ 5 mA	+ 4 mA
B8	+ 1.25 V	+ 1.56 V	+ 2.5 mA	+ 2 mA
B7	+ 0.62 V	+ 0.77 V	+ 1.25 mA	+ 1 mA
B6	+ 0.31 V	+ 0.39 V	+ 0.62 mA	+ 0.5 mA
B5	+ 0.15 V	+ 0.19 V	+ 0.31 mA	+ 0.25 mA
B4	+ 0.08 V	+ 0.1 V	+ 0.15 mA	+ 0.125 mA
B3	+ 0.04 V	+ 0.05 V	+ 0.08 mA	+ 0.062 mA
B2	+ 0.02 V	+ 0.025 V	+ 0.04 mA	+ 0.031 mA
B1	+ 0.01 V	+ 0.012 V	+ 0.02 mA	+ 0.015 mA
B0	+ 0.005 V	+ 0.006 V	+ 0.01 mA	+ 0.008 mA

Bits B12 to B15 represent the sign and the overflow outputs word of analog outputs.

(⁰) If B15 = 1 and B12, B13 or B14 = 0 the analog output is forced at the minimum value.

If B15 = 0 and B12, B13 or B14 = 1 the output is at the maximum value.

(¹) If B15 = 1 the output is 0 mA.
If B15 = 0 and B12, B13 and B14 <> 0 the output is + 20 mA.

If B15 = 1 the output is 0 mA.
If B15 = 0 and B12, B13 and B14 <> 0 the output is + 20 mA.

(²) If B15 = 1 the output is 0 mA.
If B15 = 0 the range of internal word is 0 . +32767.

(³) If B15 = 1 and B11, B12, B13 or B14 = 0 the output is at the minimum value.

If B15 = 0 and B11, B12, B13 or B14 = 1 the output is at the maximum value.

(⁴) If B15 = 1 the output is 0 mA.
If B15 = 0 and B11, B12, B13 and B14 <> 0 the output is + 20 mA.

If B15 = 1 the output is 0 mA.
If B15 = 0 and B11, B12, B13 and B14 <> 0 the output is + 20 mA.



ANALOG OUTPUTS DIAGRAMS 12 BITS

a Analog unit dip switches are formatted for using an UCZA/UCZB Central Unit



b Analog unit dip switches are formatted for most significant byte

c Analog unit dip switches are formatted for least significant byte



Voltage ($\pm 10\text{ V}$, $\pm 12.5\text{ V}$)



Current (0 ... 20 mA)



Current (4 ... 20 mA)



Data conversion table

This table shows the bit value of analog words in decimal and hexadecimal.

Bit of word	Decimal	Hexadecimal
	Maximum +32767 Minimum -32768 Resolution 1	Maximum 7FFF Minimum 8001 Resolution 1
B15	-32768	8000
B14	+16384	4000
B13	+8192	2000
B12	+4096	1000
B11	+2048	0800
B10	+1024	0400
B9	+512	0200
B8	+256	0100
B7	+128	0080
B6	+64	0040
B5	+32	0020
B4	+16	0010
B3	+8	0008
B2	+4	0004
B1	+2	0002
B0	+1	0001

Range of analog Input values within the central unit.				
		UCZA UCZB	Most significant byte	Least significant byte
8 bits	Max	0.996 (4080)	32512	255
	Min	0	0	0
12 bits	Max	0.999 (4092)	32752	2047
	Min	- 1.000 (- 4096)	- 32768	- 2048

5.2.1 ICSE 08 A6 8 inputs, 8 bits

Analog Input remote unit

The analog input remote unit can be used for 0 ... 10 V, 0 ... 20 mA or 4 ... 20 mA. The dip switches in the rear of the unit and the wiring on the plug-in base enable the choice of current or voltage input.


The unit is configured for 0 ... 20 mA or 4 ... 20 mA current ranges with an handheld programming unit (TCZ) or CS 31 configuration functions (see chapter 2, in volume 2 «Central Units»).

The factory default setting is 0 ... 20 mA.

Description of the unit front :

- Ten status led's:
 - Eight yellow input status led's «I0» to «I7»①
 - Two green power supply led's «+ 5 V», «± 15 V»..... ②
- Six yellow led's to display the signal value of inputs ... ③
- «TEST» push-button ④
- Red error led ⑤
- List of error codes ⑥

The unit has to be mounted on a plug-in base ECZ



8 analog inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	no	no
Power supply output 10 VDC ($\pm 1\%$)	50 mA	50 mA
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.8 W	8 W
Order number : FPR 334 5601	R1012	R0016/R0014
Weight (kg)	0.25	0.43

INPUT SPECIFICATIONS


Nominal range	0 ... 10 V	0 ... 20 mA	4 ... 20 mA
Maximum value	30 V	20 mA	20 mA
Input resistance	100 k	250	250
Resolution : 8 bits	$\pm 1/2$ LSB (± 19.6 mV)	$\pm 1/2$ LSB (± 40 μ A)	$\pm 1/2$ LSB (± 31 μ A)
Linearity error	$\pm 3/4$ LSB (± 29.4 mV)	$\pm 3/4$ LSB (± 60 μ A)	$\pm 3/4$ LSB (± 47 μ A)
Error of maximum value	± 0.5 %	± 0.8 %	± 0.8 %
Amplification error between two channels	1 LSB (39 mV)	1 LSB (62 μ A)	1 LSB (62 μ A)
Temperature coefficient	100 ppm/K	150 ppm/K	150 ppm/K
Time constant of input filter	100 ms	20 ms	20 ms
Max refresh time	10 ms	10 ms	10 ms

CHANNEL POSSIBLE CONFIGURATIONS

Dip switches in the rear of the unit	Configuration from the central unit		Terminal "current"	Terminal "voltage"
	0 ... 20	4 ... 20		
ON	X		0 ... 20 mA	
OFF	X		0 ... 5 V	0 ... 10 V
ON		X	4 ... 20 mA	
OFF		X	1 ... 5 V*	2 ... 10 V*

* For these special formats, the conversion tables are not available.

• Electrical connection




The function of each channel depends on the wired terminals.

NOTE : Terminals 15 and 30 (output + 10 V) are internally connected.

All common terminals are internally connected but it's better to use the terminal nearest the channel used.

• Connection of input A :





The wires for analogue inputs must be shielded and the shield has to be connected to the earth on the side of the remote unit.

• Initialization

The selection between current or voltage depends upon the dip switches in the rear of the unit. One dip switch for one channel :

- N. 1 : channel 00
- N. 2 : channel 01
- N. 3 : channel 02
- N. 4 : channel 03
- N. 5 : channel 04
- N. 6 : channel 05
- N. 7 : channel 06
- N. 8 : channel 07



Dip switches have to be in the **ON** position for current configuration.

Dip switches have to be in the **OFF** position for voltage configuration.

NOTE : The factory default setting is $\pm 10V$.

In voltage configuration (dip switches OFF) the current input can be used in different ways :

- In voltage input 0 ... 5 V. If the unit is configured in 0 ... 20 mA from the central unit.
- In voltage input 1 ... 5 V. If the unit is configured in 4 ... 20 mA from the central unit.

After configured and wired the unit :



- The unit initializes itself after power on.
- The error led goes out after initialization.
- The value of the analog input IO is displayed on the 8 led's on the right and the led's "+ 5 and + 15" are illuminated.

• Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31	07 KR 91 07 KT 92 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 05 08 ... 15	00 ... 05	even 00 ... 14		1 ... 8
Switch N. 8 on the plug-in base		OFF	ON	OFF	ON	OFF
Input	A	EWxx, 00	EWxx, 08	EAx, 00	EAx, 08	IAx0
	B	EWxx, 01	EWxx, 09	EAx, 01	EAx, 09	IAx1
	C	EWxx, 02	EWxx, 10	EAx, 02	EAx, 10	IAx2
	D	EWxx, 03	EWxx, 11	EAx, 03	EAx, 11	IAx3
	E	EWxx, 04	EWxx, 12	EAx, 04	EAx, 12	IAx4
	F	EWxx, 05	EWxx, 13	EAx, 05	EAx, 13	IAx5
	G	EWxx, 06	EWxx, 14	EAx, 06	EAx, 14	IAx6
	H	EWxx, 07	EWxx, 15	EAx, 07	EAx, 15	IAx7

In the case of UCZA/UCZB, the addresses 08 ... 14 are only allowed with SCZ unit.
For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description.

The value of the input selected by pressing the "TEST" button can be displayed on the 6 led's on the right. These 6 led's have the following meaning :



no led ON ○○○○○○	3 led's ON ●●●○○○	6 led's ON ●●●●●●	Configuration
0 V	5 V	10 V	0 ... 20 mA
0 V	2.5 V	5 V	
0 mA	10 mA	20 mA	
2 V	6 V	10 V	4 ... 20 mA
1 V	3 V	5 V	
4 mA	12 mA	20 mA	

Fault indication:

- Led 0 : «Unit error»
- Led 1 : «Bus error»

The configuration of each channel is indicated by the led 4.

- Led 4 : «4 ... 20»
Current configuration 4 ... 20 mA

Led 4 «OFF» : Channel in 0 ... 20 mA or 0 ... 10 V, depends upon the dip switches in the rear of the unit.

Led 4 «ON »: Channel in 4 ... 20 mA or 2 ... 10 V, depends upon the dip switches in the rear of the unit.

If an error occurs, (see chapter 9, volume 2 «In case of failure»).

5.2.2 ICSE 08 B5 8 inputs, 12 bits

Analog Input remote unit


The analogue input remote unit can be used for ± 10 V, ± 5 V, ± 20 mA or 4 ... 20 mA. The dip switches in the rear of the unit enable the choice of current or voltage input.

The unit is configured for ± 20 mA or 4 ... 20 mA current ranges with an handheld programming unit (TCZ) or CS 31 configuration functions (see chapter 2, volume 2 «Central Units»).

Description of the unit front :

- Ten status led's:
 - Eight yellow input status led's «I0» to «I7»①
 - Two green power supply led's «+ 5 V», «± 15 V»..... ②
- Six yellow led's to display the signal value of inputs ③
- «TEST» push-button ④
- Red error led ⑤
- List of error codes ⑥

The unit has to be mounted on a plug-in base ECZ.



8 analog inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Power supply output 10 VDC (± 1 %)	no	no
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.8 W	8 W
Order number : FPR 334 6501	R1012	R0016/R0014
Weight (kg)	0.25	0.43

INPUT SPECIFICATIONS

Nominal range	$\pm 10 \text{ V}$	$\pm 20 \text{ mA}$	4 ... 20 mA
Maximum value	+ 15 V	+ 25 mA	+ 25 mA
Minimum value	- 15 V	- 25 mA	- 25 mA
Input resistance	100 k	250	250
Resolution : 12 bits	$\pm 1 \text{ LSB}$ ($\pm 5 \text{ mV}$)	$\pm 2 \text{ LSB}$ ($\pm 20 \mu\text{A}$)	$\pm 2 \text{ LSB}$ ($\pm 20 \mu\text{A}$)
Linearity error	$\pm 1 \text{ LSB}$ ($\pm 5 \text{ mV}$)	$\pm 2 \text{ LSB}$ ($\pm 20 \mu\text{A}$)	$\pm 2 \text{ LSB}$ ($\pm 20 \mu\text{A}$)
Error of maximum value	$\pm 0.3 \%$	$\pm 0.5 \%$	$\pm 0.5 \%$
Amplification error between two channels	1 LSB (5 mV)	2 LSB (20 μA)	2 LSB (20 μA)
Temperature coefficient	100 ppm/K	150 ppm/K	150 ppm/K
Time constant of input filter	0.5 ms	0.5 ms	0.5 ms
Max refresh time	10 ms	10 ms	10 ms

CONFIGURATION BY THE CENTRAL UNIT

Dip switches in the rear of the unit	$\pm 10 \text{ V}$	$\pm 20 \text{ mA}$	4 ... 20 mA
ON		$\pm 20 \text{ mA}$	
OFF		$\pm 5 \text{ V}$	
ON			4 ... 20 mA
OFF			1 ... 5 V
ON	$\pm 40 \text{ mA}^*$		
OFF	$\pm 10 \text{ V}$		


* Forbidden.

NOTE : The factory default setting is $\pm 10 \text{ V}$.

Configure a channel :


- put the dip switch in the rear of the unit on the position ON or OFF
- configure the input by the central unit with the programming unit TCZ or with the user configurable functions in the user program.

• Electrical connection



NOTE : All common terminals are internally connected but it's better to use the terminal nearest the channel used.

• Connection of input A :





The wires for analogue inputs must be shielded and the shield has to be connected to the earth on the side of the remote unit.

• Initialization

The selection between current or voltage depends upon the dip switches in the rear of the unit. One dip switch for one channel :

- No. 1 : channel 00
- No. 2 : channel 01
- No. 3 : channel 02
- No. 4 : channel 03
- No. 5 : channel 04
- No. 6 : channel 05
- No. 7 : channel 06
- No. 8 : channel 07



Dip switches have to be in the «ON» position for current configuration.

Dip switches have to be in the «OFF» position for voltage configuration.

NOTE : the factory default setting is $\pm 10V$.

After configured and wired the unit :



- The unit initializes itself after power on.
- The error led goes out after initialization.
- The value of the analog input IO is displayed on the 6 led's on the right and the led's "+ 5 and ± 15 " are illuminated.

• Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31	07 KR 91 07 KT 92 07 KT 93	UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 05 08 ... 15	00 ... 05	even 00 ... 14		1 ... 8
Switch N. 8 on the plug-in base		OFF	ON	OFF	ON	OFF
Input	A	EWxx, 00	EWxx, 08	EAx, 00	EAx, 08	IAx0
	B	EWxx, 01	EWxx, 09	EAx, 01	EAx, 09	IAx1
	C	EWxx, 02	EWxx, 10	EAx, 02	EAx, 10	IAx2
	D	EWxx, 03	EWxx, 11	EAx, 03	EAx, 11	IAx3
	E	EWxx, 04	EWxx, 12	EAx, 04	EAx, 12	IAx4
	F	EWxx, 05	EWxx, 13	EAx, 05	EAx, 13	IAx5
	G	EWxx, 06	EWxx, 14	EAx, 06	EAx, 14	IAx6
	H	EWxx, 07	EWxx, 15	EAx, 07	EAx, 15	IAx7

In the case of UCZA/UCZB, the addresses 08 ... 14 are only allowed with SCZ unit.
For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description.

The value of the input selected by pressing the "TEST" button can be displayed on the 6 led's on the right. These 6 led's have the following meaning :



no led ON ○○○○○○	3 led's ON ●●●○○○	6 led's ON ●●●●●●	Configuration
- 10 V	0 V	+ 10 V	± 10 V
- 20 mA	0 mA	+ 20 mA	± 20 mA
- 5V	0 V	+ 5 V	
-	4 mA	20 mA	4 ... 20 mA
-	1 V	5 V	

Fault indication:

Led 0 : «Unit error»

Led 1 : «Bus error»

The configuration of each channel is indicated by the led's 4 and 5.

Led 4 : «4 ... 20»

Current configuration 4 ... 20 mA

Led 4 and 5 «OFF» :

Configuration - 20 ... 20 mA

Each channel can be displayed by pressing the "TEST" button.

The channel IO is always displayed after initialization until otherwise selected.

If an error occurs, (see section 9 of chapter 2 «In case of failure»).

5.2.3 ICST 08 A8 8 inputs PT100, 8 bits

Analog Input remote unit


The analog input remote unit can be used for measurement of temperature. The inputs have to be connected to the PT 100 sensors (2 or 3 wires) according the IEC 751 standard (class A and class B).

The range of temperature is : $- 50\text{ }^{\circ}\text{C} \dots + 150\text{ }^{\circ}\text{C}$
($- 58\text{ }^{\circ}\text{F} \dots + 302\text{ }^{\circ}\text{F}$)

Description of the unit front :

- Ten status led's:
 - Eight yellow input status led's «I0» to «I7»①
 - Two green power supply led's «+ 5 V», «± 15 V»..... ②
 - Six yellow led's to display the signal value of inputs ③
 - «TEST» push-button ④
 - Red error led..... ⑤
 - List of error codes ⑥

The unit has to be mounted on a plug-in base ECZ



8 analoge inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	no	no
Power supply output	no	no
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.8 W	8 W
Order number : FPR 333 5801	R1012	R0016/R0014
Weight (kg)	0.25	0.43

INPUT SPECIFICATIONS





Nominal scale	- 50 ... + 150 °C	(- 58 °F ... + 302 °F)
Maximum value	+ 154.45 °C	(+ 310 °F)
Minimum value	- 52.47 °C	(- 62.45 °F)
Offset	0 °C	(0 °F)
Resolution : 8 bits	0.8 °C	(1.44 °F)
Accuracy on full scale (out of the allowance on sensor and for an ambient temperature of the unit for 0 °C ... +55 °C (+32 °F ... +131 °F))	± 1.0 °C	(± 1.8 °F)
Allowance on sensor		
- type A (IEC 751)	± 0.5 °C on full scale	(± 0.9 °F)
- type B (IEC 751)	± 1 °C on full scale	(± 1.8 °F)
Ohmic value of the PT 100 sensor	80.31 ... 157.31	
Temperature coefficient	100 ppm/ °C	
Max refresh time	300 ms for 8 channels	

- * The different characteristics are available on the used range 0 °C ... + 55 °C (+32 °F ... + 131 °F) of the remote unit.
- * The non linearity of the sensor is compensated.

● Electrical connection

"3 wires" connection

"2 wires" connection



• Initialization

- The unit initializes itself after power ON.
- The error led goes out after initialization.

The value of the analog input I0 is displayed on the 6 led's on the right and the led's «+ 5 V» and «± 15 V» are illuminated.

• Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS	07 KR 31	07 KR 91 07 KT 92 07 KT 93	UCZA/UCZB		PCZB	
Address xx on the plug-in base ECZ	00 ... 05 08 ... 15	00 ... 05	even 00 ... 14		1 ... 8	
Switch N. 8 on the plug-in base	OFF	ON	OFF	ON	OFF	
Input	A	EWxx, 00	EWxx, 08	EAx, 00	EAx, 08	I Ax0
	B	EWxx, 01	EWxx, 09	EAx, 01	EAx, 09	I Ax1
	C	EWxx, 02	EWxx, 10	EAx, 02	EAx, 10	I Ax2
	D	EWxx, 03	EWxx, 11	EAx, 03	EAx, 11	I Ax3
	E	EWxx, 04	EWxx, 12	EAx, 04	EAx, 12	I Ax4
	F	EWxx, 05	EWxx, 13	EAx, 05	EAx, 13	I Ax5
	G	EWxx, 06	EWxx, 14	EAx, 06	EAx, 14	I Ax6
	H	EWxx, 07	EWxx, 15	EAx, 07	EAx, 15	I Ax7


In the case of UCZA/UCZB, the addresses 08 ... 14 are only allowed with the SCZ unit.
For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description.

ANALOG INPUTS 8 BITS

Input range	– 50 °C ... + 150 °C	(– 58 °F ... + 302 °F)
Resolution	0.8 °C	(1.44 °F)
Maximum	154.45 °C	(310 °F)
Minimum	– 52.47 °C	(– 62.45 °F)

Bits of analog word	Range least significant byte and for central units UCZA/UCZB		Range most significant byte	
	°C	°F	°C	°F
B15	– 157.00 °C	(– 250.60 °F)	– 157.00 °C	(– 250.60 °F)
B14	**	**	78.50 °C	(173.30 °F)
B13	**	**	39.25 °C	(102.65 °F)
B12	**	**	19.63 °C	(67.33 °F)
B11	78.50 °C	(173.30 °F)	9.81 °C	(49.66 °F)
B10	39.25 °C	(102.65 °F)	4.91 °C	(40.84 °F)
B9	19.63 °C	(67.33 °F)	2.45 °C	(36.41 °F)
B8	9.81 °C	(49.66 °F)	1.23 °C	(34.21 °F)
B7	4.91 °C	(40.84 °F)	0.61 °C	(33.10 °F)
B6	2.45 °C	(36.41 °F)	0.31 °C	(32.56 °F)
B5	1.23 °C	(34.21 °F)	0.15 °C	(32.27 °F)
B4	0.61 °C	(33.10 °F)	0.08 °C	(32.14 °F)
B3	0.31 °C	(32.56 °F)	0.04 °C	(32.07 °F)
B2	0.15 °C	(32.27 °F)	0	0
B1	0.08 °C	(32.14 °F)	0	0
B0	0.04 °C	(32.07 °F)	0	0

The choice of setting of the dip switches 2 and 3 on the plug-in base gives two different tables.
(See chapter 5.1, volume 2 "General")



Approximate function

$$T \text{ } ^\circ\text{C} = 0.0383 \text{ VAL}$$

$$\text{VAL} = 26.1096 T \text{ } ^\circ\text{C}$$


VAL : input word after conversion and linearity correction.

T °C : temperature in degree Celsius

Use the following formula to get the temperature in degree Fahrenheit :

$$^\circ\text{F} = \frac{9}{5} ^\circ\text{C} + 32$$

Range least significant byte and UCZA/UCZB



Approximate function

$$T\text{ }^{\circ}\text{C} = 0.0048\text{ VAL}$$

$$\text{VAL} = 208.33\text{ T }^{\circ}\text{C}$$

VAL : input word after conversion and linearity correction.



T °C : temperature in degree Celsius

Use the following formula to get the temperature in degree Fahrenheit :

$$^{\circ}\text{F} = \frac{9}{5}\text{ }^{\circ}\text{C} + 32$$

Range most significant byte

The value of input selected by pressing the «TEST» button can be displayed on the 6 led's on the right. These 6 led's have the following meaning :



Each channel can be selected by pressing the «TEST» button.

Channel I0 is always displayed after initialization until otherwise selected.

Fault indication:

- Led 0 : «Unit error»
- Led 1 : «Bus error»
- Led 4 : «Out of range»

- Led 4 «OFF» : the channel is wired and the temperature is in the due range.
- Led 4 «ON» : measure out of range or short circuit detection (If VAL VAL MIN), or open circuit detection (If VAL VAL MAX).

If an error occurs, (see chapter 9, volume 2, «In case of failure»).

5.2.4 ICST 08 A9 8 inputs PT 100, 8 bits

Analog Input remote unit


The analog input remote unit can be used for measurement of temperature. The inputs have to be connected to the PT 100 sensors (2 or 3 wires) according the IEC 751 standard (class A and class B).

The range of temperature is : 0 °C ... + 300 °C
(+ 32 °F ... + 572 °F)

Description of the unit front :

- Ten status led's:
 - Eight yellow input status led's «I0» to «I7»①
 - Two green power supply led's «+ 5 V», «± 15 V»②
- Six yellow led's to display the signal value of inputs③
- «TEST» push-button④
- Red error led⑤
- List of error codes⑥

The unit has to be mounted on a plug-in base ECZ



8 analog inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	no	no
Power supply output	no	no
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.8 W	8 W
Order number : FPR 333 5901	R1012	R0016/R0014
Weight (kg)	0.25	0.43

INPUT SPECIFICATIONS





Nominal scale	0 °C ... + 300 °C	(+ 32 °F ... + 572 °F)
Maximum value	+ 300.5 °C	(+ 572.9 °F)
Minimum value	- 5 °C	(+ 23 °F)
Offset	0 °C	(0 °F)
Resolution : 8 bits	1.2 °C	(2.16 °F)
Accuracy on full scale (out of the allowance on sensor and for an ambient temperature of the unit for 0 °C ... + 55 °C) (+ 32 °F ... + 131 °F)	± 1.5 °C	(± 2.7 °F)
Allowance on sensor		
- type A (IEC 751)	± 0.75 °C on full scale	(± 1.35 °F)
- type B (IEC 751)	± 1.8 °C on full scale	(± 3.24 °F)
Ohmic value of the PT 100 sensor	100 ... 212.02	
Temperature coefficient	100 ppm/ °C	
Max refresh time	300 ms for 8 channels	

- * The different characteristics are available on the used range 0 °C ... 55 °C (+ 32 °F ... + 131 °F) of the remote unit.
- * The no linearity of the sensor is compensated.

• Electrical connection

"3 wires" connection

"2 wires" connection



• Initialization

- The unit initializes itself after power ON.
- The error led goes out after initialization.

The value of the analog input I0 is displayed on the 6 led's on the right and the led's «+ 5 V» and «± 15 V» are illuminated.

• Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS	07 KR 31	07 KR 91 07 KT 92 07 KT 93	UCZA/UCZB		PCZB	
Address xx on the plug-in base ECZ	00 ... 05 08 ... 15	00 ... 05	even 00 ... 14		1 ... 8	
Switch N. 8 on the plug-in base	OFF	ON	OFF	ON	OFF	
Input	A	EWxx, 00	EWxx, 08	EAx, 00	EAx, 08	IAx0
	B	EWxx, 01	EWxx, 09	EAx, 01	EAx, 09	IAx1
	C	EWxx, 02	EWxx, 10	EAx, 02	EAx, 10	IAx2
	D	EWxx, 03	EWxx, 11	EAx, 03	EAx, 11	IAx3
	E	EWxx, 04	EWxx, 12	EAx, 04	EAx, 12	IAx4
	F	EWxx, 05	EWxx, 13	EAx, 05	EAx, 13	IAx5
	G	EWxx, 06	EWxx, 14	EAx, 06	EAx, 14	IAx6
	H	EWxx, 07	EWxx, 15	EAx, 07	EAx, 15	IAx7


In the case of UCZA/UCZB, the addresses 08 ... 14 are only allowed with the SCZ unit.
For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description.

ANALOG INPUTS 8 BITS

Input range 0 °C ... + 300 °C (+ 32 °F ... + 572 °F)
 Resolution 1.2 °C (2.16 °F)
 Maximum 300.5 °C (+ 572.9 °F)
 Minimum - 5 °C (+ 23 °F)

Bits of analog word	Range least significant byte and for central units UCZA/UCZB		Range most significant byte	
	°C	°F	°C	°F
B15	- 303.00 °C	(513.40 °F)	- 303.00 °C	(513.40 °F)
B14	**	**	151.50 °C	(304.70 °F)
B13	**	**	75.75 °C	(168.35 °F)
B12	**	**	37.88 °C	(100.18 °F)
B11	151.50 °C	(304.70 °F)	18.94 °C	(66.09 °F)
B10	75.75 °C	(168.35 °F)	9.47 °C	(49.04 °F)
B9	37.88 °C	(100.18 °F)	4.73 °C	(40.51 °F)
B8	18.94 °C	(66.09 °F)	2.37 °C	(36.26 °F)
B7	9.47 °C	(49.04 °F)	1.18 °C	(34.12 °F)
B6	4.73 °C	(40.51 °F)	0.59 °C	(33.06 °F)
B5	2.37 °C	(36.26 °F)	0.30 °C	(32.54 °F)
B4	1.18 °C	(34.12 °F)	0.15 °C	(32.27 °F)
B3	0.59 °C	(33.06 °F)	0.08 °C	(32.14 °F)
B2	0.30 °C	(33.54 °F)	0	0
B1	0.15 °C	(32.27 °F)	0	0
B0	0.08 °C	(32.14 °F)	0	0

The choice of setting of the dip switches 2 and 3 on the plug-in base gives two different tables.
 (See chapter 5.1, volume 2 «General»)



Approximate function

$$T \text{ } ^\circ\text{C} = 0.074 \text{ VAL}$$

$$\text{VAL} = 13.5135 T \text{ } ^\circ\text{C}$$


VAL : input word after conversion and linearity correction.

T °C : temperature in degree Celsius

Use the following formula to get the temperature in degree Fahrenheit :



$$^\circ\text{F} = \frac{9}{5} ^\circ\text{C} + 32$$

Range least significant byte and UCZA/UCZB



Range most significant byte

The value of input selected by pressing the «**TEST**» button can be displayed on the 6 led's on the right. These 6 led's have the following meaning :



Each channel can be selected by pressing the «**TEST**» button.

Channel I0 is always displayed after initialization until otherwise selected.

Fault indication:

- Led 0 : «**Unit error**»
- Led 1 : «**Bus error**»
- Led 4 : «**Out of range**»

- Led 4 «**OFF**» : the channel is wired and the temperature is in the due range.
- Led 4 «**ON**» : measure out of range, or short circuit detection (if VAL > VAL MIN), or open circuit detection (if VAL < VAL MAX).

If an error occurs, (see chapter 9, volume 2 «**In case of failure**»).

5.2.5 Analog Input Module ICDT 08 B5

8 inputs, configurable for temperature sensors or as voltage inputs
24 V DC, CS31 system bus connection electrically isolated




Fig. 5.2.5–1: Analog input module ICDT 08 B5

Contents

Intended purpose	5.2.5– 1
Display and operating elements on the front panel	5.2.5– 1
Electrical connection	5.2.5– 1
Configuration	5.2.5– 3
Measuring ranges of the input channels	5.2.5– 4
Addressing	5.2.5–10
Normal operation	5.2.5–10
Diagnosis and displays	5.2.5–10
Technical data	5.2.5–12
Front foil and outline dimensions	5.2.5–16

Intended purpose

The analog input module ICDT 08 B5 is a remote module on the CS31 system bus. It has 8 analog input channels with the following features:

- The channels are configured in pairs for the connection of the following temperature or voltage sensors:
 - $\pm 10\text{ V}$ / $\pm 5\text{ V}$ / $\pm 500\text{ mV}$ / $\pm 50\text{ mV}$
 - 4...20 mA (with an external 250 Ω shunt)
 - Pt100 / Pt1000 with linearization
 - Thermocouples of types J, K and S with linearization
 - Only electrically isolated sensors may be used.

- The range of $\pm 5\text{ V}$ is also suitable for measuring 0...20 mA, if an external shunt of 250 Ω is used.

- The configuration of the input channels as well as the setting of the module address are performed at DIL switches.

The ICDT 08 B5 module uses **one** address in the word input range of 0...6. Each of the 8 channels needs 16 bits.

The module is supplied with 24 V DC. The CS31 system bus connection is electrically isolated from the remaining module components.

The module offers a number of diagnosis functions (see chapter "Diagnosis and displays"). A self-calibration is carried out cyclically by the module's internal control circuit.

Display and operating elements on the front panel

- ① 8 green LEDs for channel selection and diagnosis, 8 green LEDs for a rough display of an analog channel
- ② List of diagnosis information belonging to the LEDs, if they are used for diagnosis
- ③ Red LED for error message
- ④ Test button

Electrical connection

The module is mounted on a 15-mm-high DIN rail or fastened with 4 screws. The following figure shows the electrical connection of the analog input module.

Connection examples for temperature sensors





Fig. 5.2.5-2: Electrical connection of the analog input module ICDT 08 B5


Configuring the input channels and setting the module address on the CS31 system bus

The measuring ranges are set in pairs (i.e. always for two channels together) at the DIL switches 1 and 2. The setting on the address DIL switch determines the module address, the analog value representation and the type of line frequency suppression (50 Hz or 60 Hz or none).

The switches are under the cover on the right side of the module housing. The following drawing illustrates the setting modes.



<input type="checkbox"/>	+/- 10 V
<input type="checkbox"/>	+/- 5 V or 0...20 mA (with a 250 ohms shunt)
<input type="checkbox"/>	+/- 500 mV
<input type="checkbox"/>	+/- 50 mV
<input type="checkbox"/>	Pt100 with linearization
<input type="checkbox"/>	Pt1000 with linearization
<input type="checkbox"/>	reserved
<input type="checkbox"/>	Thermocouple of type J with linearization
<input type="checkbox"/>	Thermocouple of type K with linearization
<input type="checkbox"/>	Thermocouple of type S with linearization
<input type="checkbox"/>	reserved
<input type="checkbox"/>	4...20 mA (with a 250 ohms shunt)
<input type="checkbox"/>	No evaluation of channels. For getting more speed, it is a good idea to set the switches in this way, if pairs of channels are unused.



Specifications of the platinum temperature sensors Pt100/Pt1000:

Pt100	= Platinum 100 Ω at 0 °C	Measuring range	-50...400 °C	Current sink	2 mA
Pt1000	= Platinum 1000 Ω at 0 °C	Measuring range	-50...400 °C	Current sink	0.2 mA

Specifications of the thermocouples of types J, K and S:

Type J	= Fe-CuNi	0...1200 °C	Iron / Copper-Nickel	+	= Fe	-	= CuNi
Type K	= NiCr-NiAl	0...1372 °C	Nickel-Chromium/Nickel-Aluminium	+	= NiCr	-	= NiAl
Type S	= Pt10Rh-Pt	0...1600 °C	Platinum-10% Rhodium / Platinum	+	= Pt10Rh	-	= Pt

Fig. 5.2.5-3: Configuration of the input channels and setting of the module address on the CS31 system bus

Measuring ranges of the input channels

All input signals are evaluated as differential signals. The sensor signals are connected double-pole to the inputs U+ and U- (for examples see Fig. 5.2.5–2). The relationship between the input signals and the output numerical values is shown in the figures 5.2.5–7 to 5.2.5–9. All unused channels have to be short-circuited (see also the termination of unused inputs configured as Pt100/Pt1000 channels).

± 10 V / ± 5 V / ± 500 mV / ± 50 mV

The set measuring range is converted into the numerical number range without linearization in the following way:

Analog representation **a**: -4095 ... 0... +4095

Analog representation **b**: -32760 ... 0...+32760

If input voltages overflow the measuring range, the overflow number of +32767 is output. If the input voltage underflows the measuring range, the underflow number of -32767 is output. In both cases, an error message is sent via the CS31 system bus.

All unused channels have to be short-circuited.

4...20 mA / 0...20 mA

The following configurations can be set:

Measuring range Setting

4...20 mA 4...20 mA

0...20 mA ± 5 V

The two input terminals have to be circuited in parallel with a 250 Ω shunt in both cases.

All unused channels have to be short-circuited.



Pt100 / Pt1000

When resistance thermometers are used, a constant current must flow through their sensor resistors in order to build a voltage drop necessary for the evaluation in the module. The analog module provides two constant current sinks for this purpose.

The two following figures show configurations with Pt100 and Pt1000 resistance thermometers. The module linearizes the temperature-resistance curves if channels configured for Pt100/Pt1000. The accuracy of the integrated current sinks of 2 mA and 0.2 mA is also compensated in these measuring configurations.

The following three paragraphs describe the allocations of the integrated current sinks:

Resistance thermometers which are connected to the terminals 5 to 15 (channels EA n,00 to EA n,03), may use **only one of the two** sinks at the terminals 16 **or** 17 (2 mA **or** 0.2 mA).



Resistance thermometers which are connected to the terminals 24 to 34 (channels EA n,04 to EA n,07), may use **only one of the two** sinks at the terminals 35 or 36 (2 mA or 0.2 mA).

Use of Pt100 and Pt1000 sensors at the same time is possible. One group of the sensors (e.g. Pt100) can be connected to the upper terminals, the other group (e.g. Pt1000) to the lower terminals.

The terminals 7, 10, 13, 26, 29 and 32 (labelled with NC) can be used as connecting tags for the current loops (see also Fig. 5.2.4–2).

Independent of the analog representation **a** or **b**, the measuring range of **-50°C...400°C** is allocated linear to the number range of **-1022...+8190** (see also the figures 5.2.5–7 to 5.2.5–9).

If input voltages overflow the measuring range, the overflow number of +32767 is output. If the input voltage underflows the measuring range, the underflow number of -32767 is output. In both cases, an error message is sent via the CS31 system bus.

If a broken wire (open circuit) occurs in the current loop, the number -32767 is output. If a broken wire (open circuit) occurs in the sensor line, the number +32767 is output. In both cases, an error message is sent via the CS31 system bus.

If unused Pt100/Pt1000 channels would be connected to a wire jumper, its resistance of 0 Ω would pretend the measuring value of a very low temperature. As a result, the error message "Underflow" would be output. In order to prevent such error messages, unused Pt100/Pt1000 channels should be terminated as follows:

Pt 100 by a resistor of 120 Ω
 Pt 100 0 by a resistor of 1200 Ω

Connection of other temperature-dependent resistors

In principle, all temperature-dependent resistors can be connected to the module instead of Pt100/Pt1000 sensors. As configurations, the settings ± 5 V, ± 500 mV and ± 50 mV are suitable. If necessary, the linearization of the temperature-resistance curve must be performed with the PLC program. The integrated current sinks can be used. In doing so, the following has to be observed:

- The voltage drop over all resistors circuited in series may not be greater than
 - 7 V** (using the current sink of 0.2 mA),
 - 2.5 V** (using the current sink of 2 mA).
- The tolerance of the integrated current sinks is ± 1,5 %. There is no compensation by the module in this application. This is a difference compared with the Pt100/Pt1000 settings.

Thermocouples of types J, K and S

The thermocouples are connected directly or via compensation wires to the terminals U+ and U-. The correct polarity must be observed by all means.

The reference junction temperature sensor is integrated in the module near the terminals. When evaluating the absolute temperature, the terminals are considered as the reference junction.




Fig. 5.2.5–6: Connection of 2 J-type and 2 K-type thermocouples

The thermoelectric voltage generated by the thermocouples is converted into binary values inside the module and then linearized according to the thermocouple type. In order to get the absolute temperature, the temperature of the reference junction is added.

Independent of the analog representation **a** or **b**, the measuring range is allocated linear to the number range as follows (see also the figures 5.2.5–7 to 5.2.5–9):

Type J: 0°C...1200°C Number range 0...24576
Type K: 0°C...1372°C Number range 0...28096
Type S: 0°C...1600°C Number range 0...32760

If input voltages overflow the measuring range, the overflow number of +32767 is output. If the input voltage underflows the measuring range, the underflow number of -32767 is output. In both cases, an error message is sent via the CS31 system bus. Temperatures lower than 0°C are evaluated as "Underflow".

If a broken wire (open circuit) occurs, the number -32767 is output. In addition, an error message is sent via the CS31 system bus.

All unused channels must be short-circuited.

Note:

Since L type thermocouples (Iron/constantan, Fe-CuNi according to DIN 43710) are similar to J type thermocouples, they also can be used in the temperature range of 0...900 °C. The slightly greater thermal Emf generated by the L type thermocouple, however, pretends a little higher temperature. The following table illustrates this fact (all temperature data is referred to a reference temperature of 0 °C):

Temperature at the measuring point	Temperature evaluated by the module, if an L type thermocouple is used instead of a J type thermocouple
25 °C	25.63 °C
50 °C	51.23 °C
100 °C	101.89 °C
200 °C	203.13 °C
400 °C	405.69 °C
600 °C	609.78 °C
900 °C	920.41 °C

Configuration "Unused channel"

If channels are unused in pairs, it is useful to omit them from the acquisition of the measured value and processing in the software. The other channels are processed faster then. Figure 5.2.5-3 shows how to set the configuration "No evaluation of channels".

Relationship between the measuring values and the arrangement of the bits in the 16-bit word according to the analog representations a and b

The measuring ranges for the analog channels are configured in pairs (i.e. always for 2 channels together), see Fig. 5.2.5-3. If an overflow or an underflow occurs, or if an open circuit is detected, the numbers +32767 or -32767 are output.

The following three figures illustrate the evaluation functions of the module.

Analog representation / measuring range

Bit No. in the 16-bit word

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
a (T200)	-100 %	-100 %	-100 %	-100 %	50 %	25 %	12.5 %	6.25 %	3.13 %	1.56 %	0.78 %	0.39 %	0.20 %	0.10 %	0.05 %	0.02 %
$\pm 10V$	-10V (sign)			5V	2.5V	1.25V	625mV	313mV	156mV	78mV	39mV	20mV	10mV	5 mV	2mV	
$\pm 5V$	-5V (sign)			2.5V	1.25V	625mV	313mV	156mV	78mV	39mV	20mV	10mV	5mV	2mV	1mV	
$\pm 0.5V$	-500mV (sign)			250mV	125mV	63mV	31mV	16mV	7,8mV	3,9mV	2mV	1mV	0.5mV	0.2mV	0.1mV	
$\pm 50mV$	-50mV (sign)			25mV	12.5mV	6.3mV	3.1mV	1.6mV	0.8mV	0.4mV	0.2mV	0.1mV	0.05mV	0.02mV	0.01mV	
Bit values	-4096 (sign)			2048	1024	512	256	128	64	32	16	8	4	2	1	

Analog representation a, measuring ranges $\pm 10 V$, $\pm 5 V$, $\pm 500 mV$, $\pm 50 mV$, 12 bits resolution plus sign, the value range from $-100...+100 \%$ corresponds to the numbers $F001_H...0FFF_H$ ($-4095...+4095$), Overflow: $7FFF_H$ (32767), Underflow: 8001_H (-32767)

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
b (CS31)	-100 %	50 %	25 %	12.5 %	6.25 %	3.13 %	1.56 %	0.78 %	0.39 %	0.20 %	0.10 %	0.05 %	0.02 %	0	0	0
Sign																
$\pm 10V$	-10V	5V	2.5V	1.25V	625mV	313mV	156mV	78mV	39mV	20mV	10mV	5 mV	2mV	0	0	0
$\pm 5V$	-5V	2.5V	1,25V	625mV	313mV	156mV	78mV	39mV	20mV	10mV	5mV	2mV	1mV	0	0	0
$\pm 0.5V$	-500mV	250mV	125mV	63mV	31mV	16mV	7.8mV	3.9mV	2mV	1mV	0.5mV	0.2mV	0.1mV	0	0	0
$\pm 50mV$	-50mV	25mV	12.5mV	6.3mV	3.1mV	1.6mV	0.8mV	0.4mV	0.2mV	0.1mV	0.05mV	0.02mV	0.01mV	0	0	0
Bit values	-32768	16384	8192	4096	2048	1024	512	256	128	64	32	16	8	4	2	1

Analog representation b, measuring ranges $\pm 10 V$, $\pm 5 V$, $\pm 500 mV$, $\pm 50 mV$, 12 bits resolution plus sign, the value range from $-100...+100 \%$ corresponds to the numbers $8008_H...7FF8_H$ ($-32760...+32760$), Overflow: $7FFF_H$ (32767), Underflow: 8001_H (-32767)

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
a or b	-100 %	50 %	25 %	12.5 %	6.25 %	3.13 %	1.56 %	0.78 %	0.39 %	0.20 %	0.10 %	0.05 %	0.02 %	0.01 %	0.005 %	0
Sign																
Pt100	-1600°C	800°C	400°C	200°C	100°C	50°C	25°C	12.5°C	6.25°C	3.13°C	1.56°C	0.78°C	0.39°C	0.2°C	0.1°C	0
Pt1000																
Thermo-couples	0	800°C	400°C	200°C	100°C	50°C	25°C	12.5°C	6.25°C	3.13°C	1.56°C	0.78°C	0.39°C	0	0	0
Bit values	-32768	16384	8192	4096	2048	1024	512	256	128	64	32	16	8	4	2	1

Analog representation a/b, measuring ranges for Pt100/Pt1000 with 12 bits resolution plus sign, the value range from $-50...+400^\circ C$ corresponds to the numbers $FC02_H...1FFE_H$ ($-1022...+8190$), Overflow / open circuit in the sensor line: $7FFF_H$ (32767), Underflow / open circuit in the current loop: 8001_H (-32767)

Analog representation a/b, measuring ranges for thermocouples with 12 bits resolution without sign, the value range from $0...+1600^\circ C$ corresponds to the numbers $0_H...7FF8_H$ ($0...+32760$) Overflow: $7FFF_H$ (32767), Underflow / open circuit: 8001_H (-32767)

Fig. 5.2.5-7: Relationship between the measuring values and the arrangement of the bits in the 16-bit word according to the analog representations a and b

**Relationship between the measuring value and the output number,
Voltage input (analog representation a, T200)**





Fig. 5.2.5-8: Relationship between the measuring value and the output number (part 1)

Relationship between the measuring value and the output number, voltage input (analog representation b), temperature input (analog representation a or b)



Specifications of the platinum temperature sensors Pt100/Pt1000:

Pt100 = Platinum 100 Ω at 0 °C Measuring range -50...400 °C Current sink 2 mA
Pt1000 = Platinum 1000 Ω at 0 °C Measuring range -50...400 °C Current sink 0.2 mA

Specifications of the thermocouples of types J, K and S:

Type J = Fe-CuNi	0...1200 °C	Iron / Copper-Nickel	+ = Fe - = CuNi
Type K = NiCr-NiAl	0...1372 °C	Nickel-Chromium/Nickel-Aluminium	+ = NiCr - = NiAl
Type S = Pt10Rh-Pt	0...1600 °C	Platinum-10% Rhodium / Platinum	+ = Pt10Rh - = Pt

Fig. 5.2.5-9: Relationship between the measuring value and the output number (part 2)

Addressing

An address has to be set on each module, so that the central unit can access the inputs and outputs correctly.

A detailed description concerning the item "Addressing" is contained in the chapters "Addressing" of the central units and couplers. For setting the analog format (representation a and b) see Fig. 5.2.5–3.

The switches for setting the address are under the cover on the right side of the module housing (see Fig. 5.2.5–3). If the central units 07 KR 31, 07 KT 31, 07 KR 91, 07 KT 92 and 07 KT 93 are used as bus masters, the following address allocations are valid:

Central units 07 KR 31 / 07 KT 31 / 07 KR 91 / 07 KT 92 / 07 KT 93			
The address DIL switch No. 8 is set to OFF (recommendation):			
Chan.		Chan.	
E0	EW xx,00	E4	EW xx,04
E1	EW xx,01	E5	EW xx,05
E2	EW xx,02	E6	EW xx,06
E3	EW xx,03	E7	EW xx,07
The address DIL switch No. 8 is set to ON :			
Chan.		Chan.	
E0	EW xx,08	E4	EW xx,12
E1	EW xx,09	E5	EW xx,13
E2	EW xx,10	E6	EW xx,14
E3	EW xx,11	E7	EW xx,15
xx: Group number of the address, set on the address DIL switch with the switches 4...7. Recommended addresses with 07 KR 31 / 07 KT 31 / 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master: 00....05			

The module uses 8 analog inputs on the CS31 system bus.

Normal operation

- The module initializes itself after power ON. During initialization all LEDs are ON.
- If the CS31 system bus does not run, the LED ③ flashes. The error LED also light up, if an error occurs during initialization.

Diagnosis and displays

The module ICDT 08 B5 offers the following diagnosis functions:

- Detection of open circuit (broken wire), if Pt100/Pt1000 temperature sensors or thermocouples are used
- Storing and holding ready this information for interrogation (error type and error location)
- Detection of an error inside the module
- Detection of a transmission error


If one of these errors is detected, the red error LED lights up. **The error message is then sent to the central unit or to the coupler.**

- Open circuit (cut wire)

Error class 4 (FK4)		M 255,14
Error number: 09	→	MW 255,08
Device type: 05	→	MW 255,09
Group number (address):	→	MW 255,10
Channel number:	→	MW 255,11
- Overflow (out of range)

Error class 4 (FK4)		M 255,14
Error number: 10 dec.	→	MW 255,08
Device type: 05	→	MW 255,09
Group number (address):	→	MW 255,10
Channel number:	→	MW 255,11

By means of the test button all diagnosis functions can be selected for each channel. Pressing the test button the first time the channel 0 is selected: LED 0 flashes.



When releasing the test button, the error information belonging to this channel is displayed by the green LEDs 0 to 7 for a period of ca 3 seconds.

Meaning of the LEDs if lighting up:

- 0 Error inside the module (Unit error)
- 1 Error on the CS31 system bus (Bus error)
- 2 not used
- 3 Open circuit (Cut wire)
- 4 Overflow (Out of range)
- 5 not used
- 6 not used
- 7 not used

The meaning of the diagnosis LEDs is labelled on the front panel of the module in English.

The error messages on the module and in the central unit are reset again, when the errors have been eliminated, no new errors have occurred **and** the error elimination has been acknowledged.

Acknowledging an error after error elimination:

- by pressing the test button for a period of ca. 5 seconds or
- with the PC or
- with the PLC program in the central unit


Pressing and releasing the test button further times, the test procedure repeats for all of the other input channels.

After calling information from the last channel, a lamp test is carried out by pressing the test button the next time. All LEDs of the module must light up. After that, the positions of the address DIL switches (module address on the CS31 system bus) is displayed for a period of ca. 5 seconds. LED 0 shows the position of switch No. 1 (LEDs 0 to 7 belong to the switches 1 to 8).

Display of an analog value

When the test button is not pressed, 8 LEDs display the analog value of one selected channel roughly. Meaning of the LEDs:

- all LEDs OFF → minimum value
- all LEDs ON → maximum value



Minimum and maximum values are:

Configuration	Min. value all LEDs OFF	Max. value all LEDs ON
+/- 10 V	-10 V	+10 V
+/- 5 V	-5 V	+5 V
+/- 500 mV	-500 mV	+500 mV
+/- 50 mV	-50 mV	+50 mV
+/- 20 mA	-20 mA	+20 mA
0 V / 0 mA = 4 LEDs ON		
4...20 mA	4 mA	20 mA
12 mA = 4 LEDs ON		
Pt100 Pt1000	-50°C -50°C	-400°C -400°C
0°C = 1 LED ON		
Thermocouple type J	0°C	+1600°C
Thermocouple type K	0°C	+1600°C
Thermocouple type S	0°C	+1600°C
800°C = 4 LEDs ON		
Fig 5.2.5–12: Minimum and maximum values for the analog display		

Technical data ICDT 08 B5

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

General data of the module

Admissible temperature range, module in operation	0...65 °C
Rated supply voltage	24 V DC
Current consumption	max. 0.15 A
Power dissipation	max. 3 W
Overvoltage category	II according to IEC 1133, part 2 (system data)
Protection against reversed connection of supply voltage	yes
Conductor cross section for the removable terminal blocks	max. 2 x 2.5 mm ²
Number of analog input channels	8
Electrical isolation	CS31 system bus interface from the remaining module components
Address setting and configuration	with DIL switches located under the cover on the right side of the module housing
Diagnosis	see chapter "Diagnosis and displays"
Operating and error displays	17 LEDs altogether, see chapter "Diagnosis and displays"
Mechanical dimensions	120 x 140 x 85 mm
Weight	450 g
Order No.	GJR5 2516 00 R101

Technical data of the analog inputs (applies for all settings)

Number of channels per module	8 (configurable in pairs)
Electrical isolation	versus the CS31 system bus interface
Line frequency suppression	configurable for 50 Hz or 60 Hz or none
Input signal delay	0 (no RC combination)
Line frequency suppression (software filter)	20.0 ms with 50 Hz line frequency 16.7 ms with 60 Hz line frequency
Permissible overvoltage at the inputs	max. +/- 30 V
Refresh time per channel incl. input delay and conversion time	
– line frequency suppression 50/60 Hz	typ. 100 ms
– no line frequency suppression	typ. 30 ms
– if thermocouples are used with line frequency suppression 50/60 Hz	typ. 150 ms
The total refresh time will be shorter if not all of the channels are used (for configuration see Fig. 5.2.5–3).	

Voltage input

Input impedance	> 1 M Ω
Measuring ranges	rated values +/- 10 V, +/- 5 V, +/- 500 mV, +/- 50 mV
Permissible overvoltage at the inputs	max. +/- 30 V
Resolution	12 bits + sign
Total error	$\leq \pm 0.5$ % of full scale
Unused channels	have to be short-circuited

Current input 0...20 mA / 4...20 mA

By terminating the input terminals with a shunt, the voltage input can also be used for input currents. The following specifications are valid:

Current measuring range	0...20 mA	4...20 mA
Selected measuring range	+/- 5 V	4...20 mA
Required external shunt	250 Ω	250 Ω
Permissible overvoltage at the inputs	max. +/- 30 V	max. +/- 30 V
Destruction limits of the shunt	depends on its own specifications	
Total error	$\leq \pm 0.5$ % of full scale \pm tolerance of the shunt	

Pt100/Pt1000 input

Evaluation range with linearization	-50°C...+400°C
Resistance of the sensors within the evaluation range	
Pt100	80.31 Ω ...247.04 Ω
Pt1000	803.1 Ω ...2470.4 Ω
Resolution	12 bits + sign (1 LSB = 0.1°C)
Permissible total line resistance of both current-carrying lines	max. 50 Ω per sensor (in 4-wire configuration)
Evaluation error within the range of -50...+400°C (linearity, linearization, temperature range, resolution, adjustment)	Pt100: +/- 0.5 % of full scale Pt1000: +/- 1.0 % of full scale
Constant current sinks for the sensors	
Pt100	2 mA
Pt1000	0.2 mA
Power dissipation in the sensor	
Pt100	temperature = 0°C: 0.4 mW temperature = 400°C: 1.0 mW
Pt1000	temperature = 0°C: 0.04 mW temperature = 400°C: 0.1 mW
No-load voltage of the current output	< +15 V
Permissible total voltage drop at the sensors and lines circuited in series	max. 7,0 V (current sink 0.2 mA is used) max. 2,5 V (current sink 2.0 mA is used)
Cable length, if cables have been laid in parallel	
shielded	max. 50 m
two-core shielded and cross section ≥ 0.5 mm ²	max. 200 m

Unused input channels:

If unused Pt100/Pt1000 channels would be connected to a wire jumper, its resistance of 0 Ω would pretend the measuring value of a very low temperature. As a result, the error message "Underflow" would be output. In order to prevent such error messages, unused Pt100/Pt1000 channels should be terminated as follows:

Pt 100 by a resistor of 120 Ω
Pt 100 0 by a resistor of 1200 Ω

Connection of other temperature-dependent resistors:

In principle, all temperature-dependent resistors can be connected to the module instead of Pt100/Pt1000 sensors. As configurations, the settings ± 5 V, ± 500 mV and ± 50 mV are suitable. If necessary, the linearization of the temperature-resistance curve must be performed with the PLC program. The integrated current sinks can be used. In doing so, the following has to be observed:

- The voltage drop over all resistors circuited in series may not be greater than
7 V (using the current sink of 0.2 mA),
2.5 V (using the current sink of 2 mA).
- The tolerance of the integrated current sinks is $\pm 1,5$ %. There is no compensation by the module in this application. This is a difference compared with the Pt100/Pt1000 settings.

Connection of thermocouples

Possible thermocouples types J, K and S

Evaluation range with linearization

Type J	Fe-CuNi	0°C...+1200°C	at	0...57.942 mV
Type K	NiCr-NiAl	0°C...+1372°C	at	0...41.269 mV
Type S	Pt10Rh-Pt	0°C...+1600°C	at	0... 9.585 mV

The module has an internal reference junction. The temperature value of this junction is added to the temperature measured by the thermocouple.

Resolution 12 bits + sign (1 LSB = 0.4°C)

Evaluation error within the range of 0...+1600°C
(linearity, linearization, temperature range, resolution, adjustment) +/- 0.5 % of full scale

Cable length, if cables have been laid in parallel
shielded max. 50 m
two-core shielded and cross section ≥ 0.5 mm² max. 200 m

Unused channels have to be short-circuited

Connection to the ABB Procontic CS31 system bus

Interface standard EIA RS-485

Electrical isolation versus supply voltage and inputs



Mechanical data

Mounting on DIN rail according to DIN EN 50022-35, 15 mm deep.
The DIN rail is located in the middle between the upper and the lower edges of the module.

Fastening by screws using 4 M4 screws.

Width x height x depth 120 x 140 x 85 mm

Wiring method	by removable terminal blocks with screw-type terminals,
conductor cross section	max. 2 x 2.5 mm ²
Weight	450 g
Outline dimensions (for mounting)	see the drawing on the next page
Mounting hints	
Mounting position	vertical, terminals above and below
Cooling	The natural convection cooling must not be hindered by cable ducts or other material mounted in the switchgear cabinet.
Ordering data	
Module ICDT 08 B5	Order No. GJR5 2516 00 R101
Scope of delivery	Analog input module ICDT 08 B5 1 3-pole terminal block 3 5-pole terminal blocks 2 9-pole terminal blocks



The module is 85 mm deep.

If a DIN rail is used, the mounting depth is increased by the overall depth of the rail.

Fig. 5.2.5-13: ICDT 08 B5, Front foil and outline dimensions, **the dimensions for assembly bore holes are printed in bold.**

5.2.6 ICST 08 A7 8 inputs PT100, 8 bits

Analog Input remote unit


The analog input remote unit can be used for measurement of temperature. The inputs have to be connected to the PT 100 sensors (2 or 3 wires) according the IEC 751 standard (class A and class B).

The range of temperature is : $-30\text{ °C} \dots +20\text{ °C}$
($-22\text{ °F} \dots +68\text{ °F}$)

Description of the unit front :

- Ten status led's:
 - Eight yellow input status led's «I0» to «I7»①
 - Two green power supply led's «+ 5 V», «± 15 V».....②
 - Six yellow led's to display the signal value of inputs③
 - «TEST» push-button④
 - Red error led.....⑤
 - List of error codes⑥

The unit has to be mounted on a plug-in base ECZ



8 analog inputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	8	8
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	no	no
Power supply output	no	no
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.8 W	8 W
Order number : FPR 333 5701	R1012	R0016/R0014
Weight (kg)	0.25	0.43

INPUT SPECIFICATIONS

Nominal scale

- 30 °C ... + 20 °C (- 22 °F ... + 68 °F)

Maximum value

+ 21.88 °C

Minimum value

- 34.16 °C

Offset

0 °C

Resolution : 8 bits

0.11 °C

Accuracy on full scale

(out of the allowance on sensor and for an ambient temperature of the unit for 0 °C ... +55 °C (+32 °F ... +131 °F))

± 1 °C

Allowance on sensor

- type A (IEC 751)

± 0.5 °C on full scale

- type B (IEC 751)

± 1 °C on full scale

Ohmic value of the PT 100 sensor

86.6 ... 108.9

Temperature coefficient

100 ppm/ °C

Max refresh time





300 ms for 8 channels

- * The different characteristics are available on the used range 0 °C ... + 55 °C (+32 °F ... + 131 °F) of the remote unit.
- * The no linearity of the sensor is compensated.

● Electrical connection

"3 wires" connection

"2 wires" connection



• Initialization

- The unit initializes itself after power ON.
- The error led goes out after initialization.

The value of the analog input I0 is displayed on the 6 led's on the right and the led's «+ 5 V» and «± 15 V» are illuminated.

• Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS	07 KR 31	07 KR 91 07 KT 92 07 KT 93	UCZA/UCZB		PCZB	
Address xx on the plug-in base ECZ	00 ... 05 08 ... 15	00 ... 05	even 00 ... 14		1 ... 8	
Switch N. 8 on the plug-in base	OFF	ON	OFF	ON	OFF	
Input	A	EWxx, 00	EWxx, 08	EAx, 00	EAx, 08	I Ax0
	B	EWxx, 01	EWxx, 09	EAx, 01	EAx, 09	I Ax1
	C	EWxx, 02	EWxx, 10	EAx, 02	EAx, 10	I Ax2
	D	EWxx, 03	EWxx, 11	EAx, 03	EAx, 11	I Ax3
	E	EWxx, 04	EWxx, 12	EAx, 04	EAx, 12	I Ax4
	F	EWxx, 05	EWxx, 13	EAx, 05	EAx, 13	I Ax5
	G	EWxx, 06	EWxx, 14	EAx, 06	EAx, 14	I Ax6
	H	EWxx, 07	EWxx, 15	EAx, 07	EAx, 15	I Ax7


In the case of UCZA/UCZB, the addresses 08 ... 14 are only allowed with the SCZ unit.
For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description.

ANALOG INPUTS 8 BITS

Input range – 30 °C ... + 20 °C (– 22 °F ... + 68 °F)
 Resolution 0.11 °C
 Maximum 21.88 °C
 Minimum – 34.16 °C

Bits of analog word	Range least significant byte and for central units UCZA/UCZB		Range most significant byte	
	°C	°F	°C	°F
B15	– 157.00 °C	(– 250.60 °F)	– 157.00 °C	(– 250.60 °F)
B14	**	**	**	(173.30 °F)
B13	**	**	**	(102.65 °F)
B12	**	**	19.63 °C	(67.33 °F)
B11	**	(173.30 °F)	9.81 °C	(49.66 °F)
B10	**	(102.65 °F)	4.91 °C	(40.84 °F)
B9	19.63 °C	(67.33 °F)	2.45 °C	(36.41 °F)
B8	9.81 °C	(49.66 °F)	1.23 °C	(34.21 °F)
B7	4.91 °C	(40.84 °F)	0.61 °C	(33.10 °F)
B6	2.45 °C	(36.41 °F)	0.31 °C	(32.56 °F)
B5	1.23 °C	(34.21 °F)	0.15 °C	(32.27 °F)
B4	0.61 °C	(33.10 °F)	0.08 °C	(32.14 °F)
B3	0.31 °C	(32.56 °F)	0.04 °C	(32.07 °F)
B2	0.15 °C	(32.27 °F)	0	0
B1	0.08 °C	(32.14 °F)	0	0
B0	0.04 °C	(32.07 °F)	0	0

The choice of setting of the dip switches 2 and 3 on the plug-in base gives two different tables.
 (See chapter 5.1, volume 2 "General")



Approximate function

$$T \text{ } ^\circ\text{C} = 0.0383 \text{ VAL}$$


VAL : input word after conversion and linearity correction.

T °C : temperature in degree Celsius

Use the following formula to get the temperature in degree Fahrenheit :

$$^\circ\text{F} = \frac{9}{5} \text{ } ^\circ\text{C} + 32$$

Range least significant byte and UCZA/UCZB



Approximate function

$$T \text{ } ^\circ\text{C} = 0.0048 \text{ VAL}$$

VAL : input word after conversion and linearity correction.



T °C : temperature in degree Celsius

Use the following formula to get the temperature in degree Fahrenheit :

$$^\circ\text{F} = \frac{9}{5} \text{ } ^\circ\text{C} + 32$$

Range most significant byte

The value of input selected by pressing the «**TEST**» button can be displayed on the 6 led's on the right. These 6 led's have the following meaning :



Each channel can be selected by pressing the «**TEST**» button.

Channel I0 is always displayed after initialization until otherwise selected.

Fault indication:

- Led 0 : «**Unit error**»
- Led 1 : «**Bus error**»
- Led 4 : «**Out of range**»

Led 4 «**OFF**» : the channel is wired and the temperature is in the due range.

Led 4 «**ON**» : measure out of range or short circuit detection (If VAL VAL MIN), or open circuit detection (If VAL VAL MAX).

If an error occurs, (see chapter 9, volume 2, «**In case of failure**»).

5.3.1 ICSA 04 B5 4 outputs, 12 bits

Analog Output remote unit


The analog output remote unit can be used for $\pm 10\text{ V}$, $\pm 12.5\text{ V}$, $0 \dots 20\text{ mA}$ or $4 \dots 20\text{ mA}$.

The wiring on the plug-in base ECZ is used to select the current or voltage input.

The unit is configured by the dip switches in the rear of the unit. The configuration by the central unit is not necessary.

Description of the unit front :

- Four yellow output status led's «O0» to «O3»①
- Two inactive led's
- Two green power supply led's «+ 5 V», «± 15 V» ②
- Eight yellow led's to display the signal value of outputs③
- «TEST» push-button ④
- Red error led ⑤
- List of error codes ⑥



The unit has to be mounted on a plug-in base ECZ.


4 analog outputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of outputs per unit	4	4
Power supply isolation	no	yes (1500 VAC)
Outputs opto-isolated	no	no
Power supply outputs 10 VDC ($\pm 1\%$)	no	no
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.8 W	8 W
Order number : FPR 334 1501	R1042	R0046/R0044
Weight (kg)	0.25	0.43

OUTPUT SPECIFICATIONS

Nominal range	$\pm 10 \text{ V}$	$\pm 12.5 \text{ V}$	$0 \dots 20 \text{ mA}$	$4 \dots 20 \text{ mA}$
Resolution : 12 bits	$\pm 1 \text{ LSB}$ ($\pm 5 \text{ mV}$)	$\pm 1 \text{ LSB}$ ($\pm 6 \text{ mV}$)	$\pm 1 \text{ LSB}$ ($\pm 10 \mu\text{A}$)	$\pm 1 \text{ LSB}$ ($\pm 8 \mu\text{A}$)
Linearity error	$\pm 1 \text{ LSB}$ ($\pm 5 \text{ mV}$)	$\pm 1 \text{ LSB}$ ($\pm 6 \text{ mV}$)	$\pm 1 \text{ LSB}$ ($\pm 4.8 \mu\text{A}$)	$\pm 1 \text{ LSB}$ ($\pm 4 \mu\text{A}$)
Error of maximum value	$\pm 0.3 \%$	$\pm 0.5 \%$	$\pm 0.5 \%$	$\pm 0.5 \%$
Temperature coefficient	100 ppm/K	100 ppm/K	100 ppm/K	100 ppm/K
Maximum load current	$\pm 2 \text{ mA}$	$\pm 2 \text{ mA}$	–	–
Resistance of the load circuit	–	–	500	500



• Electrical connection



• Initialization

The selection between current or voltage output is dependent upon the dip switches in the rear of the unit. Two switches for one channel :

- N° 1 : channel 00
- N° 2 : channel 00
- N° 3 : channel 01
- N° 4 : channel 01
- N° 5 : channel 02
- N° 6 : channel 02
- N° 7 : channel 03
- N° 8 : channel 03



The factory default setting is $\pm 10\text{V}$.

The commons are internally connected.

NOTE : Channels 19 to 30 are the same as 4 to 15.

The wires for analogue outputs must be shielded and the shield has to be connected to the earth on the side of the remote unit.

Possible configuration

dip switch	output current	output voltage
OFF ON 	0 ... 16 mA*	± 10 V
OFF ON 	4 ... 20 mA	± 10 V
OFF ON 	4 ... 25 mA*	± 12.5 V
OFF ON 	0 ... 20 mA	± 12.5 V

* For this special format the output conversion tables are not allowed.

The unit initializes itself after power on.

The error led goes out after initialization.

The value of the analog output O0 is displayed on the 8 led's on the right and the led's "+ 5 and ± 15" are illuminated.



• Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91, 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 05		even 00 ... 14		1 ... 8
Switch N. 8 on the plug-in base		OFF	ON	OFF	ON	OFF
Output	A	AWxx, 00	AWxx, 08	AAxx, 00	AAxx, 08	OAx0
	B	AWxx, 01	AWxx, 09	AAxx, 01	AAxx, 09	OAx1
	C	AWxx, 02	AWxx, 10	AAxx, 02	AAxx, 10	OAx2
	D	AWxx, 03	AWxx, 11	AAxx, 03	AAxx, 11	OAx3

In the case of UCZA/UCZB, the addresses 08 ... 14 are only allowed with the SCZ unit.

For the PC board 07 CM 90 and the coupler boards 07 CS 61 or 35 CS 91, refer to their own description.

The value of the output selected by pressing the "TEST" button can be displayed on the 8 leds on the right. These 8 led's have the following meaning :



no led ON ○○○○○○○○	4 led's ON ●●●●○○○○	8 led's ON ●●●●●●●●	Configuration
- 10 V - 12.5 V	0 V	+ 10 V + 12.5 V	± 10 V ± 12.5 V
-	0 mA	20 mA	0 ... 20 mA
-	0 mA	16 mA	0 ... 16 mA
-	4 mA	20 mA	4 ... 20 mA
-	4 mA	25 mA	4 ... 25 mA

Each channel can be displayed by pressing the "TEST" button.

The channel 00 is always displayed after initialization until otherwise selected.

Fault indication:

- Led 0 : «Unit error»
- Led 1 : «Bus error»
- Led 2 : «15 V Fail»
- Led 3 : «Output error»

The configuration of each channel is indicated by the led's 4 and 5.

- Led 4 : «4 ... 20»
Current configuration 4 ... 20 mA or ± 12.5 V

Led 4 «OFF» :
Channel 0 ... 20 mA or ± 10 V, depends upon the dip switches in the rear of the unit.

Led 4 «ON» :
Channel 4 ... 20 mA or ± 12.5 V, depends upon the dip switches in the rear of the unit.

Led 5 «± 10 V» :
± 10 V configuration.

Led 5 «OFF» :
Current or ± 12.5 V configuration.

Led 5 «ON» :
Channel ± 10 V.

If an error occurs, (see chapter 9, volume 2 «In case of failure»).

NOTE : The 4 ... 20 mA configuration with an handheld programming unit TCZ or CS 31 configuration functions (see chapter 2, volume 2 «Central Unit») is necessary for detecting error (open circuit detection),

5.4.1 ICSM 06 A6 4 inputs, 2 outputs, 8 bits

Analog Input/Output remote unit

The analog output channels can be used for 0 ... 10 V, 0 ... 20 mA or 4 ... 20 mA. The wiring on the plug-in base ECZ enables the choice of current or voltage channel.


The unit is configured for 0 ... 20 mA or 4 ... 20 mA current ranges with an handheld programming unit (TCZ) or CS 31 configuration functions (see chapter 2, volume 2 «Central Unit»).

The factory default setting is 0 ... 20 mA.

Description of the unit front :

- Eight status leds :
 - Two yellow input status leds «O0» and «O1»①
 - Four yellow input status leds «I0, I1, I2, I3, I4» ... ②
 - Two green power supply leds «+ 5 V», «± 15 V».... ③
- Eight yellow leds to display the signal value of inputs or outputs ④
- «TEST» push-button⑤
- Red error led ⑥
- List of error codes ⑦

The unit has to be mounted on a plug-in base ECZ.



4 analog inputs and 2 analog outputs per unit

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Number of inputs per unit	4	4
Power supply isolation	no	yes (1500 VAC)
Inputs opto-isolated	no	no
Power supply output 10 VDC ($\pm 1\%$)	50 mA	50 mA
Number of outputs per unit	2	2
Outputs electrically isolated	no	no
Maximum power consumption	0.2 A	10 VA
Maximum power dissipation	4.8 W	8 W
Order number : FPR 335 0601	R1062	R0066/R0064
Weight (kg)	0.25	0.43


INPUT SPECIFICATIONS

Nominal range	0 ... 10 V	0 ... 20 mA	4 ... 20 mA
Maximum value	12 V	25 mA	25 mA
Minimum value	- 5 V	- 10 mA	- 10 mA
Input resistance	100 k	250	250
Resolution : 8 bits	± 1/2 LSB (± 19.6 mV)	± 1/2 LSB (± 40 µA)	± 1/2 LSB (± 31 µA)
Linearity error	± 3/4 LSB (± 29.4 mV)	± 3/4 LSB (± 60 µA)	± 3/4 LSB (± 47 µA)
Error of maximum value	± 0.5 %	± 0.8 %	± 0.8 %
Amplification error between two channels	1 LSB (39 mV)	1 LSB (62 µA)	1 LSB (62 µA)
Temperature coefficient	100 ppm/K	150 ppm/K	150 ppm/K
Time constant of input filter	100 ms	20 ms	20 ms
Max refresh time	10 ms	10 ms	10 ms

OUTPUT SPECIFICATIONS

Nominal range	± 10 V	0 ... 20 mA	4 ... 20 mA
Resolution : 8 bits	± 1/2 LSB (± 40 mV)	± 1/2 LSB (± 40 µA)	± 1/2 LSB (± 31 µA)
Linearity error	± 1 LSB (± 80 mV)	± 1 LSB (± 80 µA)	± 1 LSB (± 62 µA)
Error of maximum value	± 1 %	± 1 %	± 1 %
Temperature coefficient	100 ppm/K	150 ppm/K	150 ppm/K
Maximum load current	± 2 mA	–	–
Resistance of the load circuit	–	500	500

● **Electrical connection**




(1) For the current input unit, a jumper is required.

The commons 0 V are internally connected.

The function of each channel depends on the wired terminals.

● **Connections of input A :**



The wires for analogue inputs or output must be shielded and the shield has to be connected to the earth on the side of the remote unit.

● **Selection current or voltage**

The selection between current or voltage input is dependent upon the wiring on the plug-in base. When the unit is configured for 4 ... 20 mA, the ranges available are shown in the table below. The analog outputs must be configured as the factory default setting is ± 10 V.

	Terminal	Configuration 0 ... 20 mA	Configuration 4 ... 20 mA
Inputs			
A	5 and 4	0 ... 10 V	2 ... 10 V
	5 and 7	0 ... 5 V (2)	1 ... 5 V
	5 + 6 and 7	0 ... 20 mA	4 ... 20 mA
B	9 and 8	0 ... 10 V	2 ... 10 V
	9 and 11	0 ... 5 V (2)	1 ... 5 V
	9 + 10 and 11	0 ... 20 mA	4 ... 20 mA
C	13 and 12	0 ... 10 V	2 ... 10 V
	13 and 15	0 ... 5 V (2)	1 ... 5 V
	13 + 14 and 15	0 ... 20 mA	4 ... 20 mA
D	28 and 27	0 ... 10 V	2 ... 10 V
	28 and 30	0 ... 5 V (2)	1 ... 5 V
	28 + 29 and 30	0 ... 20 mA	4 ... 20 mA
Outputs			
E	21 and 23	0 ... 20 mA	4 ... 20 mA
	22 and 23	- 10/+ 10 V	- 6/+ 10 V
F	24 and 26	0 ... 20 mA	4 ... 20 mA
	25 and 26	- 10/+ 10 V	- 6/+ 10 V

(2) Note : The range 0 ... 5 V can be used for special application.

● Initialization

The unit initializes itself after power on.

The error led goes out after initialization. The value of the analog output 00 is displayed on the 8 led's on the right and the led's «+ 5V» and «± 15V» are illuminated.

● Utilization

VARIABLES USED IN THE CENTRAL UNIT						
CENTRAL UNITS		07 KR 31, 07 KR 91, 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ		00 ... 05		even 00 ... 14		1 ... 8
Switch N. 8 on the plug-in base		OFF	ON	OFF	ON	OFF
Input	A	EWxx, 00	EWxx, 08	EAx, 00	EAx, 08	IAx0
	B	EWxx, 01	EWxx, 09	EAx, 01	EAx, 09	IAx1
	C	EWxx, 02	EWxx, 10	EAx, 02	EAx, 10	IAx2
	D	EWxx, 03	EWxx, 11	EAx, 03	EAx, 11	IAx3
Output	A	AWxx, 00	AWxx, 08	AAx, 00	AAx, 08	OAx0
	B	AWxx, 01	AWxx, 09	AAx, 01	AAx, 09	OAx1

In the case of UCZA/UCZB, the addresses 08 ... 14 are only allowed with the SCZ unit.
For the PC board 07 CM 90 and the coupler boards 07 CS 61 or 35 CS 91, refer to their own description.

● Specific configuration : ICSM 06 A6 as binary remote unit

The ICSM 06 A6 remote unit can be used as a binary remote unit on the CS31 bus.

This specific configuration allows the connection of 31 analog remote units on CS31 bus instead of 12.


That means that all analog values can be sent or received by the central unit as binary values.

The analog/binary and binary/analog conversions are realized by the remote unit.

The setting of binary configuration is with the dip switches 2 and 3 of the plug-in base on ON position.

In this case (binary configuration), only the even addresses are allowed and the real address of the remote unit is obtained by the physical address multiplied by 2.

For example :



● Utilization

VARIABLES USED IN THE CENTRAL UNIT				
CENTRAL UNITS		07 KR 31, 07 KR 91, 07 KT 92, 07 KT 93	UCZA/UCZB	PCZB
Physical address y on the plug-in base ECZ		00 ... 15	00 ... 15	00 ... 15
Address in the central unit $xx = y \times 2$		00 ... 30	xx : 00 ... 30	xx : 00 ... 30
Switch N. 8 on the plug-in base		OFF	OFF	OFF
Input	A	E _{xx} , 00 E _{xx} , 07	E _{xx} , 00 E _{xx} , 07	I _{xx} 00 I _{xx} 07
	B	E _{xx} , 08 E _{xx} , 15	E _(xx+1) , 00 E _(xx+1) , 07	I _{xx} 08 I _{xx} 15
	C	E _(xx+1) , 00 E _(xx+1) , 07	E _(xx+2) , 00 E _(xx+2) , 07	I _(xx+1) 00 I _(xx+1) 07
	D	E _(xx+1) , 08 E _(xx+1) , 15	E _(xx+3) , 00 E _(xx+3) , 07	I _(xx+1) 08 I _(xx+1) 15
Output	A	A _{xx} , 00 A _{xx} , 07	A _{xx} , 00 A _{xx} , 07	O _{xx} 00 O _{xx} 07
	B	A _{xx} , 08 A _{xx} , 15	A _(xx+1) , 00 A _(xx+1) , 07	O _{xx} 08 O _{xx} 15



For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description.

Note : This specific configuration allows a high number of remote units on CS31 bus with the 07 CS 61 coupler. The ICSM 06 A6 uses only 64 I/O points (instead of 128). The code for T200 configuration table is EA32.

The mode 4 - 20 mA has to be set in analog configuration by the central unit then, the switches 2 and 3 are moved in ON position.

In mode 4 - 20 mA, it is not possible to detect on opened circuit. The value is always 0 and never negative.

The value of the input or output selected by pressing the "TEST" button can be displayed on the 8 led's on the right. These 8 led's have the following meaning :



Fault indication:

- Led 0 : «Unit error»
- Led 1 : «Bus error»
- Led 2 : «10 V Fail»
- Led 3 : «Output error»

The configuration of each channel is indicated by the led's 4 and 5 :

- Led 4 : «4 ... 20»
Current configuration 4 ... 20 mA
- Led 5 «± 10 V» :
± 10 V Voltage configuration (only for outputs).
- Led's 4 and 5 «OFF» :
0 ... 20 mA configuration.

If an error occurs, (see chapter 9, volume 2 «In case of failure»).

Analog inputs

no led ON ○○○○○○○○	4 led's ON ●●●●○○○○	8 led's ON ●●●●●●●●	Configuration
0 V	5 V	10 V	0 ... 20 mA
0 V	2.5 V	5 V	
0 mA	10 mA	20 mA	
2 V	6 V	10 V	4 ... 20 mA
1 V	3 V	5 V	
4 mA	12 mA	20 mA	

Analog outputs

no led ON ○○○○○○○○	4 led's ON ●●●●○○○○	8 led's ON ●●●●●●●●	Configuration
- 10 V	0 V	10 V	± 10 V
0 mA	10 mA	20 mA	0 ... 20 mA
4 mA	12 mA	20 mA	4 ... 20 mA

Each channel can be displayed by pressing the "TEST" button.

The channel 00 is always displayed after initialization until otherwise selected.

Chapter	Description	Page
6.1	ICSF 08 D1 : high speed counter	6.1-1
6.2	TCAD : Remote display	6.2-1
6.3	CS31 Bus units	
6.3.1	NCB : CS31 Bus Amplifier	6.3.1-1
6.3.2	NCBR : CS31 Bus Amplifier with redundancy	6.3.2-1

6.1 ICSF 08 D1 High speed counter

Special remote unit

This unit can count three channels A, B and C at high speed.

Five modes of operation are possible :

- 32 bit counter incremental encoder input
- 32bit counter, incrementing on channel A and decrementing on channel B
- 32 bit counter, addition of channels A and B
- Three independant 16 bit counters for channel A, B and C
- Three 16 bit frequency meters for channels A,B and C

The mode of operation is selected by setting the DIP switches on the rear of the unit.

The counters can be set to detect rising, falling or rising and falling edges.


4 binary inputs for counter data setting and 7 binary static outputs are provided.

The status of the outputs is determined by the comparison of the counter(s) and setpoint values and the count direction.

The unit has to be mounted on a plug-in base ECZ.

Description of the unit front :

- Six yellow leds for outputs status①
- One yellow led for "UP" for count direction②
- Four yellow leds for inputs status③
- One green led "SUPPLY"④
- "TEST" push button⑤
- One error red led⑥
- List of the error codes⑦



high speed counter

TECHNICAL CHARACTERISTICS		
Power supply	24 VDC	230 VAC/120 VAC
Max counting frequency	50 kHz	50 kHz
Number of counter inputs (depends on the selected mode)	1 or 3*	1 or 3*
Number of binary inputs	4	4
Number of binary outputs	7	7
Isolated power supply of the unit	no	yes (1500 VAC)
Isolated inputs/outputs	no	no
Isolated power supply output (max. 2 W)		
- 24 VDC (not regulated)	no	} Max. 2 an total
- 15 VDC (± 5%)	50 mA	
- 5 VDC (±5 %)	200 mA	
Max power consumption	5 W	10 VA
Order number FPR3323101	R1012	R0016/R0014
Weight (kg)	0.25	0.43

COUNTER INPUT CHARACTERISTICS

Differential mode (connection of a incremental encoder \overline{AA} , \overline{BB} , \overline{CC})

Mini voltage	$\pm 1 \text{ V}$
Max voltage	$\pm 15 \text{ V}$

For all others modes (connection between 0 V and A, B, C)

Nominal voltage	15 V
Max voltage	+ 30 V
Min voltage	+ 8 V
Nominal voltage	5 V
Max voltage	+ 10 V
Min voltage	+ 3.2 V

TECHNICAL CHARACTERISTICS

Binary input characteristics

VALID	terminal 29	count enable
RPI	terminal 14	reference point initiator
RESET	terminal 15	reset the counter
SET	terminal 30	Set the counter with the set point

Nominal voltage 24 VDC

signal level of the inputs,nominal value

Signal 0	- 3 to + 5 V
Signal 1	+ 15 to + 30 V

Current input for 24 VDC 6 mA

Input delay 1 ms

Binary output characteristics

= 0	terminal 21	Counter = 0
> 0	terminal 22	Counter > 0
= C1	terminal 23	Counter = threshold 1
> C1	terminal 24	Counter > threshold 1
= C2	terminal 25	Counter = threshold 2
> C2	terminal 26	Counter > threshold 2
UP	terminal 27	Direction of counter

Nominal voltage 24 VDC

Max current 300 mA

short circuit protection yes


● Electrical connection

The common "-" terminals and the "0V" terminals are not internally connected.

Power supply 24 VDC

The common "+" must be connected to the 24VDC of the 24VDC power supply.

Power supply 230 VAC and 120 VAC



Note : When using the 230 VAC or 120 VAC versions, the internal 24 VDC supply can be used providing the load if it is not greater than 50 mA ; if it is, an external 24 VDC power supply must be used.

The 0 VDC of an external power supply used only to provide the outputs has not to be connected to the common -, if the outputs have to be reset to 0 with a power off of this supply.

If the load is inductive, the common - and the 0V terminals must be connected together to avoid overvoltage within the output circuitry an free weeling diode is built-in, this however increases the response time.

● Initialization

After configured and wired the unit :

- the unit initializes itself after power **On**.
- the error led goes out after initialization.
- the counters, the thresholds are reset to 0 and the target window to 2.

● Utilization


VARIABLES USED IN THE CENTRAL UNIT					
CENTRAL UNITS	07 KR 31, 07 KR 91 07 KT 92, 07 KT 93		UCZA/UCZB		PCZB
Address xx on the plug-in base ECZ	00 ... 05		01, 03, 05		1 ... 8
Switch N° 8 on the plug-in base ECZ	OFF	ON	OFF	ON	OFF
Inputs					
Counter (high word)	EWxx, 00	EWxx,08	EWxx, 00	EWxx, 08	IAX0
Counter (low word)	EWxx, 01	EWxx,09	EWxx, 01	EWxx, 09	IAX1
Counter (high word)	EWxx, 02	EWxx,10	EWxx, 02	EWxx, 10	IAX2
Status of binary I/O	EWxx, 03	EWxx,11	EWxx, 03	EWxx, 11	IAX3
Configuration & diagnosis	EWxx, 04	EWxx,12	EWxx, 04	EWxx, 12	IAX4
Outputs					
Command	AWxx, 00	AWxx,08	AWxx, 00	AWxx, 08	OAX0
Parameter 1	AWxx, 01	AWxx,09	AWxx, 01	AWxx, 09	OAX1
Parameter 2	AWxx, 02	AWxx,10	AWxx, 02	AWxx, 10	OAX2

In the case of UCZA/UCZB, the addresses 9,11,15 are only allowed with the SCZ unit.

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

Switches' configuration

– Dip-switches on the plug-in base ECZ







– Dip-switches on the rear of the remote unit

The possible configuration are :

Dip-switches	OFF	ON
1	Input A set at 5V	Input A set at 12-30 V
2	Input B set at 5V	Input B set at 12-30 V
3	Input C set at 5V	Input C set at 12-30 V
4	Increment counter	Decrement counter
5 (*)	Counter x 2	Counter x 1
6 (*)	Count on rising edge	Count on falling edge
7	Count on all edges x 4	Allow n° 5 and 6
8	Incremental mode	Other modes

(*) Only if dip-switch n° 7 is on


Setting of different modes



For the setting of switches 5, 6 and 7 refer to the description of different modes.

INPUTS

Interdependance between the inputs A,B,C,VALID,SET,RESET and RPI.



The input RPI enables the input C only for the modes 1, 2 or 3.

The input RPI has not to be connected (OV) for the modes 4 and 5.

Status of binary Inputs and Outputs

The status of the binary inputs and outputs is written to the following word :

EW xx,03, EWxx,11, IAx3

where xx is the address of the remote unit selected on the plug-in base ECZ.

Composition of the word

B0	"Data transfer status" 0 = busy 1 = free
B1	SET
B2	RESET
B3	RPI
B4	VALID
B5	-
B6	-
B7	-
B8	= 0
B9	> 0
B10	= C1
B11	> C1
B12	= C2
B13	> C2
B14	"UP" 0 = decrement 1 = increment
B15	-

Bit B0 indicates the data transfer status and is checked to sending parameters and commands from the central unit to the counter unit.

Bits B1 to B4 indicate the status of the binary inputs.

Bits B8 to B14 indicate the status of the transistor outputs.

If the input valid is off, all binary outputs are reset to 0 but the internal status B8 - B14 is always available.

Configuration and diagnosis

The configuration and diagnosis are accessed with the following words.

EW xx,04, EWxx,12, IA y4

where xx is the address of the remote unit selected on the plug-in base ECZ.

Composition of the word

B0	short-circuit on the output "= 0"
B1	short-circuit on the output "> 0"
B2	short-circuit on the output "= C1"
B3	short-circuit on the output "> C1"
B4	short-circuit on the output "= C2"
B5	short-circuit on the output "> C2"
B6	short-circuit on the output "UP"
B7	"OVERLOAD"
B8	Mode 32 bits or 2 x 16 bits
B9	Dip-switch n°6
B10	Dip-switch n°7
B11	Dip-switch n°8
B12	Dip-switch n°5
B13	Dip-switch n°4
B14	-
B15	"OVERFLOW"

B7 : "OVERLOAD" is set when the temperature of the unit is too high. All of then outputs are reset to "0".

B15 : "OVERFLOW" indicate a counter error , when the counter value exceeds the maximun or when the counter frequency is too high.

B8 : indicate the mode operation for the counter (DIP-switch n°2 on the plug in base).

– B8 = 0 mode 32 bits (DIP switch n° 2 on "ON")

– B8 = 1 mode 2 x 16 signed bits(DIP switch n° 2 on "OFF")

In the mode 2 x 16 bit. The high word represents the number of positive or negative overflows of the low word.

The high word is incremented with a positive overflow on the transition from + 32767 à – 32768 of the low word. In a similar manner the high word is decremented on the transition from – 32768 à + 32767of the low word.

Example :

High word = + 6 (6 positive overflows)

Low word = + 18000.

$(6 \times 32767) + 18000 = 214602 = \text{value of counter}$

B9 to B13 : these bits indicate the positions of the dip-switches on the rear of the counter unit.

If the bit is 1, the dip-switch is on position "ON".

Transfer of command

The time required to transfer commands to the counter unit depends upon the configuration of the installation (n° of units on the bus).

It is necessary to have a short delay between two different transfers to ensure correct operation.

- First possibility

Start a timer for 50-100 milliseconds after each transfer and wait until the time is elapsed before transferring the next command.


- Second possibility

Use the internal protocol of the remote unit (Bit 0 of the binary input/output status word).

This bit is called the "Data transfer status".

Data transfer status = "0" ⇒ Executing command


Data transfer status = "1" ⇒ Executing complete



Before using a new command (to send new parameters), the value 0 has to be loaded in the command word.

Example :

Transfert the setpoint 2000 then the target window 6.




The different parameters for the modes 1, 2 or 3 are :

Command	Parameter 1	Parameter 2	
0	-	-	No command (used with the protocol for sending the command)
1	High word	Low word	Load threshold 1 with the highword lowword value
2	High word	Low word	Load threshold 2 with the highword lowword value
3	High word	Low word	Set point value, enabled by binary set input
4 (*)	-	0 to 255	Set the target window of the counter maximum value 255 (= ± 127)
5	-	-	Reset the counter value to "0" (independant of input VALID)
6	High word	Low word	Set the counter with the value (independant of input VALID)

(*) the counter content is continuously compared to 0 and the two thresholds, one target window can be loaded via the bus, wich defines the width of the comparing windows. The following diagram shows an example.

The factory default is 2 (± 1).



The different parameters for the mode 4 are :

Counter A

Command	Parameter 1	Parameter 2	
410	-	-	reset
411	-	data (16 bits)	set the counter to the value data
412	-	data (16 bits)	setpoint value, enabled by binary set and valid inputs
413	-	data (16 bits)	Load threshold A, result on outputs = C1 and > C1

Counter B

Command	Parameter 1	Parameter 2	
420	-	-	reset
421	-	data (16 bits)	set the counter to the value data
422	-	data (16 bits)	setpoint value, enabled by binary set and valid inputs
423	-	data (16 bits)	Load threshold B, result on outputs = C2 and > C2

Counter C

Command	Parameter 1	Parameter 2	
430	-	-	reset
431	-	data (16 bits)	set the counter to the value data
432	-	data (16 bits)	setpoint value, enabled by binary set and valid inputs
433	-	data (16 bits)	Load threshold C, result on outputs = 0 and > 0

The different parameters for the mode 5 are :

The different commands for the frequency meters are the same as the commands for the 3 counters(mode 4)

The period is loaded with the command = 400 and parameter 2 = data
(period = data* 100 ms)

precision:

3/100 for 100 ms

3/1000 for 1 s


3/10000 for 10 s

3/100000 for 100 s


Mode 1 : 32 bit counter for incremental encoder

Configuration

Setting the DIP switches in the rear of the remote unit




counting inputs A and B



The above shown pulse diagram results in counting upwards. The counting direction can be reversed by interchanging inputs A and B.

Relationship between RPI (reference point initiator) and C (zero point).

In order to reset the counter to 0 when crossing the machine zero point, the inputs RPI and C are used.




The falling edge of C resets the counter to 0 while RPI is ON. The signal C must not occur twice or more times within one period of RPI. The VALID must be ON.

Mode 2 : 32 bit counter, incrementing one channel A and decrementing on channel B.

Configuration

Setting the DIP switches in the rear of the remote unit counting inputs A and B




Impulses on input A count upwards, impulses on input b count downwards. Depending on the setting of the DIP switches, rising edges, falling edges or both edges trigger counting.

The inputs C and RPI have the effects as mode 1.

Mode 3 : 32 bit counter addition of channel A and B

Configuration

Setting the DIP switches in the rear of the remote unit




counting inputs A and B

Impulses on input A and B count upwards. Depending on the setting of the DIP switches, rising edges, falling edges or both edges trigger counting.

The inputs C and RPI have the effects as mode 1.


Mode 4 : 3 independant 16 bits counters on rising edge on channels A, B and C.

Configuration



Each counter counts from 0 or from the initial value.

When the counter counts from +32767 to -32768, the overflow error is not generated.




A hardware reset resets the 3 counters in one time.
A hardware set sets the 3 counters in one time.

The comparison between each counter and the corresponding threshold is signed.

The 3 counters are used with the following variables :
Counter A : EWxx,00
Counter B : EWxx,01
Counter C : EWxx,02

Mode 5 : 3 independant 16 bits frequency meters


Configuration



The 3 frequency meters are independant and their functions are the same as mode 4.

The measurement period is the same for the 3 counters and the range is : 100 ms ... 6563.5 seconds

The value of the frequency is determined in the following way :



The 3 frequency meters are used with the following variables :


Frequency A : EWxx,00
Frequency B : EWxx,01
Frequency C : EWxx,02

● Fault indication

The led's indicate the following :

- Led 0 : "Unit error"
- Led 1 : "Bus error"
- Led 3 : "Overflow" (the counter counts beyond its counting limits or thr counting frequency is too high)
- Led 4 : "Overload" (temperature inside the unit is too high,all outputs are set to 0)
- Led 5 : "Short circuit"

If an error occurs the red led error is **On** (see Chapter 9, Volume 2 «In case of failure»).



Description of the unit front :

- Front plate IP 65 ①
- Display 2 lines, 32 characters ②
- "Key function" push-button ③

The remote display TCAD displays informations concerning machine and process status, concerning maintenance, etc.

It is directly connected to the CS 31 by a twisted pair. This allows the following **advantages** :

- reduction of the wiring and material costs.
- the serial port of central unit remains free.
- The messages stored in EEPROM in the remote display TCAD are called by their message number from the central unit.
- The various messages activated from the central unit are scrolled on the screen **every two seconds**.

- The activated messages can be deactivated **one by one or all at once**.

- The message is displayed on **2 lines of 16 supertwist 8 mm high characters**.

- **Two variable datas** can be embedded in each message. Each data has a maximum of 6 characters, one of which is for the sign.

- A buzzer (programmable) can be activated or deactivated.


- A **key function** is available on the front plate. It can be used in the user program as an input to acknowledge a message, the buzzer, etc.

- The remote display TCAD is programmed with a **PC based programming software**.

TECHNICAL CHARACTERISTICS

Power supply	24 VDC
Isolated power supply	yes
Internal buzzer	yes (programmable)
Number of serial interface	1 RS 232 C for programming 1 RS 485 (reserved for CS 31 bus)
Display	alphanumeric through 2 lines of 16 characters supertwist 8 mm high
Front unit protection	IP 65
Rear unit protection	IP 20
Memory	127 messages + 1 background message, both 32 characters in EEPROM
Operation temperature	0 °C to 55 °C
Power supply connection	rear removable terminal block
Programming interface connection	SUB D9 pins female
CS 31 interface connection	rear removable terminal block
Order number : FPR 3203 526	R1002
Weight	0.4 kg

For more details, refer to its own description



C 248 D

The NCB is an amplifier for CS31 bus. It ensures a amplifier function whereas the maximum lenght on one bus can reached upto 2km with the instalation of 3 NCB.

The use of NCB is totally transparent and a diagnosis is available on the unit and on the central unit if almost one of the different lines is faulty.


Description

- Removable connector for 24 VDC power supply ... ①
- Removable connector for CS31 bus input..... ②
- Removable connector for CS31 bus output 1 ③
- 1 green led labelled "power" to indicate the presence of supply ✓
- TX I : communication in progress from CS31 bus master to NCB.
TX O : communication in progress from remote unit to NCB ⑤
- 2 red leds labelled "OUT" and "IN" to indicate the default on the CS31 bus ≈

TECHNICAL CHARACTERISTICS

Power supply	24 VDC
Isolated power supply	no
Maximum consumption	4 W
Isolated RS485 CS31 bus IN/OUT and power supply	yes (1000 VAC)
Isolated RS485 CS31 bus OUT/IN and power supply	yes (1000 VAC)
Maximum delay between input/output signals	< 2 μ s
Integrated resistor for end of line	yes (120 Ohm 1/4 W)
Mounting on DIL rail	yes
Widht x height x depth	120 x 80 x 85
Order number	FPR 347 1200 R1002
Weight	340g


● Electrical connections



B2 : bus 1
B1 : bus 2

● Installation

All EMC protection rules have to be applied (see chapter 1.1.2 vol. 2)




The resistance for end of line (120Ω 1/4W) is already integrated into the NCB.

The terminals IN have to be connected to the above CS31 bus segment (CS31 master side) for the handling of diagnosis.

The choice of the CS31 bus cable is very important to reach long distance communication and to avoid disturbances in communication.

A typical configuration is :



The cable has to be chosen according on the following rule :

$$*L1 + L2 + L3 + L4 < 1200 \text{ m}$$

The standard cable can be used (check general characteristics chapter 1)

$$*1200 \text{ m} < L1 + L2 + L3 + L4 < 1500 \text{ m}$$

Cable characteristics

- twisted pair (nb twists > 10 per meters)
- capacitance : $C < 100 \text{ nF/km}$ (100 pF/m)
- impedance characteristic :
80 to 120 Ohms ($= \sqrt{L/C}$ with L : inductance)
- **transmission velocity**
($= 1/\sqrt{LC}$) > 55 % light velocity (300 000 km/s)

$$*1200 \text{ m} < L1 + L2 + L3 + L4 < 2000 \text{ m}$$

Cable characteristics

- twisted pair (nb twists > 10 per meters)
- capacitance : $C < 100 \text{ nF/km}$ (100 pF/m)
- impedance characteristic :
80 to 120 Ohms ($= \sqrt{L/C}$ with L : inductance)
- **transmission velocity**
($= 1/\sqrt{LC}$) > 66 % light velocity (300 000 km/s)

Fault indication :

An open circuit and short circuit on the CS31 bus are detected by the NCB. In this case, the different CS31 bus segments below the default are out of order. The CS31 bus segment above the default runs properly.

The leds ERRORS "OUT" or "IN" are "ON" according on the CS31 bus in default.

This error is displayed on the central unit (FK3) as a remote unit error.

The access to the default is different according on the type of central unit :

07KR31 / 07KT31

– access to the default with the function block COPY to the memory address SEG : 0h and OFFSET : 8660h

If the value is 2Ah, then almost one of the NCB's is on default. (The red led on central unit is OFF).

The default is reset on the central unit when 0 is written at the address 0:8660h (with the function block COPY).

– access to the default as an FK3 error number 17d with the versions produced after April 96 (07KR31 index J and 07KT31 index B).

07KR91 / 07KT92 / 07KT93

– access to default with the function block COPY to the memory address SEG : C000h and OFFSET:0100h

If the value is 2Ah, then almost one of the NCB's is on default. (The red led on central unit is ON).

The default is reset on the central unit when 0 is written at the address 0C00/0100h (with the function block COPY).

07CS61 (for T200)

– Version index c R202

The default is seen as a bus error without any remote unit number.

– Version index d R202 and next

The default is set in the bit 4 of the word MW4104,03 for the first CS31 line, MW4105,11 for the second CS31 line, MW4107,03 for the third CS31 line and MW4108,11 of the fourth CS31 line.

07CS91 (for T300) and UCZA/UCZB

The diagnosis is not available.

How to solve the error ?

– Check the different connexions on the CS31 bus (the terminals b1 and b2 must not be inversed).

– Check the CS31 bus to find where is the error.

In case of short-circuit, all remote units on the corresponding segment are in default.

The open circuit can be detected by the NCB only if this default happens between NCB and the first remote unit. For the cases, the central unit will detect a disconnected remote unit

When the failure disappears, the NCB quits the error by itself and the red leds go out.


A remote unit error is always normally detected by the central unit.

6.3.2

NCBR

CS 31 Bus unit

CS 31 Bus Amplifier with redundancy



C 243 D

The NCBR is an amplifier for CS31 bus with integrated redundancy functions.

NCBR allows two types of configurations :

– Reliable installation

In this case, NCBR is used to built up a redondant data transmission medium.

– Extended installation

The NCBR is then used to built up star configuration and therefore to cover wide areas.

The redundancy functions is provided by 2 parallel buses between 2 NCBR or with one bus in ring configuration with only one NCBR.

It also ensures a amplifier function whereas the maximum lenght on one bus can reached upto 1800 m with the installation of 3 NCBR.

The use of NCBR is totally transparent and a diagnosis is available on the unit and on the central unit if almost one of the different lines is faulty.


Description

- Removable connector for 24 VDC power supply ... ①
- Removable connector for CS31 bus input 1 ②
- Removable connector for CS31 bus input 2 ③
- Removable connector for CS31 bus output 1 ④
- Removable connector for CS31 bus output 2 ⑤
- 1 green led labelled "power" to indicate the presence of supply ⑥
- 2 yellow leds labelled "TX I" and "TX O" to indicate the communication between central unit and NCBR ⑦
- 4 red leds labelled "OUT1", "OUT2", "IN1" and "IN2" to indicate the default on the different CS31 buses ⑧
- Parallel or ring configuration selection ⑨

TECHNICAL CHARACTERISTICS

Power supply	24 VDC
Isolated power supply	no
Maximum consumption	6 W
Isolated RS485 CS31 bus IN1/IN2, OUT1, OUT2 and power supply	yes (1000 VAC)
Isolated RS485 CS31 bus IN2/IN1, OUT1, OUT2 and power supply	yes (1000 VAC)
Isolated RS485 CS31 bus OUT1/IN1, IN2, OUT2 and power supply	yes (1000 VAC)
Isolated RS485 CS31 bus OUT2/IN1, IN2, OUT1 and power supply	yes (1000 VAC)
Maximum delay between input/output signals	< 2 μ s
Integrated resistor for end of line	yes (120 Ohm 1/4 W) on output (OUT) yes (1500 Ohm 1/4 W) on input (IN)
Mounting on DIL rail	yes
Width x height x depth	120 x 80 x 85
Order number	FPR 347 1300 R1002
Weight	340g

● Electrical connections




b2 : bus 1
b1 : bus 2

IN 1 and OUT 1 : segment 1
IN 2 and OUT 2 : segment 2

● Installation

All EMC protection rules have to be applied (see chapter 1.1.2 vol. 2)

Parallel configuration




The resistor for end of line (120Ω 1/4 W) is already integrated into the NCBR.

The maximum length of each segment is 500 m.

The maximum length in one direction (for example : $L1 + L2 + L4$) depends on the cable characteristics (check below for cable specifications).

In case on failure on L2 (resp. L3), the remote units connected on L2 (resp. L3) between the failure and the below NCBR lose the communication with the central unit.


Ring configuration



The maximum length of each segment is 500 m.

The maximum length in one direction (for example : L1 + L2) depends on the cable characteristics (check below for cable specifications).

Star configuration



The maximum length of each segment is 500 m.


The maximum length in one direction (for example : L1 + L3 + L6) depends on the cable characteristics (check below for cable specifications).

Upto 7 NCBR can be installed in this configuration.


The 3 different configurations can be mixed together.

The limits are only 3 NCBR on one direction and only 31 remote units for the complete configuration (a NCBR unit doesn't use a CS31 bus address).


Example of others configurations :




C 252DGB



C 253DGB



C 254DGB



C 255DGB

with $L2 + L3 < 800 \text{ m}$

The choice of the CS31 bus cable is very important to reach long distance communication and to avoid disturbances in this communication.

The maximum length for one direction depends on the cable specifications.

The maximum length for each segment is 500 m.

• **If the maximum length is lower than 1200 m** then the standard cable can be used (check general characteristics chapter 1).

• **If the maximum length is lower than 1500 m** then the cable characteristics are :

- twisted pair (nb twists > 10 per meters)
- capacitance : $C < 100 \text{ nF/km}$ (100 pF/m)
- impedance characteristic :
80 to 120 Ohms ($= \sqrt{L/C}$ with L : inductance)
- **transmission velocity**
($= 1/\sqrt{LC}$) > 55 % light velocity (300 000 km/s)

• **If the maximum length is lower than 1800 m** then the cable characteristics are :

- twisted pair (nb twists > 10 per meters)
- capacitance : $C < 100 \text{ nF/km}$ (100 pF/m)
- impedance characteristic :
80 to 120 Ohms ($= \sqrt{L/C}$ with L : inductance)
- **transmission velocity**
($= 1/\sqrt{LC}$) > 66 % light velocity (300 000 km/s)

● How is it running ?

The NCBR is waiting a character on the inputs IN1 and IN2.

When the first characters of a frame is received on one of the two buses, the corresponding line is validated and then the characters on the other bus are ignored.

After the end of the frame (delay > 20 μs) , the NCBR waits again a frame on the two input buses.

– Redondancy and star configuration

The switch "**OUT CONFIGURATION**" has to be on position **PARALLEL**.

The frame is sent in the same time on the two output buses.

– Ring configuration

The switch "**OUT CONFIGURATION**" has to be on position **RING**.

After the initialization, the electrical level on OUT 1 is modified and the NCBR checks if the electrical level on OUT 2 is also modified.

- If yes, the ring is closed and then the frame is sent only on OUT 1.

- If no, the ring is opened and the frame is sent on OUT 1 and OUT 2.

The red leds are alternatively ON).

The NCBR checks for each characters if the character arrives on OUT 2.

When the ring is again closed, the two frames are overlapped.

It could happen a transmission error, in this case the telegram is ignored and it will be sent again.

After power supply ON, the red leds go out and the yellow indicate the communication.

● Fault indication :

An open circuit and short circuit on the CS31 bus are detected by the NCBR.

This error is displayed on the central unit.

The leds ERRORS "OUT1", "OUT2", "IN1", or "IN2" are ON according on the CS31 bus in default.

The access to the default is different according on the type of central unit :

07KR31 / 07KT31

– access to the default with the function block COPY to the memory address SEG : 0h and OFFSET : 8660h

If the value is 2Ah, then almost one of the NCBR's is on default. (The red led on central unit is OFF).

The default is reset on the central unit when 0 is written at the address 0:8660h (with the function block COPY).

– access to the default as an FK3 error number 17d with the versions produced after April 96 (07KR31 index J and 07KT31 index B).

07KR91 / 07KT92 / 07KT93

– access to default with the function block COPY to the memory address SEG : C000h and OFFSET:0100h

If the value is 2Ah, then almost one of the NCBR's is on default. (The red led on central unit is ON).

The default is reset on the central unit when 0 is written at the address 0C00/0100h (with the function block COPY).

07CS61 (for T200)

– Version index c R202

The default is seen as a bus error without any remote unit number.

– Version index d R202 and next

The default is set in the bit 4 of the word MW4104,03 for the first CS31 line, MW4105,11 for the second CS31 line, MW4107,03 for the third CS31 line and MW4108,11 of the fourth CS31 line.

07CS91 (for T300) and UCZA/UCZB

The diagnosis is not available.

How to solve the error ?

- Check the different connexions on the CS31 bus (the terminals b1 and b2 must not be inversed).
- Check the presence and value of the resistance of end line
- Check the CS31 bus to find where is the error.

In case of short-circuit, all remote units on the corresponding segment are in default.

The open circuit can be detected by the NCBR only if this default happens between NCBR and the first remote unit of the last segment or on the segment between two NCBR (in parallel or ring configuration).

When the failure disappears, the NCBR quits the error by itself and the red leds go out.

A remote unit error is always normally detected by the central unit.

Chapter	Description	Page
7.1	Robot card	
7.1.1	ICBG 32 L7 : 32 binary inputs/outputs	7.1.1-1
7.1.2	ICBG 64 L7 : 64 binary inputs/outputs	7.1.2-1

7.1.1 ICBG 32 L7 32 binary input/outputs

Robot card


This card is a 32 channel binary inputs/ outputs card for communication between the CS31 system and ABB type S3 robots (it is mounted in the robot rack).

The power supply is taken from the robot rack.
The CS31 system bus is used for the communication.

The card is seen as a standard input/output unit by the robot and CS31 system.

Description of the front module :

- Sixteen yellow input status led's ①
- Sixteen yellow output status led's ②
- Red led to indicate errors ③
- Two yellow led's to significate the input/output led's ④
- "SELECT" push-button. ⑤



Robot coupler 32 Inputs/Outputs

SPECIFICATIONS

Power supply (taken from the robot)	+ 5 V and + 15 VDC
Power supply isolation	no
Number of inputs	16
Number of outputs	16
Maximum consumption	4 W
Order number FPR3330705	R0321
Weight (kg)	0.3


● Connection

The address of the card is set with the diil switch SW1 in the same manner as the plug-in base.

Connect the CS31 bus to the connector X1 of the card with the special cable (YB560105-DZ ABB Robotics)

Connect the wires of this cable to the CS31 bus.

- pin 30A : bus 1
- pin 30C : bus 2



Insert the card into a binary input/output slot of the robot rack (refer to robot documentation for user details).

● Initialization

- The card initializes itself after powered on the robot and the CS31. The input led's 1,2,8 et "F" are illuminated.
- After a correct initialization, the error led "F" switch off, The input led's take their function, the system is now ready to run.

Example of addressing input/output card.

This card is inserted in the first binary input/output slot of the rack and the address is set by SW1 for the CS31 bus.

VARIABLES USED			
Robot	07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB	PCZB
Address xx on the switch SW1	00 ... 61	00 ... 61	1 ... 31
1 - 8	xx, 00 ... xx,07	xx, 00 ... xx, 07	xx00 ... xx007
9 - 16	xx, 08 ... xx,15	xx+100 ... xx+1,07	xx08 ... xx15

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

● Utilisation

This card is used like a standard remote binary input/output unit.

The usual instructions are used to read inputs and write outputs.

This card is used like one DSQC 223 by the robot.

Each output bit of the robot is an input bit of the CS31.

Each input bit of the robot is an output of the CS31.

Example : The robot sets output 5 to 1. This is read using the input (Exx,05 or lxx 05).

In the same way input 7 of the robot can be set by writing to Axx,07 or Oxx,07 of the CS31.

The function of the led's on the front of the card can be selected by pressing the "SELECT" push-button on the card (I/O status or address and diagnosis).

- The "I/O" led is illuminated when the led's indicate the input/output status.
- The "ADR" led is illuminated when the led's indicate the setting of SW1.

If a fault occurs the "F" led is illuminated and the fault code is displayed on the led's:

- Led 1 : "**Bus error**" No initialization on the CS31 bus.
- Led 2 : "**Unit error**" No initialization on the robot
- Led 4 : "**ROM error**"
- Led 5 : "**External RAM error**"
- Led 6 : "**Internal RAM error**"
- Led 7 : "**Microprocessor error**"
- Led 8 : "**Other error**"

If an error occurs, see chapter "**In case of failure**".

7.1.2 ICBG 64 L7 64 binary inputs/outputs

Robot card


This card is a 64 channel binary inputs/outputs card for communication between the CS31 system and ABB type S3 robots (it takes two slots in the robot rack).

The power supply is taken from the robot rack.
The CS31 system bus is used for the communication.

The card is seen as a standard input/output module by the robot and CS31 system.

Description of the front module :

- Sixteen yellow input status led's ①
- Sixteen yellow output status led's ②
- Red led to indicate errors ③
- Two yellow led's to significate the input/output led's ④
- "SELECT" push-button. ⑤



Robot coupler 64 Inputs/Outputs

SPECIFICATIONS	
Power supply (taken from the robot)	+ 5 V and + 15 VDC
Power supply isolation	no
Number of inputs	32
Number of outputs	32
Maximum consumption	4 W
Order number FPR3330705	R0641
Weight (Kg)	0.3


Connection

The address of the card is set with the diil switch SW1 in the same manner as the plug-in base.

Connect the CS31 bus to the connector X1 of the card with the special cable (YB560105-DZ ABB Robotics)

Connect the wires of this cable to the CS31 bus.

- pin 30A : bus 1
- pin 30C : bus 2



Insert the card into a binary input/output slot of the robot rack (refer to robot documentation for user details).

Initialization

- The card initializes itself after powered on the robot and the CS31. The input led's 1,2,8 et "F" are illuminated.
- After a correct initialization, the error led "F" switch off, The input led's take their function, the system is now ready to run.

Utilisation

This card is used like a standard remote binary input/output unit.

The usual instructions are used to read inputs and write outputs.

This card is used like two DSQC 223 by the robot.

Each output bit of the robot is an input bit of the CS31. Each input bit of the robot is an output of the CS31.

Example : The robot sets output 5 to 1. This is read using the input (Exx,05 or lxx 05).

In the same way input 7 of the robot can be set by writing to Axx,07 or Oxx,07 of the CS31.

The function of the led's on the front of the card can be selected by pressing the "SELECT" push-button on the card (I/O status or address and diagnosis).

- The "I/O1" led is illuminated when the led's indicate the 16 first channels status.
- The "I/O2" led is illuminated when the led's indicate the 16 others channels status.
- The "ADR" led is illuminated when the led's indicate the setting of SW1.

If a fault occurs the "F" led is illuminated and the fault code is displayed on the led's:

- Led 1 : **"Bus error"** No initialization on the CS31 bus.
- Led 2 : **"Unit error"** No initialization on the robot
- Led 4 : **"ROM error"**
- Led 5 : **"External RAM error"**
- Led 6 : **"Internal RAM error"**
- Led 7 : **"Microprocessor error"**
- Led 8 : **"Other error"**

If an error occurs, see chapter **"In case of failure"**.

Example of addressing input/output card.

This card is inserted in the first binary input/output slot of the rack and the address is set by SW1 for the CS31 bus.

VARIABLES USED			
Robot	07 KR 31, 07 KR 91 07 KT 92, 07 KT 93	UCZA/UCZB	PCZB
Address xx on the switch SW1	00 ... 60	00 ... 60	1 ... 30
1 - 8	xx, 00 ... xx,07	xx, 00 ... xx, 07	xx00 ... xx07
9 - 16	xx, 08 ... xx,15	xx+1,00 ... xx+1,07	xx08 ... xx15
17 - 24	xx+1,00 ... xx+1,07	xx+2,00 ... xx+2,07	xx100 ... xx107
25 - 32	xx+1,08 ... xx+1,15	xx+3,00 ... xx+3,07	xx108 ... xx115

For the PC board 07 CM 90 and the coupler boards 07 CS 61 and 35 CS 91, refer to their own description

Any more available

Any more available


Chapter	Description	Page
8.1	Serial line converters	
8.1.1	NCC 232 : RS232/RS232 isolated converter	8.1.1-1
8.1.2	NCC 485 : RS232/RS485 isolated converter	8.1.2-1
8.2	TCZ handheld terminal	8.2-1
8.3	TCZ Adaptor "off-line"	8.3-1
8.4	System cables	
8.4.1	FPTN404948R00002 :Programmition and test (sub D9)	8.4.1-1
8.4.2	FPTN404948R00005 :Programmition and test (sub D25)	8.4.2-1
8.4.3	FPTN404948R00006 :ASCII and MODBUS communication (sub D9)	8.4.3-1
8.4.4	FPTN404948R00001 :ASCII and MODBUS communication (sub D25)	8.4.4-1
8.4.5	FPTN404948R00004 : communication TCZ adaptor printer 07DR12	8.4.5-1
8.5	Batteries	8.5-1

8.1.1

NCC 232

Serial line converters

RS232/RS232 isolated converter



C 219 D


The NCC 232 module is an RS232/RS232 interface converter. It is the solution of transmission problems in industrial data communications.

The NCC 232 allows a isolated connection between two RS232 interfaces.

In full duplex protocol, the NCC 232 allows long ranges transfers, the creation of point to point connection.

Description

- Removable connector for 24VDC power supply ①
- Removable connector for RS232 interface ②
- SubD9 connector for RS232 interface ③
- Switch for MODBUS/ASCII or active modes ④
- 1 green Led labelled "power" to indicate the presence of supply ⑤
- 1 green Led labelled "power" to indicate the presence of the isolated supply for RS232 interface ⑥
- 2 yellow Leds labelled "TXD" and "RXD" to indicate the data processing ⑦
- Cable for connection between the RS232 interface of NCC 232 and the RS232 interface of the CS31 central units ⑧



C 223 D

TECHNICAL CHARACTERISTICS

Power supply	24 VDC
Isolated power supply	yes
Maximum baud rate	19200
Maximum consumption	40 mA
Mechanical data :	
– Mounting on DIL rail	yes
– Width x height x depth	120x80x85
Order number	FPR3471000R0006
Weight	340g


RS232 SubD 9 interface characteristics

Connector	SubD 9 male
Transfer signals	TxD, RxD
Handshake	RTS, CTS
Protocol	user specific

RS232 interface characteristics


Connector	removable
Isolated power supply	yes
Transfer signals	TxD, RxD
Handshake	RTS, CTS
Protocol	user specific
Range	max 15m
<u>Cable</u> :	
Connectors	subD 9 male-SubD 9 female
Length	33cm

● Electrical connections




● Connectors assignment

Power supply




24VDC 0VDC Ground

RS232 interface



RS232 SubD 9 interface




- pin 1 : not used
 - pin 2 : RxD
 - pin 3 : TxD
 - pin 4 : CTS
 - pin 5 : RTS
 - pin 6 : MODBUS/ASCII (valid with switch SW1)
 - pin 7 : ground
 - pin 8 : not used
 - pin 9 : not used
- (shield to the ground)

Cable

SubD 9 female.....	SubD 9 male
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

● Configurations



SW1

– **OFF** : pin 6 is independant of pin 7


Active mode configuration for CS31 central units.

– **ON** : pin 6 is connected to pin 7

ASCII or MODBUS mode configuration according CS31 central units and value of the system constant KW00,06 (refer to central units descriptions).

● Installation

The NCC 232 has to be installed closed to the central unit with the specific cable or with a cable as short as possible. All EMC protection rules has to be applied (refer chapter 1.1.2 vol.2).




The 24 VDC power supply of the central unit can be used to supply only one unit NCC 232.

8.1.2

NCC 485

Serial line converters

RS232/RS485 isolated converter




C 214 D

The NCC 485 module is an RS232/RS485 interface converter. It is the solution of transmission problems in industrial data communications.

The NCC 485 allows a isolated connection between two RS232 interface and an RS485 interface.

In half or full duplex protocol, the NCC 485 allows long ranges transfers, the creation of multiple point connection.

It is particularly adapted for the connection of the central units 07KR31 and 07KT31 to a MODBUS network.



C 223 D

Description

- Removable connector for 24VDC power supply ①
- Removable connector for RS485 interface ②
- SubD9 connector for RS232 interface ③
- Switch for MODBUS/ASCII or active modes ④
- Dip-switches for RS485 configuration ⑤
- 1 green Led labelled "power" to indicate the presence of supply ⑥
- 1 green Led labelled "iso power" to indicate the presence of the isolated supply for RS485 interface ⑦
- 2 yellow Leds labelled "TXD" and "RXD" to indicate the data processing ⑧
- Cable for connection between the RS232 interface of NCC 485 and the RS232 interface of the CS31 central units ⑨

TECHNICAL CHARACTERISTICS

Power supply	24 VDC
Isolated power supply	yes
Maximum baud rate	19200
Maximum consumption	40 mA
Mechanical data :	
– Mounting on DIL rail	yes
– Width x height x depth	120x80x85
Order number	FPR3471100R0006
Weight	340g


RS232 interface characteristics

Connector	Sub D9 male
Transfer signals	TxD, RxD
Direction switching RS485	TxD
Delay	10 μ s at the begin of frame 2.2ms at the end
Protocol	user specific

RS485 interface characteristics


Isolated RS485 interface	yes
Half of full duplex communication	yes
Integrated resistance for impedance of end of line	yes
Maximum number of NCC 485 on RS485 line	32
Range	1200m twisted pair
Polarization line	yes per switch
<u>Cable</u> :	
Connectors	SubD 9 male-SubD 9 female
Lenght	33cm

● Electrical connections




● Connectors assignment

Power supply




24VDC 0VDC Ground

RS485 interface



- D1-** : half/full duplex
- D1+** : half/full duplex
- SH** : shield
- D2-** : full duplex
- D2+** : full duplex

RS232 interface




- pin 1 : not used
 - pin 2 : RxD
 - pin 3 : TxD
 - pin 4 : not used
 - pin 5 : not used
 - pin 6 : MODBUS/ASCII (valid with switch SW1)
 - pin 7 : ground
 - pin 8 : not used
 - pin 9 : not used
- (shield to the ground)

Cable


SubD 9 female	SubD 9 male
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

● Configurations



SW1

- **OFF** : pin 6 is independant of pin 7
Active mode configuration for CS31 central units.
- **ON** : pin 6 is connected to pin 7
ASCII or MODBUS mode configuration according CS31 central units and value of the system constant KW00,06 (refer to central units descriptions).



SW2

Dip-switch 1 :

- SW2-1 ON 120 Ohm resistor between D2+ and D2–
- SW2-1 has to be set to ON only if NCC 485 is installed at one of the ends of RS485 line.

Dip-switch 2 :

- SW2-2 ON 120 Ohm resistor between D1+ and D1–
- SW2-2 has to be set to ON only if NCC 485 is installed at one of the ends of RS485 line.

Dip-switch 3 : SW2-3 ON OFF

Dip-switch 4 : SW2-4 OFF ON
 full duplex half duplex

Dip-switch 5 : SW2-5 ON polarization of D2+ line

Dip-switch 6 : SW2-6 ON polarization of D2– line


Dip-switch 7 : SW2-7 ON polarization of D1+ line

Dip-switch 8 : SW2-8 ON polarization of D1– line

Caution : The RS485 has to be polarized by only one of the participants.

● Installation


The NCC 485 has to be installed closed to the central unit with the specific cable or with a cable as short as possible. All EMC protection rules has to be applied (refer chapter 1.1.2 vol.2).




The 24 VDC power supply of the central unit can be used to supply only one unit NCC 485.

● Configuration

Half duplex configuration



Full duplex configuration





Order number FPR 3200002R1001

TCZ spare cable


Order number ABB : FPTN407548R0001

TCZ handheld terminal is used for programming and test of the central units type PCZB and CS20.

It can also be used for diagnosis configuration and setting of central units type UCZA/UCZB and 07KR31,07KR91 and 07KT92/93.

A back-up lithium battery is under a removable cover in the rear of TCZ.

8.3 TCZ adaptor "off-line" Material



Order number ABB : FPTN404958R0002

The TCZ adaptor supplies the supply voltage for the TCZ programming if it is running in the "off-line" mode (without connection to the central unit).

This adaptor is also used to connect the TCZ to a printer.

8.4 System cable


Material

8.4.1 FPTN404948R0002

Programming and test (Sub D9)


The system cable serves to connect all types of central units to a PC.AT for programming and test.

Connector :



- 9 pole sub. D connector pins central unit side.
- 9 pole sub. D connector sockets PC.AT side.

length : 2 meters




8.4.2 FPTN404948R0005

Programming and test (SubD25)


The system cable serves to connect all types of CS31 central units to a PC.AT for programming and test.

Connector :



- 9 pole sub. D connector pins central unit side.
- 25 pole sub. D connector sockets PC.AT side.

length : 2 meters




8.4.3 FPTN404948R0006

ASCII and MODBUS communication (Sub D9)


The system cable serves to connect all types of CS31 central units to 9 DB connector of an external device for ASCII communication (terminal, printer, etc...) or PC.AT. It must be used for MODBUS communication with 07 KR 31

Connector :



- 9 pole sub. D connector pins central unit side.
- 9 pole sub. D connector sockets external device side.

length : 2 meters




8.4.4 FPTN404948R0001

ASCII and MODBUS communication(SubD25)


The system cable serves to connect all types of CS31 central units to 25 DB connector of an external device for ASCII communication (terminal, printer, etc...) or PC.AT. It must be used for MODBUS communication with 07 KR 31

Connector :




- 9 pole sub. D connector pins central unit side.
- 25 pole sub. D connector sockets external device side.

length : 2 meters



8.4.5 FPTN404948R0004
Communication TCZ adaptor-printer 07DR12.

25 pole sub. D connector pins printer side.
25 pole sub. D connector pins TCZ adaptor side.



External device

Central unit

- Lithium battery for UCZA/UCZB :
Order number ABB : FPTN404949R001
- Lithium battery for TCZ :
Order number ABB : FPTN404949R002
- Spare battery (5 V) for the battery module for TCZ :
Order number ABB : FPTN404949R003

Chapter	Description	Page
9.1	Internal diagnosis	9.1
9.1.1	General	9.1
9.1.2	Use of "TEST" push-button	9.1
9.1.3	Sump up the diagnosis	9.2
9.2	Open circuit detection	9.4
9.2.1	Detection for inputs	9.4
9.2.2	Detection for outputs	9.4
9.3	Overload and short-circuit	9.4
9.4	Diagnosis of the various central units	9.4

9.1 Internal diagnosis

9.1.1 General

All modules execute automatic diagnosis tests, which are specific to the unit type.

On the occurrence of a fault, the red led next to the test button is illuminated.

- Led constant : fault stored
- Led flashing : remote unit not initialized (occurs during power on).

The fault codes are displayed on the led's of the unit.

9.1.2 Use of "TEST" push-button

The "TEST" push-button enables the type of fault and the channel on which it occurred to be displayed by a code on the I/O status led's.

Faults can be deleted with the "TEST" push-button if the fault condition no longer exists.

Use of test function:

- Press the push-button, the led of the selected channel will flash (channel 0, 1, etc...).
- On releasing the "TEST" push-button the diagnosis information for the selected channel is displayed.
- Press the "TEST" push-button again to obtain the information for the same test on the next channel.
- Press the "TEST" push-button after the last channel to test all the led indicators.

On releasing the "TEST" push-button the dil switch setting of the plug-in base is displayed on the led's 0-7 (ICSM06A6 and ICSA04B5 led's 0 to 5).

- Pressing the "TEST" push-button for more than 10 seconds clears all of the stored faults.

9.1.3 Sum up the diagnosis

The units can execute the diagnosis functions displayed:

A - Binary input/output units

Led 0 - Unit error

Led 1 - Bus error

Led 2 -

Led 3 - Cut wire

Led 4 - Overload

Led 5 - Short circuit

Led 6 - OUTPUT

Output channel

Led 7 - INPUT

Input channel

Units	Led 0	Led 1	Led 2	Led 3	Led 4	Led 5	Led 6	Led 7
ICSI 08 D1	X	X		X				X
ICSI 16 D1	X	X		X				X
ICSI 08 E1	X	X						X
ICSI 16 E1	X	X						X
ICSI 08 E3/E4	X	X						X
ICSC 08 L1	X	X		X	X	X	X	X
ICFC 16 L1	X	X		X	X	X	X	X
ICSK 20 F1	X	X						X
ICSO 08 R1	X	X					X	
ICSO 08 Y1	X	X		X*	X	X	X	
ICSO 16 N1	X	X			X			

* no power supply in 24 VDC for the outputs

B - Analogue units

Led 0 - Unit error

Led 1 - Bus error

Led 2 - 10 V fail

Led 3 - Output error

Led 4 - 4-20

In case of ICST 08 A8/A9

Led 5 - ± 10 V

Led 4 : out of range

Led 6 -

Led 7 -

Units	Led 0	Led 1	Led 2	Led 3	Led 4	Led 5	Led 6	Led 7
ICSM 06 A6	X	X	X	X	X	X		
ICSE 08 A6	X	X			X			
ICSE 08 B5	X	X			X	X		
ICSA 04 B5	X	X		X	X	X		
ICST 08 A8	X	X			X			
ICST 08 A9	X	X			X			

C - High speed counter

- Led 0 - Unit error
- Led 1 - Bus error
- Led 2 -
- Led 3 - Overflow
- Led 4 - Overload
- Led 5 - Short circuit
- Led 6 -
- Led 7 -

Units	Led 0	Led 1	Led 2	Led 3	Led 4	Led 5	Led 6	Led 7
ICSF 08 D1	X	X		X	X	X		

D - Robot coupler card

- Led 1 - Bus error No initialization on CS31 bus
- Led 2 - Unit error No initialization on robot
- Led 3 -
- Led 4 - ROM error
- Led 5 - External RAM error
- Led 6 - Internal RAM error
- Led 7 - Microprocessor error
- Led 8 - Other error

Cards	Led 1	Led 2	Led 3	Led 4	Led 5	Led 6	Led 7	Led 8
ICBG 32 L7	X	X		X	X	X	X	X
ICBG 64 L7	X	X		X	X	X	X	X
ICBG 32 M7	X	X		X	X	X	X	X
ICBG 64 M7	X	X		X	X	X	X	X

E - Remote display TCDA

- No led
- A message on the remote display TCDA appear in of case disconnection on the CS 31 bus

F - CS 31 bus units

9.2 Open circuit detection


Open circuit detection is configured by user program or TCZ.

9.2.1 Detection for inputs

A resistor has to be mounted in parallel of the input captor.

With an inductive captor, the minimal current is 1mA.

Resistor : from 20 kOhm to 30 kOhm



9.2.2 Detection for outputs

The detection is done by analysing the current consumption.

9.3 Overload and short-circuit

A - Overload

Detection for $I > I$ overload for a time T , output is momentarily opened (The value is written in the technical description of each module).

B - Short-circuit

When $I > I$ short-circuit, the output is reset to "0" up to a quit of the fault (The value is written in the technical description of each module).

9.4 Diagnosis of the various central units

All details of the failures described above can be reached in the central units by the fonction MAILBOX or in specific diagnosis variables (cf central units descriptions).

ABB CS31

Intelligent decentralized automation system

Central processing units
07 KR 31 / 07 KT 31



ABB Control

ABB

Chapter	Description	Page
1.	Brief description / Main features of the central units 07 KR 31 / 07 KT 31	1-1
1.1	Project planning / start up	1.1-1
1.2	Technical characteristics	1.2-1
1.3	Overview of possibilities	1.3-1
1.4	Operands (variables and constants)	1.4-1
1.5	Mapping	1.5-1
1.6	Software functions	1.6-1
1.7	Terminal mode : availables functions	1.7-1
2.	Front panel	2-1
3.	Electrical connections / Terminal assignments	3-1
3.1	Electrical isolation and notes on earthing	3.1-1
3.2	Connection for ABB Procontic CS31 system bus	3.2-1
3.3	24VDC output voltage for the signal supply of the inputs	3.3-1
3.4	Battery	3.4-1
3.5	Serial interface	3.5-1
3.6	Dimensions	3.6-1
4.	High speed counter	4-1
5.	Processing times	5-1
5.1	Program processing time t_{up}	5.1-1
5.2	Set cycle time t_c	5.2-1
5.3	Reaction time in case of binary signals	5.3-1
6.	Addressing	6-1
6.1	Recommended unit addresses on the CS31 system bus	6.1-1
6.2	Address setting for the units	6.2-1
6.3	07 KR 31 / 07 KT 31 used stand-alone central unit	6.3-1
6.4	07 KR 31 / 07 KT 31 used as bus master central unit	6.4-1
6.5	Intelligent I/O remote units (Slave central units)	6.5-1
7.	Purpose of the I/O configuration	7-1
7.1	Performing and reading the I/O configuration	7.1-1
8.	Diagnosis - Introduction	8-1
8.1	Structure of diagnosis	8.1-1
8.2	Acknowledgement of error messages in the remote units	8.2-1
8.3	Errors flags in the central unit, error classification	8.3-1
8.4	Acknowledgement of error messages in the central unit	8.4-1
8.5	Additional diagnosis functions	8.5-1
8.6	Meaning of the contents of the error word flags	8.6-1
8.7	Reaction on the bus master central unit and the remote units in case of errors	8.7-1

9.	Programming and test	9-1
9.1	On-line modifications	9.1-1
10.	Man-machine communication (MMC)	10-1
11.	MODBUS® protocol - General presentation	11-1
11.1	MODBUS protocol	11.1-1
11.2	MODBUS configuration	11.2-1
11.3	Cross reference list MODBUS / 07 KR 31 or 07 KT 31	11.3-1
11.4	Reaction time with MODBUS communication	11.4-1
12.	Differences between 07 KR 31, 07 KT 31 and 07 KR 91, 07 KT 92, 07 KT 93	12-1
13.	Ordering data	13-1

MODBUS® is a registered trademark of GOULD Inc.

The central units 07 KR 31 and 07 KT 31 work either as:

- **Bus master** in the decentralized automation system ABB Procontic CS31 or as
- **Intelligent I/O** (Slave remote processor) in the decentralized automation system ABB Procontic CS31 or as
- **Stand-alone central unit.**

The 07 KR 31 and 07 KT 31 have a 24V d.c. or 120V a.c. or 230V a.c. power supply voltage.

Main features :

- **12 binary inputs**
- **8 binary relay outputs for the 07 KR 31 unit
8 binary transistor outputs for the 07 KT 31 unit**
- **1 supply output regulated 24V d.c.** for the versions 120V a.c. and 230V a.c.
- **1 counting input for counting frequencies up to 10 kHz**
- **1 CS31 system bus interface for system expansion**
- **Serial interface COM1 :**
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
 - can be set as a MODBUS interface : master and slave.
- **Real-time clock**
- **LED's** for displaying the binary input and output signals as well as operating conditions and error messages.
- **Wiring on the plug-in base ECZ**
- **Password for user program**
- **Store and back-up datas** which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- **RUN/STOP** switch for starting and aborting the program execution
- **Extensive diagnosis functions**
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected remote units.

The following has to be observed for project planning and start-up :

- **Programming** is performed using ABB Procontic programming software, which can be run on commercially available IBM compatible PCs (see documentation for programming system 907 PC 331).

- **Diagnosis and service device TCZ** (terminal mode) (see volume 7.3, see chapter 9 "Programming and test" and chapter 3.5 "serial interface")

The processor processes the user program contained in the RAM. It is loaded into the RAM via the serial interface COM1 and can also be changed there. An additional save command is used to save the program in the EEPROM.

NOTE : In the course of the following operations

- Power "ON"
- **RUN/STOP** switch from **STOP** → **RUN**
- Program start-up with programming system
- Cold start of the PLC

The RAM is overwritten by the contents of the EEPROM.

- **On-line program modification**

The two existing RAMs allow a quick modification of the user program to be performed without interrupting the operation (see chapter 9.1 ON-LINE modifications or see ABB programming system 907 PC 331).

- **Change-over between the application modes**

- Stand-alone central unit
- Bus master central unit and
- Intelligent I/O remote unit (Slave central unit)

The central unit is set to "Stand-alone" upon delivery. Changing the application mode is carried out in the following three steps :

1. Change the system constant KW 0,0 in the PLC, (see chapter 1.4 "Operands" § System constants).
2. Save the user program in the EEPROM.
3. Activate new application mode by :
 - calling up the menu item of "Enable PLC mode" in the ABB programming and test system or
 - performing a warm start or
 - performing a cold start.

- **Setting the cycle time**

(see chapter 5 "Processing times")

- **Addressing when remote units are connected**

(see chapter 6 "Addressing")

- **Initialisation of data storage areas**

System constants can be used to determine which data areas are to be initialised with the value of "0" *during program start-up*. A specific initialization is possible for the following areas. It is also possible to initialize partial areas only :

- Binary flags
- Word flags
- Double word flags
- Step chains
- Historical values
(see chapter 1.4 "Operands" § System constants)

- **Reactions on errors of error class 3**

The user can configure whether or not the user program is to be aborted automatically, if an class 3 error occurs, (see chapter 1.4 "Operands" § System constants).

- **Starting-up the CS31 system after power ON**

The user can enter a number of *n* remote units in system constant KW 0.9. The user program starts only i.e. it handles process inputs and outputs only, if at least *n* remote units have been adopted into the CS31 system bus cycle, (see chapter 1.4 "Operands" § System constants).

GENERAL CHARACTERISTICS

Power supply of 07 KR 31 / 07 KT 31	24 VDC	230 VAC / 120 VAC
Number of inputs per unit	12	12
Number of outputs per unit	8	8
Isolated power supply	no	yes (1500 VAC)
Maximum consumption	0.3 A	10 VA
Order numbers : FPR3600227 for 07 KR 31	R1202	R0206/R0204
FPR3600228 for 07 KT 31	R1202	R0206/R0204
Weight (kg)	0.25	0.43

INPUT CHARACTERISTICS

Opto isolated inputs	no	no
Signal level of the inputs, nominal value	24 VDC	24 VDC
Signal level of the input		
0 signal	-3 to +5V	-3 to +5V
1 signal	+15 to +30V	+15 to +30V
Input current for 24 VDC	5 mA	5 mA
Input delay (*)	5 ms	5 ms

(*) This delay can't be modified

OUTPUT CHARACTERISTICS FOR 07 KR 31

Isolated	yes	yes
Switching capacity under 2 A (resistive or inductive load) 120/230 VAC 50/60Hz DC	2 A 60 W (2A)	2 A 60 W (2A)
Nominal current	2 A AC-1 1 A AC-3	2 A AC-1 1 A AC-3
Minimum power for the contacts 10 mA	12 VDC 10 mA	12 VDC
Supply output 24 VDC 100 mA	no	yes
Total current		
Common M-Q 120/230 VAC 50/60Hz 24 VDC	6 A 6 A	6 A 6 A
Common R-T 120/230 VAC 50/60Hz 24 VDC	4 A 4 A	4 A 4 A
Short-circuit protection	no	no
Over voltage protection	Varistor	Varistor

OUTPUT CHARACTERISTICS FOR 07 KT 31

Isolated	no	no
Switching capacity under 0,5 A (resistive or inductive load) 24 VDC	0,5 A 15 W (0,5 A)	0,5 A 15 W (0,5 A)
Nominal current	0,5 A	0,5 A
Supply output regulated 24 VDC ($\pm 5\%$) 100 mA	no	yes
Total current for 8 outputs	4 A	4 A
Short-circuit protection for each output	Yes	Yes
Thermal protection for each output 2 A with 25 °C ambient 1.5 A with 55 °C ambient	Yes	Yes
Over voltage protection	Yes	Yes

Program memory	EEPROM Typ. 2 kinst. (8 kbytes)
Cycle time	6 ms/kinst. bits 30 ms/kinst. words
Binary inputs	12 integrated 744 external
Binary outputs	8 integrated outputs 496 external
Analog inputs	224
Analog outputs	48
Serial interface	1 RS232C 1 RS485 (reserved for CS31 bus)
High speed counter	1 (10 kHz) (using the first binary input of the central unit)
Real time clock	1
Password	yes
On-line programming	yes
Communication protocol	ASCII MODBUS : master and slave
Binary flags	512
Word flags	256
Double word flags	32
Word constants	128
Double word constants	32
Sequencers (steps)	256
Diagnosis bit	16
Diagnosis words	32
Timers	illimited (only 42 running at the same time)
Counters	illimited
Boolean and arithmetic functions	yes
Software functions	more than 30 (see chapter 1.5 " Software functions ")

NOTE : The number of inputs/outputs is the number of available I/O in the central unit. The number of physical inputs/outputs depends on the type of remote units (maxi 31 units).

1.4 07 KR 31 / 07 KT 31 Operands Central processing units (variables and constants)

● Available variables and constants

– Inputs

E 00,00...E 61,15	:	Binary inputs, CS31 remote units
E 62,00...E 62,11	:	Binary inputs of the central unit 07 KR 31 or 07 KT 31
E 63,14	:	High-speed binary inputs ($T_D = 0.02$ ms), signal is identical to E 62,00
E 63,13	:	High-speed counter, interrogation of "Zero crossing"
EW 00,00...EW 05,15	:	Analog inputs, CS31 remote units
EW 08,00...EW 15,15	:	Analog inputs, CS31 remote units
EW 06,15	:	High-speed counter, interrogation of the counter content
EW 07,00...EW 07,07	:	Reserved
EW 07,08...EW 07,14	:	Reading of the real-time clock
EW 07,15	:	Status for CS31 system bus

– Outputs

A 00,00...A 61,15	:	Binary outputs, CS31 remote units
A 62,00...A 62,07	:	Binary outputs of the central unit 07 KR 31 or 07 KT 31
A 63,15	:	High-speed counter, adoption of start value
AW 00,00...AW 05,15	:	Analog outputs, CS31 remote units
AW 06,15	:	High-speed counter, "Start value"

– Internal operands

M 00,00...M 21,15	:	Binary flags
M 230,00...M 239,15	:	
M 255,00...M 255,15	:	Diagnosis flags
S 00,00...S 15,15	:	Steps
K 00,00...K 00,01	:	Binary constants
MW 00,00...MW 5,15	:	Word flags
MW 230,00...MW 239,15	:	
MW 254,00...MW 255,15	:	Diagnosis words
KW 00,00...KW 07,15	:	Word constants
MD 00,00...MD 01,15	:	Double word flags
KD 00,00...KD 01,15	:	Double word constants

– Time values for time functions

KD yy,xx	:	Time values for time functions such as ESV, ASV etc. are configured as <i>double word constants</i> or
MD yy,xx	:	<i>as double word flags</i> . Only integral multiples of 5 ms are permitted.

● System constants / diagnosis flags / CS31 status (overview)

– Setting the operating modes

The constants KW 00,00...KW 00,15 are reserved as system constants. Even the constants KW 00,12...KW 00,15 which are not used yet may *under no circumstances* be used for other purposes.

KW 00,00	:	Setting the central unit operating modes, (Stand-alone central unit, Master central unit, Slave central unit)
KW 00,01	:	Initialization : bit flag area
KW 00,02	:	Initialization : word flag area
KW 00,03	:	Initialization : double word flag area

- KW 00,04 : Initialization : step chain flag area
- KW 00,05 : Initialization : historical values
- KW 00,06 : Application modes of the serial interface COM 1
- KW 00,07 : Central unit reaction to class 3 errors
- KW 00,08 : Not used
- KW 00,09 : Initialization of the CS31 system after power ON, warm start or cold start
- KW 00,10 : Size of the transmitting area of the slave central unit
- KW 00,11 : Size of the receiving area of the slave central unit

– Setting the cycle time

- KD 00,00 : The cycle time of the central unit program is preset with this constant. The cycle time is given in the unit of measurement milliseconds. Only integral multiples of 5 ms are permitted. The maximal value allowed in master configuration is 100 ms and in slave configuration 250 ms.

– Error diagnosis

- Summation error display : M 255,10 indicates, that the central unit has detected an error
- Fatal error, FK1 : M 255,11 = 1 i.e. error detected, detailed information in MW 254,00...MW 254,07
- Serious error, FK2 : M 255,12 = 1 i.e. error detected, detailed information in MW 254,08...MW 254,15
- Light error, FK3 : M 255,13 = 1 i.e. error detected, detailed information in MW 255,00...MW 255,07
- Warning, FK4 : M 255,14 = 1 i.e. error detected, detailed information in MW 255,08...MW 255,15

– First-cycle detection

M 255,15

This binary flag can be used for detection of the *first* program cycle after a program start. It is always set to "zero" after each program start, independent of the initialization instructions given by the system constants. If this flag is read by the user program and then set to "1", it can be found out whether or not the user program was started once more.

– CS31 status word

EW 07,15

- Bit 0 = 1 : No class 2 error present.
- Bit 1 = 1 : Central unit has been adopted into the CS31 bus cycle (only relevant if used as a slave).
- Bit 2 : Not used.
- Bit 3 = 0 : Battery failure.
- Bits 4...7 : Not used.
- Bits 8...15 : Maximum number of modules on the CS31 system bus, found out until now (only relevant if used as a master).

– Real time clock

- EW 07,08 second (0..59)
- EW 07,09 minute (0..59)
- EW 07,10 hour (0..23)
- EW 07,11 day of the week (1..7)
- EW 07,12 day
- EW 07,13 month (1..12)
- EW 07,14 year (0..99)

Time and date are set by using the UHRS command in the terminal mode or by using the function block UHR in a program.

● **System constants / Setting of operating modes**

– **Definitions**

At first, the definitions used with the setting of operating modes are explained :

- Cold start
- Warm start

1°) Cold start

- All of the RAM memories are tested and deleted.
- If there is *no user program* in the EEPROM, the default values are set to all of the system constants (identical to the factory settings).
- The operating modes given by the system constants are set.
- The CS31 system bus is initialized again (only when used as a master on the CS31 system bus).

Performing a cold start

- Command KALT <CR> in terminal mode (see volume 7.3) or
- Menu field "Cold start" in the programming system.

2°) Warm start

- All of the RAM memories, with the exception of the program memory and the operand memory (flags), are tested and deleted.
- If there is a *user program* in the EEPROM, this program is loaded into the RAM including the system constants.
- The operating modes given by the system constants are set.
- The CS31 system bus is initialized again (only when used as a master on the CS31 system bus).

Performing a warm start

- Power OFF/ON, or
- Command WARM <CR> in terminal mode (see volume 7.3) or
- Menu field "Enable PLC mode" in the programming system.

● **Operating mode : Master central unit, Slave central unit or Stand-alone central unit**

- Absolute identifier : KW 0,0
- Symbolic identifier : MAST_SLV
- Meaning of the values of the constant :
 - Master central unit at the CS31 system bus –1 (FFFF_H)
 - Stand-alone central unit –2 (FFFE_H)

- Slave central unit at CS31 system bus : CS31 unit addresses 0...61,100

If the value = 100 : the address is given by the switches of ECZ.

- Range of values : –2, –1, 0...61,100
- Default value : –2 (Stand-alone)

Important !

The change of the central unit operation mode is carried out in three steps :

1. Change system constant KW 0,0 in the central unit.
2. Save user program in the EEPROM.
3. Activate new central unit operating mode with the following steps :
 - Call menu point "Enable PLC mode" in the ABB programming and test system or
 - perform a warm start or
 - perform a cold start.

● **Back-up of data areas**

Back-up of data areas, i.e. saving of data during power OFF/ON, is only feasible with built-in battery. The following data can be backed, completely or partly :

- Binary flags
- Words flags
- Double word flags
- Step chains
- Historical values

In order to back-up certain data, they have to be excluded from initialization to 0.

● **Initialization of data areas**

During program start, that data areas are initialized to 0 partly or completely, that are defined by system constants. The initialization works as shown in the following table.

An external battery is not necessary (see §3.4 Battery).

Conditions, --> Action	Flags, step chains, and historical values which are initialized (set to 0)
Menu item --> Abort -->Cold start	all
RUN/STOP switch to RUN, --> Power ON	 according to the values of the system constants (see below)
RUN/STOP switch, --> RUN	
Menu item --> Abort --> Start	

● **Initialization : Binary flags**

- Absolute identifier : KW 0,1
- Symbolic identifier : INIT_M

Value n of the system constant KW 00,01	Binary flag areas which are initialized (set to 0)
n = 0 (default)	M 000,00...M 021,15 M 230,00...M 239,15 M 255,00...M 255,15
n = 1...21	M n,00...M 021,15 M 230,00...M 239,15 M 255,00...M 255,15
n = 22...229	M 230,00...M 239,15 M 255,00...M 255,15
n = 230...239	M n,00...M 239,15 M 255,00...M 255,15
n = 240...255	M 255,00...M 255,15
n < 0, n > 255	M 255,10...M 255,15

- Example : KW 00,01 = 20
- Bits initialized : M 020,00...M 021,15
M 230,00...M 239,00
M 255,00...M 255,15
- Bits backed : M 000,00...M 019,15

● **Initialization : Word flags**

- Absolute identifier : KW 0,2
- Symbolic identifier : INIT_MW

Value n of the system constant KW 00,02	Word flag areas which are initialized (set to 0)
n = 0 (default)	MW 000,00...MW 005,15 MW 230,00...MW 239,15 MW 254,00...MW 255,15
n = 1...5	MW n,00...MW 005,15 MW 230,00...MW 239,15 MW 254,00...MW 255,15
n = 230...239	MW n,00...MW 239,15 MW 254,00...MW 255,15
n = 240...253	MW 254,00...MW 255,15
n = 254...255	MW n,00...MW 255,15
n < 0, n > 255	no initialization

● **Initialization : Double word flags**

- Absolute identifier : KW 0,3
- Symbolic identifier : INIT_MD

Value n of the system constant KW 00,03	Double word flag areas which are initialized (set to 0)
n = 0 (default)	MD 000,00...MD 01,15
n = 1	MD n,00...MD 01,15
n < 0, n > 1	no initialization

● **Initialization : Step chains**

- Absolute identifier : KW 0,4
- Symbolic identifier : INIT_S

Value n of the system constant KW 00,04	Step chain areas which are initialized (set to 0)
n = 0 (default)	S 000,00...S 15,15
n = 1...15	S n,00...S 15,15
n < 0, n > 15	no initialization


● **Initialization : Historical values**

- Absolute identifier : KW 0,5
- Symbolic identifier : INIT_VW

Value n of the system constant KW 00,05	Historical values which are initialized (set to 0)
n = 0 (default)	Initialization of all historical values
n < 0, n > 0	no initialization

● **Application mode : Serial interface COM1**

- Absolute identifier : KW 00,06
- Symbolic identifier : MODE_SST
- Meaning of the values of the constant :



- Modes :
 - Active mode : 1
 - Passive mode (MMC) : 2
 - The status of pin 6 applies : <0, =0, >2
 - MODBUS slave mode : 101...355
 - pin 6 applies
 - MODBUS address : 1...255
 - MODBUS master mode : 100
 - pin 6 applies

- Delay modification on RTS signal : 1000...1355
2000...2355

- RTS signal inverted : 10000...12355

- Range of values : 0, 1, 2, 100...355
(modulo 1000 or 10000)
- Default value : 0
i.e. the application mode of the serial interface is determined by the status of pin 6 of the interface connector.

A change of this system constant becomes effective :
- immediately.

● PLC reaction to class 3 errors

- Absolute identifier : KW 0,7
- Symbolic identifier : FK3_REAK
- Meaning of the values of the constant :
Just output error : 0
Output error and
aband PLC program <0, >0
- Range of values : <0, =0, >0
- Default value : 0
i.e. just output error.

A change of this system constant becomes effective :
- immediately.

● Initialization of the CS31 system after power ON, warm start or cold start

- Absolute identifier : KW 0,9
- Symbolic identifier : HOCHFAHR
- This system constant is only effective if the central unit is configured as a bus master.
- Meaning of the values of the constant :
The user program is started.
The central unit takes no notice of initialization of the CS31 remote units and their adoption into the CS31 bus cycle : =0

The user program is not started until at least *n* remote units have been initialized and adopted into the CS31 bus cycle : =+n
- Range of values : 0...+31
- Default value : 0
i.e. the user program is started immediately.

A change of this system constant becomes effective :

- with the next warm start or
- with the next cold start.

● Size of the transmitting area of the slave central unit

- Absolute identifier : KW 00,10
- Symbolic identifier : SLV_SEND
- Meaning of the values of the constant :

The slave central unit can be used at the CS31 system bus *either* in the binary area *or* in the word area. The binary values are transferred byte by byte. It is possible to set the number of bytes (or words) which are to be sent from the slave central unit to the master central unit.

- For use in the binary area :
Transmitting : 2...15 bytes 2...15
- For use in the word area :
Transmitting : 1...8 words 101...108
- Default value : 4
- Range of values : 2...15 and 101...108

A change of this system constant becomes effective :

- with the next warm start or
- with the next cold start.

Note :

The default setting
- in the binary area is :
- transmit 4 bytes and
- receive 4 bytes.

This is defined by the default combination
KW 00,10 = KW 00,11 = 0.

The configured combination
KW 00,10 = KW 00,11 = 4 has the same result as the default combination.

The combination
KW 00,10 = KW 00,11 = 100
is inadmissible ! It would mean :
Transmit 0 words and receive 0 words.

When employed in the word area, the unused higher 8 channels of the address can be used by an analogue unit (no KR/KT).

A change of this system constant becomes effective :
- immediately.

● Size of the receiving area of the slave central unit

- Absolute identifier : KW 00,11
- Symbolic identifier : SLV_REC

- Meaning of the values of the constant :

The slave central unit can be used at the CS31 system bus *either* in the binary area *or* in the word area. It is possible to set the number of bytes (or words) which are to be received by the slave central unit from the master central unit.

- For use in the binary area :
Receiving : 2...15 bytes 2...15
- For use in the word area :
Receiving : 1...8 words 101...108
- Default value : 0
- Range of values : 2...15 and 101...108

A change of this system constant becomes effective :

- with the next warm start or
- with the next cold start.

Note :

The default setting

- in the binary area is :
 - transmit 4 bytes and
 - receive 4 bytes.

This is defined by the default combination

KW 00,10 = KW 00,11 = 0.

The configured combination

KW 00,10 = KW 00,11 = 4 has the same result as the default combination.

The combination

KW 00,10 = KW 00,11 = 100

is inadmissible ! It would mean :

Transmit 0 words and receive 0 words.

When employed in the word area, the unused higher 8 channels of the address can be used by an analogue unit (no KR/KT).

A change of this system constant becomes effective :

- immediately.

● **Central unit cycle time**

- Absolute identifier : KD 0,0
- Symbolic identifier : ZYKL_ZEIT
- Meaning of the values of the constant :
The central unit program is processed cyclically in the time intervals stated by the set cycle time.
The entries are made in the unit of measurement (ms).
The smallest cycle time that can be entered is 5 ms.
Only integral multiples of 5 ms are permissible.
- Range of values : 5...100 for a master CPU
5...250 for a slave CPU
- Default value : 10

A change of this system constant becomes effective :

- with the next program start.

● Mapping

System mapping

FFFF	Compiled program 1
D800 D7FF	
B000 AFFF	Compiled program 2
AF00 AEFF	Reserved
AC00 ABFF	I/O Datas
A800 A7FF	Reserved
8981 8980	Micro-code in RAM
8800 87FF	Constants
8000 7FFF	RAM non safeguarded
5000 4FFF	Reserved
4000 3FFF	Datas
2000 1FFF	UART
1000 0FFF	ASIC 2 - input ASIC
0000	ASIC 1 - output ASIC

Data mapping

AEFF	EW 15,15
AD00 ACFF	EW 00,00
AC80 AC7F	E 63,15
AC00	E 00,00
	A 63,15
	A 00,00
8980 897F	K 00,00; K 00,01
8900 88FF	KD 01,15
8800	KD 00,00
	KW 07,15
	KW 00,00
85FF 8500	AW 07,15
	AW 00,00
47D1 47B2	S 015,15
	S 000,00
467F 4600	MD 001,15
	MD 000,00
4581 4542	MW 255,15
4541	MW 254,00
4402 4401	MW 239,15
	MW 230,00
	MW 005,15
4342 4341	MW 000,00
	M 255,15
4340 433F	M 255,00
	M 239,15
432C 432B	M 230,00
	M 021,15
4300 42FF	M 000,00
	Historical values
4100 40FF	
	Timers
4000	

● Name of function	Call in		● Program control functions		
(CEs arranged according to function groups)	FBD/LD		Conditional jump to label	SPBM /SPRUNG	
	ext.IL / IL	(1)	Target label	MRK / MR	
			Program end	PE	
● Binary functions			Conditional program end	=PE	(2)
AND	&	(2)	Soubroutine call for an		
OR	/	(2)	assembler program	CALLUP	
Exclusive OR	=1	(2)			
Allocation	=	(2)	● Format conversion		
			BCD to binary conversion	BCDDUAL / BCDBIN	
● Latch functions			Binary to BCD conversion	DUALBCD / BINBCD	
Allocation, set memory	=S	(2)	Pack binary variables in word	PACK	
Allocation, reset memory	=R	(2)	Unpacking a word into binary		
Set memory, dominating	RS	(2)	variables	UNPACK	
Reset memory, dominating	SR	(2)	Word to double word conversion	WDW	
			Double word to word conversion	DWW	
● Arithmetic functions, word			● Pulse		
Addition	+	(2)	Puls(rising edge)	I+	(2)
Subtraction	-	(2)	Puls(falling edge)	I-	(2)
Multiplication	*	(2)			
Division	:	(2)	● Logical functions with word values		
Multiplication with division	*/ / MULDI		AND combination, word	WAND	
Multiplication by 2			OR combination, word	WOR	
to the power of n	MUL2N		Exclusive OR combination, word	WXOR	
Absolute value generator	BETR		● Access to physical addresses		
Allocation Word	=W	(2)	Copying memory areas	COPY	
Allocation direct constant			Read word with enabling	WOL	
to word variable	ZUDKW		● Higher order functions		
● Comparison functions			Binary selection gate	AWTB	
Greater than	>	(2)	Selection gate, word	AWT	
Greater than or equal to	>=	(2)	Maximum value generator	MAX	
Equal	=?	(2)	Minimum value generator	MIN	
Unequal	><	(2)	Limiter	BEG	
Less than	<	(2)	List allocator	LIZU	
Less than or equal to	<=	(2)	Binary value change annunciator	BMELD	
● Timer functions			Read word variable, indexed	IDLm / IDL	
On delay	ESV		Write word variable, indexed	IDSm / IDS	
Off delay	ASV		Clock	UHR	
Monostable element «abort»	MOA		● Automatic control engineering functions		
Monostable element «constant»	MOK		Proportional-integral-controller	PI	
● Counter functions			Pulse duration modulator	PDM	
Up-down counter	VRZ				

(1) If a different call exists for IL compared to FBD/LD and extended IL. It is additionally given and separated by a /.

(2) This function is generated in the IL by a sequence of commands and/or blocks.

● **Communication through serial interface**

Initialization and configuration to
the serial interface SINIT

Output of ASCII characters and
HEX values through a serial
interface DRUCK

Reception of characters EMAS

Modbus master MODBUS

● **CS31 functions**

Configure CS31 unit CS31CO

Acknowledge CS31 error CS31QU

The terminal mode is used with the active mode of the central unit 07 KR 31 or 07 KT 31.

The central unit can be programmed, tested and all operative functions are available.

The communication is in ASCII protocol.

This terminal mode can be used with the aid of a terminal, the TCZ service device or the ABB Procontic programming software 907PC331.

For a complete description refer to Vol 7 part 3.

The list of the different commands can be displayed with the command H <CR>. The description of the commands is only in English language.

● Command for creating the user program


AEND	Prepare a program change on a running central unit program
ALT	Reactivate the user program stored in EEPROM
AL	Display central unit capacity utilization normally less than 100%
D	Display program
DEEP	Erase user program in EEPROM
FREI	Enable a program change on a running user program
IDA	Display program identification
IDR	Delete program identification
IDS	Enter program identification
K	Enter/edit values of indirect constants
NOP	Delete program part, i.e. overwrite program part with NOPs
O	Optimise the program all NOPs are deleted; syntax: O<CR>
P	Display free program memory area
S	Enter/edit user program (substitute)
SP	Save user program in EEPROM
V	Move user program (only towards to the end)

● Command for testing the user program


A	Abort user program
FEHLER	Display contents of the error register
FORC	Enter Force values (max. 7 words and 31 bits)
FORCA	Display Force values
FORCR	Delete forcing
G	start user program
KALT	Perform cold start
PS	Display program status
ST	Display central unit status
WARM	Perform a warm start
Y	Overwrite value of a variable with a value to be entered
Z	Display status of variables
ZD	Display and continually update status of variables
ZZ	Display only the values of variables

● Commands for configuring

KONFS	Display/change operating modes English/German (The German language has to be used with the ABB Procontic software 907 PC 331)
MAIL	Configuration and diagnosis of CS31 remote units
PASS :	Password  enable or disable the password value : 4 hexanumbers The value 0000 is not allowed The user can't have access to the following commands AEND, D, DEEP, FREI, N, NOP, O, S, V (display or modification of program) when the program is protected by a password.
UHR	Display time and date
UHRS	Set time and date (without syntax control)




Central unit 07 KR 31



Central unit 07 KT 31

- ① 12 yellow led's labelled "**Input**" to indicate status of the inputs.
- ② 8 yellow led's labelled "**Output**" to indicate the presence of the outputs.
- ③ 1 green led labelled "**Supply**" to indicate the presence of the supply
- ④ 1 green led "**RUN**"
- ⑤ 1 red led for the error status
- ⑥ 1 "**RUN/STOP**" switch to start and stop the program execution
- ⑦ 1 serial interface RS 232 C
- ⑧ Assignment of the indentifiers for the inputs
- ⑨ Assignment of the identifiers for the outputs
- ⑩ The central unit has to be plugged on the plug-in base ECZ.


The plug-in base ECZ can be mounted on a DIN rail 35 x 15 mm - EN 50022.




The **RUN/STOP** switch is used to start or abort the processing of the user program.

The central units 07 KR 31 and 07 KT 31 have to be mounted on the plug-in base ECZ.
The terminals are connected on the plug-in base ECZ.

07 KR 31 - 120 VAC / 230 VAC versions




07 KT 31 - 120 VAC / 230 VAC versions




The internal 24 VDC (100 mA) power supply is only available for the 230VAC/120VAC versions. This power is used to power the inputs.

07 KR 31 - 24 VDC version



07 KT 31 - 24 VDC version



Please observe in particular :

- The earthing measures
- The handling of the electrically isolated input groups
- The handling of the electrically isolated output groups
- The connection of analog-value receiver and analog-value sensor
- The earthing of the switch cabinet mains socket

For 07 KT 31

- A free wheel diode is not necessary because the protection is integrated into the transistor component.
- An external thermal fuse max. 5A has to be connected between the common + terminals and the 24 VDC to avoid damage in case of use of a lot of overload outputs.

Variables used in the central unit

Input	Channel	Output	Channel
A	E62,00	M	A62,00
B	E62,01	N	A62,01
C	E62,02	O	A62,02
D	E62,03	P	A62,03
E	E62,04	Q	A62,04
F	E62,05	R	A62,05
G	E62,06	S	A62,06
H	E62,07	T	A62,07
I	E62,08		
J	E62,09		
K	E62,10		
L	E62,11		

3.1



07 KR 31 / 07 KT 31 Central processing units

Electrical isolation and notes on earthing




The following illustration shows the parts of the device's circuit which are electrically isolated from each other as well as the internal connections which exist. Both the creepage distances and clearances as well as the test voltages used correspond to DIN/VDE 0160.

The earth on the plug-in base ECZ has to be connected directly and on the shortest possible way to the switch cabinet earthing using a wire with a cross section of 6 mm² in order to ensure safe earthing and as an EMC measure.

For the 07 KR 31 :




For the 07 KT 31 :



Please observe :

- All of the CS31 devices, no matter whether they are master or slave devices, are connected with the twisted-pair bus line as follow :
 - One core of the bus line is looped through via the bus n°2 terminals of the CS31 system bus.
 - The other core of the bus line is looped through via the BUS 2 terminals of all devices to be connected to the CS31 system bus.
- If the central unit 07 KR 31 / 07 KT 31 is located at the beginning or at the end of the bus line, the bus terminating resistor (120 1/4W) has to be connected additionally between the bus n°1 and the bus n°2 terminals.
- The shield of the twisted-pair bus line is looped through via the shield terminals of all the devices to be connected to the CS31 system bus.
- The handling of the CS31 system bus is described in detail in volume 2, System data.




3.3 07 KR 31 / 07 KT 31 24V output voltage for the signal Central processing units supply of the inputs

The central units 07 KR 31 / 07 KT 31 provide a 24VDC (100mA) voltage output for the 12 binary input signals (for this purpose only).

This 24V output voltage is only available for the 230 / 120VAC version.

The internal 24V power supply is overload-proof. The 24V output voltage is ready for operation again approx. 2 minutes after an overload has been eliminated.



All data (flags, words, historical datas, real-time clock) can be stored in a zeropower RAM (battery included into the RAM).

The battery lifetime is 5 years. The battery lifetime is the time during which the device remains operable in order to backup data while the supply voltage of the central is switched off. As long as there is a supply voltage available, there is no more load on the battery other than its own leakage current.

The battery can not be changed.

A battery failure is detected with the bit 3 of the status word EW 07,15 :


Bit 3 = 0 : battery failure

Bit 3 = 1 : no battery failure.

Interface standard : EIA 232

● Assignment of the serial interface

The serial interface has the following pin assignment :



- G** : Housing Protective Ground (Shield)
- 1** : not used
- 2** : TxD Transmit Data (Output)
- 3** : RxD Receive Data (Input)
- 4** : RTS Request To Send (Output)
- 5** : CTS Clear To Send (Input)
- 6** : PROG*
- 7** : SGND Signal Ground (0V)
- 8** : not used
- 9** : +5V out Supply for the TCZ service device**

* 1 = Active mode (Programming/test)
 0 = - Passive mode (DRUCK/EMAS applications),
 Pin 6 shorted to 0V
 - MODE MODBUS Pin 6 shorted to 0V out

** 5V output (only for supplying the TCZ service device) :
 The connected service device receives its voltage supply via the interface cable.

● Operating modes of the serial interface

The operating mode of the interface has to be set according to the application in each case :

- Programming and test or
- Man-machine-communication MMC
- MODBUS protocol (master and slave)

Active mode : The active mode is used for programming and testing the central unit, i.e. it gives the user access to all the programming and test functions of the central unit.

Passive mode : The passive mode is used to perform a communication configured with the DRUCK and EMAS blocks between the user program and a device connected to the serial interface.

MODBUS protocol : The MODBUS protocol is used to perform a communication between the central unit and a device connected to the serial interface.

● Conditions for setting the operating modes of the serial interface.


- Modes

System constant KW00,06*	RUN/STOP switch	System cable/device	Mode set by this
0,<0,>2,<100 >355	STOP	X	active
	RUN	07 SK 90 FPTN404948R0002	active
		07 SK 91, TCZ FPTN404948R0006	passive
1	X	X	active
2	STOP	X	active
	RUN		passive
>99, <356	X	07 SK 91 FPTN404948R0006 (Pin 6 shorted to 0V)	MODBUS
		07 SK 90 FPTN404948R0002	active

X : Without effect

* : KW 00,06 modulo 1000 or 10000

- Delay on RTS signal



System constant KW 00,06	$T_1 - T_2 - T_3$
0 - 99 or 10000 - 10099 (active or passive modes)	The RTS signal depends on the number of characters in the received buffer. When the buffer is full, the RTS signal is modified.
100 - 355 or 10100 - 10355 (MODBUS mode)	$T_1 = 0$ $T_2 = 0$ $T_3 = 0$
1000 - 1099 11000 - 11099 (active or passive modes)	$T_1 = T_2 = T_3 = 1$ character (i.e. : at baud rate = 9600 bauds, time for 1 character : $T = 1,15$ ms)
1100 - 1355 2100 - 2355 11100 - 11355 12100 - 12355 (MODBUS mode)	$T_2 = 5$ ms $T_1 = T_3 = 0$
2000 - 2099 12000 - 12099 (active or passive modes)	$T_1 = T_2 = T_3 = 3$ characters (i.e. : at baud rate = 9600 bauds, time for 3 characters : $T = 3,45$ ms)

● Interface parameters

Active mode : The setting of the interface parameters cannot be changed

Data bits : 8
 Stop bits : 1
 Parity bits : none
 Baud rate : 9600
 Synchronization : RTS/CTS

MODBUS mode : Default setting

Data bits : 8
 Stop bits : 1
 Parity bits : none
 Baud rate : 9600

Passive mode :

Interface identifier COM1 : 1
 The function block SINIT has to be used to set up the parameters.


● Signal level

System constant KW 00,06	Actif RTS signal level
00000 - 02355	- 10V
10000 - 12355	+10V


3.6

07 KR 31 / 07 KT 31
Central processing units


Dimensions




07 KR 31 / 07 KT 31



07 KR 31 / 07 KT 31 c/w plug-in base ECZ




Plug-in base ECZ



● Features

The high-speed counter used in the central units 07 KR 31 or 07 KT 31 works independently of the user program. Its features are as follows :

- The counting frequency is max. 10 kHz. The counter counts the 0→1 edges at terminal 04 on the plug-in base ECZ (also designated as E 62,00).
- The counter counts upwards from –32768 to +32767 (8000_H...7FFF_H). If +32767 is exceeded, the counter skips to –32768.
- Sequence of the counting procedure :



- Setting the counter in the user program :
 - to the value contained in the internal word variable AW 06,15
 - using the internal variable A 63,15 = 1.

NOTE : If the internal variable A 63,15 = 1 is present during several processing cycles, the processor sets the counter at the program end in each case. During the remaining time of the processing cycle, the counter counts pulses at terminal 04.

- The counter content can be read via the internal variable EW 06,15.

- Zero-crossing message (signal changes from 0 to 1 when the counter contents changes from –1 to 0) :
 - always via the internal variable E 63,13.

The zero-crossing message is cancelled when the counter is set.

- Fast input of binary signals into the user program with a delay of < 0,02 ms :
- Terminal 04 (also designated as E 62,00) : Internal variable E 63,14.

● Preset start values

You can preset both *positive* and *negative* start values for the counter.

The counting operation starts at the start value and is continued in correspondence with the arrows in the diagram until the enabling is stopped or a start value is loaded again.

● Negative start value

The minimum negative start value is – 32768 (8000_H). By presetting a negative start value it is thus possible to count a maximum of 32768 pulses up to the zero crossing of the counter.

● Positive start value

If a positive start value is preset, the counter counts up to the value of +32767 (7FFF_H), continues the counting operation at the value of –32768 (8000_H) and then signals the zero crossing when reaching the transition from –1 to 0.

The minimum positive start value is 1. If you preset this value, 65535 pulses will be counted up to the zero crossing.

In order to count more than 32767 pulses up to the zero crossing, the start value has to be calculated according to the following equation :

$$\text{Start value} = 32767 - (\text{number of pulses} - 32768)$$

Example :

40 000 pulses are to be counted.

The start value is in the positive range, because more than 32768 pulses have to be counted.

Calculation :

$$\begin{aligned} \text{Start value} &= 32767 - (\text{number of pulses} - 32768) \\ &= 32767 - (40\,000 - 32768) \\ &= 25535 \end{aligned}$$

The most important times for the application of the central units 07 KR 31 / 07 KT 31 with or without connected remote units are :

- The **reaction time** t_{kk} is the time between a signal transition at the input terminal and the signal response at the output terminal.

In case of binary signals, the reaction time consists of the input delay t_D , the cycle time t_{UP} of the program processing and the bus transmission time, if the system is expanded by remote units.

- The **cycle time** t_C determines the time intervals after which the processor starts the execution of the user program again.

The cycle time has to be specified by the user. It should be greater than the program processing time t_{UP} of the user program, the CS31 bus transmission time and the related waiting times.

The cycle time is also the time base for some time-controlled functions, such as for the timers.

- The **program processing time** t_{UP} is the net time for processing the user program.

For the configuration and for determining the reaction time t_{kk} , the following steps are necessary :

- Determining the program processing time t_{UP}
- Determining the bus cycle time t_b , if there are any remote units connected to the central unit.
- Addition of the other times which are within the cycle time t_C .
- Specification of the cycle time t_C .
- Reaction time t_{kk} as the sum of the input delay t_D and 2 x cycle time t_C and output delay t_{DO} .

In addition to calculating the cycle time t_C in accordance with chapter 5.2 it is possible to measure the capacity utilization on the programmed central unit – with the RUN/STOP switch set to RUN. The menu item of "Display central unit status" in the programming software 907 PC 331 can be used for this purpose. Increase the cycle time t_C until the capacity utilization is below 80 %.

The capacity utilization could be greater than 100 %. In this case, a FK3 error is generated (code 200_D), M 255,13 is set to 1.

The central unit is always processing. This capacity utilization allows to reduce the cycle time even if the initialization is too long.

5.1 07 KR 31 / 07 KT 31 Central processing units

Program processing time t_{UP}

● Binary instructions of the type :

!M / M &M = M

!NM /NM &NM = NM

Processing time for 1000 instructions : 6 ms

!M /M &M = SM

!NM /NM &NM = RM

Processing time for 1000 instructions : 6 ms

● Word instructions of the type :

!MW +MW -MW = MW

!-MW -MW +MW = -MW

Processing time for 1000 instructions : 18 ms

!MW *MW *MW = MW

Processing time for 1000 instructions : 120 ms

!-MW : MW :-MW = -MW

Processing time for 1000 instructions : 750 ms

● Mixed instructions

- 65 % binary : !, /, &, =

- 20 % word : !, +, -, =

- 15 % word : !, *, =

Processing time for 1000 instructions : 25,5 ms

- The program processing times of all the function blocks are specified in the documentation of the programming software 907 PC 331.

TIMES TO BE TAKEN INTO CONSIDERATION WHEN THE CENTRAL UNITS 07 KR 31 / 07 KT 31 ARE USED AS :				
	Stand alone	Slave	Bus master inputs and outputs remote units	Explanation
	–	$500\mu s \leq t_B \leq 2200\mu s$	$t_B \geq 3 \text{ ms}$	– Communication time on the CS31 bus. – For a slave t_B has to be added to t_{UP} each t_B cycle time of the master. The worst case is only one slave on CS31 bus with a short cycle time in the master.
	t_{UP}	t_{UP}	t_{UP}	Program processing time

The cycle time t_c has to be preset by the user taking the following equation into consideration :

$$t_c \geq t_B + t_{UP}$$

This equation assumes that the processor always gets access in the most unfavourable moment.

– For a slave, the bus transmission time is :

$$T_B \text{ slave} = 66 \mu s + \text{number of sent/received bytes}$$

The cycle time t_c is stored in KD 00,00 and can be selected in 5 ms time steps. If the selected cycle time is too short, the processor will come in default then.

If this lack of time is getting too large over 16 successive cycles, the processor will generate an error (FK3) and continue the program execution (according the value of the system constant KW 00,07).

Using some function blocks, such as the PI controller, the error-free execution depends on an exact timing sequence. Make sure that there is a larger time reserve.

The correct setting of the cycle time can be checked by the following procedure :

– Loading the user program into the central unit.

- If the operating mode has been switched over from stand-alone to bus master : Power ON or menu item "Enable PLC mode" in the programming software.
- Interrogation of the capacity utilization using the menu item of "Display PLC status".
- Changing the cycle time t_c until the capacity utilization is below 80 %.

5.3 07 KR 31 / 07 KT 31 Reaction time Central processing units in case of binary signals

TIMES TO BE TAKEN INTO CONSERATION WHEN THE CENTRAL UNITS 07 KR 31 / 07 KT 31 ARE USED AS :				
	Stand alone inputs and outputs of its own	Slave inputs and outputs of its own	Bus master inputs and outputs via remote units	Explanation
Inputs of remote unit or central units	$t_D = 5 \text{ ms}$	$t_D = 5 \text{ ms}$	$t_D = (8 \text{ ms})$	Inputs signal delay t_D of binary remote units normally typ. 8 ms or of central unit type 5 ms.
Cycle time	$t_C \geq 5 \text{ ms}$	$t_C \geq 5 \text{ ms}$	$t_C \geq 5 \text{ ms}$	Cycle time t_C , to be set by the user.
Outputs of remote units or outputs of the central unit	—	—	$t_{do} (< 1 \text{ ms})$	Output signal delay time of binary remote units : normally < 1 ms for a transistor output and < 5 ms for a relay output.

- The maximum reaction time t_{kk} (input terminal to output terminal) results from the asynchronicity of the operations.
- Bus master central unit via inputs and outputs of remote units :

$$t_{kk} = t_D + 2 \cdot t_C + t_{do} + t_B + n \cdot 100 \text{ } \mu\text{s}$$

with

$$t_C \geq t_{UP} + t_B$$

t_{UP} : program processing time
 t_B : bus CS31 cycle time
 n : number of units on the bus

In case of analog signals, the refresh times are to be entered in the formula instead of the delay times.

Example : Bus master central unit + 1 binary input module + 1 binary output unit + 2 analog input units, reaction time for binary signals via the remote units :

input delay time : $t_D = 8 \text{ ms}$

bus CS31 cycle time : $t_B = 3 \text{ ms} + 387 \text{ } \mu\text{s} + 323 \text{ } \mu\text{s} + 1355 \text{ } \mu\text{s} + 1355 \text{ } \mu\text{s}$

$$t_B = 5,4 \text{ ms}$$

cycle time : $t_C = 15 \text{ ms} (t_C > t_B + t_{UP})$


output delay time : $t_{do} = 1 \text{ ms}$

terminal-to-terminal reaction time c.a. : $t_{kk} = 44,8 \text{ ms}$


The cycle time t_b of the CS31 bus depends on number and type of the remote units (see vol. 2 refresh time).

Structure examples with 07 KR 31 / 07 KT 31 / 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master

Example 1 : 07 KR 31, 07 KT 31, 07 KR 91, 07 KT 92 or 07 KT 93 used as stand-alone central unit




07 KR 91
07 KT 92 / 07 KT 93




07 KR 31 / 07 KT 31

Example 2 : 07 KR 31, 07 KT 31, 07 KR 91, 07 KT 92 or 07 KT 93 used as bus master on the CS31 system bus, as remote units only I/O units are used.



Example 3 : 07 KR 31, 07 KT 31, 07 KR 91, 07 KT 92 or 07 KT 93 as bus master and as slave on the CS 31 system bus, in addition I/O units.



Without regard to the address ranges, the following units can be connected to a CS31 system bus :

- max. 1 bus master
- max. 31 remote units/slaves

Further restrictions result from the address range of the central units :


- | | | | |
|--------------------|-------------------------------|------------------------------|-------------------------------|
| 07 KR 31/07 KT 31: | - max. 28 analog input units | 07 KR 91/07 KT 92/07 KT 93 : | - max. 12 analog input units |
| | - max. 12 analog output units | | - max. 12 analog output units |
| | - max. 31 binary input units | | - max. 31 binary input units |
| | - max. 31 binary output units | | - max. 31 binary output units |

There may be further restrictions according to the structure of the installation and the type of remote units. For the recommended addresses, (see chapter 6.1 "**Recommended unit addresses on the CS31 bus**").

Structure of the input and output addresses in the remote units

The binary input unit ICSI 08 D1 will be explained here as an example.

The bus master central unit reads the input signals as operands. The complete address of an input signal has the following structure :



6.1 07 KR 31 / 07 KT 31 Recommended unit addresses Central processing units on the CS31 bus

The standard addressing has the purpose of :

- simplifying and schematizing the setting of addresses on the CS31 system bus
- simplifying diagnosis and troubleshooting.

The standard addressing makes sure that there will be no address overlapping even for units with a bigger amount of data.

Recommendations :

- Assign a specific unit address for each unit/each slave central unit; binary and analog units can be set to the same address.
- Unit addresses for binary remote units and central units : 0, 2..., 58, 60 (all even numbers), (see also chapter 6.5 "**Intelligent I/O remote units** (slave central units)").
- Unit addresses for analog remote unit :
0...5 and 8...15 : analog input remote units
0...5 : analog output remote units.
- Address switch No. 8 on the plug-in base ECZ always set to OFF (≤ 7) for the binary remote units.

● Input and output units connected as slaves to the CS31 system bus

The remote units are mounted on the plug-in base ECZ. This plug-in base is equipped with an address switch (DIP switch) for setting the unit address.

The combination of unit type, unit address and channel number results in the variable address used by the bus master central unit.

● Setting the address switch for binary units

The possible range of unit addresses when using the central units 07 KR 31 / 07 KT 31 is :

– 0...61

● Setting the address switch for analog units

The possible range of unit addresses when using the central units 07 KR 31 / 07 KT 31 is :

– 0...5 and 8...15 : analog input remote units

– 0...5 : analog output remote units

6.3 07 KR 31 / 07 KT 31 07 KR 31 / 07 KT 31 used as a Central processing units stand-alone central unit

If the central units 07 KR 31 / 07 KT 31 are used without the CS31 system bus connected, perform the following setting when programming in the user program :

System constant KW 00,00 = -2

This value is the factory setting.

6.4 07 KR 31 / 07 KT 31 07 KR 31 / 07 KT 31 used as a Central processing units bus master central unit

If remote units (slaves) are connected to the central unit 07 KR 31 or 07 KT 31 via the CS31 system bus, proceed as follows :

1. Change the system constant : KW 00,00 = -1
2. Save the user program in the EEPROM.
3. Activate the new PLC mode by :
 - calling the menu item "Enable PLC mode" in the ABB programming and test system, or
 - entering the command WARM <CR> in terminal mode or
 - power ON or
 - cold start.

The central units 07 KR 31, 07 KT 31, 07 KR 91, 07 KT 92 and 07 KT 93 can also be used as slaves at the CS31 system bus, (see chapter 6 "Addressing" example 3). The central units 07 KR 31 / 07 KT 31 / 07 KR 91 / 07 KT 92 / 07 KT 93 may be used both in the binary range and in the word range.

The address can be set to a value from 0 to 61. The maximum permissible address depends on the size of the set transmit and receive range. The larger you choose the transmit or the receive range, the smaller is the maximum permissible address (see examples 1...3).

If you want to switch over to the "slave mode", proceed as follows :

1. Change the system constant : KW 00,00 = 0...61
Only for 07 KR 31 and 07 KT 31 : if KW 00,00 = 100, the address of the slave is chosen by the di1 switches of the plug-in base ECZ as a standard remote unit address range : 0...61.
2. Save the user program in the EEPROM.
3. Activate the new PLC mode by :
 - calling the menu item "Enable PLC mode" in the ABB programming and test system or
 - entering the command WARM <CR> in terminal mode or
 - power ON or
 - cold start.

There is no direct access to the inputs and outputs of the slave central unit via the CS31 system bus. The communication between master and slave is performed using input and output operands.

All the master data are consistently transferred to the slave, and all the slave data are consistently transferred to the master.

The slave central unit can be used *either* in the binary range *or* in the word range of the CS31 system bus. The transmit and receive ranges of the slave can be adapted to the application-specific requirements by means of the two system constants KW 00,10 and KW 00,11 (see also chapter 1.4 "Operands" § System constants).

- You can set :
- The size of the transmit and receive ranges and
 - the mode of employment of the slave (in the binary or the word range).

Default condition :


If the central units 07 KR 31 / 07 KT 31 / 07 KR 91 / 07 KT 92 / 07 KT 93 are switched over to the "slave mode", they behave like binary input and output units with 32 inputs and 32 outputs when connected to the CS31 system bus.

This means that the default setting of the transmit and receive ranges is within the binary range of the master. Their size is 32 bits each (4 bytes).

Example 1 :

Default configuration of the slave (binary range) :
 KW 00,10 = 0 : Slave transmit range : 4 bytes
 (4 bytes * 8 channels = 32 binary O)
 KW 00,11 = 0 : Slave receive range : 4 bytes
 (4 bytes * 8 channels = 32 binary I)

Note :
 The default configuration is the same as the configuration KW 00,10 = KW 00,11 = 4.




n : Unit address of the slave central unit
 for this example : 0 ≤ n ≤ 60

For the slave address of n = 12 the following applies, for example :
 The output signal A 00,00 of the 07 KR 31 used as slave is the input signal E 12,00 for the 07 KR 31 used as bus master.

Example 2 :

Configuration of the slave for the binary range :

KW 00,10 = 15 : Slave transmit range : 15 bytes
 (15 bytes * 8 channels = 120 binary O)
 KW 00,11 = 06 : Slave receive range : 6 bytes
 (6 bytes * 8 channels = 48 binary I)




n : Unit address of the slave central unit
 for this example : $0 \leq n \leq 54$

For the slave address of n = 12 the following applies, for example :
 The output signal A 00,00 of the 07 KR 31 used as slave is the input signal E 12,00 for the 07 KR 31 used as bus master.

Example 3 :

Configuration of the slave for the word range :

KW 00,10 = 101 : Slave transmit range : 1 word
 (1 word = 1 word output)
 KW 00,11 = 108 : Slave receive range : 8 words
 (8 words = 8 words inputs)



n : Unit address of the slave central unit
 (see chapter 6.2 "Address setting for the units").

For the slave address of n = 4 the following applies, for example :
 The output signal AW 00,00 of the 07 KR 31 used as slave is the input signal EW 04,00 for the 07 KR 31 used as bus master.

Dependent on the type of I/O units the following can be configured :

- in case of binary I/O units, an input delay different from the factory setting,
- in case of binary units with combined I/O channels, these channels can also be defined as input only or output only,
- in case of binary units, open-circuit monitoring at inputs and outputs,
- in case of analog units, measuring or output ranges which differ from the factory setting.

Switching over of inputs and outputs, switching on the diagnosis functions and changing the measuring and output ranges are performed as follows, depending on the unit type :

- Performing the I/O configuration via the CS31 system bus, either by means of the user program of the bus master central unit or by means of a terminal.
- Setting of switches on the plug-in base ECZ or on the rear side of the input/output unit.
- External wiring on the input/output unit terminals.

In some cases, there is a relation between the settings made on the remote unit and the information and diagnosis messages which can be interrogated at the remote unit or via the CS31 system bus. This relation will be explained in the following chapters.

There is no need for you to perform an I/O configuration via the CS31 system bus if the factory setting is sufficient. Once an I/O configuration has been performed, it will remain stored in the corresponding I/O unit until it is changed again. Even in case of power OFF it will not be deleted.

All possibilities of the I/O configuration are described in the volume 2 "**Hardware description**".

7.1 07 KR 31 / 07 KT 31 Performing and reading Central processing units the I/O configuration

There are the following possibilities for system structures when using 07 KR 31 or 07 KT 31 as bus master :

- Performing and reading the I/O configuration via the user program of the bus master central unit 07 KR 31 or 07 KT 31
- Performing and reading the I/O configuration by means of the terminal or
- Reading the I/O configuration from the remote units.

Performing and reading the I/O configuration via the user program

The function block CS31CO is available for the I/O configuration of the units. This function block is part of the programming software 907 PC 331 and is described in the corresponding documentation.

Performing and reading the I/O configuration by means of the terminal or TCZ

This method is based on the fact that the central units 07 KR 31 / 07 KT 31 use a dialogue language at the programming interface which allows the I/O configuration to be performed and interrogated by means of simple protocols (see volume 7.3, chapter 3 "**MAIL command**").

07 KR 31 and 07 KT 31 are equipped with the special function for I/O configuration.

The following devices can be used as terminal :

- A commercially available terminal equipped with an EIA-232 interface, such as VT100.
- A PC equipped with the programming software 907 PC 331. All the interface data are correctly set under the main menu item of "PLC communication 2", sub-item "Terminal emulation".
- The service device TCZ in the operating mode
1 = TERMINAL, 2 = CHAR.MODE, N = transmission speed unchanged, 9600 Baud.

Reading I/O configuration and diagnosis data at the remote unit

(See vol. 2. "**Hardware description**").

The diagnosis system of the 07 KR 31 and 07 KT 31 is designed to ensure a quick and efficient troubleshooting. For this purpose, it is classified :

- "**vertically**" in diagnosis, error flags, reactions, LED display and acknowledgement, (see chapter 8.2 "**Acknowledgement of error messages in the remote units**").

There are interrelations between the bus master central unit and the remote units. The central unit reads the diagnosis data which the remote units have found out. An acknowledgement in the central unit also causes the stored error messages in the remote units to be deleted.

- "**horizontally**" in 4 error classes, in correspondence with the severity of the error, (see chapter 8.2 "**Acknowledgement of error messages in the remote units**").


This concept is based on a system structure consisting of a bus master central unit and several remote units, and remote processors as well. The diagnosis system detects the following errors :

- Errors in the bus master central unit
- Errors on the CS31 system bus
- Errors in the remote units
- Errors in the wiring of the remote units on the process side

The troubleshooting is performed as follows :

- The red LED on the central unit 07 KR 31 gives first hints. The errors detected by the remote units are also displayed here.
- If these hints are not sufficient, the error flags have to be read out. For the meaning of the error flags, (see chapters 8.6 "**Meaning of the contents of the error word flags**" and 8.7 "**Reaction on the bus master central unit and the remote units in case of errors**").
- The status register EW 07,15 in the central unit supplies additional information to be used for the diagnosis (see chapter 8.2 "**Acknowledgement of error messages in the remote units**").
- The remote units indicate errors occurring in their area. Detailed information can be obtained by pressing the test key on the units, (see chapter 8.3 "**Error flags in the central unit, error classification**").

Central processing units



C.119 D

8.2

07 KR 31 / 07 KT 31 Central processing units

Acknowledgement of error messages in the remote units


The remote units store and display the error messages detected independently of the central unit. The error messages can be acknowledged :

- on the remote units by pressing the test button
- in the user program by means of the function block CS31QU (this also deletes the error message stored in the central unit)
- in the terminal mode by means of the command MAIL (see volume 7.3 chapter 3 "MAIL command").

If the error has not been eliminated, the error message appears again.

M 255,10	= 1	Summation error message
M 255,13	= 1	Error class message (FK3 error)
MW 255,00	= 15	Error detection : remote unit is disconnected
MW 255,01	= 05	Unit type : analogue input and output
MW 255,02	= 03	Group number (unit address)
MW 255,03	= 0	} not concerned, as well as all the other error flags which have not been mentioned
MW 255,04	= 0	
MW 255,05	= 0	
MW 55,06	= 0	
MW 255,07	= 0	

Example of an error message



LED displays on the bus master central unit 07 KR 31 or 07 KT 31

Run led lights : up
Red led : error

Reaction of the bus master central unit 07 KR 31 or 07 KT 31

The processing program and the bus operation continue running (if KW 0,7 = 0).

Reaction of the remote unit ICSM 06 A6 : All of the outputs turn to 0.

Reaction of the remote unit ICSC 08 L1 : Data exchange with the bus master central unit 07 KR 31 or 07 KT 31.

Status word EW 07,15 in the central unit 07 KR 31 or 07 KT 31

- Bit 0 = 1 no class 2 error
- Bit 1 = 0 only applicable for 07KR31 or 07KT31 used as a slave
- Bit 2 not used.
- Bit 3 = 1 no battery failure.
- Bits 4...7 not used
- Bits 8...15 = 2 max. number of units connected to the CS31 system bus which have been found since the last power-on operation. Will not be altered by the error which has occurred in the meantime.

Errors which occurred :

The bus line to the remote unit having the unit address 3 has been broken during operation.

Error flags in the central unit 07 KR 31 or 07 KT 31

It is assumed that the error flags have been set to 0 by acknowledgement/deletion before the error occurred. In the following, only those error flags will be listed the contents of which changes.

Acknowledgement of the error flags in the central unit 07 KR 31 or 07 KT 31

Eliminate the error before acknowledgement. Otherwise the error message will appear again.

The bit flags M 255,10 and M 255,13 can be acknowledged by :

- power ON
- program "Start" (on-line in the programming software 907 PC 331)
- cold start (menu item in 907 PC 331)
- setting the RUN/STOP switch to RUN
- overwriting the flag M 255,13 with "0" in the user program
- overwriting the flag M 255,13 with "0" by means of the operating function "Overwrite" (see volume 7.3 chapter 3).
- using the function block CS31QU in the user program. The block is applicable only for errors which concern the CS31 system bus. It also deletes the error message in the remote units.

The error LED turns off upon the acknowledgement.

The word flags MW 255,00...MW 255,07 can only be deleted by overwriting them. They are overwritten by newly occurring errors.

Acknowledgement of error flags in the remote unit ICSM 06 A6

- on the unit by pressing the test button for a longer time
- in the user program of the central unit using the CS31QU block
- in the terminal mode by means of the MAIL command (see volume 7.3 chapter 3).

8.3

07 KR 31 / 07 KT 31

Error flags in the central unit, Central processing units error classification

The central unit offers error messages for the user program which are classified into 4 error classes (FK1...FK4) according to their severity. The error messages are stored in error flags and can be used in the user program and be read by the programming system.

The following table gives you an overview of the error flags.

Error class	FK1 = fatal error	FK2 = serious error	FK3 = light error	FK4 = warning
General feature of the error class, examples	Save operation of the operating system is no longer ensured. <i>Error example :</i> – Checksum error in the operating system EPROM	The operating system works correctly, but the error-free processing of the user program is not guaranteed. <i>Error example :</i> – Write/read error when testing the user RAM	The choice whether the user program has to be aborted by the operating system or not depends on the application. The user decides which reactions are to be initiated. <i>Error example :</i> – Remote module has failed	Errors which occur on peripheral devices or which will show their effect only in the future. The user decides which reactions are to be initiated. <i>Error example :</i> – Short circuit on a remote module
Summation error message (1)	M 255,10			
Error class message (if 1, an error exists)	M 255,11	M 255,12	M 255,13	M 255,14
Error detection (word) (2)	MW 254,00	MW 254,08	MW 255,00	MW 255,08
Detailed info 1 (word) (2)	MW 254,01	MW 254,09	MW 255,01	MW 255,09
Detailed info 2 (word) (2)	MW 254,02	MW 254,10	MW 255,02	MW 255,10
Detailed info 3 (word) (2)	MW 254,03	MW 254,11	MW 255,03	MW 255,11
Detailed info 4 (word) (2)	MW 254,04	MW 254,12	MW 255,04	MW 255,12
Detailed info 5 (word) (2)	MW 254,05	MW 254,13	MW 255,05	MW 255,13
Detailed info 6 (word) (2)	MW 254,06	MW 254,14	MW 255,06	MW 255,14
Detailed info 7 (word) (2)	MW 254,07	MW 254,15	MW 255,07	MW 255,15
Led displays after initialization	Red led or LED RUN does not go on, if RUN/STOP switch is set to RUN	Red led or LED RUN does not go on, if RUN/STOP switch is set to RUN	Red led	Red led
Reaction when switching on the central unit / Reaction during operation	All the outputs remain set to 0 or are set to 0. The programming system does not have access. The central units is in reset while the error is present.	All the outputs remain set to 0 or are set to 0. The programming system can get access. The user program is not started or is aborted.	You can choose in case of an error : – Just report the error : Evaluate the error flag M 255,13 – Abort the user program : Set system constant KW 0,7 = 1 (FK3_REAK)	Evaluation of the error messages using the user program
Acknowledgement of the summation error message/ of the error class message	– Power ON – Cold start	– Power ON – Cold start	– Power ON / cold start – Set the RUN/STOP switch to RUN – Start the program using 907 PC 331 – Set M 255,13 or M 255,14 to 0 – In case of CS31 error : function block CS31QU – Spontaneous if error FK4 disappears and code ≤ 15	
(1) The summation error flag M 255,10 becomes 1, if at least one of the error class flags is set to 1. If M 255,10 = 0, the central unit has not found any error. The summation error flag is deleted automatically when the error class flags are acknowledged.		(2) The central unit enters the last found error into the relevant error flag record for each error class. The entry is made at the end of the program cycle and remains unchanged during the next running program cycle. The word flags can only be acknowledged by overwriting them with "0".		

8.4 07 KR 31 / 07 KT 31 Acknowledgement of error messages Central processing units in the central unit

Error messages remain stored and will be displayed until they are acknowledged. The following applies :

- The summation error message, the error class messages (bit flags) and the relevant red LED is reset with power ON, for example. For other possibilities for resetting/acknowledging them, (see chapters 8.2 "**Acknowledgement of error messages in the remote units**" and 8.3 "**Errors flags in the central unit, error classification**").
- The error identifiers and the detailed information (word flags) have to be reset by means of the user program or by means of the operating function "Overwrite" (see volume 7.3 chapter 3). They are also reset when a cold start is performed or by a power-fail.

The error message will appear again, if the error has not been eliminated.

Status word EW 07,15

The following data are continuously updated in the status word EW 07,15 :

- Bit 0 : this bit is valid for the stand-alone central unit, for the master central unit and for the slave central unit.
Bit 0 = 1, there is *no error* of class 2.
Bit 0 = 0, there is *an error* of class 2.

- Bit 1 : this bit is valid only for the slave central unit.
Bit 1 = 1, the slave central unit is adopted into the bus cycle of the master central unit.
Bit 1 = 0, the slave central unit is *not* adopted into the bus cycle of the master central unit.

- Bit 2 is not used.

- Bit 3 : this bit detects a battery failure.
Bit 3 = 1, there is no battery failure.
Bit 3 = 0, there is a battery failure.

- Bit 4...7 are not used.

- Bit 8...15 : *Maximum* number of remote units which have been existing in the CS31 bus cycle of the master central unit since the last power-ON or since the last cold start. Their number may be larger than the number of the remote units which are *currently* existing in the CS31 bus cycle.

8.6 07 KR 31 / 07 KT 31 Meaning of the contents Central processing units of the error word flags

Explanation of the following table :

- Address = Memory address at which the error was detected.
- Group number = Unit address of the remote unit
- Channel number = Number of the faulty channel
- Unit type Meaning
 - 000 Binary input
 - 001 Analog input
 - 002 Binary output
 - 003 Analog output
 - 004 Binary input/output
 - 005 Analog input/output
 - 255 Bus master or slave central unit in which the error has occurred and is stored.

Error class	Error description	Error identifier in MW 254,00		Detailed info 1 in MW 254,01	Detailed info 2 in MW 254,02	Detailed info 3 in MW 254,03	Further detailed infos in MW 254,04 ... MW 254,07
		Dec	Hex				
FK1 Fatal error	Checksum error of the system EPROM				–	–	–

Error class	Error description	Error identifier in MW 254,08		Detailed info 1 in MW 254,09	Detailed info 2 in MW 254,10	Detailed info 3 in MW 254,11	Further detailed info in MW 254,12 ... MW 254,15
		Dec	Hex				
FK2 Serious error	RAM defective (user program or operand memory)	128 _D	80 _H	Address	–	–	–
	Illegal master-slave identifier	129 _D	81 _H	–	–	–	–
	More timers than available in the central unit were required during the execution time.	255 _D	FF _H	–	–	–	–


Error class	Error description	Error identifier in MW 255,00		Detailed info 1 in MW 255,01	Detailed info 2 in MW 255,02	Detailed info 3 in MW 255,03	Further detailed info in MW 255,04 ... MW 255,07
		Dec	Hex				
FK3 Light error	Remote unit disconnected	15 _D	F _H	Unit type	Group number	–	–
	CS31 bus error (there is no remote unit on the bus) Note : If there are only analog units connected to the CS31 system bus, this error message may occur when the supply voltage is switched on although the analog units have been correctly adopted into the CS31 bus cycle after a certain time. Reason : The analog units have a long initialization time. After this time is over, they only now appear at the CS31 bus as remote units. During the initialization time the master central unit cannot recognize them.	16 _D	10 _H	–	–	–	–
	NCB or NCBR error Note : One of the different CS31 buses is on default. Check red leds on NCB or NCBR to find on which line the error is.	17 _D	11 _H	–	–	–	–
	Cycle time KD 00,00 too short	200 _D	C8 _H	–	–	–	–

Error class	Error description	Error identifier in MW 255,08		Detailed info 1 in MW 255,09	Detailed info 2 in MW 255,10	Detailed info 3 in MW 255,11	Further detailed info in MW 255,12 ... MW 255,15
		Dec	Hex				
FK4 Warning	Internal error of a remote unit	1 _D	1 _H	Unit type	Group number	Channel number	–
	Cut wire (open circuit)	2 _D	2 _H	Unit type	Group number	Channel number	–
	Wrong level of an analog output	3 _D	3 _H	Unit type	Group number	Channel number	–
	Overload	4 _D	4 _H	Unit type	Group number	Channel number	–
	10V FAIL	5 _D	5 _H	Unit type	Group number	Channel number	–
	Overload + cut wire	6 _D	6 _H	Unit type	Group number	Channel number	–
	Short circuit	8 _D	8 _H	Unit type	Group number	Channel number	–
	Short circuit + cut wire	10 _D	A _H	Unit type	Group number	Channel number	–
	Overload + short circuit	12 _D	C _H	Unit type	Group number	Channel number	–
	Short circuit + overload + cut wire	14 _D	E _H	Unit type	Group number	Channel number	–
	During start-up, the system detects that the program end is missing	129 _D	81 _H	–	–	–	–
	During start-up, the system detects a syntax error in the user program	131 _D	83 _H	Program address	–	–	–
	During start-up, the system detects that the historical value memory is too small	132 _D	84 _H	–	–	–	–
	During start-up, the system detects that no cycle time has been set	133 _D	85 _H	–	–	–	–
	During start-up, the system detects that there are bracketing errors in the user program	134 _D	86 _H	Program address	–	–	–
	During start-up, the system detects that the target label for a conditional jump is missing	135 _D	87 _H	Program address	–	–	–
	The user program is not started because the number of remote units which are adopted into the CS31 bus cycle is smaller than the number configured in KW 00,09.	138 _D	8A _H	Configured number of remote units (KW 00,09)	Actual number of remote units connected to the CS31 bus cycle	–	–
	User program too large for memory size	140 _D	8C _H	–	–	–	–
	Compiled code	141 _D	8D _H	–	–	–	–

N°	Error	Display/reaction of the bus master central unit	Display/reaction of the input/output remote units	Display/reaction of the slave central units
1	Bus master central unit has failed, e.g. because of power failure	No display, all outputs are off.	Error red LED lights up. All the outputs are turned to 0	07 KR 91 / 07 KT 92/93 : – LED BA is on – LED RE flashes – Bit 1 = 0 in the status word EW 07,15
3a	CS31 system bus is disconnected (all the remote units are disconnected)	Displays : red LED Flags : M 255,10 = 1 M 255,13 = 1 for further flags see 8.3		07 KR 31 / 07 KT 31 – red LED flashes – Bit 1 = 0 in the status word EW 7,15
3b	CS31 system bus is short-circuited			
4a	CS31 system bus is disconnected (the remote units are only disconnected in part)	Displays : red LED	Remote units without connection to the bus master central unit : same as 1	Slave central units without connection to the bus master central unit : same as 1
4b		Flags : M 255,10 = 1 M 255,13 = 1 for further flags see 8.3	Remote units with connection to the bus master central unit : no display/reaction	Slave central units with connection to the bus master central unit : no display/reaction
5a	A remote unit has been lost on the CS31 system bus. Cause :	Displays : red LED Flags : M 255,10 = 1 M 255,13 = 1 for further flags see 8.3	Remote units with connection to the bus master central unit : no display/reaction	Slave central units with connection to the bus master central unit : no display/reaction
5b	No connection to the CS31 system bus		Remote units without connection to the bus master central unit : same as 1	Slave central unit without connection to the bus master central unit : same as 1
5c	defective remote unit			07 KR 31 / 07 KT 31 / 07 KR 91 / 07 KT 92/93 Error class FK1 / FK2, all outputs turn to 0.
5d	Power failure			all outputs turned to 0
6a	An error has occurred at the inputs or outputs of a remote unit e.g. a short circuit.	Displays : red LED Flags : M 255,10 = 1 M 255,14 = 1 for further flags see 8.3	Concerned remote unit : error LED red lights up the LEDs of status of inputs/outputs by means of the test button detailed infos.	Concerned 07 KT 92/93 : Display : K = short circuit Concerned 07 KT 31 Display : red led Flags : M 255,10 = 1 M 255,14 = 1 for further flags see 8.3
6b			Other remote unit : no display/reaction	Other slave central units : no display/reaction

Reaction on the bus master central unit and the remote units in case of errors (continued)

N°	Error	Display/reaction of the bus master central unit	Display/reaction of the input/output remote units	Display/reaction of the slave central units
7a	Two remote input units of the same type have been set to the same address	The error is detected only when the signal statuses of the two units become different. The message is faulty in this case, and the units are considered to be disconnected. Display : Red error LED Flags : M 255,10 = 1 M 255,13 = 1 for other flags see 8.3 / 8.6	Concerned units same as 1 Other units : no display/reaction	same as 1
7b	Two remote units of the same type have been set to the same address.	No reaction, unless there is a large distance between the remote units.	Faultless operation of the two units, unless they are far apart from each other.	Not applicable because inputs and outputs are always present.
7c	Two remote units of different types, but with overlapping ranges have been set to the same address, e.g. ICSI 16 D1 and ICSK 20 F1.	The error is already detected during the initialization. The two remote units are not adopted into the bus cycle. The error is not detected.	Concerned units : same as 1	Concerned units : same as 1
			Other units : no display/reaction	Other units : no display/reaction
7d	Address 62 or 63 has been set to a binary remote unit.	Is not detected.	– Output of the signals in parallel to the bus master – Input signals are ignored.	–
7e	An address higher than 5 has been set to an analog remote unit.	Is not detected.	same as 1	



● **Historical values**

Some functions use historical values :

- ASV : 1 word
- BMELD : (2 + #n / 2) words if n is even
(2 + #n+1 / 2) words if n is odd
- CALLUP : #VGW words
- DRUCK : 1 word
- EMAS : 1 word
- MOA : 1 word
- MODBUS : 1 word
- MOK : 1 word
- PI : 4 words
- SINIT : 1 word
- UHR : 1 word
- VRZ : 2 words

A maximum of 128 historical values can be used in a program. The number of timers in the program is illimited; a maximum of 42 timers can run at the same time.

If KW 00,05 is different from 0 and if a function block using historical values is activated, its historical values are stored in a file and restored after a STOP/RUN or a power supply.

● **On-line modifications**

- Insertion of a function block using historical values when the central unit is running :

If a function block using historical values is inserted in the program when the central unit is running, its historical values are not shifted in the file of historical values. In this case, all datas used in the function blocks with historical values are wrong.

Program	File
Function block 1	Historical value 1
Function block 2	Historical value 2
Function block 3	Historical value 3

If the function block 4 is inserted between the blocks 2 and 3, the historical values are not shifted in the right order.

Modified program	File
Function block 1	Historical value 1
Function block 4	Historical value 2
Function block 2	Historical value 3
Function block 3	New historical value

- In case of a too long coded program :


In case of a too long coded program (2 klnst with a lot of instructions which are coded on 6, 7 or 8 bytes), the status of central unit displays :

On-line : not available.

The central unit has to be in stop mode for a transfer of the program.

Note : in stop mode, the status always displays :

On-line : not available.



ASCII Communication

● TCAD

- Display of 127 messages + 1 background message on 2 lines of 16 characters.

ASCII Communication

- Two variable datas can be embedded in a message.
- A buzzer can be activated or dasactivated.
- A key function is available on the front plate.

● 35 BS 40

- Control via the serial interface COM1 of the central unit in passive mode (see page 3.5-1 "Serial interface").
- Control via the serial interface COM2 is only possible in passive mode, (see 07KT92 / 07KT93).
- Display of texts. 999 two-line texts can be stored and called by the central unit.
- Display of variables coming from the central unit.
- Entry of commands and values via the keyboard.
- Programming using the editor 935 BS 40.

● Other control panels with ASCII communication.

● Other devices, e.g. printer, modem

- Control via the serial interface of the central unit in passive mode or active mode (see page 3.5-1 "Serial interface").
- Control via the serial interface COM2 is only possible in passive mode (see 07KT92 / 07KT93).

The central units 07 KR 31 and 07 KT 31 have a built-in MODBUS interface used as a master or a slave on a MODBUS network.

The communication is in binary format (RTU) with an CRC16 checksum.

● **Central unit used as a MODBUS slave :**

All datas (inputs, outputs, internal memories, ...) can be read or write without any user program when using 07 KR 31 or 07 KT 31 as a slave on the MODBUS network.

● **Central unit used as a MODBUS master :**

The function block MODBUS has to be used in the user program. It allows the writing and the reading of datas in the MODBUS slaves.

The function block **SINIT** is necessary only if the user wants to change the factory setting parameters of the communication (baud rate, parity, ...).

NOTE : The central units 07 KR 31 and 07 KT 31 can be used as a master or a slave on the CS31 bus.

● **The MODBUS status** (master or slave) of the 07 KR 31/ 07 KT 31 is in the system constant **KW00,06**.

The value of the system constant KW00,06 and the pin 6 assignment on the cable determine the protocol of the serial interface RS232C (programming and test, man machine communication or MODBUS).

The central units 07 KR 31 and 07 KT 31 are able to recognize the number of the slave asked by the master and to interpret the «diffusion messages» (slave number required = zero).

● **The 07 KR 31 and 07 KT 31 are able to identify the following function codes :**

- Reading of n bits Code 01 or 02
- Reading of n words Code 03 or 04
- Writing of one bit Code 05
- Writing of one word Code 06
- Quick reading of 8 bits Code 07
- Writing of n bits Code 0F
- Writing of n words Code 10

The following error codes can be generated :

- Error code 01 = unknown function code
- Error code 02 = address error
- Error code 03 = data error

11.1 07 KR 31 / 07 KT 31 Central processing units

MODBUS protocol

The MODBUS protocol is a request/reply type : the master MODBUS sends a request, then waits passively an answer from the slave.

The communication frames are set up on the same way :

- Slave number (1 byte)
- Function code (1 byte)
- Message text (N bytes)
- CRC16 check (2 bytes)

● Read n bits (0 < n < 255)

Function code : 01 or 02

send :

SLAVE	FCT	ADH	ADL	NB OF	BITS	CRCH	CRCL
-------	-----	-----	-----	-------	------	------	------

receive :

SLAVE	FCT	NBYTE	.. DATA ..	CRCH	CRCL
-------	-----	-------	------------	------	------

DATA :
7th 1st 15th 8th

Example :

Read 16 bits at the address 0000H

send :

01 01 00 00 00 10 3D C6

receive :

01 01 02 00 00 B9 FC

● Read n words (0 < n < 100)

Function code : 03 or 04

send :

SLAVE	FCT	ADH	ADL	NB OF WORDS	CRCH	CRCL
-------	-----	-----	-----	-------------	------	------

receive :

SLAVE	FCT	NBYTE	.. DATA ..	CRCH	CRCL
-------	-----	-------	------------	------	------

DATA :
1st 2nd ...

Example :

Read 10 words at the address 0060H

send :

01 03 00 60 00 0A C5 D3

receive :

01 03 14 0000 0000 0000 0000 0000
 0000 0000 0000 0000 0000
 A367

with 14H = 20 bytes

● Write 1 bit

Function code : 05

send :

SLAVE	FCT	ADH	ADL	DATA	DATA	CRCH	CRCL
-------	-----	-----	-----	------	------	------	------

receive :

SLAVE	FCT	ADH	ADL	DATA	DATA	CRCH	CRCL
-------	-----	-----	-----	------	------	------	------

DATA : bit = 0 → 00 00
 bit = 1 → FF 00

Example :

Write 1 at the address 2000H

send :

01 05 20 00 FF 00 87 FA

receive :

01 05 20 00 FF 00 87 FA

● Write 1 word

Function code : 06

send :

SLAVE	FCT	ADH	ADL	DATA	DATA	CRCH	CRCL
-------	-----	-----	-----	------	------	------	------

receive :

SLAVE	FCT	ADH	ADL	DATA	DATA	CRCH	CRCL
-------	-----	-----	-----	------	------	------	------

DATA :
HI(WORD) LO(WORD)

Example :

write 1234H at the address 2000H

send :

01 06 20 00 12 34 8F 7D

receive :

01 06 20 00 12 34 8F 7D

● **Write of n bits (1 < n < 255)**

Function code: 0F

send :

SLAVE	FCT	ADH	ADL	NB OF BITS	NBYTE	..DATA..	CRCH	CRCL
-------	-----	-----	-----	------------	-------	----------	------	------

DATA :
|_|_|_|_|_|_|_| |_|_|_|_|_|_|_|
7th 1st 15th 8th

receive :

SLAVE	FCT	ADH	ADL	NB OF BITS	CRCH	CRCL
-------	-----	-----	-----	------------	------	------

Example :

Write 5 bits (set to 1) at the address 2000H

send :

01 0F 20 00 00 05 01 1F 29 FE

receive :

01 0F 20 00 00 05 9E 08

with : 05H=NB OF BITS

01H=NBYTE

1FH=0001 1111B data

02H=NBYTES*2(1H*2)

● **Write of n words (1 < n < 100)**

Function code : 10

send :

SLAVE	FCT	ADH	ADL	NB OF WORDS	NBYTE	..DATA..	CRCH	CRCL
-------	-----	-----	-----	-------------	-------	----------	------	------

DATA :
|_|_| |_|_|
1st 2nd

receive :

SLAVE	FCT	ADH	ADL	NB OF WORDS	CRCH	CRCL
-------	-----	-----	-----	-------------	------	------

Example :

write : 1H at the address 2000H

2H at the address 2001H

3H at the address 2002H

send :

01 10 20 00 0003 06 0001 0002 0003 91 41

receive :

01 10 20 00 00 03 8B C8

● **Error code :**

receive :

SLAVE	FCT v 80H	ERR	CRCH	CRCL
-------	-----------	-----	------	------

Error code 01 = unknown function code

Error code 02 = address error

Error code 03 = data error


Example : address error

receive after reading n words (code 03H)

01 83 02 C0 C0

with 83H=80H+03H

● **Timing**



Time between characters (x) :

At 9600 Bauds : 1 ms

The time between two characters must be lower than x

Time between frames (y) :

Rate (Bauds)	Time y (ms)
19200	4
9600	5,5
4800	11
2400	21
1200	42
600	83
300	166
150	330

A new frame is detected only if the delay after the previous frame is higher than y. If the delay is lower, a CRC error happens on the previous frame.

11.2 07 KR 31 / 07 KT 31 Central processing units

MODBUS configuration

The mode MODBUS protocol in the 07 KR 31 and 07 KT 31 depends on the value of the system constant KW00,06 and the connection between the pin 6 and pin 7 on the cable.

The mode MODBUS protocol, when it is selected, is always available even if the central unit is in STOP mode.

The programming mode is again available when there is no connection between pin 6 and pin 7; the program can be tested or modified by the programming software 907 PC 331.

● Master and slave configuration

The system constant KW 00,06 selects the status of the central unit on the MODBUS network.

The value has to be greater than 100.

The slave number is the value of KW 00,06 minus 100.

The MODBUS slave numbers are between 01 and 255 so the value of KW 00,06 for a MODBUS slave configuration is from 101 up to 355.

The number 00 is for the diffusion of messages (all slaves on the MODBUS network read the message).

The value of KW 00,06 for a MODBUS master configuration is 100.

● Communication parameters

The factory setting is :

- 9600 bauds
- parity : none
- data bits : 8
- stop bits : 1

These parameters can be changed with the function block SINIT in the user program.

Refer to the documentation of the function block.

SINIT :
 FREI
 SSK
 BAUD
 Stop
 ZL
 PTY
 E/O
 Echo
 SBRK
 FEND
 ENDS
 ENDE

The following parameters have no influence on the configuration on the serial line in MODBUS protocol :

Echo
 SBRK
 FEND
 ENDS
 ENDE

● Serial line connection RS232C


07KR31 (Sub D9 female) MODBUS

TXD 2 _____ RXD
 RXD 3 _____ TXD
 SGND 7 _____ SGND
 6 _____

RTS 4 _____ CTS
 CTS 5 _____ RTS
 DTR
 DCD
 DSR

It is not necessary to connect the CTS/RTS pins on 07 KR 31 or 07 KT 31.

Signal level on the Modbus slave :



The following cables are available :

- FPTN 404948R0001 (SubD25-SubD9)
- FPTN 404948R0006 (SubD9-SubD9)

● List of accessible parameters by the master MODBUS

All following parameters of 07 KR 31 / 07 KT 31 can be read or written by the master MODBUS :

Bits : E 00,00 upto E 63,15
A 00,00 upto A 63,15
M 000,00 upto M 21,15 and
M 230,00 upto M 239,15 and
M 255,00 upto M 255,15
S 000,00 upto S 15,15
– in reading n bits (Function codes 01 or 02)
– in quick read of 8 bits (Function code 07)
– in writing n bits (Function codes 05 or 0F)

Words : EW 00,00 upto EW 07,15
AW 00,00 upto AW 07,15
MW 00,00 upto MW 05,15 and
MW 230,00 upto MW 239,15 and
MW 254,00 upto MW 255,15
KW 00,00 upto KW 07,15
– in reading n words
(Function codes 03 or 04)
– in writing n words
(Function codes 06 or 10)

It is possible to write inputs with MODBUS. The setting is only available for one central unit cycle. The result in the user program is a rising or falling edge on the binary input and a set point for one cycle for the analogue input.

● BITS

– INPUTS

in reading with the functions : 1 or 2 (from 1 to 255 Bits)
in writing : 5 or F (from 1 to 255 Bits)

	Address 07KR31 or 07KT31	Address MODBUS
E 00,00	0000 _H	0000 _D
E 00,01	0001 _H	0001 _D
.	.	.
E 00,15	000F _H	0015 _D
E 01,00	0010 _H	0016 _D
.	.	.
E 01,15	001F _H	0031 _D
.	.	.
E 62,00	03E0 _H	0992 _D
.	.	.
E 63,15	03FF _H	1023 _D

– OUTPUTS

in reading with the functions : 1 or 2 (from 1 to 255 Bits)
in writing : 5 or F (from 1 to 255 Bits)

	Address 07KR31 or 07KT31	Address MODBUS
A 00,00	1000 _H	4096 _D
A 00,01	1001 _H	4097 _D
.	.	.
A 00,15	100F _H	4111 _D
A 01,00	1010 _H	4112 _D
.	.	.
A 01,15	101F _H	4127 _D
.	.	.
A 62,00	13E0 _H	5088 _D
A 63,15	13FF _H	5119 _D

– Flags

in reading with the functions : 1 or 2 (from 1 to 255 bits)
in writing : 5 or F (from 1 to 255 bits)
in quick read with the function : 7 (bits M001,00 to M001,07)

	Address 07KR31 or 07KT31	Address MODBUS
M 000,00	2000 _H	8192 _D
M 000,01	2001 _H	8193 _D
.	.	.
M 001,00	2010 _H	8208 _D
M 021,15	215F _H	8543 _D
.	.	.
M 230,00	2E60 _H	11872 _D
.	.	.
M 239,15	2EFF _H	12031 _D
M 255,00	2FF0 _H	12272 _D
M 255,15	2FFF _H	12287 _D

– Sequencers

in reading with the functions : 1 or 2 (from 1 to 255 bits)
in writing : 6 (bit to bit)
(Only set to 1 is allowed)

	Address 07KR31 or 07KT31	Address MODBUS
S 00,00	3000 _H	12288 _D
S 00,01	3001 _H	12289 _D
.	.	.
S 01,15	301F _H	12319 _D
S 02,00	3020 _H	12320 _D
.	.	.
S 15,15	30FF _H	12543 _D

● **WORDS**

– **INPUTS**

in reading with the functions : 3 or 4 (from 1 to 100 words)
 in writing : 6 or 10 (from 1 to 100 words)

Address 07KR31 or 07KT31	Address MODBUS	
EW 00,00	0000 _H	000 _D
EW 00,00	0001 _H	001 _D
.	.	.
EW 00,15	000F _H	015 _D
EW 01,00	0010 _H	016 _D
.	.	.
EW 01,15	001F _H	031 _D
.	.	.
EW 07,15	007F _H	127 _D

– **OUTPUTS**

in reading with the functions : 3 or 4 (from 1 to 100 words)
 in writing : 6 or 10 (from 1 to 100 words)

Address 07KR31 or 07KT31	Address MODBUS	
AW 00,00	1000 _H	4096 _D
AW 00,01	1001 _H	4097 _D
.	.	.
AW 00,15	100F _H	4111 _D
AW 01,00	1010 _H	4112 _D
.	.	.
AW 01,15	101F _H	4127 _D
.	.	.
AW 07,15	107F _H	4223 _D

– **Internal words**

in reading with the functions : 3 or 4 (from 1 to 100 words)
 in writing : 6 or 10 (from 1 to 100 words)

Address 07KR31 or 07KT31	Address MODBUS	
MW 000,00	2000 _H	8192 _D
MW 000,01	2001 _H	8193 _D
.	.	.
MW 005,15	205F _H	8543 _D
MW 230,00	2E60 _H	11872 _D
.	.	.
MW 239,15	2EFF _H	12031 _D
.	.	.
MW 254,00	2FE0 _H	12271 _D
.	.	.
MW 255,15	2FFF _H	12287 _D

– **Indirect constants**

in reading with the functions : 3 or 4 (from 1 to 100 words)

Address 07KR31 or 07KT31	Address MODBUS	
KW 00,00	3000 _H	12288 _D
KW 00,01	3001 _H	12289 _D
.	.	.
KW 01,15	301F _H	12319 _D
KW 02,00	3020 _H	12320 _D
.	.	.
KW 07,15	307F _H	12415 _D

The treatment time depends on :

- the baud rate
- the number of bytes of the frame
- the cycle time of the central unit
- the central unit load

The central unit has a buffer of 256 bytes. The treatment by the central unit of the frame starts after the time of 3/2 character after the last received character.

● For a Modbus slave 07 KR 31 / 07 KT 31

The transmission time (sending+receiving) is :
(Nb bytes*11/ baud)*1000 ms.

The basic time in the central unit is :

- reading n bits : 0.827 ms + nb bits*0.246 ms
- reading n words : 0.731 ms + nb words*0.182 ms
- write 1 bit : 1.062 ms
- write 1 word : 1.025 ms
- write n bits : 1.113 ms + nb bits*0.039 ms
- write n words : 1.099 ms + nb words*0.182 ms
- quick reading of 8 bits : 0.265 ms

The treatment time in the central unit is:

Cycle time + (INT(basictime / ((1-load)*cycle time)))*cycle time

The total response time is :

sending time + treatment time in the central unit
+ receiving time

Example :

Read 10 words
9600 bauds
cycle time : 30ms
central unit load : 60%

Sending frame :

01 03 00 60 00 0A C5 D5
8*11/9600*1000 = 9.17ms

Receiving frame :

01 03 14 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 A3 67
25*11/9600*1000 = 28.64ms

Basic time :

0.731 + 10*0.182 = 2.551ms

Treatment time :

30 + INT(2.551 / 30*(1-0.6))*30= 30ms

The total response time is :

9.17 + 28.64 + 30 = 67.81 ms

This time is a medium time.

Measurement of response time :

Nb variables	Bit		Word	
	read	write	read	write
1	10 - 60	50	10 - 60	60
10	10 - 60	60	10 - 60	110
50	10 - 60	110	110 - 170	220
100	50 - 60	110	220 - 280	390
150	50 - 110		-	-
255	50 - 110		-	-

(T min - Tmax)ms

- Cycle time : 10 ms
- Central unit load : 80 %
- Baud rate : 9600
- 07 KR 31 / 07 KT 31 master

● For a Modbus master 07 KR 31 / 07 KT 31

The transmission times are always the same.

● Capacities

The central units 07 KR 91, 07 KT 92, 07 KT 93 have a very high powerfull treatment. A large number of software functions and a high velocity allows complexe applications.

The central units 07 KR 31 and 07 KT 31 are used for smaller applications or as slave in a complexe application.

	Velocity	Memory
07 KR 31, 07 KT 31	6ms/1kinst	EEPROM 2kinst (8kbytes)
07 KR 91, 07 KT 92/93	2ms/1kinst	Flash EPROM 7kinst (32kbytes)

The user program has to be stored in EEPROM in the 07 KR 31 and 07 KT 31.

The user program can be stored in RAM in the 07 KR 91/ 07 KT 92 (only if the flash EPROM is erased and the battery is mounted).

● Range of variables

The range of different variables in the 07 KR 31 / 07 KT 31 is smaller than the range in the 07 KR 91 / 07 KT 92 / 07 KT 93 (see chapter 1.4 "Operands").

● Refresh variables

All variables (inputs and outputs) are refreshed in the 07 KR 31 / 07 KT 31 even if these variables are not written in the user program.

In case of a data acquisition application where the 07 KR 31/ 07 KT 31 is connected to a supervisor, it is not necessary to write in the user program the inputs or outputs (binary or analog).

● Cycle time

07 KR 31, 07 KT 31 :

The CS 31 bus cycle time is included in the cycle time KD00,00.

The maximum cycle time (KD00,00) is 100ms for a master configuration and 250ms for a slave configuration.

An error FK3 (code 200) is generated if the cycle time is greater than the time in KD00,00 :

- the central unit aborts or continues the execution of the program according to the value of the system constant KW00,07.

07 KR 91, 07 KT 92, 07 KT 93 :

The CS 31 bus cycle time is not included in the cycle time KD00,00.

The value of the cycle time is not limited.

An error FK2 (code 131) is generated if the cycle time is greater than the time in KD00,00 :

- the central unit aborts the execution of the program.

Slave central unit

07 KR 91, 07 KT 92, 07 KT 93 :

The cycle time t_c is independant of the master or slave functions.

07 KR 31, 07 KT 31 :

The cycle time t_c depends on the configuration of the CS 31 bus and the cycle time of the master.

● Timers and historical values

	Timers running in the same time	Error in case of more timers	Historical values
07 KR 31 07 KT 31	42	FK2(255)	128 (excepted timer)
07 KR 91 07 KT 92 07 KT 93	80	FK2(257)	1000 (included timers)

● Modification of a timer value online

The new value of KD or MD is taken into account :

- immediatly in a central unit serie 30;
- at the next timer in a central unit serie 90.

● Address of a slave central unit

The address is determined by	System constant KW00,00	Plug-in base ECZ
07 KR 31 07 KT 31	0 ... 61	switch if KW0,0 = 100
07 KR 91 07 KT 92 07 KT 93	0 ... 61	no

● Diagnosis

A user program too large (memory size too small) is detected in the 07 KR 31/07 KT 31. An error FK4(140) is generated.

The overlapping ranges are not detected by the 07 KR 31 or the 07 KT 31.

● Forced variables

Maximum number of I/O signals to be forced

	07KR91, 07KT92/93	07KR/KT31
binary inputs	64	31
binary outputs	64	
word inputs	16	7
word outputs	16	

● Brackets

	07KR91, 07KT92/93	07KR/KT31
nesting depth	15	8

● Analog remote modules

With the 07 KR 91, 07 KT 92 or 07 KT 93, a maximum of 12 analog input units can be connected on the CS31 bus.

With the 07 KR 31 or 07 KT 31, a maximum of 28 analog input units can be connected on the CS31 bus.

● Modbus

The central units 07 KR 31 and 07 KT 31 have a built-in MODBUS interface used as a master or a slave on a MODBUS network.

The central units 07 KR 91, 07 KT 92 or 07 KT 93 can be coupled to the 07 MK 92 coupler to be used as a MODBUS master or slave on a MODBUS network.

● Password

A password can be used in the 07 KR 31 or 07 KT 31 to lock the program access in reading or writing.

● KW 00,08

The KW 00,08 constant is used in the 07 KT 92 / 07 KT 93 central units to detect an output short circuit.

The KW 00,08 constant is not used in the 07 KT 31.

● Battery

A battery failure is detected with the bit 3 of the status word EW 07,15.

The battery can not be changed in the 07 KR 31 or 07 KT 31. In the 07 KR 91, 07 KT 92 or 07 KT 93, a led is lighted in case of battery failure and the battery can be changed.

● FK4 errors

A FK4 error (which code value is lower or equal than 15) is automatically reset in the 07 KR 31 or 07 KT 31 if it is reset in the remote unit.

FK4 errors	07KR31/07KT31	07KR91/07KT92/07KT93
< 15	red led	Leds BE and RE
> 15	red led	No led

● Reset of MW254,00...MW255,15

	07KR31/07KT31	07KR91/07KT92/07KT93
Reset	- overwrite - power supply OFF without back up	- overwrite

- **Central unit 07 KR 31**

230 VAC	Order No. FPR 360 0227 R0206
120 VAC	Order No. FPR 360 0227 R0204
24 VDC	Order No. FPR 360 0227 R1202

- **Central unit 07 KT 31**

230 VAC	Order No. FPR 360 0228 R0206
120 VAC	Order No. FPR 360 0228 R0204
24 VDC	Order No. FPR 360 0228 R1202

- **Plug-in base ECZ** Order No. FPR 370 0001 R0001

- **Accessories**

Programming cable 9 pins	Order No. FPTN 404 948 R0002
Programming cable 25 pins	Order No. FPTN 404 948 R0005

MODBUS or MMC cable 9 pins	Order No. FPTN 404 948 R0006
MODBUS or MMC cable 25 pins	Order No. FPTN 404 948 R0001

System cable 07 SK 90	Order No. GJR5 2502 00 R0001
System cable 07 SK 91	Order No. GJR5 2503 00 R0001
System cable 07 SK 92	Order No. GJR5 2504 00 R0001

Operation station 35 BS 40	Order No. GJV3 0753 04 R0001
Operation station 35 BS 93	Order No. GJV3 0729 01 R0003

- **Programming and test software and operating manual**

(both 907 PC 33 and 907 PC 331 are required)

907 PC 33 German ⁽¹⁾	Order No. GJP5 2039 00 R0102
907 PC 33 English ⁽¹⁾	Order No. GJP5 2040 00 R0102

907 PC 331 German ⁽²⁾	Order No. GJP5 2045 00 R0102
907 PC 331 English ⁽²⁾	Order No. GJP5 2046 00 R0102

- **Further literature**

System description ABB Procontic CS31 English	Order No. FPTN 440 004 R2001
System description ABB Procontic T200 English	Order No. GATS 1314 99 R2001
System description ABB Procontic T300 English	Order No. GATS 1315 99 R2002


System description ABB Procontic CS31 German	Order No. GATS 1316 99 R1002
System description ABB Procontic T200 German	Order No. GATS 1314 99 R1001
System description ABB Procontic T300 German	Order No. GATS 1315 99 R1002

1) Description General Part

2) Description 07 KR 31 / 07 KR 91 / 07 KT 92 - Specific Part + Software diskettes

Central Units
07 KR 91,
07 KT 92 and 07 KT 93

Order No.
GATS 1316 23 R2001



Regulations Concerning the Setting up of Installations

Apart from the basic "Regulations for the Setting up of Power Installations" DIN VDE* 0100 and for "The Rating of Creepage Distances and Clearances" DIN VDE 0110 Part 1 and Part 2 the regulations "The Equipment of Power Installations with Electrical Components" DIN VDE 0160 in conjunction with DIN VDE 0660 Part 500 have to be taken into due consideration.

Further attention has to be paid to DIN VDE 0113 Part 1 and Part 200 in case of the control of working and processing machines. If operating elements are to be mounted near parts with dangerous contact voltage DIN VDE 0106 Part 100 is additionally relevant.

If the protection against direct contact according to DIN VDE 0160 is required, this has to be ensured by the user (e.g. by incorporating the elements in a switch-gear cabinet). The devices are designed for pollution severity 2 in accordance with DIN VDE 0110 Part 1. If higher pollution is expected, the devices must be installed in appropriate housings.

The user has to guarantee that the devices and the components belonging to them are mounted following these regulations. For operating the machines and installations, other national and international relevant regulations, concerning prevention of accidents and using technical working means, also have to be met.

The ABB Procontic devices are designed according to IEC 1131 Part 2. Meeting this regulation, they are classified in overvoltage category II which is in conformance with DIN VDE 0110 Part 2.

For the direct connection of ABB Procontic devices, which are powered with or coupled to AC line voltages of overvoltage category III, appropriate protection measures corresponding to overvoltage category II according to IEC-Report 664/1980 and DIN VDE 0110 Part 1 are to install.

Equivalent standards:

DIN VDE 0110 Part 1 \triangleq IEC 664

DIN VDE 0113 Part 1 \triangleq EN 60204 Part 1

DIN VDE 0660 Part 500 \triangleq EN 60439-1 \triangleq IEC 439-1

All rights reserved to change design, size, weight, etc.


* VDE stands for "Association of German Electrical Engineers".

ABB Schalt- und Steuerungstechnik GmbH Heidelberg

Table of contents

1	Central units 07 KR 91 R202/R252	1– 1
1.1	Brief description	1– 2
1.2	Structure of the front panel	1– 4
1.3	Electrical connection	1– 6
1.4	High-speed counter	1–16
1.5	Technical data	1–18
2	Central units 07 KT 92 R202/R262	2– 1
2.1	Brief description	2– 2
2.2	Structure of the front panel	2– 4
2.3	Electrical connection	2– 6
2.4	High-speed counter	2–16
2.5	Technical data	2–18
3	Central units 07 KT 93 R101/R171	3– 1
3.1	Brief description	3– 2
3.2	Structure of the front panel	3– 4
3.3	Electrical connection	3– 6
3.4	High-speed counter	3–16
3.5	Technical data	3–18
A	Appendix	A1– 1
A1	Processing times	A1– 1
A2	Addressing with 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master	A2– 1
A3	I/O configuration	A3– 1
A4	Diagnosis	A4– 1
A5	Programming and test	A5– 1
A6	Man-machine-communication	A6– 1
A7	Operands 07 KR 91, 07 KT 92 and 07 KT 93 (variables and constants)	A7– 1
A8	The ARCnet system	A8– 1

Central Units
07 KR 91 R202 and R252



Regulations Concerning the Setting up of Installations

Apart from the basic "Regulations for the Setting up of Power Installations" DIN VDE* 0100 and for "The Rating of Creepage Distances and Clearances" DIN VDE 0110 Part 1 and Part 2 the regulations "The Equipment of Power Installations with Electrical Components" DIN VDE 0160 in conjunction with DIN VDE 0660 Part 500 have to be taken into due consideration.

Further attention has to be paid to DIN VDE 0113 Part 1 and Part 200 in case of the control of working and processing machines. If operating elements are to be mounted near parts with dangerous contact voltage DIN VDE 0106 Part 100 is additionally relevant.

If the protection against direct contact according to DIN VDE 0160 is required, this has to be ensured by the user (e.g. by incorporating the elements in a switch-gear cabinet). The devices are designed for pollution severity 2 in accordance with DIN VDE 0110 Part 1. If higher pollution is expected, the devices must be installed in appropriate housings.

The user has to guarantee that the devices and the components belonging to them are mounted following these regulations. For operating the machines and installations, other national and international relevant regulations, concerning prevention of accidents and using technical working means, also have to be met.

The ABB Procontic devices are designed according to IEC 1131 Part 2. Meeting this regulation, they are classified in overvoltage category II which is in conformance with DIN VDE 0110 Part 2.

For the direct connection of ABB Procontic devices, which are powered with or coupled to AC line voltages of overvoltage category III, appropriate protection measures corresponding to overvoltage category II according to IEC-Report 664/1980 and DIN VDE 0110 Part 1 are to install.

Equivalent standards:

DIN VDE 0110 Part 1 \triangleq IEC 664

DIN VDE 0113 Part 1 \triangleq EN 60204 Part 1

DIN VDE 0660 Part 500 \triangleq EN 60439-1 \triangleq IEC 439-1

All rights reserved to change design, size, weight, etc.

* VDE stands for "Association of German Electrical Engineers".

ABB Schalt- und Steuerungstechnik GmbH Heidelberg

1 Central unit 07 KR 91

Central unit with max. 28 kB user program




Fig. 1–1: Central unit 07 KR 91

Contents

1.1	Brief description	1– 2	1.3.9	Serial interface COM1	1–14
1.1.1	Main features	1– 2	1.3.10	Networking interface	1–16
1.1.2	Project planning /start-up	1– 2	1.4	High-speed counter	1–17
1.2	Structure of the front panel	1– 4	1.5	Technical data	1–20
1.2.1	Terminal assignment overview	1– 5	1.5.1	General data	1–20
1.3	Electrical connection	1– 6	1.5.2	Power supply 07 KR 91 R202	1–20
1.3.1	Application example for input and output wiring	1– 6	1.5.3	Power supply 07 KR 91 R252	1–20
1.3.2	Connecting the supply voltage	1– 8	1.5.4	24 V output voltage for the supply of inputs	1–21
1.3.3	Electrical isolation and notes on earthing	1– 9	1.5.5	Lithium battery	1–21
1.3.4	Connection for ABB Procontic CS31 system bus	1–10	1.5.6	Binary inputs	1–21
1.3.5	24 V output voltage for the signal supply of the inputs	1–10	1.5.7	Binary outputs	1–22
1.3.6	Connection of the binary inputs	1–11	1.5.8	Connection of serial interface COM1 ..	1–23
1.3.7	Connection of the binary outputs	1–12	1.5.9	Connection to the ABB Procontic CS31 system bus	1–23
1.3.8	Battery and battery replacement	1–13	1.5.10	LED displays	1–23
			1.5.11	High-speed hardware counter	1–23
			1.5.12	Mechanical data	1–24
			1.5.13	Mounting hints	1–24
			1.5.14	Ordering data	1–25

1.1 Brief description

The central unit 07 KR 91 works either as

- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit.

The module is provided in two versions with supply voltages of 24 V DC and 115/ 230 V AC:

07 KR 91 R202:

The device has a 115/230 V AC power supply voltage. It provides a 24 V output voltage for the supply of its own binary inputs.

07 KR 91 R252:

The device has a 24 V DC power supply voltage. It is provided with an additional interface for connecting communication modules (e.g. 07 KP 90).

Both module versions have the following main features:

1.1.1 Main features

- 20 binary inputs
- 12 binary relay outputs
- 1 counting input for counting frequencies up to 10 kHz
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail

- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution
- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

1.1.2 Project planning / start-up

The following has to be observed for project planning and start-up:

- Programming is performed using ABB Procontic programming software, which can be run on commercially available IBM compatible PCs (see documentation for the programming system 907 PC 331)
- Diagnosis and service device TCZ (terminal mode) (see volume 7.3, see chapter A5 (Appendix), Programming and test, see 1.3.9 Serial interface COM1)
- The processor processes the user program contained in the RAM. It is loaded into the RAM via the serial interface COM1 and can also be changed there. An additional save command is used to save the program in the Flash EPROM.

Note: In the course of the following operations

- Power 'ON'
- RUN/STOP switch from STOP → RUN
- Program start-up with programming system
- Cold start of the PLC

the RAM is overwritten by the contents of the Flash EPROM, if a user program is contained in the Flash EPROM.

- On-line program modification
The two existing RAMs allow a quick modification of the user program to be performed without interrupting the operation (see ABB programming system 907 PC 331).
- Change-over between the application modes
 - Stand-alone central unit
 - Bus master central unit and
 - Slave central unit

The central unit is set to "Stand-alone" upon delivery. Changing the application mode is carried out in the following three steps:

1. Change the system constant KW 00,00 in the PLC, see chapter A7.3 (Appendix), System constants

2. Save the user program in the Flash EPROM
 3. Activate new application mode by:
 - calling up the menu item of "Enable PLC mode" in the ABB programming and test system or
 - performing a warm start or
 - performing a cold start.
- Setting the cycle time
see chapter A1 (Appendix), Processing times
 - Addressing when remote modules are connected
see chapter A2 (Appendix), Addressing
 - Back-up of data areas
Back-up of data areas, i.e. saving of data during power OFF/ON, is only feasible with built-in battery. The following data can be backed, completely or partly:
 - Binary flags
 - Word flags
 - Double word flags
 - Step chains
 - Historical values

In order to back-up certain data, they have to be excluded from initialization to 0.

- Initialization of data areas
During *program start*, that data areas are initialized to 0 partly or completely, that are defined by system constants, see chapter A7.3 (Appendix), System constants.

If no battery is effective or if the system constants are in their default values (factory settings), all of the above mentioned data areas are completely set to 0 after power OFF/ON.
- Reactions on errors of error class 3
The user can configure whether or not the user program is to be aborted automatically, if an class 3 error occurs, see chapter A7.3 (Appendix), System constants.
- Starting-up the CS31 system after power ON
The user can enter a number of n remote modules in KW 00,09. The user program starts only, i.e. it handles process inputs and outputs only, if at least n remote modules have been adopted into the CS31 system bus cycle, see chapter A7.3 (Appendix), System constants.

1.2 Structure of the front panel





Fig. 1–2: Central unit 07 KR 91 with reference points

- ① Fastening of the device on DIN rail
- ② Fastening of the device by screws
- ③ Faston earthing terminal 6.3 mm
- ④ Supply voltage connection
- ⑤ 24 V output voltage for input supply
- ⑥ Battery compartment
- ⑧–⑩ 20 binary inputs in three groups
- ⑪ Assignment of the identifiers for the inputs
- ⑫–⑭ 12 binary relay outputs in 3 groups
- ⑮ Assignment of the identifiers for the outputs
- ⑯ Serial interface COM1 (programming, MMC)
- ⑰ Connection for ABB Procontic CS31 system bus
- ⑱ Cover of the interface for the connection of communication modules (may only be removed for connecting communication modules)
- ⑲ Switch for RUN/STOP operation
- ⑳ LEDs for supply voltage and battery
- ㉑ LEDs for RUN and error class
- ㉒ LEDs for CS31 system bus
- ㉓ Plastic sheet (detachable for labelling)

- | | | | |
|---|-------|----------------------------------|--------------------------|
| ⑳ | green | <input type="checkbox"/> BA | Bus active |
| | red | <input type="checkbox"/> BE | Bus error |
| | red | <input type="checkbox"/> RE | Remote unit error |
| | red | <input type="checkbox"/> SE | Serial unit error |
| ㉑ | green | <input type="checkbox"/> RUN | User program is running |
| | red | <input type="checkbox"/> FK1 | Fatal error |
| | red | <input type="checkbox"/> FK2 | Serious error |
| | red | <input type="checkbox"/> FK3 | Light error |
| ㉒ | green | <input type="checkbox"/> Supply | Supply voltage available |
| | red | <input type="checkbox"/> Battery | Battery not effective |

For further information see chapter A4.3 (Appendix), Troubleshooting by means of LED displays on the central unit

- ⑲  The RUN/STOP switch is used to start or abort the processing of the user program.

1.2.1 Terminal assignment overview





Fig. 1-2a: Central unit 07 KR 91, terminal assignment

1.3 Electrical connection

1.3.1 Application examples for input and output wiring

The following two illustrations show application examples for 07 KR 91 R202 and R252 in which different possibilities for wiring inputs and outputs are used. Please observe in particular:

- The earthing measures, see also the earthing of the switch cabinet mains socket
- The handling of the electrically isolated input groups
- The handling of the electrically isolated output groups at three different voltage sources
- The demagnetization (diode) of a 24 V DC valve







Fig. 1-3a: Application example for the central unit 07 KR 91 R252 (supply voltage 24 V DC)

1.3.2 Connecting the supply voltage

07 KR 91 R202: Supply voltage 115 V AC, 230 V AC

The mains supply voltage is connected via a 5-pole detachable terminal block.

Attention: Plug and unplug terminal block only with power is off!



Terminal assignment:


- | | | |
|-----------|---------|--|
| 27 | NC | This terminal is not used (NC = Not connected) |
| 28 | L1/230V | Connection of the phase conductor 230 V, 50/60 Hz |
| 29 | L1/115V | Connection of the phase conductor 115 V, 50/60 Hz |
| 30 | N | Connection of the neutral cond. |
| 31 | PE | Protective Earth terminal, connected with the Faston terminal inside the device.
Do not cause earth loops!
Connect PE and Faston to the same earthing potential! |

Fig. 1-4: Assignment of the terminal block for the 115/230 V AC mains voltage

07 KR 91 R252: Supply voltage 24 V DC

The supply voltage of 24 V DC is connected via a 5-pole detachable terminal block.

Attention: Plug and unplug terminal block only with power is off!



Terminal assignment:

- | | | |
|-----------|----|--|
| 27 | NC | This terminal is not used. (NC = Not connected) |
| 28 | NC | This terminal is not used. (NC = Not connected) |
| 29 | L+ | Supply voltage +24 V DC |
| 30 | M | Reference potential (0V) |
| 31 | PE | Protective Earth terminal, connected with the Faston terminal inside the device.
Do not cause earth loops!
Connect PE and Faston to the same earthing potential! |

Fig. 1-5: Assignment of the terminal block for the 24 V DC-IN supply voltage

1.3.3 Electrical isolation and notes on earthing

The following illustrations show the parts of the devices' circuit which are electrically isolated from each other as well as the internal connections which exist. Both the creepage distances and clearances as well as the test voltages used correspond to DIN/VDE 0160.

The 6.3 mm Faston terminal in the lower left corner has to be connected directly and on the shortest possible way to the switch cabinet earthing using a wire with a cross section of 6 mm² in order to ensure safe earthing and as an EMC measure.




Fig. 1-6: Electrical isolation and connections inside the central unit 07 KR 91 R202





Fig. 1-7: Electrical isolation and connections inside the central unit 07 KR 91 R252

1.3.4 Connection for ABB Procontic CS31 system bus

The connection to the ABB Procontic CS31 system bus is made by means of a 3-pole detachable terminal block. Please observe:

- All of the CS31 devices, no matter whether they are master or slave devices, are connected with the twisted-pair bus line as follows:
 - One core of the bus line is looped through via the BUS1 terminals of all devices to be connected to the CS31 system bus.
 - The other core of the bus line is looped through via the BUS2 terminals of all devices to be connected to the CS31 system bus.
- If the central unit 07 KR 91 is located at the beginning or at the end of the bus line, the bus terminating resistor (120 Ω) has to be connected additionally between the BUS1 and BUS2 terminals.
- The shield of the twisted-pair bus line is looped through via the SHIELD terminals of all the devices to be connected to the CS31 system bus.
- The handling of the CS31 system bus is described in detail in volume 2, System data.




1.3.5 24 V output voltage for the signal supply of the inputs

The central unit 07 KR 91 provides a separate 24 V DC voltage output for the supply of the 20 binary input signals (for this purpose only).

This 24 V output voltage is used only if an external 24 V DC power supply unit is not available.

The internal 24 V power supply is overload-proof. The 24 V output voltage is ready for operation again approx. 2 minutes after an overload has been eliminated.



1.3.6 Connection of the binary input

The following illustration shows the configuration of the 20 binary inputs in three groups which are electrically

isolated from each other. The inputs work with 24 V DC signals in positive logic ($1 \triangleq +24 \text{ V}$).




Fig. 1–10: Terminals and assignment of the inputs

Input signals at the terminals 2 and 3

Terminal 2

– **Use as normal input signal:**

The signal is available in the user program in the operand E 62,00. The signal delay time is 7 ms.

The updating of the operand E 62,00 is performed before the start of each program cycle.

– **Use as high-speed input signal:**

The signal is available in the user program in the operand E 63,14. The signal delay time is 0.02 ms.

The updating of the operand E 63,14 is performed before the start of each program cycle.

In the Dual Port RAM (DPR) this signal is updated after each CS31 bus telegram. With the aid of the function block WOL this signal can be read in the Dual Port RAM (word address C000:1FE_H, Bit 14).

– **Use for the high-speed counter:**

The signal is used as counting input (10 kHz) for the high-speed counter.

Terminal 3

– **Use as normal input signal:**

The signal is available in the user program in the operand E 62,01. The signal delay time is 7 ms.

The updating of the operand E 62,01 is performed before the start of each program cycle.

– **Use as high-speed input signal:**

The signal is available in the user program in the operand E 63,15. The signal delay time is 0.02 ms.

The updating of the operand E 63,15 is performed before the start of each program cycle.


In the Dual Port RAM (DPR) this signal is updated

after each CS31 bus telegram. With the aid of the function block WOL this signal can be read in the Dual Port RAM (word address C000:1FE_H, Bit 15).

– **Use for the high-speed counter:**

The signal is used as enable input for the high-speed counter.

Circuit configuration of the binary inputs of the third group as an example (E63,00...E 62,03)




1.3.7 Connection of the binary outputs

The following illustration shows the circuit configuration of the binary outputs of the third group as an example.

The three groups (see the terminal configuration in the illustration on the next page) are electrically isolated from each other. The outputs work with relays. Each four relays from one group have a common voltage supply (Common terminal). These Common terminals can be supplied from different voltage sources.

Caution! If outputs are operated with dangerous contact voltages, the terminal block must be plugged in or unplugged only with their voltage switched off!


In order to suppress switching sparks when switching inductive AC loads, the relay contacts are equipped with varistors. If, however, **inductive DC loads** are switched, **one free-wheeling diode must be mounted in parallel to each of the loads** for demagnetization (see also Figures 1–3 and 1–4).



Yellow LEDs indicate the statuses of the outputs.

The user can enter symbol names of the program or signal abbreviations here. The plastic sheet can be detached for labelling.

Fig. 1–13: Terminals and assignment of the outputs



1.3.8 Battery and battery replacement




Fig. 1–14: Battery and battery replacement

The battery lifetime is 1.5 years (typ. 3 years) at 25°C. The battery lifetime is the time during which the device remains operable in order to backup data while the supply voltage of the central unit is switched off. As long as there is a supply voltage available, there is no more load on the battery other than its own leakage current.

The following handling notes have to be observed:


- Use only lithium batteries approved by ABB.
 - Replace the battery by a new one at the end of its life.
 - **Never short-circuit the battery!**
There is danger of overheating and explosion. Avoid accidental short-circuits, therefore do not store batteries in metallic containers or boxes and do not bring it into contact with metallic surfaces.
 - **Never try to charge the battery!**
Danger of overheating and explosion!
 - **Replace the battery only with the supply voltage switched on!**
Otherwise you risk data being lost.
 - **Dispose of battery environmentally consciously!**
 - If no battery is built-in or if the battery is exhausted, the red LED 'Battery' lights up.
- The lithium battery 07 LE 90 can be inserted into the battery compartment in order to
 - backup data of user program in RAM
 - backup data of additionally in RAM contained information, e.g. flag statuses
 - backup of time and date (real-time clock).

1.3.9 Serial interface COM 1

Interface standard: EIA-232

Assignment of the serial interface COM1

The serial interface has the following pin assignment:



Operating modes of the serial interface COM1

The operating mode of the interface has to be set according to the application in each case:

- Programming and test or
- Man-machine-communication MMC

Active mode: The active mode is used for programming and testing the central unit, i.e. it gives the user access to all the programming and test functions of the central unit.

Passive mode: The passive mode is used to perform a communication configured with the DRUCK and EMAS blocks between the user program and a device connected to the serial interface.

Conditions for setting the operating modes of the interface COM1

RUN/STOP switch	System constant KW00,06	System cable/device	Mode set by this
STOP	x	x	Active
RUN	1	x	Active
	2	x	Passive
	0, <0, >2	07 SK 90	Active
		07 SK 91, TCZ	Passive

x: without effect

Temporary interruption of the passive mode

While a communication between the DRUCK or EMAS blocks and a device connected to COM1 is being executed, it may be come necessary to modify the program, for example. For this purpose, you must switch over COM1 from the passive mode into the active mode.

Switch-over: Passive mode → Active mode

There are three possibilities for switching over:

- Set the RUN/STOP switch to the "STOP" position
- Replace cable 07 SK 91 by cable 07 SK 90 (if KW 00,06 is set to ≤ 0 or > 2)
- Send the following special command to the PLC:
``

The latter option has the advantage that the switch-over can also be controlled remotely, e.g. via telephone line and suitable dial-up modems. The ASCII character `` has the decimal code of 127 and the hexadecimal code of `7FH`. You can generate this character by simultaneously pressing the control key `<CTRL>` and the delete key `<—>`.

Notes:

On German keyboards, the control key is labelled by `<Strg>` instead of `<CTRL>`.

If the switch-over to the active mode was performed using the special command ``, please observe the following:

During the execution of the PLC program, the system constant KW 00,06 must **not** be sent to the PLC because this would cause the system to be switched back to the passive mode.

The special command assigns the value of "1" to the image of the system constant KW 00,06 located in the operand memory. The PLC evaluates the value of this image and sets the kind of application of COM1 correspondingly.

Switching back: Active mode —> Passive mode

There are three possibilities for switching back:

- Return RUN/STOP switch to the "RUN" position
- Replace cable 07 SK 90 by cable 07 SK 91 again.
- Cancel the special command as follows:
 - If the PLC program is in the "aborted" condition:
Start the PLC program.
 - If the PLC program is in the "running" condition:
send the original value of the system constant KW 00,06 to the PLC again
(907 PC 33 menu item "Send constants")

or
overwrite the system constant KW 00,06 by the original value
(907 PC 33 menu item "overwriting")

Interface parameters

Active mode: The settings of the interface parameters cannot be changed

Data bits:	8
Stop bits:	1
Parity bits:	none
Baud rate:	9600
Synchronization:	RTS/CTS

Passive mode: Default setting

Synchronization:	RTS/CTS
Interface identifier COM1:	1
Baud rate:	9600
Stop bits:	1
Data bits:	8
Parity bits:	none
Echo:	off
Send Break Character:	0
Enabling End-of-text character for sending direction:	no ¹⁾
Sending End-of-text character:	<CR> ¹⁾
Receiving End-of-text character:	<CR> ²⁾

1) The default End-of-text character for the sending direction (CR) is not sent. Nevertheless, this default End-of-text character (CR) must not appear in the message text of the assigned DRUCK block.

2) For the direction of reception, an End-of-text character is always necessary. This default End-of-text character (CR) must not appear neither in the message text nor in the user data of the assigned EMAS block.

For the passive mode of COM1, the interface parameters can be changed using the SINIT function block. If the changed values are not plausible, the COM1 interface uses the default values.

The interface is newly initialized each time the operating mode is switched over.


The active-mode parameters are set in the active mode, whereas in the passive mode the parameters established by the SINIT block or the default values are set.

1.3.10 Networking interface

The 07 KR 91 **R252** central unit is equipped with a special parallel interface. It is thus possible to network it with another bus system using an additional communication

processor module. The additional communication processor has its own housing.

Both housings (of the 07 KR 91 **R252** and of the communication processor) are assembled by means of a snap-on connection.




1.4 High-speed counter

Features

The high-speed counter used in the central units 07 KR 91, 07 KT 92 and 07 KT 93 works independently of the user program and is therefore able to response quickly to external signals. Its features are as follows:

- The counting frequency is max. 10 kHz. The counter counts the 0→1 edges at terminal 02 (also designated as E 62,00).
- The counter counts upwards from –32768 to +32767 (8000_H...7FFF_H). If +32767 is exceeded, the counter skips to –32768.

Sequence of the counting procedure:



- Enabling/disabling of the counting procedure using the internal variable A 63,14 in the user program:
 - A 63,14 = 0:
The internal variable A 63,13 = 1 enables the counting procedure, whereas A 63,13 = 0 disables it.
 - A 63,14 = 1:
Signal 1 at terminal 03 (also designated as E 62,01) enables the counting procedure, whereas signal 0 disables it. A 63,13 is without effect.
Note: The dead time may be 0...1.5 ms.

- Setting the counter in the user program:
 - to the value contained in the internal word variable AW 06,15
 - using the internal variable A 63,15 = 1.

Note: If the internal variable A 63,15 = 1 is present during several processing cycles, the processor sets the counter at the program end in each case. During the remaining time of the processing cycle, the counter counts pulses at terminal 02.

- The counter content can be read via the internal variable EW 06,15.
- Zero-crossing message (signal changes from 0 to 1 when the counter contents changes from –1 to 0):
 - always via the internal variable E 63,13,
 - at the terminal 36 (also designated as A 62,00) only, if the internal variable A 63,14 = 1 is set.
Note: The reaction time may be 0...1.5 ms. The direct control of the output A 62,00 from the user program is disabled by A 63,14 = 1.

The zero-crossing message is cancelled when the counter is set.

- Fast input of binary signals into the user program with a delay of < 0.02 ms:
 - Terminal 02 (also designated as E 62,00):
Internal variable E 63,14
 - Terminal 03 (also designated as E 62,01):
Internal variable E 63,15

Block diagram

see next page




Fig. 1-18: 07 KR 91, High-speed counter, block diagram

Configuration example

● Task:

- 180 pieces each of a unit load have to be filled into a packing.
- Each filled-in piece generates one pulse.
- When the packing is full, the counter is immediately prepared for the next filling operation.
- The enabling signal for the filling operation is sent by the packaging machine.
- The end of the counting operation has to be signalled to the packaging machine immediately.

● Wiring

- Connect the signal line for the counting pulses to terminal 02.
- Connect the signal line for the enabling of the counting operation to terminal 03.
- Connect the signal line for "zero crossing" of the counter to terminal 36.

● Configuration steps: PLC program

1) Activate terminals 03 and 36

- The terminals 03 and 36 are activated using the operand A 63,14.

IL (instruction list):

```
! K 00,01  
= A 63,14 (with K 00,01 = 1)
```

2) Preset start value for the counter

The start value (AW 06,15) is set to the value of –180. The counter will then count starting from –180 in positive direction. The transition from –1 to 0 will be signalled.

IL (instruction list):

```
! KW 01,00  
= AW 06,15 (with KW 01,00 = –180)
```

3) Adopt start value into the counter

After each counting operation, the start value is immediately set again into the counter by means of the "zero crossing" signal (E 63,13). Operand A 63,15 = 1 has to be set for this purpose. At program start, the start value is loaded once into the counter by means of the initialization flag M 255,15 (M 255,15 has the value of 0 after program start).

IL (instruction list):

```
! NM 255,15  
/ E 63,13  
= A 63,15  
:  
:  
other PLC program parts  
:  
:  
! K 00,01  
= M 255,15 (set M 255,15 = 1)  
! PE (program end)
```

Preset start values

You can preset both *positive* and *negative* start values for the counter.

The counting operation starts at the start value and is continued in correspondence with the arrows in the diagram until the enabling is stopped or a start value is loaded again.

Negative start value

The minimum negative start value is –32768 (8000_H).

By presetting a negative start value it is thus possible to count a maximum of 32768 pulses up to the zero crossing of the counter.

Positive start value

If a positive start value is preset, the counter counts up to the value of +32767 (7FFF_H), continues the counting operation at the value of –32768 (8000_H) and then signals the zero crossing when reaching the transition from –1 to 0.

The minimum positive start value is 1. If you preset this value, 65535 pulses will be counted up to the zero crossing.

In order to count more than 32767 pulses up to the zero crossing, the start value has to be calculated according to the following equation:

$$\text{Start value} = 32767 - (\text{number of pulses} - 32768)$$

Example:

40 000 pulses are to be counted.

The start value is in the positive range, because more than 32768 pulses have to be counted.

Calculation:

$$\begin{aligned} \text{Start value} &= 32767 - (\text{number of pulses} - 32768) \\ &= 32767 - (40\,000 - 32768) \\ &= 25535 \end{aligned}$$

1.5 Technical data 07 KR 91

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

1.5.1 General data

Number of binary inputs	20
Number of binary relay outputs	12
I/O expansion via CS31 system bus by up to	744 binary inputs 496 binary outputs 96 analog input channels 48 analog output channels max. 31 remote modules altogether
Number of serial interfaces	1 (for programming or connection to man-machine communication)
Number of parallel interfaces (only 07 KR 91 R252)	1 special interface for connection of a communication processor (for networking with other bus systems)
Integrated memory, 07 KR 91 R202 / R252:	Flash EPROM 32 kB (30 kB program) RAM 256 kB (30 kB program with online programming)
Resolution of the integrated real-time clock	1 second
Data of the integrated high-speed hardware counter counting range 0...65,535 (16 bits) counting frequency	max. 10 kHz
Processing time, binary operation 65 % bits, 35 % words	typ. 0.4...0.6 ms/kB program typ. 0.7 ms/kB program
Number of software timers delay time of the timers	any (max. 80 simultaneously active) 5 ms...24.8 days
Number of up/down counter SW blocks	any
Number of bit flags	4096
Number of word flags	4096
Number of double word flags	512
Diagnosis	cycle time monitoring, battery monitoring, detection of syntax errors and checksum monitoring
Indication of operating statuses and errors	42 LEDs altogether

1.5.2 Power supply 07 KR 91 R202

Mains voltage (rated value)	115 V AC
	or
Power dissipation	230 V AC max. 20 W

1.5.3 Power supply 07 KR 91 R252

Rated supply voltage	24 V DC
Current consumption	max. 0.4 A plus output current through terminal 34 (output voltage for the supply of the binary inputs)
Protection against reversed terminal connection	yes

1.5.4 24 V output voltage for the supply of inputs

Rated voltage	24 V DC
Load capability	max. 160 mA
Protection against overload	with a PTC resistor
Conductor cross section of the removable 3-pole terminal block	max. 2.5 mm ²

1.5.5 Lithium battery

Battery for back-up of RAM contents	07 LE 90 battery module
Lifetime at 25°C	1.5 years (typ. 3 years)

1.5.6 Binary inputs

Number of channels per module	20
Distribution of channels into groups	2 groups of 8 channels each, 1 group of 4 channels
Common reference potential for group 1 (8 channels) for group 2 (8 channels) for group 3 (4 channels)	ZP1.0 (channels 62,00...62,07) ZP1.1 (channels 62,08...62,15) ZP1.2 (channels 63,00...63,03)
Electrical isolation	between the groups, between groups and other circuitry (see also Figures 1–6 and 1–7)
Signal coupling of input signals	with optocoupler
Input signal delay of channels E 62,00...E 63,03 channels E 63,14 and 63,15 for counter control	typ. 7 ms typ. 0.02 ms typ. 0.02 ms
Signalling of input statuses	one green LED per channel, the LEDs correspond functionally to the input signals
Input signal voltage signal 0 signal 1 ripple when signal 0 within –30 V...+ 5 V when signal 1	–30 V...+ 5 V +13 V...+30 V within +13 V...+30 V
Allowed input overvoltage	± 36 V, for 100 ms only
Input current per channel input voltage = +24 V input voltage = + 5 V input voltage = +13 V input voltage = +30 V	typ. 8.0 mA ≥ 0.2 mA ≥ 2.0 mA ≤ 10.0 mA
Labelling for the inputs	symbol names or short signal designations can be labelled on the removeable front panel foil
Max. cable length unshielded	600 m
Max. cable length shielded	1000 m
Conductor cross section of the removable terminal blocks	max. 2.5 mm ²

1.5.7 Binary outputs

Number of channels per module	12 relay outputs
Distribution of channels into groups	3 groups of 4 channels each
Common supply voltage	
for group 1 (common 1)	W1 (channels 62,00...62,03)
for group 2 (common 2)	W2 (channels 62,04...62,07)
for group 3 (common 3)	W3 (channels 62,08...62,11)
Electrical isolation	between the groups, between groups and other circuitry (see also Figures 1–6 and 1–7)
Signalling of output statuses	one yellow LED per channel, the LEDs correspond functionally to the output signals
Switching voltage	12 V AC/DC...250 V AC/DC
Switching current per relay	
115/230 V AC, 50/60 Hz	$\cos \varphi = 1.0; I_{\max} = 2 \text{ A}$
115/230 V AC, 50/60 Hz	$\cos \varphi = 0.4; I_{\max} = 1 \text{ A}$
220 V DC	$I_{\max} = 0.2 \text{ A}$
24 V DC	$I_{\max} = 2.0 \text{ A}$
Total load per common potential (W1...W3)	max. 4 A
Leakage current per contact, contact open	max. 1 mA
Switching power	
in case of AC	max. 460 W
in case of DC	max. 50 W
Permissible lamp load	
in case of AC	max. 0.5 A, max. 100 W
in case of DC	max. 0.5 A, max. 25 W
Switching frequency	
with lamp load	max. 8 Hz (+30 %)
with inductive loads (full load)	max. 2 Hz
ON delay	$\leq 10 \text{ ms}$
OFF delay	$\leq 8 \text{ ms}$
Minimum switching power	2 W or 2 VA
Protection for relay contacts when switching inductive loads	
in case of AC	built-in varistor
in case of DC	a free-wheeling diode must be circuited in parallel to the load
Contact life time	
mechanical	$> 4 \times 10^7 \text{ cycles}$
230 V AC, load = 2 A (resistive load)	$> 4 \times 10^5 \text{ cycles}$
Labelling for the outputs symbol names or short signal designations can be	labelled on the removeable front panel foil
Conductor cross section of the removable terminal blocks	max. 2.5 mm ²

1.5.8 Connection of serial interface COM1

Interface standard	EIA RS–232
Programming with 907 PC 33	by means of IBM PC (or compatible)
Man–machine communication	yes, e.g. with ABB Procontic Operating Station 35 BS 40
Display and updating of timers, counters and parameters	yes, e.g. with TCZ Service Device
Electrical isolation	07 KR 91 R202 07 KR 91 R252
Potential differences	In order to avoid potential differences between the 07 KR 91 central unit and the peripheral device connected to the COM1 interface, this device is supplied from the switch cabinet socket (see also the earthing connections in Figures 1–3 and 1–4).
Pin configuration and description of the COM1 interface	see chapter 1.3.9

1.5.9 Connection to the ABB Procontic CS31 system bus

Interface standard	EIA RS–485
Connection	as a Master PLC as a Slave PLC
Setting of the CS31 module address	yes, transmitting and receiving area are configurable yes, see chapter "system constants"
Electrical isolation	yes, by system constant, stored in the Flash EPROM of the Slave PLC
Terminal assignment and description of the CS31 bus interface	versus supply voltage, inputs/outputs, versus COM1 interface (see also Figures 1–6 and 1–7)
Conductor cross section of the removable 3-pole terminal block	see chapter 1.3.4 max. 2.5 mm ²

1.5.10 LED displays

LEDs for indication of:

– statuses of binary inputs	1 green LED per channel
– statuses of binary outputs	1 yellow LED per channel
– power supply exists	1 green LED
– battery	1 red LED
– program runs (RUN)	1 green LED
– error classes (FK1, FK2, FK3)	1 red LED per error class
– CS31 system bus runs (BA)	1 green LED
– bus specific errors (BE, RE, SE)	3 red LEDs

1.5.11 High-speed hardware counter

Data of the integrated high–speed hardware counter	
counting range	0...65,535 (16 bits)
counting frequency	max. 10 kHz
used inputs	62,00 and 62,01 (the signal delay of these inputs is set to 0.02 ms for the counter)
used outputs	62,00

1.5.12 Mechanical data

Mounting on DIN rail

according to DIN EN 50022–35, 15 mm deep.
The DIN rail is located in the middle between the upper and the lower edges of the module.

Fastening by screws

using 4 M4 screws.

Width x height x depth

240 x 140 x 85 mm

Wiring method


by removable terminal blocks with screw-type terminals, conductor cross section max. 2.5 mm²

Weight

1.6 kg

Dimensions (for mounting)

see the following drawing



All dimensions in mm.

The device is 85 mm deep. The interface connector COM1 is set deeper so that the mounting depth required does not become any larger even with detachable interface cables. If, however, a DIN rail is used, the mounting depth is increased by the overall depth of the rail.

The dimensions for assembly bore holes are printed in bold.

1.5.13 Mounting hints

Mounting position

vertical, terminals above and below

Cooling

The natural convection cooling must not be hindered by cable ducts or other material mounted in the switch cabinet.

1.5.14 Ordering data

Central unit 07 KR 91 R202

Order No. GJR5 2500 00 R202

Central unit 07 KR 91 R252

Order No. GJR5 2500 00 R252

Scope of delivery

Central unit 07 KR 91 R202 or R252

2 9-pole terminal blocks

5 5-pole terminal blocks

2 3-pole terminal blocks

Safety and mounting instructions

Accessories

System cable 07 SK 90

Order No. GJR5 2502 00 R1

System cable 07 SK 91

Order No. GJR5 2503 00 R1

System cable 07 SK 92

Order No. GJR5 2504 00 R1

Battery module 07 LE 90

Order No. GJR5 2507 00 R1

Bus termination resistor

Simulation device 07 SG 90

Order No. GJR5 2506 00 R1

(includes a number of switches and push-buttons to enter binary input signals)

Programming and test software and operating manual

(both 907 PC 33 and 907 PC 331 are required)

907 PC 33 German ¹⁾

Order No. GJP5 2039 00 R202

907 PC 33 English ¹⁾

Order No. GJP5 2040 00 R202

907 PC 331 German ²⁾

Order No. GJP5 2045 00 R202

907 PC 331 English ²⁾

Order No. GJP5 2046 00 R202

Further Literature

System description ABB Procontic CS31

English

Order No. FPTN 440 004 R2001

System description ABB Procontic T200

English

Order No. GATS 1314 99 R2001

System description ABB Procontic T300

English

Order No. GATS 1315 99 R2002

System description ABB Procontic CS31

German

Order No. GATS 1316 99 R1002

System description ABB Procontic T200

German

Order No. GATS 1314 99 R1001

System description ABB Procontic T300


German

Order No. GATS 1315 99 R1002

¹⁾ Description General Part

²⁾ Description 07 KR 91 / 07 KT 92/93-Specific Part + Software Diskettes

Central Units
07 KT 92 R202 and R262



Regulations Concerning the Setting up of Installations

Apart from the basic "Regulations for the Setting up of Power Installations" DIN VDE* 0100 and for "The Rating of Creepage Distances and Clearances" DIN VDE 0110 Part 1 and Part 2 the regulations "The Equipment of Power Installations with Electrical Components" DIN VDE 0160 in conjunction with DIN VDE 0660 Part 500 have to be taken into due consideration.

Further attention has to be paid to DIN VDE 0113 Part 1 and Part 200 in case of the control of working and processing machines. If operating elements are to be mounted near parts with dangerous contact voltage DIN VDE 0106 Part 100 is additionally relevant.

If the protection against direct contact according to DIN VDE 0160 is required, this has to be ensured by the user (e.g. by incorporating the elements in a switch-gear cabinet). The devices are designed for pollution severity 2 in accordance with DIN VDE 0110 Part 1. If higher pollution is expected, the devices must be installed in appropriate housings.

The user has to guarantee that the devices and the components belonging to them are mounted following these regulations. For operating the machines and installations, other national and international relevant regulations, concerning prevention of accidents and using technical working means, also have to be met.

The ABB Procontic devices are designed according to IEC 1131 Part 2. Meeting this regulation, they are classified in overvoltage category II which is in conformance with DIN VDE 0110 Part 2.

For the direct connection of ABB Procontic devices, which are powered with or coupled to AC line voltages of overvoltage category III, appropriate protection measures corresponding to overvoltage category II according to IEC-Report 664/1980 and DIN VDE 0110 Part 1 are to install.

Equivalent standards:

DIN VDE 0110 Part 1 \triangleq IEC 664

DIN VDE 0113 Part 1 \triangleq EN 60204 Part 1

DIN VDE 0660 Part 500 \triangleq EN 60439-1 \triangleq IEC 439-1

All rights reserved to change design, size, weight, etc.

* VDE stands for "Association of German Electrical Engineers".

ABB Schalt- und Steuerungstechnik GmbH Heidelberg




Fig. 2–1: Central unit 07 KT 92

Contents

2.1	Brief description	2– 2	2.3.13	Battery and battery replacement	2–15
2.1.1	Main features	2– 2	2.3.14	Serial interface COM1	2–16
2.1.2	Project planning / start-up	2– 2	2.3.15	Serial interface COM2	2–18
2.2	Structure of the front panel	2– 4	2.3.16	Networking interface	2–19
2.2.1	Terminal assignment overview	2– 5	2.4	High-speed counter	2–20
2.3	Electrical connection	2– 6	2.5	Technical data	2–23
2.3.1	Application example for input and output wiring	2– 6	2.5.1	General data	2–23
2.3.2	Connecting the supply voltage	2– 7	2.5.2	Power supply	2–23
2.3.3	Electrical isolation and notes on earthing	2– 8	2.5.3	24 V output voltage for the supply of inputs	2–24
2.3.4	ARCnet interface	2– 9	2.5.4	Lithium battery	2–24
2.3.5	Connection for ABB Procontic CS31 system bus	2– 9	2.5.5	Binary inputs	2–24
2.3.6	24 V output voltage for the signal supply of the inputs	2–10	2.5.6	Binary outputs	2–25
2.3.7	Connection of the binary inputs	2–10	2.5.7	Analog inputs	2–25
2.3.8	Connection of the analog inputs	2–11	2.5.8	Analog outputs	2–26
2.3.9	Identifier assignment for binary and analog inputs	2–12	2.5.9	Connection of serial interface COM1 ..	2–26
2.3.10	Connection of the binary outputs	2–13	2.5.10	Connection of serial interface COM2 ..	2–27
2.3.11	Connection of the analog outputs	2–14	2.5.11	Connection to the ABB Procontic CS31 system bus	2–27
2.3.12	Identifier assignment for the outputs (binary and analog)	2–15	2.5.12	Connection of ARCnet	2–27
			2.5.13	LED displays	2–28
			2.5.14	High-speed hardware counter	2–28
			2.5.15	Mechanical data	2–29
			2.5.16	Mounting hints	2–29
			2.5.17	Ordering data	2–30

2.1 Brief description

The central unit 07 KT 92 works either as

- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit.

The device has a 24 V DC power supply voltage. It is provided with an additional interface for connecting communication modules (e.g. 07 KP 90).

The central unit 07 KT 92 **R262** is equipped with an **integrated ARCnet coupler** (and an ARCnet interface).

2.1.1 Main features

- 12 binary inputs
- 8 binary transistor outputs
- 4 analog inputs
- 2 analog outputs
- 1 counting input for counting frequencies up to 50 kHz
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
- Serial interface COM2 as an MMC interface
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution

- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

2.1.2 Project planning / start-up

The following has to be observed for project planning and start-up:

- Programming is performed using ABB Procontic programming software, which can be run on commercially available IBM compatible PCs (see documentation for the programming system 907 PC 331)
- Diagnosis and service device TCZ (terminal mode) (see volume 7.3, see chapter A5 (Appendix), Programming and test, see 2.3.14 Serial interface COM1)
- The processor processes the user program contained in the RAM. It is loaded into the RAM via the serial interface COM1 and can also be changed there. An additional save command is used to save the program in the Flash EPROM.

Note: In the course of the following operations

- Power 'ON'
- RUN/STOP switch from STOP → RUN
- Program start-up with programming system
- Cold start of the PLC

the RAM is overwritten by the contents of the Flash EPROM, if a user program is contained in the Flash EPROM.

Important note:

If a PLC is used with an ARCnet interface, a certain section of the PLC TURBO program memory No. 2 is reserved for ARCnet.

If programs with more than 2 k instructions are executed, the system-dependent capacity utilization can possibly be increased by reason of the reduced TURBO memory No. 2 when *changes are made to a running program*.

There are *no* problems, if

- the capacity utilization is less than 80 % *before* making changes to a running program or if
- the program length is less than 2 k instructions.

- On-line program modification

The two existing RAMs allow a quick modification of the user program to be performed without interrupting the operation (see ABB programming system 907 PC 331).

- Change-over between the application modes
 - Stand-alone central unit
 - Bus master central unit and
 - Slave central unit

The central unit is set to "Stand-alone" upon delivery. Changing the application mode is carried out in the following three steps:

1. Change the system constant KW 00,00 in the PLC, see chapter A7.3 (Appendix), System constants
 2. Save the user program in the Flash EPROM
 3. Activate new application mode by:
 - calling up the menu item of "Enable PLC mode" in the ABB programming and test system or
 - performing a warm start or
 - performing a cold start.
- Setting the cycle time
see chapter A1 (Appendix), Processing times
 - Addressing when remote modules are connected
see chapter A2 (Appendix), Addressing
 - Back-up of data areas
Back-up of data areas, i.e. saving of data during power OFF/ON, is only feasible with built-in battery. The following data can be backed, completely or partly:
 - Binary flags
 - Word flags
 - Double word flags
 - Step chains
 - Historical values

In order to back-up certain data, they have to be excluded from initialization to 0.

- Initialization of data areas
During *program start*, that data areas are initialized to 0 partly or completely, that are defined by system constants, see chapter A7.3 (Appendix), System constants.

If no battery is effective or if the system constants are in their default values (factory settings), all of the above mentioned data areas are completely set to 0 after power OFF/ON.

- Reactions on errors of error class 3
The user can configure whether or not the user program is to be aborted automatically, if an class 3 error occurs, see chapter A7.3 (Appendix), System constants.

- Starting-up the CS31 system after power ON

The user can enter a number of n remote modules in KW 00,09. The user program starts only, i.e. it handles process inputs and outputs only, if at least n remote modules have been adopted into the CS31 system bus cycle, see chapter A7.3 (Appendix), System constants.

2.2 Structure of the front panel





Fig. 2-2: Central unit 07 KT 92 with reference points

- ① Fastening of the device on DIN rail
- ② Fastening of the device by screws
- ③ Faston earthing terminal 6.3 mm
- ④ Supply voltage connection 24 V DC
- ⑤ 24 V output voltage for input supply
- ⑥ Battery compartment
- ⑦-⑧ 12 binary inputs in two groups
- ⑨ 4 analog inputs in one group
- ⑩ Assignment of the identifiers for the inputs
- ⑪ 8 binary transistor outputs in one group
- ⑫ ARCnet BNC connector (version R262 only)
- ⑬ 2 LEDs for ARCnet operation (version R262)
- ⑭ 2 analog outputs ± 10 V
- ⑮ Assignment of the identifiers for the outputs
- ⑯ Serial interface COM1 (programming, MMC)
- ⑰ Serial interface COM2 (MMC)
- ⑱ Connection for ABB Procontic CS31 system bus
- ⑲ Cover of the interface for the connection of communication modules (may only be removed for connecting communication modules)
- ⑳ Switch for RUN/STOP operation
- ㉑ LEDs for supply voltage and battery
- ㉒ LEDs for RUN and error class
- ㉓ LEDs for CS31 system bus
- ㉔ LED for overload/short-circuit (LED K)

- ① Plastic sheet (detachable for labelling)

- | | | | |
|---|-------|----------------------------------|--------------------------|
| ⑳ | green | <input type="checkbox"/> BA | Bus active |
| | red | <input type="checkbox"/> BE | Bus error |
| | red | <input type="checkbox"/> RE | Remote unit error |
| | red | <input type="checkbox"/> SE | Serial unit error |
| ㉑ | green | <input type="checkbox"/> RUN | User program is running |
| | red | <input type="checkbox"/> FK1 | Fatal error |
| | red | <input type="checkbox"/> FK2 | Serious error |
| | red | <input type="checkbox"/> FK3 | Light error |
| ㉒ | green | <input type="checkbox"/> Supply | Supply voltage available |
| | red | <input type="checkbox"/> Battery | Battery not effective |

For further information see chapter A4.3 (App.) Troubleshooting by means of LED displays on the central unit

- ㉓  The RUN/STOP switch is used to start or abort the processing of the user program.

2.2.1 Terminal assignment overview





Fig. 2-2a: Central unit 07 KT 92, terminal assignment

2.3 Electrical connection

2.3.1 Application examples for input and output wiring

The following illustration shows an application example in which different possibilities for wiring inputs and outputs are used.




Please observe in particular:

- The earthing measures
- The handling of the electrically isolated input groups
- The handling of the electrically isolated output group
- The connection of analog-value receiver and analog-value sensor
- The earthing of the switch cabinet mains socket

2.3.2 Connecting the supply voltage

The 24 V DC supply voltage is connected via a 5-pole detachable terminal block.


Attention: Plug and unplug terminal block only with power is off!



2.3.3 Electrical isolation and notes on earthing

The following illustration shows the parts of the device's circuit which are electrically isolated from each other as well as the internal connections which exist. Both the creepage distances and clearances as well as the test voltages used correspond to DIN/VDE 0160.

The 6.3 mm Faston terminal in the lower left corner has to be connected directly and on the shortest possible way to the switch cabinet earthing using a wire with a cross section of 6 mm² in order to ensure safe earthing and as an EMC measure.



2.3.4 ARCnet interface, see also chapter A8 (Appendix)

- The ARCnet coupler is integrated in the central unit 07 KT 92 **R262**. The DIL switch for setting the ARCnet address is accessible through the cutout of the external networking interface.
- The ARCnet coupler is supplied from the internal 24 V DC power supply.

Important note:

If a PLC is used with an ARCnet interface, a certain section of the PLC TURBO program memory No. 2 is reserved for ARCnet.

If programs with more than 2 k instructions are executed, the system-dependent capacity utilization can possibly be increased by reason of the reduced TURBO memory No. 2 when *changes are made to a running program*.

There are *no* problems, if

- the capacity utilization is less than 80 % *before* making changes to a running program or if
- the program length is less than 2 k instructions.
- The function blocks AINIT, ASEND, AREC and APOLL are available for the ARCnet coupling.
- The data packages are read from the ARCnet controller interrupt-controlled. The interrupt routine stores the data package in the storage buffer. The APOLL block serves for the sending direction. It transfers data packages from the storage buffer to the ARCnet controller for sending them off.
- The ARCnet coupler interface is designed as a bus with BNC connector for coaxial cable. The ARCnet bus is earthed inside the module via a capacitor. As an EMC measure and for protection against dangerous contact voltages, the bus has to be earthed directly at a central place.
- Using the simplest configuration, called Linear ARCnet, a coaxial cable (RG62, 93 W) is layed from station to station and connected with T plugs at all stations. At both ends of the cable, termination resistors with 93 W each have to be installed, for more information see chapter A8.1 (Appendix). In a Linear ARCnet, a maximum of 8 stations is possible at a cable length of 300 m.
- The parallel networking interface is used for the ARCnet coupler inside the module. However, it is still available from outside as an external networking interface. The serial interface module 07 KP 92 can be connected here, for instance.

Setting the ARCnet Node Number (station address) of the central unit




Fig. 2-5a: Setting the ARCnet Node Number (station address) of the central unit 07 KT 92 R262

2.3.5 Connection for ABB Procontic CS31 system bus




Fig. 2-6: Assignment of the ABB Procontic CS31 system bus interface

The connection to the ABB Procontic CS31 system bus is made by means of a 3-pole detachable terminal block. Please observe:


- All of the CS31 devices, no matter whether they are master or slave devices, are connected with the twisted-pair bus line as follows:
 - One core of the bus line is looped through via the BUS1 terminals of all devices to be connected to the CS31 system bus.
 - The other core of the bus line is looped through via the BUS2 terminals of all devices to be connected to the CS31 system bus.
- If the central unit 07 KT 92 is located at the beginning or at the end of the bus line, the bus terminating resistor (120 W) has to be connected additionally between the BUS1 and BUS2 terminals.
- The shield of the twisted-pair bus line is looped through via the SHIELD terminals of all the devices to be connected to the CS31 system bus.
- The handling of the CS31 system bus is described in detail in volume 2, System data.

2.3.6 24 V output voltage for the signal supply of the inputs

The central unit 07 KT 92 provides a separate 24 V DC voltage output for the supply of the 12 binary input signals (for this purpose only).

This 24 V output voltage is used only if an external 24 V DC power supply unit is not available.

The internal 24 V power supply is overload-proof. The 24 V output voltage is ready for operation again approx. 2 minutes after an overload has been eliminated.



2.3.7 Connection of the binary inputs

The following illustration shows the circuit configuration of the binary inputs of the first group as an example.

Features:

- The 12 binary inputs are arranged in two groups.
- The two groups E 62,00...E 62,07 and E 62,08...E 62,11 are electrically isolated from each other (see Fig. 2-5).
- The inputs use 24 V signals in positive logic ($1 \triangleq +24 \text{ V}$).

Input signals at the terminals 2 and 3

Terminal 2

– Use as normal input signal:

The signal is available in the user program in the operand E 62,00. The signal delay time is 7 ms.

The updating of the operand E 62,00 is performed before the start of each program cycle.

– Use as high-speed input signal:

The signal is available in the user program in the operand E 63,14. The signal delay time is 8 ms.

The updating of the operand E 63,14 is performed before the start of each program cycle.

In the Dual Port RAM (DPR) this signal is updated after each CS31 bus telegram. With the aid of the function block WOL this signal can be read in the Dual Port RAM (word address C000:1FE_H, Bit 14).

– Use for the high-speed counter:

The signal is used as counting input (50 kHz) for the high-speed counter.

Terminal 3

– Use as normal input signal:

The signal is available in the user program in the operand E 62,01. The signal delay time is 7 ms.

The updating of the operand E 62,01 is performed before the start of each program cycle.

– Use as high-speed input signal:

The signal is available in the user program in the operand E 63,15. The signal delay time is 8 ms.


The updating of the operand E 63,15 is performed before the start of each program cycle.

In the Dual Port RAM (DPR) this signal is updated after each CS31 bus telegram. With the aid of the function block WOL this signal can be read in the Dual Port RAM (word address C000:1FE_H, Bit 15).

– Use for the high-speed counter:

The signal is used as enable input for the high-speed counter.

Circuit configuration of the binary inputs of the first group as an example (E62,00...E 62,07)



2.3.8 Connection of the analog inputs, with signal ranges either 0...10 V, 0...5 V or 0...20 mA

The following illustration shows the circuit configuration of the analog inputs of the first channel as an example.

Features:

- The 4 analog inputs are not separated electrically.
- The A/D converter has a resolution of 12 bits.
- The analog inputs are able to evaluate the following signal ranges each as required:

0...10 V	resolution ca. 2.5 mV
0... 5 V	resolution ca. 1.25 mV
0...20 mA	resolution ca. 5 μ A

- Resolution in the PLC:
The smallest detectable changes on the analog side (2.5 mV, 1.25 mV, 5 μ A) cause the numerical value in the PLC program to be changed by the amount of 8.


- Relationship between the analog value at the analog input and the numerical value in the PLC program:

selected range	numerical values
0...10 V	0...32760 _D or 0000...7FF8 _H
0... 5 V	0...32760 _D or 0000...7FF8 _H
0...20 mA	0...32760 _D or 0000...7FF8 _H


For further information see volume 2, chapter 5.1 General information on using the analog input and output modules.

For 07 KT 92 "Assignment **b**" is valid.

Circuit configuration of the analog inputs of the first channel as an example



2.3.9 Identifier assignment for binary and analog inputs



2.3.10 Connection of the binary outputs

The following illustration shows the circuit configuration of the binary outputs.

Features of the outputs:

- The 8 outputs are arranged in one group and are electrically connected with each other.
- The outputs can be loaded with a rated current of 500 mA.
- The group as a whole is electrically isolated from the rest of the device.
- The outputs use transistors and are short-circuit-proof.
- The eight transistors of the group have a common power supply.
- The outputs are automatically switched off in case of overload or short-circuit.

- A overall error message indicates a short-circuit or an overload which has occurred on one or on several outputs.
- An overload is displayed by the red LED K and via error flags in the PLC.
- The user can set by means of a system constant whether the overloaded output is to be switched on again automatically by the PLC or whether it is to be switched on again by configuring within the PLC program, e.g. by means of the function blocks CS31QU or CS31CO. The default setting is the automatic reset of the outputs.
- The red LED K goes out when the overloaded output is switched on again after eliminating the overload.
- The acknowledgement of the error message, i.e. the resetting of the error flags, is done in correspondence with chapter A4.8 (Appendix), Acknowledgement of error messages in the central unit.

Circuit configuration of the binary outputs A 62,00...A 62,07




Fig. 2-11: Circuit configuration of the 8 transistor outputs

2.3.11 Connection of the analog outputs

The following illustration shows the circuit configuration of the analog outputs.

Features of the analog outputs:

- The analog outputs are not separated electrically.
- Load capability of the outputs max. ± 5 mA
- Resolution of the D/A converter: 12 bits
- Range of conversion: -10 V ... $+10$ V
- Resolution 5 mV
- If the numerical value in the PLC is changed by the amount of 16, the voltage at the outputs is changed by 5 mV.
- Relationship between the numerical value in the PLC program and the analog value at the analog outputs:
 - -32768 (8000_H) ... -32761 ($800F_H$) $\rightarrow -10$ V
 - -00016 ($FFF0_H$) ... -00001 ($FFFF_H$) $\rightarrow -5$ mV
 - 00000 (0000_H) ... $+00015$ ($000F_H$) $\rightarrow 0$ V
 - $+32752$ ($7FF0_H$) ... $+32767$ ($7FFF_H$) $\rightarrow +10$ V

For further information see volume 2, chapter 5.1 General information on using the analog input and output modules.

For 07 KT 92 "Assignment b" is valid.

Output 06,01 (analog output instead of the calibrated 10 V output)

With the module 07 KT 92 **R101**, the terminal 52 was assigned with a fixed and calibrated output voltage of $+10$ V. Instead of this fixed voltage, the terminal 52 of the module 07 KT 92 **R202/262** is assigned with a second analog output (channel No. 06,01). It has the same specifications as channel No. 06,00.

If the output 06,01 must have a voltage of $+10$ V, the user program has to be added by the following instruction:

```
!KW XX,YY = AW 06,01
with
KW XX,YY = 32767
```

When replacing older modules with newer ones it has to be kept in mind that the output AW 06,01 only provides the $+10$ V voltage while the program is running.

Circuit configuration of the analog outputs AW 06,00 and AW 06,01




Fig. 2-12: Circuit configuration of the analog outputs

2.3.12 Identifier assignment for the outputs (binary and analog)




Fig. 2–13: Terminals and assignments of the outputs

2.3.13 Battery and battery replacement

- The lithium battery 07 LE 90 can be inserted into the battery compartment in order to
 - backup data of user program in RAM
 - backup data of additionally in RAM contained information, e.g. flag statuses
 - backup of time and date (real-time clock).

The battery lifetime is 1.5 years at 25°C (typ. 3 years). The battery lifetime is the time during which the device remains operable in order to backup data while the supply voltage of the central unit is switched off. As long as there is a supply voltage available, there is no more load on the battery other than its own leakage current.




Fig. 2–14: Battery and battery replacement

The following handling notes have to be observed:


- Use only lithium batteries approved by ABB.
- Replace the battery by a new one at the end of its life.
- **Never short-circuit the battery!**
There is danger of overheating and explosion. Avoid accidental short-circuits, therefore do not store batteries in metallic containers or boxes and do not bring it into contact with metallic surfaces.
- **Never try to charge the battery!**
Danger of overheating and explosion!
- **Replace the battery only with the supply voltage switched on!**
Otherwise you risk data being lost.
- **Dispose of battery environmentally consciously!**
- If no battery is built-in or if the battery is exhausted, the red LED 'Battery' lights up.

2.3.14 Serial interface COM 1

Interface standard: EIA-232

Assignment of the serial interface COM1

The serial interface has the following pin assignment:



Operating modes of the serial interface COM1

The operating mode of the interface has to be set according to the application in each case:

- Programming and test or
- Man-machine-communication MMC

Active mode: The active mode is used for programming and testing the central unit, i.e. it gives the user access to all the programming and test functions of the central unit.

Passive mode: The passive mode is used to perform a communication configured with the DRUCK and EMAS blocks between the user program and a device connected to the serial interface.

The special command assigns the value of "1" to the image of the system constant KW 00,06 located in the operand memory. The PLC evaluates the value of this image and sets the kind of application of COM1 correspondingly.

Conditions for setting the operating modes of the interface COM1

RUN/STOP switch	System constant KW00,06	System cable/device	Mode set by this
STOP	x	x	Active
RUN	1	x	Active
	2	x	Passive
	0, <0, >2	07 SK 90	Active
		07SK91, TCZ	Passive

x: without effect

Temporary interruption of the passive mode

While a communication between the DRUCK or EMAS blocks and a device connected to COM1 is being executed, it may be come necessary to modify the program, for example. For this purpose, you must switch over COM1 from the passive mode into the active mode.

Switch-over: Passive mode → Active mode

There are three possibilities for switching over:

- Set the RUN/STOP switch to the "STOP" position
- Replace cable 07 SK 91 by cable 07 SK 90 (if KW 00,06 is set to ≤0 or >2)
- Send the following special command to the PLC:

The latter option has the advantage that the switch-over can also be controlled remotely, e.g. via telephone line and suitable dial-up modems. The ASCII character has the decimal code of 127 and the hexadecimal code of 7FH. You can generate this character by simultaneously pressing the control key <CTRL> and the delete key <—>.

Notes:

On German keyboards, the control key is labelled by <Strg> instead of <CTRL>.

If the switch-over to the active mode was performed using the special command , please observe the following:

During the execution of the PLC program, the system constant KW 00,06 must **not** be sent to the PLC because this would cause the system to be switched back to the passive mode.

Switching back: Active mode → Passive mode

There are three possibilities for switching back:

- Return RUN/STOP switch to the "RUN" position
- Replace cable 07 SK 90 by cable 07 SK 91 again.
- Cancel the special command as follows:

– If the PLC program is in the "aborted" condition:

Start the PLC program.

– If the PLC program is in the "running" condition:

send the original value of the system constant KW 00,06 to the PLC again (907 PC 33 menu item "Send constants")

or

overwrite the system constant KW 00,06 by the original value (907 PC 33 menu item "overwriting")

Interface parameters

Active mode: The settings of the interface parameters cannot be changed

Data bits:	8
Stop bits:	1
Parity bits:	none
Baud rate:	9600
Synchronization:	RTS/CTS

Passive mode: Default setting

Synchronization:	RTS/CTS
Interface identifier COM1:	1
Baud rate:	9600
Stop bits:	1
Data bits:	8
Parity bits:	none
Echo:	off
Send Break Character:	0
Enabling End-of-text character for sending direction:	no ¹⁾
Sending End-of-text character:	<CR> ¹⁾
Receiving End-of-text character:	<CR> ²⁾

¹⁾ The default End-of-text character for the sending direction (CR) is not sent. Nevertheless, this default End-of-text character (CR) must not appear in the message text of the assigned DRUCK block.

- 2) For the direction of reception, an End-of-text character is always necessary. This default End-of-text character (CR) must not appear neither in the message text nor in the user data of the assigned EMAS block.

For the passive mode of COM1, the interface parameters can be changed using the SINIT function block. If the changed values are not plausible, the COM1 interface uses the default values.

The interface is newly initialized each time the operating mode is switched over.


The active-mode parameters are set in the active mode, whereas in the passive mode the parameters established by the SINIT block or the default values are set.

2.3.15 Serial interface COM 2

Interface standard: EIA-232

Assignment of the serial interface COM2

The serial interface has the following pin assignment:



Operating modes of the COM2 interface

The serial interface COM2 is fixedly set to the **passive mode** (MMC interface).

The passive mode is used to perform a communication configured with the aid of the DRUCK and EMAS blocks between the user program and a device connected to the serial interface.

The application-specific initialization of COM2 can be performed using the SINIT function block.

Interface parameter

Passive mode: Default setting

Synchronization:	RTS/CTS
Interface identifier COM2:	2
Baud rate:	9600
Stop bits:	1
Data bits:	8
Parity bits:	none
Echo:	off
Send Break Character:	0
Enabling End-of-text character for sending direction:	no ¹⁾
Sending End-of-text character:	<CR> ¹⁾
Receiving End-of-text character:	<CR> ²⁾

1) The default End-of-text character for the sending direction (CR) is not sent. Nevertheless, this default End-of-text character (CR) must not appear in the message text of the assigned DRUCK block.

2) For the direction of reception, an End-of-text character is always necessary. This default End-of-text character (CR) must not appear neither in the message text nor in the user data of the assigned EMAS block.

For the passive mode of COM2, the interface parameters can be changed using the SINIT function block. If the changed values are not plausible, the COM2 interface uses the default values.

In the passive mode the parameters established by the SINIT block or the default values are set.

2.3.16 Networking interface

The 07 KT 92 central unit is equipped with a special parallel interface. It is thus possible to network it with another bus system using an additional communication processor module. The additional communication

processor has its own housing. Both housings (of the 07 KT 92 and of the communication processor) are assembled by means of a snap-on connection.




Fig. 2–17: Mounting of 07 KT 92 with expansion (e.g. communication processor 07 KP 90)


2.4 High-speed counter

Features

The high-speed counter used in the central units 07 KR 91, 07 KT 92 and 07 KT 93 works independently of the user program and is therefore able to response quickly to external signals. Its features are as follows:

- The counting frequency is max. 50 kHz. The counter counts the 0→1 edges at terminal 02 (also designated as E 62,00).
- The counter counts upwards from –32768 to +32767 (8000_H...7FFF_H). If +32767 is exceeded, the counter skips to –32768.

Sequence of the counting procedure:



- Enabling/disabling of the counting procedure using the internal variable A 63,14 in the user program:
 - A 63,14 = 0:
The internal variable A 63,13 = 1 enables the counting procedure, whereas A 63,13 = 0 disables it.
 - A 63,14 = 1:
Signal 1 at terminal 03 (also designated as E 62,01) enables the counting procedure, whereas signal 0 disables it. A 63,13 is without effect.
Note: The dead time may be 0...1.5 ms.

- Setting the counter in the user program:
 - to the value contained in the internal word variable AW 06,15
 - using the internal variable A 63,15 = 1.

Note: If the internal variable A 63,15 = 1 is present during several processing cycles, the processor sets the counter at the program end in each case. During the remaining time of the processing cycle, the counter counts pulses at terminal 02.

- The counter content can be read via the internal variable EW 06,15.
- Zero-crossing message (signal changes from 0 to 1 when the counter contents changes from –1 to 0):
 - always via the internal variable E 63,13,
 - at the terminal 41 (also designated as A 62,00) only, if the internal variable A 63,14 = 1 is set.
Note: The reaction time may be 0...1.5 ms. The direct control of the output A 62,00 from the user program is disabled by A 63,14 = 1.

The zero-crossing message is cancelled when the counter is set.

- Fast input of binary signals into the user program with a delay of 8 ms:
 - Terminal 02 (also designated as E 62,00):
Internal variable E 63,14
 - Terminal 03 (also designated as E 62,01):
Internal variable E 63,15

Block diagram

see next page




Fig. 2-19: 07 KT 92, High-speed counter, block diagram

Configuration example

● Task:

- 180 pieces each of a unit load have to be filled into a packing.
- Each filled-in piece generates one pulse.
- When the packing is full, the counter is immediately prepared for the next filling operation.
- The enabling signal for the filling operation is sent by the packaging machine.
- The end of the counting operation has to be signalled to the packaging machine immediately.

● Wiring

- Connect the signal line for the counting pulses to terminal 02.
- Connect the signal line for the enabling of the counting operation to terminal 03.
- Connect the signal line for "zero crossing" of the counter to terminal 41.

● Configuration steps: PLC program

1) Activate terminals 03 and 41

- The terminals 03 and 41 are activated using the operand A 63,14.

IL (instruction list):

```
! K 00,01
```

```
= A 63,14 (with K 00,01 = 1)
```

2) Preset start value for the counter

The start value (AW 06,15) is set to the value of –180. The counter will then count starting from –180 in positive direction. The transition from –1 to 0 will be signalled.

IL (instruction list):

```
! KW 01,00
```

```
= AW 06,15 (with KW 01,00 = –180)
```

3) Adopt start value into the counter

After each counting operation, the start value is immediately set again into the counter by means of the "zero crossing" signal (E 63,13). Operand A 63,15 = 1 has to be set for this purpose. At program start, the start value is loaded once into the counter by means of the initialization flag M 255,15 (M 255,15 has the value of 0 after program start).

IL (instruction list):

```
! NM 255,15
```

```
/ E 63,13
```

```
= A 63,15
```

```
:
```

```
:
```

other PLC program parts

```
:
```

```
:
```

```
! K 00,01
```

```
= M 255,15 (set M 255,15 = 1)
```

```
! PE (program end)
```

Preset start values

You can preset both *positive* and *negative* start values for the counter.

The counting operation starts at the start value and is continued in correspondence with the arrows in the diagram until the enabling is stopped or a start value is loaded again.

Negative start value

The minimum negative start value is –32768 (8000_H).

By presetting a negative start value it is thus possible to count a maximum of 32768 pulses up to the zero crossing of the counter.

Positive start value

If a positive start value is preset, the counter counts up to the value of +32767 (7FFF_H), continues the counting operation at the value of –32768 (8000_H) and then signals the zero crossing when reaching the transition from –1 to 0.

The minimum positive start value is 1. If you preset this value, 65535 pulses will be counted up to the zero crossing.

In order to count more than 32767 pulses up to the zero crossing, the start value has to be calculated according to the following equation:

$$\text{Start value} = 32767 - (\text{number of pulses} - 32768)$$

Example:

40 000 pulses are to be counted.

The start value is in the positive range, because more than 32768 pulses have to be counted.

Calculation:

$$\begin{aligned} \text{Start value} &= 32767 - (\text{number of pulses} - 32768) \\ &= 32767 - (40\,000 - 32768) \\ &= 25535 \end{aligned}$$

2.5 Technical data 07 KT 92

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

2.5.1 General data

Number of binary inputs	12
Number of binary transistor outputs	8
Number of analog inputs	4
Number of analog outputs	1
I/O expansion via CS31 system bus by up to	744 binary inputs 496 binary outputs 96 analog input channels 48 analog output channels max. 31 remote modules altogether
Number of serial interfaces	2 (for programming or connection to man-machine communication)
Number of parallel interfaces	1 special interface for connection of a communication processor (for networking with other bus systems)
Integrated memory, 07 KT 92 R202 / R262:	Flash EPROM 128 kB (60 kB program + 60 kB user data) RAM 256 kB (30 kB program with online programming or 60 kB program without online programming)
Resolution of the integrated real-time clock	1 second
Data of the integrated high-speed hardware counter	
counting range	0...65,535 (16 bits)
counting frequency	max. 50 kHz
Processing time,	
binary operation	typ. 0.4...0.6 ms/kB program
65 % bits, 35 % words	typ. 0.7 ms/kB program
Number of software timers	any (max. 80 simultaneously active)
delay time of the timers	5 ms...24.8 days
Number of up/down counter SW blocks	any
Number of bit flags	4096
Number of word flags	4096
Number of double word flags	512
Diagnosis	cycle time monitoring, battery monitoring, detection of syntax errors and checksum monitoring
Indication of operating statuses and errors	31 LEDs altogether

2.5.2 Power supply

Rated supply voltage	24 V DC
Current consumption	max. 0.3 A (R202), max. 0.35 A (R262), plus output current through terminal 39 (output voltage for the supply of the binary inputs)
Protection against reversed terminal connection	yes

2.5.3 24V output voltage for the supply of inputs

Rated voltage	24 V DC
Load capability	max. 120 mA
Protection against overload	with a PTC resistor
Conductor cross section of the removable 3-pole terminal block	max. 2.5 mm ²

2.5.4 Lithium battery

Battery for back-up of RAM contents	07 LE 90 battery module
Lifetime at 25°C	1.5 years (typ. 3 years)

2.5.5 Binary inputs

Number of channels per module	12
Distribution of channels into groups	1 group of 8 channels, 1 group of 4 channels
Common reference potential for group 1 (8 channels) for group 2 (4 channels)	ZP1.0 (channels 62,00...62,07) ZP1.1 (channels 62,08...62,11)
Electrical isolation	between the groups, between groups and other circuitry (see also Fig. 2–5)
Signal coupling of input signals	with optocoupler
Input signal delay of channels E 62,00...E 62,11 channels E 63,14 and 63,15 for counter control	typ. 7 ms typ. 8 μs typ. 8 μs
Signalling of input statuses	one green LED per channel, the LEDs correspond functionally to the input signals
Input signal voltage signal 0 signal 1 ripple when signal 0 within –30 V...+ 5 V when signal 1	–30 V...+ 5 V +13 V...+30 V within +13 V...+30 V
Allowed input overvoltage	± 36 V, for 100 ms only
Input current per channel input voltage = +24 V input voltage = + 5 V input voltage = +13 V input voltage = +30 V	typ. 8.0 mA ≥ 0.2 mA ≥ 2.0 mA ≤ 10.0 mA
Labelling for the inputs	symbol names or short signal designations can be labelled on the removeable front panel foil
Max. cable length unshielded	600 m
Max. cable length shielded	1000 m
Conductor cross section of the removable terminal blocks	max. 2.5 mm ²

2.5.6 Binary outputs

Number of channels per module	8 transistor outputs
Distribution of channels into groups	1 group of 8 channels
Common supply voltage for group 1	UP1.2 (channels 62,00...62,07)
Electrical isolation	between the group and other circuitry, (see also Fig. 2–5)
Signalling of output statuses	one yellow LED per channel, the LEDs correspond functionally to the output signals
Output current rated value maximum value leakage current with signal 0	500 mA with UP1.2 = 24 V 625 mA with UP1.2 = 24 V + 25 % < 0.5 mA
Demagnetization of inductive loads	internally with free-wheeling diode and Z-diode (Z-diode voltage is 12 V)
Switching frequency with inductive loads	max. 0.5 Hz
Switching frequency with lamp load	max. 11 Hz with max. 5 W
Max. cable length	400 m (pay attention to voltage drop)
Short-circuit-proof/overload-proof reset can be carried out	yes, – automatically or – by configuration.
Total load (via UP1.2)	max. 4 A
Labelling for the outputs symbol names or short signal designations can be	labelled on the removeable front panel foil
Conductor cross section of the removable terminal blocks	max. 2.5 mm ²

2.5.7 Analog inputs

Number of channels per module	4
Distribution of channels into groups	1 group of 4 channels
Common reference potential for group 1 (4 channels)	AGND (channels 06,00...06,03)
Electrical isolation	no (see also Fig. 2–5)
Signalling of input statuses	none
Input signal ranges (selectable at each channel)	0...10 V 0... 5 V 0...20 mA
Input resistance per channel (voltage input)	ca. 100 k Ω (0...10 V range) ca. 50 k Ω (0...5 V range)
Input resistance per channel (current input)	250 Ω
Time constant of the input filter	100 μ s
Conversion time	20 μ s per channel
Resolution	12 bits
Resolution (1 LSB)	range 0...10 V 2.5 mV range 0... 5 V 1.25 mV range 0...20 mA 5.0 μ A

Relationship between input signal and hex-code	0...100 % = 0000 _H ...7FF8 _H (0...32760 decimal)
Conversion inaccuracy caused by nonlinearity, adjustment error on delivery and resolution	< 1 %
Labelling for the inputs	symbol names or short signal designations can be labelled on the removeable front panel foil
Max. cable length shielded, 2-core shielded and cross section $\geq 0.5 \text{ mm}^2$	100 m
Conductor cross section of the removable terminal blocks	max. 1.5 mm^2

2.5.8 Analog outputs

Number of channels per module	2
Reference potential	AGND (channels 06,00 and 06,01)
Electrical isolation	no (see also Fig. 2–5)
Signalling of output statuses	none
Output signal range	-10 V...0...+10 V
Output load capability	max. $\pm 5 \text{ mA}$
Resolution	12 bits
Resolution (1 LSB) range -10 V...0...+10 V	5 mV
Relationship between output signal and hex-code	
-32768...-32761 (8000 _H ...800F _H)	$\triangleq -10 \text{ V}$
-00016...-00001 (FFF0 _H ...FFFF _H)	$\triangleq -5 \text{ mV}$
00000...+00015 (0000 _H ...000F _H)	$\triangleq 0 \text{ V}$
+32752...+32767 (7FF0 _H ...7FFF _H)	$\triangleq +10 \text{ V}$
Conversion inaccuracy caused by nonlinearity, adjustment error on delivery and resolution	< 1 %
Labelling for the outputs	symbol names or short signal designations can be labelled on the removeable front panel foil
Max. cable length shielded, 2-core shielded and cross section $\geq 0,5 \text{ mm}^2$	100 m
Conductor cross section of the removable terminal block	max. 1.5 mm^2

2.5.9 Connection of serial interface COM1

Interface standard	EIA RS-232
Programming with 907 PC 33	by means of IBM PC (or compatible)
Man-machine communication	yes, e.g. with ABB Procontic Operating Station 35 BS 40
Display and updating of timers, counters and parameters	yes, e.g. with TCZ Service Device
Electrical isolation	versus binary inputs and outputs, versus CS31 system bus interface (see also Fig. 2–5)

Potential differences In order to avoid potential differences between the 07 KT 92 central unit and the peripheral device connected to the COM1 interface, this device is supplied from the switch cabinet socket (see also the earthing connections in Fig. 2–3).

Pin configuration and description of the COM1 interface see chapter 2.3.14

2.5.10 Connection of serial interface COM2

Interface standard EIA RS–232

Man–machine communication yes, e.g. with ABB Procontic Operating Station 35 BS 40

Electrical isolation versus binary inputs and outputs, versus CS31 system bus interface (see also Fig. 2–5)

Potential differences see text of COM1 (above)

Pin configuration and description of the COM2 interface see chapter 2.3.15

2.5.11 Connection to the ABB Procontic CS31 system bus

Interface standard EIA RS–485

Connection as a Master PLC yes, transmitting and receiving area are configurable
as a Slave PLC yes, see chapter "system constants", A7.3 (Appendix)

Setting of the CS31 module address yes, by system constant, stored in the Flash EPROM of the Slave PLC

Electrical isolation versus supply voltage, inputs/outputs, versus COM1/COM2 interfaces (see also Fig. 2–5)

Terminal assignment and description of the CS31 bus interface see chapter 2.3.5

Conductor cross section of the removable 3-pole terminal block max. 2.5 mm²

2.5.12 Connection to ARCnet (07 KT 92 R262 only), see also chapter A8 (Appendix)

ARCnet interface 1 channel for connection to COAX cable

Connector X4 BNC connector

Recommended system cable COAX cable Type RG–62/U (characteristic impedance 93 Ω)

Cable length 305 m with ARCnet bus with 8 stations. Further information see SMC TECHNICAL NOTE TN7–1.

LED displays green LED (BS) Operating mode "controller active", i.e. the PLC performs read and write operations

green LED (TX) Operating mode "transmit active", i.e. the PLC sends data on the ARCnet bus

Electrical isolation versus supply voltage, inputs/outputs, versus COM1/COM2 interfaces (see also Fig. 2–5)

2.5.13 LED displays

LEDs for indication of:

– statuses of binary inputs	1 green LED per channel
– statuses of binary outputs	1 yellow LED per channel
– power supply exists	1 green LED
– battery	1 red LED
– program runs (RUN)	1 green LED
– error classes (FK1, FK2, FK3)	1 red LED per error class
– CS31 system bus runs (BA)	1 green LED
– bus specific errors (BE, RE, SE)	3 red LEDs
– overload/short-circuit of the direct binary outputs	1 red LED

2.5.14 High speed hardware counter

Data of the integrated high-speed hardware counter

counting range 0...65,535 (16 bits)

counting frequency

used inputs

used outputs


max. 50 kHz

62,00 and 62,01 (the signal delay of these inputs is set to 8 µs for the counter)

62,00

2.5.15 Mechanical data

Mounting on DIN rail	according to DIN EN 50022–35, 15 mm deep. The DIN rail is located in the middle between the upper and the lower edges of the module.
Fastening by screws	using 4 M4 screws.
Width x height x depth	240 x 140 x 85 mm
Wiring method	by removable terminal blocks with screw-type terminals, conductor cross section max. 2.5 mm ²
Weight	1.6 kg
Dimensions (for mounting)	see the following drawing



2.5.16 Mounting hints

Mounting position	vertical, terminals above and below
Cooling	The natural convection cooling must not hindered by cable ducts or other material mounted in the switch cabinet.

2.5.17 Ordering data

Central unit 07 KT 92 R202
Central unit 07 KT 92 R262 (with ARCnet)

Order No. GJR5 2505 00 R202
Order No. GJR5 2505 00 R262

Scope of delivery

Central unit 07 KT 92 R202 or R262
2 9-pole terminal blocks (5.08 mm raster)
2 5-pole terminal blocks (5.08 mm raster)
3 3-pole terminal blocks (5.08 mm raster)
1 9-pole terminal block (3.81 mm raster)
2 5-pole terminal blocks (3.81 mm raster)
Safety and mounting instructions

Accessories

System cable 07 SK 90
System cable 07 SK 91
System cable 07 SK 92
Battery module 07 LE 90
Bus termination resistor

Order No. GJR5 2502 00 R1
Order No. GJR5 2503 00 R1
Order No. GJR5 2504 00 R1
Order No. GJR5 2507 00 R1

Simulation device 07 SG 90
(includes a number of switches and push-buttons to enter binary input signals)

Order No. GJR5 2506 00 R1

Programming and test software and operating manual

(both 907 PC 33 and 907 PC 331 are required)

907 PC 33 German 1)
907 PC 33 English 1)
907 PC 331 German 2)
907 PC 331 English 2)

Order No. GJP5 2039 00 R202
Order No. GJP5 2040 00 R202
Order No. GJP5 2045 00 R202
Order No. GJP5 2046 00 R202

Further Literature


System description ABB Procontic CS31 English
System description ABB Procontic T200 English
System description ABB Procontic T300 English
System description ABB Procontic CS31 German
System description ABB Procontic T200 German
System description ABB Procontic T300 German

Order No. FPTN 440 004 R2001
Order No. GATS 1314 99 R2001
Order No. GATS 1315 99 R2002
Order No. GATS 1316 99 R1002
Order No. GATS 1314 99 R1001
Order No. GATS 1315 99 R1002

1) Description General Part

2) Description 07 KR 91 / 07 KT 92 / 07 KT 93 Specific Part + software diskettes

Central Units
07 KT 93 R101 and R171



Regulations Concerning the Setting up of Installations

Apart from the basic "Regulations for the Setting up of Power Installations" DIN VDE* 0100 and for "The Rating of Creepage Distances and Clearances" DIN VDE 0110 Part 1 and Part 2 the regulations "The Equipment of Power Installations with Electrical Components" DIN VDE 0160 in conjunction with DIN VDE 0660 Part 500 have to be taken into due consideration.

Further attention has to be paid to DIN VDE 0113 Part 1 and Part 200 in case of the control of working and processing machines. If operating elements are to be mounted near parts with dangerous contact voltage DIN VDE 0106 Part 100 is additionally relevant.

If the protection against direct contact according to DIN VDE 0160 is required, this has to be ensured by the user (e.g. by incorporating the elements in a switch-gear cabinet). The devices are designed for pollution severity 2 in accordance with DIN VDE 0110 Part 1. If higher pollution is expected, the devices must be installed in appropriate housings.

The user has to guarantee that the devices and the components belonging to them are mounted following these regulations. For operating the machines and installations, other national and international relevant regulations, concerning prevention of accidents and using technical working means, also have to be met.

The ABB Procontic devices are designed according to IEC 1131 Part 2. Meeting this regulation, they are classified in overvoltage category II which is in conformance with DIN VDE 0110 Part 2.

For the direct connection of ABB Procontic devices, which are powered with or coupled to AC line voltages of overvoltage category III, appropriate protection measures corresponding to overvoltage category II according to IEC-Report 664/1980 and DIN VDE 0110 Part 1 are to install.

Equivalent standards:

DIN VDE 0110 Part 1 \triangleq IEC 664

DIN VDE 0113 Part 1 \triangleq EN 60204 Part 1

DIN VDE 0660 Part 500 \triangleq EN 60439-1 \triangleq IEC 439-1

All rights reserved to change design, size, weight, etc.

* VDE stands for "Association of German Electrical Engineers".

ABB Schalt- und Steuerungstechnik GmbH Heidelberg

3 Central unit 07 KT 93

Central unit with max. 56 kB user program + 30 kB user data




Fig. 3–1: Central unit 07 KT 93

Contents

3.1	Brief description	3– 2	3.3.11	Serial interface COM2	3–14
3.1.1	Main features	3– 2	3.3.12	Networking interface	3–15
3.1.2	Project planning/start-up	3– 2	3.4	High-speed counter	3–16
3.2	Structure of the front panel	3– 4	3.5	Technical data	3–19
3.2.1	Terminal assignment overview	3– 5	3.5.1	General data	3–19
3.3	Electrical connection	3– 6	3.5.2	Power supply	3–20
3.3.1	Application example for input and output wiring	3– 6	3.5.3	24 V output voltage for the supply of inputs	3–20
3.3.2	Connecting the supply voltage	3– 7	3.5.4	Lithium battery	3–20
3.3.3	Electrical isolation and notes on earthing	3– 8	3.5.5	Binary inputs	3–20
3.3.4	ARCnet interface	3– 9	3.5.6	Binary outputs	3–21
3.3.5	Connection for ABB Procontic CS31 system bus	3– 9	3.5.7	Connection of serial interface COM1 ..	3–21
3.3.6	24 V output voltage for the signal supply of the inputs	3–10	3.5.8	Connection of serial interface COM2 ..	3–22
3.3.7	Connection of the binary inputs	3–10	3.5.9	Connection to the ABB Procontic CS31 system bus	3–22
3.3.8	Connection of the binary outputs	3–11	3.5.10	Connection to ARCnet	3–22
3.3.9	Battery and battery replacement	3–12	3.5.11	LED displays	3–23
3.3.10	Serial interface COM1	3–13	3.5.12	High-speed hardware counter	3–23
			3.5.13	Mechanical data	3–24
			3.5.14	Mounting hints	3–24
			3.5.15	Ordering data	3–25

3.1 Brief description

The central unit 07 KT 93 works either as

- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit.

The device has a 24 V DC power supply voltage. It is provided with an additional interface for connecting communication modules (e.g. 07 KP 90).

The central unit 07 KT 93 R171 is equipped with an **integrated ARCnet coupler** (and an ARCnet interface).

3.1.1 Main features

- 24 binary inputs
- 16 binary transistor outputs
- 1 counting input for counting frequencies up to 10 kHz
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
- Serial interface COM2 as an MMC interface
- ARCnet coupler / ARCnet interface (version R171 only)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution.

- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

3.1.2 Project planning / start-up

The following has to be observed for project planning and start-up:

- Programming is performed using ABB Procontic programming software, which can be run on commercially available IBM compatible PCs (see documentation for the programming system 907 PC 331)
- Diagnosis and service device TCZ (terminal mode) (see volume 7.3, see chapter A5 (Appendix), Programming and test, see 3.3.10 Serial interface COM1)
- The processor processes the user program contained in the RAM. It is loaded into the RAM via the serial interface COM1 and can also be changed there. An additional save command is used to save the program in the Flash EPROM.

Note: In the course of the following operations

- Power 'ON'
- RUN/STOP switch from STOP → RUN
- Program start-up with programming system
- Cold start of the PLC

the RAM is overwritten by the contents of the Flash EPROM, if a user program is contained in the Flash EPROM.

- On-line program modification
The two existing RAMs allow a quick modification of the user program to be performed without interrupting the operation (see ABB programming system 907 PC 331).
- Change-over between the application modes
 - Stand-alone central unit
 - Bus master central unit and
 - Slave central unit

The central unit is set to "Stand-alone" upon delivery. Changing the application mode is carried out in the following three steps:

1. Change the system constant KW 0,0 in the PLC, see chapter A7.3 (Appendix), System constants
2. Save the user program in the Flash EPROM
3. Activate new application mode by:
 - calling up the menu item of "Enable PLC mode" in the ABB programming and test system or
 - performing a warm start or
 - performing a cold start.

- Setting the cycle time
see chapter A1 (Appendix), Processing times
- Addressing when remote modules are connected
see chapter A2 (Appendix), Addressing
- Back-up of data areas
Back-up of data areas, i.e. saving of data during power OFF/ON, is only feasible with built-in battery. The following data can be backed, completely or partly:

- Binary flags
- Word flags
- Double word flags
- Step chains
- Historical values

In order to back-up certain data, they have to be excluded from initialization to 0.

- Initialization of data areas
During *program start*, that data areas are initialized to

0 partly or completely, that are defined by system constants, see chapter A7.3 (Appendix), System constants.

If no battery is effective or if the system constants are in their default values (factory settings), all of the above mentioned data areas are completely set to 0 after power OFF/ON.

- Reactions on errors of error class 3
The user can configure whether or not the user program is to be aborted automatically, if an class 3 error occurs, see chapter A7.3 (Appendix), System constants.
- Starting-up the CS31 system after power ON
The user can enter a number of n remote modules in KW 00,09. The user program starts only, i.e. it handles process inputs and outputs only, if at least n remote modules have been adopted into the CS31 system bus cycle, see chapter A7.3 (Appendix), System constants.

3.2 Structure of the front panel




Fig. 3-2: Central unit 07 KT 93 with reference points

- ① Fastening of the device on DIN rail
- ② Fastening of the device by screws
- ③ Faston earthing terminal 6.3 mm
- ④ Supply voltage connection 24 V DC
- ⑤ 24 V output voltage for input supply
- ⑥ Battery compartment
- ⑦-⑨ 24 binary inputs in three groups
- ⑩ Assignment of the identifiers for the inputs
- ⑪ 16 binary transistor outputs in two groups
- ⑫ ARCnet BNC connector (R171 only)
- ⑬ 2 LEDs for ARCnet operation (R171 only)
- ⑭ Assignment of the identifiers for the outputs
- ⑮ Serial interface COM1 (programming, MMC)
- ⑯ Serial interface COM2 (MMC)
- ⑰ Connection for ABB Procontic CS31 system bus
- ⑱ Cover of the interface for the connection of communication modules (may only be removed for connecting communication modules)
- ⑲ Switch for RUN/STOP operation
- ⑳ LEDs for supply voltage and battery
- ㉑ LEDs for RUN and error class
- ㉒ LEDs for CS31 system bus
- ㉓ LED for overload/short-circuit (LED K)
- Plastic sheet (detachable for labelling)

⑳	green	<input type="checkbox"/> BA	Bus active
	red	<input type="checkbox"/> BE	Bus error
	red	<input type="checkbox"/> RE	Remote unit error
	red	<input type="checkbox"/> SE	Serial unit error
㉑	green	<input type="checkbox"/> RUN	User program is running
	red	<input type="checkbox"/> FK1	Fatal error
	red	<input type="checkbox"/> FK2	Serious error
	red	<input type="checkbox"/> FK3	Light error
㉒	green	<input type="checkbox"/> Supply	Supply voltage available
	red	<input type="checkbox"/> Battery	Battery not effective

For further information see chapter A4.3 (App.) Troubleshooting by means of LED displays on the central unit

⑲

RUN

STOP

The RUN/STOP switch is used to start or abort the processing of the user program.

3.2.1 Terminal assignment overview




Fig. 3–2a: Central unit 07 KT 93, terminal assignment

3.3 Electrical connection

3.3.1 Application examples for input and output wiring

The following illustration shows an application example in which different possibilities for wiring inputs and outputs are used.




Fig. 3-3: Application example for the central unit 07 KT 93


Please observe in particular:

- The earthing measures
- The handling of the electrically isolated input groups
- The handling of the electrically isolated output groups
- The earthing of the switch cabinet mains socket

3.3.2 Connecting the supply voltage

The 24 V DC supply voltage is connected via a 5-pole detachable terminal block.

Attention: Plug and unplug terminal block only with power is off!



3.3.3 Electrical isolation and notes on earthing

The following illustration shows the parts of the device's circuit which are electrically isolated from each other as well as the internal connections which exist. Both the creepage distances and clearances as well as the test voltages used correspond to DIN/VDE 0160.

The 6.3 mm Faston terminal in the lower left corner has to be connected directly and on the shortest possible way to the switch cabinet earthing using a wire with a cross section of 6 mm² in order to ensure safe earthing and as an EMC measure.





Fig. 3-5: Electrical isolation and connections inside the central unit 07 KT 93


3.3.4 ARCnet interface, see also chapter A8 (Appendix)

- The ARCnet coupler is integrated in the central unit 07 KT 93 **R171**. The DIL switch for setting the ARCnet address is accessible through the cutout of the external networking interface.
- The ARCnet coupler is supplied from the internal 24 V DC power supply.
- The function blocks AINIT, ASEND, AREC and APOLL are available for the ARCnet coupling.
- The data packages are read from the ARCnet controller interrupt-controlled. The interrupt routine stores the data package in the storage buffer. The APOLL block serves for the sending direction. It transfers data packages from the storage buffer to the ARCnet controller for sending them off.
- The ARCnet coupler interface is designed as a bus with BNC connector for coaxial cable. The ARCnet bus is earthed inside the module via a capacitor. As an EMC measure and for protection against dangerous contact voltages, the bus has to be earthed directly at a central place.
- Using the simplest configuration, called Linear ARCnet, a coaxial cable (RG62, 93 Ω) is layed from station to station and connected with T plugs at all stations. At both ends of the cable, termination resistors with 93 Ω each have to be installed, for more information see chapter A8.1 (Appendix). In a Linear ARCnet, a maximum of 8 stations is possible at a cable length of 300 m.
- The parallel networking interface is used for the ARCnet coupler inside the module. However, it is still available from outside as an external networking interface. The serial interface module 07 KP 92 can be connected here, for instance.

Setting the ARCnet Node Number (station address) of the central unit



3.3.5 Connection for ABB Procontic CS31 system bus



The connection to the ABB Procontic CS31 system bus is made by means of a 3-pole detachable terminal block. Please observe:


- All of the CS31 devices, no matter whether they are master or slave devices, are connected with the twisted-pair bus line as follows:
 - One core of the bus line is looped through via the BUS1 terminals of all devices to be connected to the CS31 system bus.
 - The other core of the bus line is looped through via the BUS2 terminals of all devices to be connected to the CS31 system bus.
- If the central unit 07 KT 93 is located at the beginning or at the end of the bus line, the bus terminating resistor (120 Ω) has to be connected additionally between the BUS1 and BUS2 terminals.
- The shield of the twisted-pair bus line is looped through via the SHIELD terminals of all the devices to be connected to the CS31 system bus.
- The handling of the CS31 system bus is described in detail in volume 2, System data.

3.3.6 24 V output voltage for the signal supply of the inputs

The central unit 07 KT 93 provides a separate 24 V DC voltage output for the supply of the 24 binary input signals (for this purpose only).

This 24 V output voltage is used only if an external 24 V DC power supply unit is not available.

The internal 24 V power supply is overload-proof. The 24 V output voltage is ready for operation again approx. 2 minutes after an overload has been eliminated.



3.3.7 Connection of the binary inputs

The following illustration shows the circuit configuration of the binary inputs of the first group as an example.

Features:

- The 24 binary inputs are arranged in three groups.
- The three groups E 62,00...E 62,07, E 62,08...E 62,15 and E 63,00...E 63,07 are electrically isolated from each other (see Fig. 3–5).
- The inputs use 24 V signals in positive logic ($1 \triangleq +24 \text{ V}$).

Input signals at the terminals 5 and 6

Terminal 5

– Use as normal input signal:

The signal is available in the user program in the operand E 62,00. The signal delay time is 2.5 ms.

The updating of the operand E 62,00 is performed before the start of each program cycle.

– Use as high-speed input signal:

The signal is available in the user program in the operand E 63,14. The signal delay time is 0.02 ms.

The updating of the operand E 63,14 is performed before the start of each program cycle.

In the Dual Port RAM (DPR) this signal is updated after each CS31 bus telegram. With the aid of the function block WOL this signal can be read in the Dual Port RAM (word address C000:1FEH, Bit 14).

– Use for the high-speed counter:

The signal is used as counting input (10 kHz) for the high-speed counter.

Terminal 6

– Use as normal input signal:

The signal is available in the user program in the operand E 62,01. The signal delay time is 2.5 ms.

The updating of the operand E 62,01 is performed before the start of each program cycle.

– Use as high-speed input signal:

The signal is available in the user program in the operand E 63,15. The signal delay time is 0.02 ms.


The updating of the operand E 63,15 is performed before the start of each program cycle.

In the Dual Port RAM (DPR) this signal is updated after each CS31 bus telegram. With the aid of the function block WOL this signal can be read in the Dual Port RAM (word address C000:1FEH, Bit 15).

– Use for the high-speed counter:

The signal is used as enable input for the high-speed counter.

Circuit configuration of the binary inputs of the first group as an example (E62,00...E 62,07)



3.3.8 Connection of the binary outputs

The following illustration shows the circuit configuration of the binary outputs.

Features of the outputs:

- The 16 outputs are arranged in two groups. Within one group, the outputs are not electrically isolated from each other.
- The outputs can be loaded with a rated current of 250 mA.
- Each group as a whole is electrically isolated from the rest of the device (see also Fig. 3–5).
- The outputs use transistors and are short-circuit-proof.
- The eight transistors of one group have a common power supply.
- The outputs are automatically switched off in case of overload or short-circuit.
- A overall error message indicates a short-circuit or an overload which has occurred on one or on several outputs.
- An overload is displayed by the red LED K and via error flags in the PLC.
- The user can set by means of a system constant whether the overloaded output is to be switched on again automatically by the PLC or whether it is to be switched on again by configuring within the PLC program, e.g. by means of the function blocks CS31QU or CS31CO. The default setting is the automatic reset of the outputs.
- The red LED K goes out when the overloaded output is switched on again after eliminating the overload.
- The acknowledgement of the error message, i.e. the resetting of the error flags, is done in correspondence with chapter A4.8 (Appendix), Acknowledgement of error messages in the central unit.

Circuit configuration of the binary outputs of the first group as an example (A 62,00...A 62,07)





Fig. 3–11: Circuit configuration of the binary outputs of the first group as an example

3.3.9 Battery and battery replacement



- The lithium battery 07 LE 90 can be inserted into the battery compartment in order to
 - backup data of user program in RAM
 - backup data of additionally in RAM contained information, e.g. flag statuses
 - backup of time and date (real-time clock).

The battery lifetime is 1.5 years (typ. 3 years) at 25°C. The battery lifetime is the time during which the device remains operable in order to backup data while the supply voltage of the central unit is switched off. As long as there is a supply voltage available, there is no more load on the battery other than its own leakage current.

The following handling notes have to be observed:


- Use only lithium batteries approved by ABB.
- Replace the battery by a new one at the end of its life.
- **Never short-circuit the battery!**
There is danger of overheating and explosion. Avoid accidental short-circuits, therefore do not store batteries in metallic containers or boxes and do not bring it into contact with metallic surfaces.
- **Never try to charge the battery!**
Danger of overheating and explosion!
- **Replace the battery only with the supply voltage switched on!**
Otherwise you risk data being lost.
- **Dispose of battery environmentally consciously!**
- If no battery is built-in or if the battery is exhausted, the red LED 'Battery' lights up.

3.3.10 Serial interface COM 1

Interface standard: EIA-232

Assignment of the serial interface COM1

The serial interface has the following pin assignment:



Operating modes of the serial interface COM1

The operating mode of the interface has to be set according to the application in each case:

- Programming and test or
- Man-machine-communication MMC

Active mode: The active mode is used for programming and testing the central unit, i.e. it gives the user access to all the programming and test functions of the central unit.

Passive mode: The passive mode is used to perform a communication configured with the DRUCK and EMAS blocks between the user program and a device connected to the serial interface.

Conditions for setting the operating modes of the interface COM1

RUN/STOP switch	System constant KW00,06	System cable/device	Mode set by this
STOP	x	x	Active
RUN	1	x	Active
	2	x	Passive
	0, <0, >2	07 SK 90	Active
		07 SK 91, TCZ	Passive

x: without effect

Temporary interruption of the passive mode

While a communication between the DRUCK or EMAS blocks and a device connected to COM1 is being executed, it may be come necessary to modify the program, for example. For this purpose, you must switch over COM1 from the passive mode into the active mode.

Switch-over: Passive mode → Active mode

There are three possibilities for switching over:

- Set the RUN/STOP switch to the "STOP" position
- Replace cable 07 SK 91 by cable 07 SK 90 (if KW 00,06 is set to ≤0 or >2)
- Send the following special command to the PLC:

The latter option has the advantage that the switch-over can also be controlled remotely, e.g. via telephone line and suitable dial-up modems. The ASCII character has the decimal code of 127 and the hexadecimal code of 7FH. You can generate this character by simultaneously pressing the control key <CTRL> and the delete key <—>.

Notes:

On German keyboards, the control key is labelled by <Strg> instead of <CTRL>.

If the switch-over to the active mode was performed using the special command , please observe the following:

During the execution of the PLC program, the system constant KW 00,06 must **not** be sent to the PLC because this would cause the system to be switched back to the passive mode.

The special command assigns the value of "1" to the image of the system constant KW 00,06 located in the operand memory. The PLC evaluates the value of this image and sets the kind of application of COM1 correspondingly.

Switching back: Active mode → Passive mode

There are three possibilities for switching back:

- Return RUN/STOP switch to the "RUN" position
- Replace cable 07 SK 90 by cable 07 SK 91 again.
- Cancel the special command as follows:
 - If the PLC program is in the "aborted" condition:

Start the PLC program.
 - If the PLC program is in the "running" condition:

send the original value of the system constant KW 00,06 to the PLC again (907 PC 33 menu item "Send constants")

or

overwrite the system constant KW 00,06 by the original value (907 PC 33 menu item "overwriting")

Interface parameters

Active mode: The settings of the interface parameters cannot be changed

Data bits:	8
Stop bits:	1
Parity bits:	none
Baud rate:	9600
Synchronization:	RTS/CTS

Passive mode: Default setting

Synchronization:	RTS/CTS
Interface identifier COM1:	1
Baud rate:	9600
Stop bits:	1
Data bits:	8
Parity bits:	none
Echo:	off
Send Break Character:	0
Enabling End-of-text character for sending direction:	no ¹⁾
Sending End-of-text character:	<CR> ¹⁾
Receiving End-of-text character:	<CR> ²⁾

¹⁾ The default End-of-text character for the sending direction (CR) is not sent. Nevertheless, this default End-of-text character (CR) must not appear in the message text of the assigned DRUCK block.

²⁾ For the direction of reception, an End-of-text character is always necessary. This default End-of-text character (CR) must not appear neither in the message text nor in the user data of the assigned EMAS block.

For the passive mode of COM1, the interface parameters can be changed using the SINIT function block. If the changed values are not plausible, the COM1 interface uses the default values.

The interface is newly initialized each time the operating mode is switched over.

The active-mode parameters are set in the active mode, whereas in the passive mode the parameters established by the SINIT block or the default values are set.

3.3.11 Serial interface COM 2

Interface standard: EIA-232

Assignment of the serial interface COM2

The serial interface has the following pin assignment:




Fig. 3-14: Assignment of the serial interface COM2

Operating modes of the COM2 interface

The serial interface COM2 is fixedly set to the **passive mode** (MMC interface).

The passive mode is used to perform a communication configured with the aid of the DRUCK and EMAS blocks between the user program and a device connected to the serial interface.

The application-specific initialization of COM2 can be performed using the SINIT function block.

Interface parameter

Passive mode: Default setting

Synchronization:	RTS/CTS
Interface identifier COM2:	2
Baud rate:	9600
Stop bits:	1
Data bits:	8
Parity bits:	none
Echo:	off
Send Break Character:	0
Enabling End-of-text character for sending direction:	no ¹⁾
Sending End-of-text character:	<CR> ¹⁾
Receiving End-of-text character:	<CR> ²⁾

- 1) The default End-of-text character for the sending direction (CR) is not sent. Nevertheless, this default End-of-text character (CR) must not appear in the message text of the assigned DRUCK block.
- 2) For the direction of reception, an End-of-text character is always necessary. This default End-of-text character (CR) must not appear neither in the message text nor in the user data of the assigned EMAS block.

For the passive mode of COM2, the interface parameters can be changed using the SINIT function block. If the changed values are not plausible, the COM2 interface uses the default values.

In the passive mode the parameters established by the SINIT block or the default values are set.

3.3.12 Networking interface

The 07 KT 93 central unit is equipped with a special parallel interface. It is thus possible to network it with another bus system using an additional communication processor module. The additional communication processor has its own housing. Both housings (of the 07 KT 93 and of the communication processor) are assembled by means of a snap-on connection.




Fig. 3–15: Mounting of 07 KT 93 with expansion (e.g. communication processor 07 KP 90)


3.4 High-speed counter

Features

The high-speed counter used in the central units 07 KR 91, 07 KT 92 and 07 KT 93 works independently of the user program and is therefore able to respond quickly to external signals. Its features are as follows:

- The counting frequency is max. 10 kHz. The counter counts the 0→1 edges at terminal 05 (also designated as E 62,00).
- The counter counts upwards from -32768 to +32767 (8000_H...7FFF_H). If +32767 is exceeded, the counter skips to -32768.

Sequence of the counting procedure:



- Enabling/disabling of the counting procedure using the internal variable A 63,14 in the user program:
 - A 63,14 = 0:
The internal variable A 63,13 = 1 enables the

counting procedure, whereas A 63,13 = 0 disables it.

- A 63,14 = 1:
Signal 1 at terminal 06 (also designated as E 62,01) enables the counting procedure, whereas signal 0 disables it. A 63,13 is without effect.
Note: The dead time may be 0...1.5 ms.

- Setting the counter in the user program:
 - to the value contained in the internal word variable AW 06,15

- using the internal variable A 63,15 = 1.

Note: If the internal variable A 63,15 = 1 is present during several processing cycles, the processor sets the counter at the program end in each case.

During the remaining time of the processing cycle, the counter counts pulses at terminal 05.

- The counter content can be read via the internal variable EW 06,15.
- Zero-crossing message (signal changes from 0 to 1 when the counter contents changes from -1 to 0):
 - always via the internal variable E 63,13,
 - at the terminal 40 (also designated as A 62,00) only, if the internal variable A 63,14 = 1 is set.
Note: The reaction time may be 0...1.5 ms. The direct control of the output A 62,00 from the user program is disabled by A 63,14 = 1.

The zero-crossing message is cancelled when the counter is set.

- Fast input of binary signals into the user program with a delay of < 0,02 ms:
 - Terminal 05 (also designated as E 62,00):
Internal variable E 63,14
 - Terminal 06 (also designated as E 62,01):
Internal variable E 63,15

Block diagram

see next page




Fig. 3-19: 07 KT 93, High-speed counter, block diagram

Configuration example

● Task:

- 180 pieces each of a unit load have to be filled into a packing.
- Each filled-in piece generates one pulse.
- When the packing is full, the counter is immediately prepared for the next filling operation.
- The enabling signal for the filling operation is sent by the packaging machine.
- The end of the counting operation has to be signalled to the packaging machine immediately.

● Wiring

- Connect the signal line for the counting pulses to terminal 05.
- Connect the signal line for the enabling of the counting operation to terminal 06.
- Connect the signal line for "zero crossing" of the counter to terminal 40.

● Configuration steps: PLC program

1) Activate terminals 06 and 40

- The terminals 06 and 40 are activated using the operand A 63,14.

IL (instruction list):

```
! K 00,01  
= A 63,14 (with K 00,01 = 1)
```

2) Preset start value for the counter

The start value (AW 06,15) is set to the value of –180. The counter will then count starting from –180 in positive direction. The transition from –1 to 0 will be signalled.

IL (instruction list):

```
! KW 01,00  
= AW 06,15 (with KW 01,00 = –180)
```

3) Adopt start value into the counter

After each counting operation, the start value is immediately set again into the counter by means of the "zero crossing" signal (E 63,13). Operand A 63,15 = 1 has to be set for this purpose. At program start, the start value is loaded once into the counter by means of the initialization flag M 255,15 (M 255,15 has the value of 0 after program start).

IL (instruction list):

```
! NM 255,15  
/ E 63,13  
= A 63,15  
:  
:  
other PLC program parts  
:  
:  
! K 00,01  
= M 255,15 (set M 255,15 = 1)  
! PE (program end)
```

Preset start values

You can preset both *positive* and *negative* start values for the counter.

The counting operation starts at the start value and is continued in correspondence with the arrows in the diagram until the enabling is stopped or a start value is loaded again.

Negative start value

The minimum negative start value is –32768 (8000_H).

By presetting a negative start value it is thus possible to count a maximum of 32768 pulses up to the zero crossing of the counter.

Positive start value

If a positive start value is preset, the counter counts up to the value of +32767 (7FFF_H), continues the counting operation at the value of –32768 (8000_H) and then signals the zero crossing when reaching the transition from –1 to 0.

The minimum positive start value is 1. If you preset this value, 65535 pulses will be counted up to the zero crossing.

In order to count more than 32767 pulses up to the zero crossing, the start value has to be calculated according to the following equation:

$$\text{Start value} = 32767 - (\text{number of pulses} - 32768)$$

Example:

40 000 pulses are to be counted.

The start value is in the positive range, because more than 32768 pulses have to be counted.

Calculation:

$$\begin{aligned} \text{Start value} &= 32767 - (\text{number of pulses} - 32768) \\ &= 32767 - (40\,000 - 32768) \\ &= 25535 \end{aligned}$$

3.5 Technical data 07 KT 93

In general, the technical system data listed in volume 2 of the system description ABB Procontic CS31 are valid for all modules and central units. Additional data or data which are different from the system data are listed as follows.

3.5.1 General data

Number of binary inputs	24
Number of binary transistor outputs	16
I/O expansion via CS31 system bus by up to	744 binary inputs 496 binary outputs 96 analog input channels 48 analog output channels max. 31 remote modules altogether
Number of serial interfaces	2 (for programming or connection to man-machine communication)
Number of parallel interfaces	1 special interface for connection of a communication processor (for networking with other bus systems)
Networking interfaces (version R171 only)	1 ARCnet interface (BNC connector)
Integrated memory, 07 KT 93 R101:	Flash EPROM 128 kB (60 kB program + 60 kB user data) RAM 256 kB (30 kB program with online programming or 60 kB program without online programming)
Integrated memory, 07 KT 93 R171:	Flash EPROM 128 kB (60 kB program + 60 kB user data) RAM 512 kB (60 kB program with online programming)
Resolution of the integrated real-time clock	1 second
Data of the integrated high-speed hardware counter counting range counting frequency	0...65,535 (16 bits) max. 10 kHz
Processing time, binary operation 65 % bits, 35 % words	typ. 0.4...0.6 ms/kB program typ. 0.7 ms/kB program
Number of software timers delay time of the timers	any (max. 80 simultaneously active) 5 ms...24.8 days
Number of up/down counter SW blocks	any
Number of bit flags	4096
Number of word flags	4096
Number of double word flags	512
Diagnosis	cycle time monitoring, battery monitoring, detection of syntax errors and checksum monitoring
Indication of operating statuses and errors	51 LEDs altogether

3.5.2 Power supply

Rated supply voltage		24 V DC
Current consumption	R101:	max. 0.2 A plus output current through terminal 1,
	R171:	max. 0.25 A plus output current through terminal 1 (output voltage for the supply of the binary inputs)
Protection against reversed terminal connection		yes

3.5.3 24V output voltage for the supply of inputs

Rated voltage		24 V DC
Load capability	with rated voltage	max. 200 mA
	with rated voltage + 25 %	max. 240 mA
Protection against overload		with a PTC resistor
Conductor cross section of the removable 3-pole terminal block		max. 2.5 mm ²

3.5.4 Lithium battery

Battery for back-up of RAM contents	07 LE 90 battery module
Lifetime at 25°C	1.5 years (typ. 3 years)

3.5.5 Binary inputs

Number of channels per module	24
Distribution of channels into groups	3 groups of 8 channels each
Common reference potential for group 1 (8 channels)	ZP1.0 (channels 62,00...62,07)
for group 2 (8 channels)	ZP1.1 (channels 62,08...62,15)
for group 3 (8 channels)	ZP1.2 (channels 63,00...63,07)
Electrical isolation	between the groups, between groups and other circuitry (see also Fig. 3–5)
Signal coupling of input signals	with optocoupler
Input signal delay of channels E 62,00...E 63,07	typ. 7 ms
channels E 63,14 and 63,15 for counter control	typ. 0.02 ms typ. 0.02 ms
Signalling of input statuses	one green LED per channel, the LEDs correspond functionally to the input signals
Input signal voltage signal 0	–30 V...+ 5 V
signal 1	+13 V...+30 V
ripple when signal 0 within –30 V...+ 5 V when signal 1	within +13 V...+30 V
Allowed input overvoltage	± 36 V, for 100 ms only
Input current per channel input voltage = +24 V	typ. 8.0 mA
input voltage = + 5 V	≥ 0.2 mA
input voltage = +13 V	≥ 2.0 mA
input voltage = +30 V	≤ 10.0 mA

Labelling for the inputs	symbol names or short signal designations can be labelled on the removeable front panel foil
Max. cable length unshielded	600 m
Max. cable length shielded	1000 m
Conductor cross section of the removable terminal blocks	max. 2.5 mm ²
3.5.6 Binary outputs	
Number of channels per module	16 transistor outputs
Distribution of channels into groups	2 groups of 8 channels each
Common reference potential for group 1 (8 channels) for group 2 (8 channels)	ZP1.3 (channels 62,00...62,07) ZP1.4 (channels 62,08...62,15)
Common supply voltage for group 1 for group 2	UP1.3 (channels 62,00...62,07) UP1.4 (channels 62,08...62,15)
Electrical isolation	between the groups, between groups and other circuitry (see also Fig. 3–5)
Signalling of output statuses	one yellow LED per channel, the LEDs correspond functionally to the output signals
Output current rated value maximum value leakage current with signal 0	250 mA with UP1.3/UP1.4 = 24 V 312 mA with UP1.3/UP1.4 = 24 V + 25 % < 0.5 mA
Demagnetization of inductive loads	internally with free-wheeling diode and Z-diode (Z-diode voltage is 12 V)
Switching frequency with inductive loads	max. 0.5 Hz
Switching frequency with lamp load	max. 11 Hz with max. 5 W
Max. cable length	400 m (pay attention to voltage drop)
Short-circuit-proof/overload-proof reset can be carried out	yes, – automatically or – by configuration.
Total load via UP1.3 max. 2 A via UP1.4	max. 2 A
Labelling for the outputs	symbol names or short signal designations can be labelled on the removeable front panel foil
Conductor cross section of the removable terminal blocks	max. 2.5 mm ²
3.5.7 Connection of serial interface COM1	
Interface standard	EIA RS–232
Programming with 907 PC 33	by means of IBM PC (or compatible)
Man–machine communication	yes, e.g. with ABB Procontic Operating Station 35 BS 40
Display and updating of timers, counters and parameters	yes, e.g. with TCZ Service Device

Electrical isolation		versus binary inputs and outputs, versus CS31 system bus interface (see also Fig. 3–5)
Potential differences		In order to avoid potential differences between the 07 KT 93 central unit and the peripheral device con- nected to the COM1 interface, this device is supplied from the switch cabinet socket (see also the earthing connections in Fig. 3–3).
Pin configuration and description of the COM1 interface		see chapter 3.3.10
3.5.8 Connection of serial interface COM2		
Interface standard		EIA RS–232
Man–machine communication		yes, e.g. with ABB Procontic Operating Station 35 BS 40
Electrical isolation		versus binary inputs and outputs, versus CS31 system bus interface (see also Fig. 3–5)
Potential differences		see text of COM1 (above)
Pin configuration and description of the COM2 interface		see chapter 3.3.11
3.5.9 Connection to the ABB Procontic CS31 system bus		
Interface standard		EIA RS–485
Connection	as a Master PLC as a Slave PLC	yes, transmitting and receiving area are configurable yes, see chapter "system constants"
Setting of the CS31 module address		yes, by system constant, stored in the Flash EPROM of the Slave PLC
Electrical isolation		versus supply voltage, inputs/outputs, versus COM1/COM2 interfaces (see also Fig. 3–5)
Terminal assignment and description of the CS31 bus interface		see chapter 3.3.5
Conductor cross section of the removable 3-pole terminal block		max. 2.5 mm ²
3.5.10 Connection to ARCnet (07 KT 93 R171 only), see also chapter A8 (Appendix)		
ARCnet interface		1 channel for connection to COAX cable
Connector X4		BNC connector
Recommended system cable		COAX cable Type RG–62/U (characteristic impedance 93 Ω)
Cable length		305 m with ARCnet bus with 8 stations. Further information see SMC TECHNICAL NOTE TN7–1.
LED displays	green LED (BS) green LED (TX)	Operating mode "controller active", i.e. the PLC performs read and write operations Operating mode "transmit active", i.e. the PLC sends data on the ARCnet bus
Electrical isolation		versus supply voltage, inputs/outputs, versus COM1/COM2 interfaces (see also Fig. 3–5)

3.5.11 LED displays

LEDs for indication of:

– statuses of binary inputs	1 green LED per channel
– statuses of binary outputs	1 yellow LED per channel
– power supply exists	1 green LED
– battery	1 red LED
– program runs (RUN)	1 green LED
– error classes (FK1, FK2, FK3)	1 red LED per error class
– CS31 system bus runs (BA)	1 green LED
– bus specific errors (BE, RE, SE)	3 red LEDs
– overload/short-circuit of the direct binary outputs	1 red LED (K)

3.5.12 High speed hardware counter

Data of the integrated high-speed hardware counter

counting range 0...65,535 (16 bits)

counting frequency

max. 10 kHz

used inputs

62,00 and 62,01 (the signal delay of these inputs is set to 0.02 ms for the counter)

used outputs

62,00

3.5.13 Mechanical data

Mounting on DIN rail

according to DIN EN 50022–35, 15 mm deep.
The DIN rail is located in the middle between the upper and the lower edges of the module.

Fastening by screws

using 4 M4 screws.

Width x height x depth

240 x 140 x 85 mm

Wiring method


by removable terminal blocks with screw-type terminals, conductor cross section max. 2.5 mm²

Weight

1.6 kg

Dimensions (for mounting)

see the following drawing



3.5.14 Mounting hints

Mounting position

vertical, terminals above and below

Cooling

The natural convection cooling must not hindered by cable ducts or other material mounted in the switch cabinet.

3.5.15 Ordering data

Central unit 07 KT 93 R101

Order No. GJR5 2513 00 R101

Central unit 07 KT 93 R171

Order No. GJR5 2513 00 R171

Scope of delivery

Central unit 07 KT 93 R101 or R171

5 9-pole terminal blocks

1 5-pole terminal block

4 3-pole terminal blocks

Safety and mounting instructions

Accessories

System cable 07 SK 90

Order No. GJR5 2502 00 R1

System cable 07 SK 91

Order No. GJR5 2503 00 R1

System cable 07 SK 92

Order No. GJR5 2504 00 R1

Battery module 07 LE 90

Order No. GJR5 2507 00 R1

Bus termination resistor

Simulation device 07 SG 90

Order No. GJR5 2506 00 R1

(includes a number of switches and push-buttons to enter binary input signals)

Programming and test software and operating manual

(both 907 PC 33 and 907 PC 331 are required)

907 PC 33 German 1)

Order No. GJP5 2039 00 R202

907 PC 33 English 1)

Order No. GJP5 2040 00 R202

907 PC 331 German 2)

Order No. GJP5 2045 00 R202

907 PC 331 English 2)

Order No. GJP5 2046 00 R202

Further Literature

System description ABB Procontic CS31

English

Order No. FPTN 440 004 R2001

System description ABB Procontic T200

English

Order No. GATS 1314 99 R2001

System description ABB Procontic T300

English

Order No. GATS 1315 99 R2002

System description ABB Procontic CS31

German

Order No. GATS 1316 99 R1002

System description ABB Procontic T200

German

Order No. GATS 1314 99 R1001

System description ABB Procontic T300

German

Order No. GATS 1315 99 R1002

1) Description General Part

2) Description 07 KR 91 / 07 KT 92 / 07 KT 93-Specific Part + Software Diskettes

ABB Procontic CS31 Intelligent Decentralized Automation System

Central Units

07 KR 91,

07 KT 92 and 07 KT 93




Table of Contents

Appendix

A1	Processing times	A1– 1
A1.1	Program processing time t_{UP}	A1– 1
A1.2	Set cycle time t_C	A1– 2
A1.3	Reaction time in case of binary signals .	A1– 4
A2	Addressing with 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master ...	A2– 1
A2.1	Introduction / Structure examples with 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master	A2– 1
A2.2	Recommended module addresses on the CS31 system bus with several re- mote modules and central units connected as slaves	A2– 3
A2.3	Address setting for the modules	A2– 3
A2.4	07 KR 91 / 07 KT 92 / 07 KT 93 used as stand-alone central units	A2– 4
A2.5	07 KR 91 / 07 KT 92 / 07 KT 93 used as bus master central unit	A2– 4
A2.6	Intelligent I/O remote modules (central units) as slaves on the CS31 system bus	A2– 5
A2.7	Special modules used as slave on the CS31 system bus	A2– 7
A2.8	Complex structure examples including addresses	A2– 7
A2.9	Module examples (slaves con- nected to the CS31 system bus)	A2– 8
A3	I/O configuration	A3– 1
A3.1	Purpose of the I/O configuration of I/O modules	A3– 1
A3.2	Settings and diagnosis on binary modules	A3– 2
A3.3	I/O configuration, changing of mea- suring ranges and diagnosis on analog modules	A3– 3

A3.31	Performing and reading the I/O configuration	A3– 4
A4	Diagnosis	A4– 1
A4.1	Introduction	A4– 1
A4.2	Structure of the diagnosis	A4– 1
A4.3	Troubleshooting by means of LED displays on the central unit	A4– 2
A4.4	Troubleshooting on the remote modules	A4– 4
A4.5	Acknowledgement of error messages in the remote modules	A4– 5
A4.6	Example of an error message	A4– 5
A4.7	Error flags in the central unit, error classification	A4– 6
A4.8	Acknowledgement of error messages in the central unit	A4– 8
A4.9	Additional diagnosis functions	A4– 8
A4.10	Meaning of the contents of the error word flags	A4– 8
A4.11	Reaction of the bus master central unit and the remote modules in case of errors	A4–13
A5	Programming and test	A5– 1
A6	Man–machine communication	A6– 1
A7	Operands 07 KR 91, 07 KT 92 and 07 KT 93 (variables and constants) ..	A7– 1
A7.1	Freely available variables and constants	A7– 1
A7.2	System constants / diagnosis flags / CS31 status (overview)	A7– 1
A7.3	System constants / Setting of operating modes	A7– 2
A8	The ARCnet system	A8– 1
A8.1	The networking configurations	A8– 1
A8.2	The features of the ARCnet system	A8– 3

A1 Processing times

The most important times for the application of the central units 07 KR 91 / 07 KT 92 / 07 KT 93 with or without connected remote modules are:

- The **reaction time t_{kk}** is the time between a signal transition at the input terminal and the signal response at the output terminal.

In case of binary signals, the reaction time consists of the input delay t_D , the cycle time t_C of the program processing and the bus transmission time, if the system is expanded by remote modules.

- The **cycle time t_C** determines the time intervals after which the processor starts the execution of the user program again.

The cycle time has to be specified by the user. It should be greater than the program processing time t_{UP} of the user program, the data transfer times and the related waiting times.

The cycle time is also the time base for some time-controlled functions, such as for the PID controller.

- The **program processing time t_{UP}** is the net time for processing the user program.

For the configuration and for determining the reaction time t_{kk} , the following steps are necessary:

- Determining the program processing time t_{UP}
- Addition of the other times which are within the cycle time t_C
- Specification of the cycle time t_C
- Determining the bus cycle time t_b , if there are any remote modules connected to the central unit

- Reaction time t_{kk} as the sum of the input delay t_v , 2 x bus cycle time t_b and 2 x cycle time t_C and output delay t_{DO} .

In addition to calculating the cycle time t_C in accordance with chapter A1.2 (Appendix) it is possible to measure the capacity utilization on the programmed central unit – with the RUN/STOP switch set to RUN. The menu item of "Display PLC status" in the programming software 907 PC 331 can be used for this purpose. Increase the cycle time t_C until the capacity utilization is below 80 %.

A1.1 Program processing time t_{UP}

- **Binary instructions of the type:**

!M /M &M =M

!NM /NM &NM =NM

Processing time for 1000 instructions: 2 ms

!M /M &M =SM

!NM /NM &NM =RM

Processing time for 1000 instructions: 2.2 ms

- **Word instructions of the type:**

!MW +MW –MW =MW

!–MW –MW +MW =–MW

Processing time for 1000 instructions: 4.1 ms

!MW *MW :MW =MW

!–MW *–MW :–MW =–MW

Processing time for 1000 instructions: 5.4 ms

- **Mixed instructions**

– 65 % binary: !, /, &, =

– 20 % word: !, +, –, =

– 15 % word: !, *, :, =

Processing time for 1000 instructions: 3 ms

- The program processing times of all the function blocks are specified in the documentation of the programming software 907 PC 331.

A1.2 Set cycle time t_C




Fig. 2–20: 07 KR 91 / 07 KT 92 / 07 KT 93, processing times

The cycle time t_C has to be preset by the user taking the following equation into consideration:

$$t_C \geq t_{bc} + t_{DP} + t_{UP} + t_p + t_{bc}$$

This equation assumes that the processor always gets access in the most unfavourable moment.

The cycle time t_C is stored in KD 00,00 and can be selected in 5 ms time steps. If the selected cycle time is too short, the processor will not be able to fulfill the tasks assigned to it. It will come in default then.

A1.3 Reaction time
in case of binary signals

		Times to be taken into consideration when the central unit 07 KR 91 / 07 KT 92 / 07 KT 93 is used as:			
		Stand-alone and slave, inputs and outputs of its own	Bus master, inputs and outputs of its own	Bus master, inputs and outputs via remote modules	Explanation
Inputs of remote modules		–	–	$t_D = (8 \text{ ms})$	Input signal delay t_D of binary remote modules, normally typ. 8 ms
		–	–	$t_B > 2 \text{ ms}$	Cycle time t_B of the CS31 system bus, depending on number and type of the remote modules, see vol. 2, system data
Inputs of the central unit		$t_D = \text{typ. } 7 \text{ ms} \text{ or } 8 \mu\text{s}$	$t_D = \text{typ. } 7 \text{ ms} \text{ or } 8 \mu\text{s}$	–	Delay time t_D of binary inputs of the central unit: E 62,00...E 63,03: typ. 7 ms E 63,14 a. E63,15: typ. 0.02 ms
		$t_C \geq 5 \text{ ms}$	$t_C \geq 10 \text{ ms}$	$t_C \geq 10 \text{ ms}$	Cycle time t_C , to be set by the user
Outputs of the central unit		$t_D = 0$	$t_D = 0$	–	Delay time t_D of the outputs of the central unit: negligible
		–	–	$t_B > 2 \text{ ms}$	Cycle time t_B of the CS31 system bus, depending on number and type of the remote modules, see vol. 2, system data
Outputs of remote modules		–	–	$t_{do} (< 1 \text{ ms})$	Output signal delay time of binary remote modules: normally < 1 ms

Fig. 2–21: 07 KR 91 / 07 KT 92 / 07 KT 93, reaction time

The maximum reaction time t_{kk} (input terminal to output terminal) results from the asynchronicity of the operations:

- Central unit via its own inputs and outputs

$$t_{kk} = t_D + 2 \cdot t_C$$

- Bus master central unit via inputs and outputs of remote modules

$$t_{kk} = t_D + 2 \cdot t_B + 2 \cdot t_C + t_{do}$$

In case of analog signals, the refresh times are to be entered in the formula instead of the delay times.


Example: Bus master central unit + 1 binary input module + 1 binary output module + 2 analog input modules, reaction time for binary signals via the remote modules:

Input delay time:	$1 \cdot t_D = 8 \text{ ms}$
2 · bus cycle time:	$2 \cdot t_B = 10.8 \text{ ms}$
2 · (2 ms + 387 μs + 323 μs + 1355 μs + 1355 μs)	
2 · cycle time:	$2 \cdot t_C = 30 \text{ ms}$
output delay time:	$1 \cdot t_{do} = 1 \text{ ms}$
Terminal-to-terminal reaction time	<u>ca. 49.8 ms</u>


A2 Addressing with 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master

A2.1 Introduction


Structure examples with 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master



Example 1: 07 KR 91, 07 KT 92 or 07 KT 93 used as stand-alone PLC



Example 2: 07 KR 91, 07 KT 92 or 07 KT 93 used as bus master on the CS31 system bus, as remote modules only I/O modules are used



Example 3: 07 KR 91, 07 KT 92 or 07 KT 93 as bus master and as slave on the CS31 system bus, 07 KR/KT 31 used as slave, in addition I/O modules

Without regard to the address ranges, the following modules can be connected to a CS31 system bus:

- max. 1 bus master
- max. 31 remote modules / slaves

Further restrictions result from the address range of the central units 07 KR 91 / 07 KT 92/93:


- max. 12 analog input modules
- max. 12 analog output modules
- max. 31 binary input modules
- max. 31 binary output modules

There may be further restrictions according to the structure of the installation and the type of remote modules. For the recommended addresses, see chapter A2.2.

Structure of the input and output addresses in the remote modules


The binary input module ICSI 08 D1 will be explained here as an example.

The bus master central unit reads the input signals as operands. The complete address of an input signal has the following structure:



Setting of the module address (group number) on the plug-in base ECZ

Example: Binary input module ICSI 08 D1 results in variable identifier E



The channel numbers are in the range of 00...07

Switch = OFF: 0 • Bit significance 1 = 0
 Switch = ON: 1 • Bit significance 2 = 2
 Switch = OFF: 0 • Bit significance 4 = 0
 Switch = ON: 1 • Bit significance 8 = 8
 Switch = OFF: 0 • Bit significance 16 = 0
 Switch = OFF: 0 • Bit significance 32 = 0

Modul address (group number) = 10

Switch position is without effect

Note: Some of other modules may have a more or less different address setting, see the following chapters.

A2.2 Recommended module addresses on the CS31 system bus with several remote modules and central units connected as slaves

The standard addressing has the purpose of

- simplifying and schematizing the setting of addresses on the CS31 system bus
- simplifying diagnosis and troubleshooting.

The standard addressing makes sure that there will be no address overlappings even for modules with a bigger amount of data.

Recommendation:

- Assign a specific module address for each module/each slave central unit, that means the giving up the possibility of double assignment of module addresses by binary and analog modules
- Module addresses for binary remote modules and central units: 8, 10, ..., 58, 60 (all even numbers), see also chapter A2.6 Central units connected as slaves to the CS31 system bus
- Module addresses for analog remote modules: 0...5
- Address switch No. 8 on the plug-in base ECZ always set to OFF (≤ 7)

A2.3 Address setting for the modules

Input and output modules connected as slaves to the CS31 system bus

The remote modules are mounted on the plug-in base ECZ. This plug-in base is equipped with an address switch (DIL switch) for setting the module address.



The combination of module type, module address and channel number results in the variable address used by the bus master central unit.

Setting the address switch for binary modules

The possible range of module addresses when using the central units 07 KR 91 / 07 KT 92 / 07 KT 93 is:

0...61

The function of the address switches is as follows:



Setting the address switches in case of analog modules


If analog modules are used, their module addresses can be set to

0...5

when the central units 07 KR 91 / 07 KT 92 / 07 KT 93 are used as bus master.

The analog representation in the 07 KR 91 / 07 KT 92 / 07 KT 93 is fixed. The analog modules have to supply their values in a suitable form and therefore to be set to the analog representation **b**. For the analog representation, see the general description of the analog modules (volume 2).

The function of the address switches is as follows:



A2.4 07 KR 91 / 07 KT 92 / 07 KT 93 used as stand-alone central units

If the central units 07 KR 91 / 07 KT 92 / 07 KT 93 are to be used without the CS31 system bus connected, perform the following setting when programming in the user program:

System constant KW 00,00 = -2

This value is the factory setting.

For the 07 KT 92 used as stand-alone central unit, see chapter A2.1 Introduction, Example 1.

A2.5 07 KR 91 / 07 KT 92 / 07 KT 93 used as bus master central unit

If remote modules (slaves) are connected to the central units 07 KR 91 / 07 KT 92 / 07 KT 93 via the CS31 system bus, proceed as follows:

1. Change the system constant: KW 00,00 = -1
2. Save the PLC program in the Flash EPROM
3. Activate the new PLC mode by:
 - Calling the menu item "Enable PLC mode" in the ABB programming and test system or
 - entering the command WARM <CR> in terminal mode or
 - power ON or
 - cold start.

A2.6 Intelligent I/O remote modules (central units) as slaves on the am CS31 system bus

The central units 07 KR 91, 07 KT 92, 07 KT 93, 07 KR 31 and 07 KT 31 can also be used as slaves at the CS31 system bus, see chapter A2.1, Addressing, Introduction, Example 3.


The central units 07 KR 91 / 07 KT 92 / 07 KT 93 / 07 KR 31 / 07 KT 31 may be used both in the binary range and in the word range.

The address can be set to a value from 0 to 61. The maximum permissible address depends on the size of the set transmit and receive range. The larger you choose the transmit or the receive range, the smaller is the maximum permissible address (see examples 1...3).

If you want to switch over to the "slave mode", proceed as follows:

1. Change the system constant: KW 00,00 = 0...61.
Only for 07 KR 31 and 07 KT 31: If KW 00,00 = 100, the address is set on the DIL switch of the plug-in base in the same way as with the standard modules, the address range is 0...61.

Meaning of the DIL switches:



2. Save the PLC program in the EEPROM
3. Activate the new PLC mode by:
 - Calling the menu item "Enable PLC mode" in the ABB programming and test system or

- entering the command WARM <CR> in terminal mode or
- power ON or
- cold start.

There is no direct access to the inputs and outputs of the slave central unit via the CS31 system bus. The communication between master and slave is performed using input and output operands.

All the master data are consistently transferred to the slave, and all the slave data are consistently transferred to the master.

The slave PLC can be used *either* in the binary range *or* in the word range of the CS31 system bus. The transmit and receive ranges of the slave can be adapted to the application-specific requirements by means of the two system constants KW 00,10 and KW 00,11 (see also chapter "System constants").

You can set:

- The size of the transmit and receive ranges and
- the mode of employment of the slave (in the binary or the word range).

Default condition:

If the central units 07 KR 91 / 07 KT 92 / 07 KT 93 / 07 KR 31 / 07 KT 31 are switched over to the "slave mode", they behave like binary input and output modules with 32 inputs and 32 outputs when connected to the CS31 system bus.

This means that the default setting of the transmit and receive ranges is within the binary range of the master. Their size is 32 bits each (4 bytes).

Example 1:

Default configuration of the slave (binary range):

KW 00,10 = 0: Slave transmit range: 4 bytes
(4 bytes * 8 channels = 32 binary O)

KW 00,11 = 0: Slave receive range: 4 bytes
(4 bytes * 8 channels = 32 binary I)

Note:

The default configuration is the same as the the configuration KW 00,10 = KW 00,11 = 4.

07 KR 91 / 07 KT 92 / 07 KT 93 / 07 KR 31 / 07 KT 31 as bus master	↔	07 KR 91 / 07 KT 92 / 07 KT 93 / 07 KR 31 / 07 KT 31 as slave with: KW 00,10 = 0 or 4 KW 00,11 = 0 or 4 Transmit or receive using E/A operands I/O operands
Receive or transmit using E/A operands (I/O operands)		Transmit or receive using E/A operands I/O operands
E n ,00	←	A 00,00
:		:
E n ,15		A 00,15
E n+1,00		A 01,00
:		:
E n+1,15	←	A 01,15
A n ,00	→	E 00,00
:		:
A n ,15		E 00,15
A n+1,00		E 01,00
:		:
A n+1,15	→	E 01,15

n: Module address of the slave central unit,
for this example: $0 \leq n \leq 60$)

For the slave address of $n = 12$ the following applies, for
example:

The output signal A 00,00 of the 07 KR 91 used as slave
is the input signal E 12,00 for the 07 KR 91 used as bus
master.

Example 2:

Configuration of the slave for the binary range:

KW 00,10 = 15: Slave transmit range: 15 bytes
(15 bytes * 8 channels = 120 binary O)

KW 00,11 = 06: Slave receive range: 6 bytes
(6 bytes * 8 channels = 48 binary I)

07 KR 31 / 07 KT 31 07 KR 91 / 07 KT 92 / 07 KT 93 as bus master	↔	07 KR 31 / 07 KT 31 07 KR 91 / 07 KT 92 / 07 KT 93 as slave with: KW 00,10 = 15 KW 00,11 = 6 Transmit or receive using E/A operands I/O operands
Receive or transmit using E/A operands (I/O operands)		Transmit or receive using E/A operands I/O operands
E n ,00	←	A 00,00
:		:
E n ,15		A 00,15
:		:
E n+7,00		A 07,00
:		:
E n+7,07		A 07,07
A n ,00	→	E 00,00
:		:
A n ,15		E 00,15
:		:
A n+2,00		E 02,00
:		:
A n+2,15		E 02,15

Notes:

The upper 8 input channels of the address $n+7$
E n+7,08...E n+7,15
can be assigned to another binary 8 bit input module
(excluding KR/KT) on the CS31 system bus.

The output channels starting from the address $n+3$
A n+3,00...A n+7,15
can be assigned to other output devices (including
KR/KT) on the CS31 system bus.

n: Module address of the slave PLC,
for this example: $0 \leq n \leq 54$)

For the slave address of $n = 12$ the following applies, for
example:


The output signal A 00,00 of the 07 KR 91 used as slave
is the input signal E 12,00 for the 07 KR 91 used as bus
master.

Example 3:

Configuration of the slave for the word range:

KW 00,10 = 101: Slave transmit range: 1 word
(1 word = 1 word output)

KW 00,11 = 108: Slave receive range: 8 words
(8 words = 8 word inputs)



n: Module address of the slave PLC,
for this example: $0 \leq n \leq 5$)

For the slave address of $n = 4$ the following applies, for example:

The output signal AW 00,00 of the 07 KR 91 used as slave is the input signal EW 04,00 for the 07 KR 91 used as bus master.

A2.7 Special modules used as slave on the CS31 system bus

● Robot coupler ICBG32L7 and ICBG64L7

The Robot coupler ICBG32L7 (ICBG64L7) behaves on the CS31 system bus like a binary input/output module equipped with 16 (32) inputs and 16 (32) outputs.

The module address can be set by means of the DIL switch on the printed circuit board.

The meaning of the DIL switch is the same as that on the plug-in base ECZ, see chapter A2.3. Switch No. 8 is always set to OFF.

Please note that the set module address and also the following address are assigned by the Robot coupler ICBG64L7.

For the signal names in the user program of the central unit, please see the description of the Robot couplers.

● Festo valve island/installation island

The Festo valve island and the Festo installation island behave on the CS31 system bus like binary input and output modules. For the scope of assigned data, please see chapter A2.9.

The module addresses are set by means of the address switches located below the cover of the "field bus node". The upper switch is provided for the unit digit, the lower switch for the tens digit.

A2.8 Complex structure examples including addresses

● Categorization of the modules with respect to the I/O terminals

There are the following two main module types:

- Binary modules. These modules are controlled by means of binary I/O operands (E or A, respectively). The Robot couplers ICBG 32 L7 and ICBG 64 L7 (always used as slave) belong also to them, as well as the central units 07 KR 91, 07 KT 92, 07 KT 93, 07 KR 31 and 07 KT 31, if they are used as slaves.
- Analog modules. These modules are controlled by means of word I/O operands (EW or AW, respectively). The central units 07 KR 91, 07 KT 92, 07 KT 93 belong to them as well as the high-speed counter ICSF 08 D1, which receives its preset data as word data, for example.

The following table contains an overview of the module types. These designations will be used in example 6.


Please note that the configurable binary modules ICSC 08 L1 and ICFC 16 L1 behave differently according to the performed setting.

A2.9 Module examples (slaves connected to the CS31 system bus)

Module types, with regard to I/O terminals	Module examples	Module types, with regard to I/O terminals	Module examples
Binary input modules with 8 inputs	ICSI 08 D1, ICSI 08 E1, ICSI 08 E4	Analog output modules with 8 outputs	ICSA 04 B5
Binary input modules with 16 inputs	ICSI 16 D1, ICSI 16 E1	Analog modules with up to 4 inputs and 4 outputs	ICSM 06 A6 (4 EA, 2 AA, therefore addressing gaps which cannot be assigned)
Binary output modules with 8 outputs	ICSO 08 R1, ICSO 08 Y1; ICSC 08 L1, if switch No. 1 is set to ON	Analog modules (word modules) with up to 8 inputs and 8 outputs	ICSF 08 D1 (high-speed counter), 07 KR 91, 07 KT 92, 07 KT 93, 07 KR 31, 07 KT 31
Binary output modules with 16 outputs	ICFC 16 L1, if switch No. 1 is set to ON, Festo valve island with up to 8 valves		
Binary output modules with 32 outputs	Festo valve island with more than 8 valves		
Binary modules with 8 inputs and 8 outputs	ICSC 08 L1, if switch No. 1 is set to OFF		
Binary modules with 16 inputs and 16 outputs (a) or 16 signals each from/to the CS31 bus (b)	(a) ICSK 20 F1, ICDG 32 L1, if switch No. 1 is set to ON, ICFC 16 L1, if switch No.1 is set to OFF, Festo installation island with up to 6 valves, (b) ICBG 32 L7		
Binary modules with 32 inputs and 32 outputs (a) or 32 signals each from/to the CS31 bus (b)	(a) Festo installation island with more than 6 valves, (b) ICBG 64 L7, ICDG 32 L1, if switch No. 1 is set to OFF		
Binary modules with 120 signals each from/to the CS31 system bus	07 KR 91 as slave 07 KT 92 as slave 07 KT 93 as slave 07 KR 31 as slave 07 KT 31 as slave		
Analog input modules with 8 inputs	ICSE 08 A6, ICSE 08 B5, ICST 08 A8, ICST 08 A9		

Examples for the assignment of module addresses,

Example 4



Example 5

		07 KR 91	07 KT 92	07 KT 93	Inputs/outputs on the central unit
Address setting in the master: KW 0,0 = -1		E 62,00...E 62,15 E 63,00...E 63,03 A 62,00...A 62,11 — —	E 62,00...E 62,11 — A 62,00...A 62,07 EW 6,00...EW 6,03 AW 6,00	E 62,00...E 62,15 E 63,00...E 63,07 A 62,00...A 62,15 — —	
Address switch on the plug-in base ECZ	Remote module	Address in the program of the master CPU		Remarks	
<p>ON 1 2 3 4 5 6 7 8 * 03 ≤ 7</p>	ICSE 08 A6 8 analog inputs	E0 : E7	EW 03,00 : EW 03,07	<ul style="list-style-type: none"> – Permissible range of module addresses for analog modules: 0...5 – * Analog representation b – 2 analog input modules with 8 channels each can be assigned to one address (16 channels together) – The same address (as for the analog input modules) may also be used for the connection of analog output modules (as shown to the left). Since the module has only 4 channels, AW 03,04...AW 03,07 (or AW 03,12...AW 03,15) cannot be used. The same corresponds to the module ICSM 06 A6. 	
<p>ON 1 2 3 4 5 6 7 8 * 03 > 7</p>	ICSE 08 A6 8 analog inputs	E0 : E7	EW 03,08 : EW 03,15		
<p>ON 1 2 3 4 5 6 7 8 * 03 ≤ 7</p>	ICSA 04 B5 4 analog outputs	A0 : A3	AW 03,00 : AW 03,03		
<p>ON 1 2 3 4 5 6 7 8 06 ≤ 7</p>	ICSI 16 E1 16 binary inputs	E00 : E15	E 06,00 : E 06,15	<ul style="list-style-type: none"> – Permissible range of module addresses for binary modules: 0...61, recommendation: 6...60 – The following might be done, but does not bring you any advantage: <ul style="list-style-type: none"> • using the same addresses for binary modules as for analog modules • collecting 2 modules with 8 bits each under one address • collecting input and output modules under one address – Slave KR/KT with 120 E and/or 120 A occupies the set address and the following 7 addresses (only half of the 7th, though). For address 4 of the example: <ul style="list-style-type: none"> – Next free address for KR/KT: binary range: 12, word range: 5 – Max. settable KR/KT address: binary range: 54, word range: 5 	
<p>ON 1 2 3 4 5 6 7 8 06 ≤ 7</p>	ICSO 08 R1 8 binary outputs	A0 : A7	A 06,00 : A 06,07		
<p>ON 1 2 3 4 5 6 7 8 06 > 7</p>	ICSO 08 R1 8 binary outputs	A0 : A7	A 06,08 : A 06,15		
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> 07 KR 91 / 07 KT 92 / 07 KT 93: KW 0,0 = 4 </div> up to 120 binary inputs and up to 120 binary outputs or up to 8 word inputs and up to 8 word outputs		KR/KT in binary range: E 04,00...E 11,07 A 04,00...A 11,07 or KR/KT in word range: EW 04,00...EW 04,07 AW 04,00...A 04,07			

Example 6

Module type, with regard to I/O terminals	Address switch on the plug-in base ECZ	07 KR 91 / 07 KT 92 / 07 KT 93	Permissible addresses
8 analog inputs	Address 0, ≤7		0...5 (2=ON, 3=OFF: Analog re- presentation (b))
8 analog inputs	Address 0, >7		EW 0,08...EW 0,15
8 analog outputs	Address 0, ≤7		EW 0,00...EW 0,07 Collection is possible AW 0,00...AW 0,07
8 analog outputs	Address 0, >7		AW 0,08...AW 0,15
4 analog inputs and 4 analog outputs	Address 1, ≤7		EW 1,00...EW 1,03 AW 1,00...AW 1,03
4 analog inputs and 4 analog outputs	Address 1, >7		EW 1,08...EW 1,11 AW 1,08...AW 1,11
8 binary inputs	Address 0, ≤7		E 0,00...E 0,07
8 binary inputs	Address 0, >7		E 0,08...E 0,15
8 binary outputs	Address 0, ≤7		E 0,08...E 0,15 Collection is possible A 0,00...A 0,07
8 binary outputs	Address 0, >7		A 0,08...A 0,15
16 binary inputs	Address 1, ≤7		E 1,00...E 1,15
16 binary outputs	Address 1, ≤7		E 1,08...E 1,11 Collection is possible A 1,00...A 1,15
32 binary outputs	Address 2, ≤7		A 2,00...A 2,15 A 3,00...A 3,15
8 binary inputs and 8 binary outputs	Address 4, ≤7		E 4,00...E 4,07 A 4,00...A 4,07 Collection is possible
8 binary inputs and 8 binary outputs	Address 4, >7		E 4,08...E 4,15 A 4,08...A 4,15
16 binary inputs and 16 binary outputs	Address 5, ≤7		E 5,00...E 5,15 A 5,00...A 5,15
32 binary inputs and 32 binary outputs	Address 6, ≤7		E 6,00...E 6,15; E 7,00...E 7,15 A 6,00...A 6,15; A 7,00...A 7,15

Examples for module types see chapter A2.9

Max. 31 slave modules on the CS31 system bus

A3 I/O configuration

A3.1 Purpose of the I/O configuration of I/O modules

Dependent on the type of I/O modules the following can be configured:

- in case of binary I/O modules, an input delay different from the factory setting,
- in case of binary modules with combined I/O channels, these channels can also be defined as input only or output only,
- in case of binary modules, open-circuit monitoring at inputs and outputs,
- in case of analog modules, measuring or output ranges which differ from the factory setting.

Switching over of inputs and outputs, switching on the diagnosis functions and changing the measuring and

output ranges are performed as follows, depending on the module type:

- Performing the I/O configuration via the CS31 system bus, either by means of the user program of the bus master central unit or by means of a terminal
- Setting of switches on the plug-in base ECZ or on the rear side of the input/output module
- External wiring on the input/output module terminals.

In some cases, there is a relation between the settings made on the remote module and the information and diagnosis messages which can be interrogated at the remote module or via the CS31 system bus. This relation will be explained in the following chapters.

There is no need for you to perform an I/O configuration via the CS31 system bus if the factory setting is sufficient. Once an I/O configuration has been performed, it will remain stored in the corresponding I/O module until it is changed again. Even in case of power OFF it will not be deleted.

A3.2 Settings and diagnosis on binary modules

The following tables give you an overview on the I/O configurations and the diagnosis functions related to them for the different module types.

Binary modules, settings and diagnosis					
I/O configurable functions	–	–	–	–	CI CO ID IO OO
Diagnosis functions according to module type a) always present b) if configured	UE	BE	OL	SC	CI CO – – –
Readable on the module by pressing the test button ¹⁾ a) Diagnosis messages b) Settings	–	–	OL	SC	CI CO IO OO
Available for the bus master user program, readable on the terminal a) cyclic transmission b) interrogable	–	–	OL	SC	CI CO ID IO –
Module type					
ICSI 08 D1	•	•		•	•
ICSI 16 D1	•	•		•	•
ICSI 08 E1	•	•			•
ICSI 16 E1	•	•			•
ICSI 08 E4	•	•			•
ICSO 08 R1	•	•			
ICSO 08 Y1	•	•	•	•	
ICSO 16 N1	•	•	•	•	
ICSK 20 F1	•	•			
ICSK 20 N1	•	•	•	•	
ICSC 08 L1	•	•	•	•	•
ICSC 16 L1	•	•	•	•	•
ICSF 08 D1	•	•			
ICDG 32 L1	•	•	•	•	
Robot coupler	•	•			
Festo devices	•	•	•	•	
07 KR 91	•	•			
07 KT 92	•	•	•	•	
07 KT 93	•	•	•	•	
07 KR 31	•	•			
07 KT 31	•	•	•	•	

Explanation

- Feature is completely available. Settings and errors can be interrogated from the involved channel.

(•) Feature is partly available, see module description.

1) Concerning the interrogation of settings and diagnosis data, see the module description and chapter "Reading I/O configuration and diagnosis data at the module" (see below).

BE Bus Error = Bus malfunction, always monitored. The module does not receive a call from the bus master, e.g. because of a broken bus line.

CI Cut Wire of Inputs = Open circuit (monitoring) at inputs, if configured. Each input circuit to be monitored has to be equipped with a resistor of 20...30 kΩ, e.g. in parallel to the signalling contact.

CO Cut Wire of Outputs = Open circuit (monitoring) at outputs, if configured. Each output expects a minimum load of approx. 40 mA when an ON signal is output.

ID Input Delay = Change of the signal delay time at inputs.

IO Input only = Each terminal (channel) can be configured so that it works only as an input (not as combined input/output).

OO Output only = This mode is set by means of a switch on the plug-in base ECZ. Setting is not possible by I/O configuration, see the module description.

OL Overload (is always monitored).

SC Short circuit (is always monitored).

UE Unit error = internal error (fault) of the module (always monitored in so far as the internal processor can detect this).

A3.3 I/O configuration, changing of measuring ranges and diagnosis on analog modules

Analog modules, settings and diagnosis									
Selectable ranges: I/O configurable (K) by means of switches (S) or wiring (V)			0–10 V	±10 V	0–20 mA	±20 mA	4–20 mA	other range	rough display of the value
Module type									
ICSE 08 A6	•	•	A	–	A	–	K	K	•
ICSE 08 B5	•	•	–	A	–	S,K	S,K	S,K	•
ICSA 04 B5	•	•	•	A	S	–	S,K*	–	•
ICSM 06 A6, inputs	•	•	A	–	A,V	–	K	A,K	•
ICSM 06 A6, outputs			–	A	A	–	K		•
Diagnosis functions accord- ing to the module type									
a) always available	UE	BE							
b) if configured			OE						
Can be read from the module by pressing the test button ¹⁾									
a) Diagnosis messages	UE	BE							
b) Settings (only switches and I/O configuration)			OE	•	•	•	•	•	
Available for bus master user program, can be read on the terminal									
a) transferred cyclically	UE	BE							
b) can be interrogated			OE				•		

Explanation:

¹⁾ Concerning the interrogation of settings and diagnosis data, see the module description and chapter "Reading I/O configuration and diagnosis data at the module" (see below).

*) Changing range by switch, activating the open-circuit monitoring by I/O configuration

BE Bus Error = Bus malfunction, always monitored. The module does not receive a call from the bus master, e.g. because of a broken bus line.

OE Output Error = Error in the output circuit.
ICSA 04 B5: Open circuit at outputs configured to 4...20 mA.
ICSM 06 A6: Short circuit at outputs configured to ± 10 V.

UE Unit error = internal error (fault) of the module (always monitored in so far as the internal processor can detect this).

A Factory setting

K Changing the range by means of the I/O configuration via the CS31 system bus

S Changing the range by means of DIL switches on the rear side of the module

V Change-over between voltage and current by means of an additional external jumper. No specification if only another terminal has to be used.

A3.3.1 Performing and reading the I/O configuration

There are the following possibilities for system structures when using 07 KR 91, 07 KT 92 or 07 KT 93 as bus master:

- Performing and reading the I/O configuration via the user program of the bus master central unit 07 KR 91, 07 KT 92 or 07 KT 93,
- Performing and reading the I/O configuration by means of the terminal or
- Reading the I/O configuration from the remote modules.

Performing and reading the I/O configuration via the user program

The function block CS31CO is available for the I/O configuration of the modules. This function block is part of the programming software 907 PC 331 and is described in the corresponding documentation.

Performing and reading the I/O configuration by means of the terminal or TCZ

This method is based on the fact that the central units 07 KR 91, 07 KT 92 and 07 KT 93 use a dialogue language at the programming interface which allows the I/O configuration to be performed and interrogated by means of simple protocols; see volume 7.3, chapter 3, "MAIL command".

07 KR 91 and 07 KT 92/93 are generally equipped with the special function for I/O configuration.

The following devices can be used as terminal:

- A commercially available terminal equipped with an EIA-232 interface, such as VT100.
- A PC equipped with the programming software 907 PC 331. All the interface data are correctly set under the main menu item of "PLC communication 2", sub-item "Terminal emulation".

- The service device TCZ in the operating mode 1 = TERMINAL, 2 = CHAR.MODE, N = transmission speed unchanged, 9600 Baud.

Reading I/O configuration and diagnosis data at the remote module

Reading the I/O configuration and the diagnosis data for an I/O terminal of a remote module will be shown in the following for the device ICSC 08 L1 as an example. The test button ④ and the LED displays ① of the module have to be used for this purpose.

When the test button is pressed for the first time, channel E/A0 (input/output 0) is selected: LED 0 flashes. After releasing the button, the diagnosis data of this channel are shown by the yellow LEDs 0 to 7 for approx. 3 seconds.

The LEDs have the following meaning:

- 0 UE = Unit error
- 1 BE = Bus error
- 2 not used
- 3 CI/CO = Cut wire of inputs/outputs
- 4 OL = Overload
- 5 SC = Short circuit
- 6 Configuration as output
- 7 Configuration as input

If the LEDs 6 and 7 light up at the same time, the channel is configured as a combined input/output.

The meaning of the LEDs ② is also printed onto the front panel of the module.

The operation is repeated for the other channels each time the test button is pressed and released.

After the last channel E/A7 (input/output 7) has been scanned, pressing the test button again causes a lamp test (LED test) to be performed. All the 8 LEDs should light up. After the button has been released, the LEDs will show the setting of the DIL switch on the plug-in base for approx. 5 seconds. LED 0 shows the position of switch No. 1 (LEDs 0...7 are assigned to the switches No. 1...8).

All error messages are stored in the module and can only be deleted by pressing the test button for 10 seconds or by power OFF/ON.

A4 Diagnosis

A4.1 Introduction

The diagnosis system of the 07 KR 91 / 07 KT 92 / 07 KT 93 is designed to ensure a quick and efficient troubleshooting. For this purpose, it is classified:

- "vertically" in diagnosis, error flags, reactions, LED displays and acknowledgement, see chapter A4.7. There are interrelations between the bus master central unit and the remote modules. The central unit reads the diagnosis data which the remote modules have found out. An acknowledgement in the central unit also causes the stored error messages in the remote modules to be deleted.
- "horizontally" in 4 error classes, in correspondence with the severity of the error, see chapter A4.7.

This concept is based on a system structure consisting of a bus master central unit and several remote modules, and remote processors as well. The diagnosis system detects the following errors:


- Errors in the bus master central unit

- Errors on the CS31 system bus
- Errors in the remote modules
- Errors in the wiring of the remote modules on the process side

The troubleshooting is performed as follows:

- The LEDs on the central unit 07 KR 91, 07 KT 92 and 07 KT 93 give first hints, see chapter A4.3. The errors detected by the remote modules are also displayed here.
- If these hints are not sufficient, the error flags have to be read out. For the meaning of the error flags, see chapters A4.7 and A4.10.
- The status register EW 07,15 in the central unit supplies additional information to be used for the diagnosis, see chapter A4.9.
- The remote modules indicate errors occurring in their area. Detailed information can be obtained by pressing the test key on the modules, see chapter A4.4.

A4.2 Structure of the diagnosis



A4.3 Troubleshooting by means of LED displays on the central unit

The LED displays on the front panel of the central unit supply initial information on the errors which occurred:

- BA = CS31 bus processor active
- BE = Bus Error (error on the CS31 system bus)
- RE = Remote Unit Error (error in/on a remote module)
- SE = Serial Unit Error (error in the CS31 bus interfacing of the central unit)
- RUN = User program is running (no error)

- FK1 = Error class 1 (fatal error)
- FK2 = Error class 2 (serious error)
- FK3 = Error class 3 (light error)
- Supply = Supply voltage available
- Battery = Battery is effective
- K = Overload/short circuit on at least one direct binary output of the central unit ZE 07 KT 92 or 07 KT 93

If no LED lights up, the central unit has not found any error. Exception: LED Battery (battery is missing); the battery is only necessary for certain applications.

LEDs for CS31 system bus and bus interfacing

LED	BA	BE	RE	SE	Meaning	Remedy
CPU	gn	rd	rd	rd		
Stand-alone-CPU, master CPU or slave CPU	☆	□	□	□	Everything ok.	—
	□	X	X	X	A fatal error occurred. The watchdog switched off the CS31 system bus. All outputs are in OFF condition.	<ul style="list-style-type: none"> • Power OFF/ON. • If unsuccessful, device is defective. • Evaluate the error flags.
	☆	□	□	☆	Dual-port RAM defective	<ul style="list-style-type: none"> • Power OFF/ON. • If unsuccessful, device is defective. • Evaluate the error flags.
	□	☆	☆	☆	Initialization phase after power ON or after cold start.	—
Master CPU	☆	☆	□	□	Master CPU does not find any remote modules on the CS31 system bus <u>after</u> power ON or after cold start.	<ul style="list-style-type: none"> • Install remote modules. • Check the CS31 bus line. • Check the supply voltage of the remote modules. • Evaluate the error flags.
	☆	□	☆	□	Error message from a remote module	<ul style="list-style-type: none"> • Evaluate the error flags. • Check the remote modules.
	☆	☆	☆	□	1 remote module can suddenly not be controlled by the master CPU anymore.	<ul style="list-style-type: none"> • Evaluate the error flags. • Check the supply voltage of the remote module. • Check the CS31 bus line. • Check the remote module.
	☆	☆	□	□	There are at least 3 remote modules on the CS31 system bus. 2 remote modules can suddenly not be controlled by the master CPU anymore.	<ul style="list-style-type: none"> • Evaluate the error flags. • Check the supply voltage of the remote modules. • Check the CS31 bus line. • Check the remote modules.
	☆	☆	☆	☆	There are at least 2 remote modules on the CS31 system bus. Suddenly no remote module can be controlled by the master CPU anymore.	<ul style="list-style-type: none"> • Evaluate the error flags. • Check the supply voltage of the remote modules. • Check the CS31 bus line. • Check the remote modules.
Slave CPU	☆	□	**	□	CS31 system bus does not work.	<ul style="list-style-type: none"> • Check the CS31 bus line. • Check master central unit.

□ = LED off, ☆ = LED on, ** = LED flashes, X = LED on or off, gn = green, rd = red

LEDs for user program and error display

LED	RUN				Meaning	Remedy
	gn	FK1 rd	FK2 rd	FK3 rd		
CPU						
Stand-alone CPU, master CPU or slave CPU	☆	□	□	□	User program is running.	—
	☆	□	□	☆	User program is running, but a light error occurred.	<ul style="list-style-type: none"> Evaluate the error flags and eliminate the error.
	□	□	□	□	The user program does not run.	<ul style="list-style-type: none"> Start the user program.
	□	□	□	☆	A light error occurred which caused the user program to be aborted automatically because <ul style="list-style-type: none"> the system constant KW 0,7 is not equal to 0, the "ABORT" block is not configured. 	<ul style="list-style-type: none"> Evaluate the error flags and eliminate the error.
	□	□	☆	□	A serious error occurred which caused the user program to be aborted automatically.	<ul style="list-style-type: none"> Evaluate the error flags and eliminate the error, if possible.
	□	☆	□	□	A fatal error occurred. The user program cannot be started.	<ul style="list-style-type: none"> Evaluate the error flags. Power OFF/ON. If unsuccessful, device is defective.
	□	□	☆	☆	A light and a serious error occurred.	<ul style="list-style-type: none"> Evaluate the error flags and eliminate the error, if possible.
	☆	☆	☆	☆	Initialization phase, power ON, cold start	—

□ = LED off, ☆ = LED on, ☆* = LED flashes, X = LED on or off, gn = green, rd = red

LEDs for supply voltage and battery

LED	Supply		Battery	Meaning	Remedy
	gn	rd			
CPU					
Stand-alone CPU, master CPU or slave CPU	☆	□		Supply voltage available and battery is effective.	—
	☆	☆		Supply voltage available and battery is not effective.	—
	□	□		Supply voltage is not available.	<ul style="list-style-type: none"> Switch power ON. Check the supply voltage.

□ = LED off, ☆ = LED on, ☆* = LED flashes, X = LED on or off, gn = green, rd = red

LED K for overload/short circuit on at least one direct binary output A 62,00...A 62,07 (A 62,15) (for 07 KT 92 and 07 KT 93 only)

LED	K		Meaning	Remedy
	rt			
CPU				
Stand-alone CPU, master CPU or Slave CPU	☆		Overload/short circuit on at least one of the direct binary outputs A 62,00...A 62,07 (A 62,15).	<ul style="list-style-type: none"> Eliminate overload/short circuit.
	□		There is no overload/short circuit.	—

□ = LED off, ☆ = LED on, ☆* = LED flashes, X = LED on or off, gn = green, rd = red

Diagnosis functions for the remote modules

The remote modules are equipped with a number of diagnosis functions. Some of these functions become active only if they have been set by means of the I/O configuration.

Explanation:

- Feature is completely available. Settings and errors can be interrogated from the involved channel.

(●) Feature is partly available, see module description.

1) Concerning the interrogation of settings and diagnosis data, see the module description and chapter A3.3 "Reading I/O configuration and diagnosis data at the module".

BE Bus Error = Bus malfunction, always monitored. The module does not receive a call from the bus master. This may have the following reasons:

- The CS31 system bus line is broken, short-circuited or wired with reversed polarity.
- The central unit has not been set as bus master, see also system constant KW 00,00 in chapter A7.3.

CI Cut Wire of Inputs = Open circuit (monitoring) at inputs, if configured. Each input circuit to be monitored has to be equipped with a resistor of 20...30 kΩ, e.g. in parallel to the signalling contact.

CO Cut Wire of Outputs = Open circuit (monitoring) at outputs, if configured. Each output expects a minimum load of approx. 40 mA when an ON signal is output.

OL Overload (is always monitored).

SC Short circuit (is always monitored).

UE Unit error = internal error (fault) of the module (always monitored in so far as the internal processor can detect this).

Troubleshooting in the remote modules

The LED (3) lights up, if the remote module has detected an error.

The remote module supplies detailed error information via the 8 LEDs (1), if the test button (4) is pressed; see also the module descriptions.

The procedure will be explained in the following for the module ICSC 08 L1 as an example.

After the test button has been pressed for the first time, channel E/A0 (input/output 0) is selected: LED0 flashes. After the button has been released, The diagnosis data of this channel are shown via the yellow LEDs 0 to 7 for approx. 3 seconds.

Diagnosis, display and messages to the central unit	
Diagnosis functions according to the module a) always available b) if configured	UE BE OL SC CI CO
Readable on the module by pressing the test button 1) a) Diagnosis messages	UE BE OL SC CI CO
Available for bus master user program, readable on the terminal a) cyclic transmission	– – OL SC CI CO
Module type	
ICSI 08 D1	● ● ●
ICSI 16 D1	● ● ●
ICSI 08 E1	● ●
ICSI 16 E1	● ●
ICSI 08 E4	● ●
ICSO 08 R1	● ●
ICSO 08 Y1	● ● ● ●
ICSO 16 N1	● ● ● ●
ICSK 20 F1	● ●
ICSK 20 N1	● ● ● ●
ICSC 08 L1	● ● ● ● ● ●
ICSC 16 L1	● ● ● ● ● ●
ICSF 08 D1	● ●
ICDG 32 L1	● ● ● ●
ICSE 08 A6	● ●
ICSE 08 B5	● ●
ICSA 08 B5	● ● ●
ICSM 06 A6	● ● ●
Robot coupler	● ●
Festo devices	● ● ● ●
07 KR 91	● ●
07 KT 92	● ● ● ●
07 KT 93	● ● ● ●
07 KR 31	● ●
07 KT 31	● ● ● ●

The LEDs have the following meaning:

- 0 Error in the module (UE = Unit error)
- 1 Error on the bus (BE = Bus error)
- 2 not used
- 3 CI/CO = Cut wire of inputs/outputs
- 4 OL = Overload
- 5 SC = Short circuit
- 6 Configuration as output
- 7 Configuration as input

If the LEDs 6 and 7 light up at the same time, the channel is configured as a combined input/output.

The meaning of the LEDs ② is also printed onto the front panel of the module.

The operation is repeated for the other channels each time the test button is pressed and released.

After the last channel E/A7 (input/output 7) has been scanned, pressing the test button again causes a lamp test (LED test) to be performed. All the 8 LEDs should light up. After the button has been released, the LED will show the setting of the DIL switch on the plug-in base for approx. 5 seconds. LED 0 shows the position of switch No. 1 (LEDs 0...7 are assigned to switches No. 1...8).

All the error messages are stored in the module and can only be deleted by pressing the test button for 10 seconds or by power OFF/ON.


A4.5 Acknowledgement of error messages in the remote modules

The remote modules store and display the error messages detected independently of the central unit. The error messages can be acknowledged

- on the remote module by pressing the test button
- in the user program by means of the function block CS31QU (this also deletes the error message stored in the central unit)
- in the terminal mode by means of the command MAIL, see volume 7.3, chapter 3.

If the error has not been eliminated, the error message appears again.

A4.6 Example of an error message



Errors which occurred:

The bus line to the remote module having the module address 3 has been broken during operation.

Error flags in the central unit 07 KR 91 / 07 KT 92 / 07 KT 93:

It is assumed that the error flags have been set to 0 by acknowledgement/deletion before the error occurred. In the following, only those error flag will be listed the contents of which changes.

- M 255,10 = 1 Summation error message
 - M 255,13 = 1 Error class message (FK3 error)
 - MW 255,00 = 15 Error detection: remote module is disconnected
 - MW 255,01 = 05 Module type: analog input and output
 - MW 255,02 = 03 Group number (module address)
 - MW 255,03 = 0
 - MW 255,04 = 0
 - MW 255,05 = 0
 - MW 255,06 = 0
 - MW 255,07 = 0
- } not concerned, as well as
} all the other error flags
} which have not been
} mentioned

LED displays on the bus master central unit 07 KR 91 / 07 KT 92 / 07 KT 93:

- BA lights up → CS31 bus processor is active. The data communication with the remote module having the address 17 is continued.
- BE lights up → Bus Error, error on the CS31 system bus.
- RE lights up → Remote Unit Error, error on a remote module.
- SE off → Serial Unit Error, CS31 bus interfacing in the central unit works correctly.
- RUN lights up
- FK3 lights up → light error

Reaction of the bus master central unit 07 KR 91 / 07 KT 92 / 07 KT 93

The processing program and the bus operation continue running (if KW 0,7 = 0).

Reaction of the remote module ICSM 06 A6: All of the outputs turn to 0.

Reaction of the remote module ICSC 08 L1: Data exchange with the bus master central unit 07 KR 91 / 07 KT 92 / 07 KT 93.

Status word EW 07,15 in the central unit 07 KR 91 / 07 KT 92 / 07 KT 93

- Bit 0 = 1 no class 2 error
- Bit 1 = 0 only applicable for 07 KR 91 / 07 KT 92 / 07 KT 93 used as slave
- Bit 2 = 1/0 Date/time of the real-time clock valid / not valid
- Bit 3 = 1/0 Battery effective / not effective
- Bit 4...7 not used
- Bit 8...15 = 2 max. number of modules connected to the CS31 system bus which have been found since the last power-on operation. Will not be altered by the error which has occurred in the meantime.

Acknowledgement of the error flags in the central unit 07 KR 91 / 07 KT 92 / 07 KT 93

Eliminate the error before acknowledgement. Otherwise the error message will appear again.

The bit flags M 255,10 and M 255,13 can be acknowledged by:

- power ON
- program "Start" (on-line in the programming software 907 PC 331)
- cold start (menu item in 907 PC 331)
- setting the RUN/STOP switch to RUN
- overwriting the flag M 255,13 with "0" in the user program
- overwriting the flag M 255,13 with "0" by means of the operating function "Overwrite", see volume 7.3, chapter 3
- using the function block CS31QU in the user program. The block is applicable only for errors which concern the CS31 system bus. It also deletes the error message in the remote module.

The relevant LEDs turn off upon the acknowledgement.

The word flags MW 255,00...MW 255,07 can only be deleted by overwriting them. They are overwritten by newly occurring errors.

Acknowledgement of error flags in the remote module ICSM 06 A6

- on the module by pressing the test button for a longer time
- in the user program of the central unit using the CS31QU block
- in the terminal mode by means of the MAIL command, see volume 7.3, chapter 3.

A4.7 Error flags in the central unit, error classification

The central unit offers error messages for the user program which are classified into 4 error classes (FK1...FK4) according to their severity. The error messages are stored in error flags and can be used in the user program and be read by the programming system.

The following table gives you an overview of the error flags.

Error class	FK1 = fatal error	FK2 = serious error	FK3 = light error	FK4 = warning
General feature of the error class, examples	Save operation of the operating system is no longer ensured. <u>Error examples:</u> – Checksum error in the operating system EPROM – Write/read error when testing the operating system RAM	The operating system works correctly, but the error-free processing of the user program is not guaranteed. <u>Error examples:</u> – Checksum error in the user program (Flash EPROM) – Write/read error when testing the user RAM	The choice whether the user program has to be aborted by the operating system or not depends on the application. The user decides which reactions are to be initiated. <u>Error examples:</u> – Flash EPROM cannot be programmed – Dual port RAM to the CS31 part (LED SE) is faulty – Remote module has failed (LED RE)	Errors which occur on peripheral devices or which will show their effect only in the future. The user decides which reactions are to be initiated. <u>Error examples:</u> – Short circuit on a remote module
Summation error message ¹⁾	M 255,10			
Error class message (if 1, an error exists)	M 255,11	M 255,12	M 255,13	M 255,14
Error detection (word) ²⁾	MW 254,00	MW 254,08	MW 255,00	MW 255,08
Detailed info 1 (word) ²⁾	MW 254,01	MW 254,09	MW 255,01	MW 255,09
Detailed info 2 (word) ²⁾	MW 254,02	MW 254,10	MW 255,02	MW 255,10
Detailed info 3 (word) ²⁾	MW 254,03	MW 254,11	MW 255,03	MW 255,11
Detailed info 4 (word) ²⁾	MW 254,04	MW 254,12	MW 255,04	MW 255,12
Detailed info 5 (word) ²⁾	MW 254,05	MW 254,13	MW 255,05	MW 255,13
Detailed info 6 (word) ²⁾	MW 254,06	MW 254,14	MW 255,06	MW 255,14
Detailed info 7 (word) ²⁾	MW 254,07	MW 254,15	MW 255,07	MW 255,15
LED displays after initialization	FK1 lights up or LED RUN does not go on, if RUN/STOP switch is set to RUN	FK2 lights up or LED RUN does not go on, if RUN/STOP switch is set to RUN	FK3 lights up. In addition, according to error type: LED BE (Bus Error) LED RE (Remote Unit Error) LED SE (Serial Unit Error)	LED RE (Remote Unit Error) lights up
Reaction when switching on the central unit / Reaction during operation	All the outputs remain set to 0 or are set to 0. The programming system does not have access. Attention: Both processors of the central unit monitor each other mutually, thus facilitating a powerful diagnosis. If the safety requirements are higher, use specially approved controllers.	All the outputs remain set to 0 or are set to 0. The programming system can get access. The user program is not started or is aborted.	You can choose in case of an error: – Just report the error: Evaluate the error flag M 255,13 – Abort the user program: Set system constant KW 0,7 = 1 (FK3_REAK) or M 255,13 to the function block ABORT	Evaluation of the error messages using the user program
Acknowledgement of the summation error message / of the error class message	– Power ON – Cold start	– Power ON – Cold start	– Power ON / cold start – Set the RUN/STOP switch to RUN – Start the program using 907 PC 331 – Set M 255,13 or M 255,14 to 0 – In case of CS31 error: function block CS31QU	
¹⁾ The summation error flag M 255,10 becomes 1, if at least one of the error class flags is set to 1. If M 255,10 = 0, the central unit has not found any error. The summation error flag is deleted automatically when the error class flags are acknowledged.		²⁾ The central unit enters the last found error into the relevant error flag record for each error class. The entry is made at the end of the program cycle and remains unchanged during the next running program cycle. The word flags can only be acknowledged by overwriting them with "0".		

Error class	Error description	Error identifier in MW 254,08		Detailed info 1 in MW 254,09	Detailed info 2 in MW 254,10	Detailed info 3 in MW 254,11	Further detailed info in MW 254,12 : MW 254,15
		Dec	Hex				
FK2 Serious error	RAM defective (user program or operand memory)	128 _D	80 _H	Address	–	–	–
	Illegal master-slave identifier	129 _D	81 _H	–	–	–	–
	A serious error has occurred when the CS31 bus interfacing was initialized. The CS31 bus processor does not give any response to the PLC side within the specified time.	130 _D	82 _H	–	–	–	–
	PLC is overloaded, cycle time is too short.	131 _D	83 _H	–	–	–	–
	An error which cannot specified in detail is detected by the operating system during the execution time.	132 _D	84 _H	–	–	–	–
	Checksum error in the Flash EPROM	133 _D	85 _H	–	–	–	–
	CS31 bus processor does not send an OK response to the PLC after a cold start command issued by the PLC.	134 _D	86 _H	–	–	–	–
	Error detection not used at the moment.	135 _D	87 _H	–	–	–	–
	CS31 bus processor reports an error via EW 07,15 bit 0. This bit is checked before each start of the PLC program.	136 _D	88 _H	–	–	–	–
	An illegal value has been configured (KW 00,10 or KW 00,11) for specifying the size of the I/O area between the master PLC and the slave PLC.	137 _D	89 _H	–	–	–	–
	More timers than available in the PLC were required during the execution time.	257 _D	101 _H	–	–	–	–
	An unknown operator/block is detected in the user program during the execution time.	258 _D	102 _H	–	–	–	–
	The CS31 bus processor does not work correctly. Therefore it does not authorize the operating processor to access the dual-port RAM.	259 _D	103 _H	–	–	–	–

Error class	Error description	Error identifier in MW 255,00 Dec Hex	Detailed info 1 in MW 255,01	Detailed info 2 in MW 255,02	Detailed info 3 in MW 255,03	Further detailed info in MW 255,04 : MW 255,07
FK3 Light error	Remote module disconnected	15 _D F _H	Module type	Group number	–	–
	CS31 bus error (there is no remote module on the bus) Note: If there are only analog modules connected to the CS31 system bus, this error message may occur when the supply voltage is switched on although the analog modules have been correctly adopted into the CS31 bus cycle after a certain time. Reason: The analog modules have a long initialization time. After this time is over, they only now appear at the CS31 bus as remote modules. During the initialization time the master PLC cannot recognize them.	16 _D 10 _H	–	–	–	–
	The Flash EPROM is not programmable.	128 _D 80 _H	Address of defective memory cell	–	–	–
	The Flash EPROM cannot be deleted.	129 _D 81 _H	Address of the memory cell which cannot be deleted	–	–	–
	The PLC application mode configured in the system constant KW 00,00 has not been activated yet. Please perform activation (see also system constant KW 00,00).	130 _D 82 _H	Value of KW 00,00 activated last	Value of KW 00,00 not yet activated	–	–
	CRC error in Flash EPROM	131 _D 83 _H	Address of the block with CRC error	Segment address of the block with CRC error	–	–

Error class	Error description	Error identifier in MW 255,08		Detailed info 1 in MW 255,09	Detailed info 2 in MW 255,10	Detailed info 3 in MW 255,11	Further detailed info in MW 255,12 : MW 255,15
		Dec	Hex				
FK4 Warning	Internal error of a remote module	1 _D	1 _H	Module type	Group number	Channel number	–
	Cut wire (open circuit)	2 _D	2 _H	Module type	Group number	Channel number	–
	Wrong level of an analog output	3 _D	3 _H	Module type	Group number	Channel number	–
	Overload	4 _D	4 _H	Module type	Group number	Channel number	–
	Overload + short circuit	6 _D	6 _H	Module type	Group number	Channel number	–
	Short circuit	8 _D	8 _H	Module type	Group number	Channel number	–
	Short circuit + cut wire	10 _D	A _H	Module type	Group number	Channel number	–
	Overload + short circuit	12 _D	C _H	Module type	Group number	Channel number	–
	Short circuit + overload + cut wire	14 _D	E _H	Module type	Group number	Channel number	–
	There is no user program when the system is started.	128 _D	80 _H	–	–	–	–
	During start-up, the system detects that the program end is missing	129 _D	81 _H	–	–	–	–
	During start-up, the system detects that the number of block parameters has not been specified correctly for a certain block.	130 _D	82 _H	Program address of the block	Progr. addr. of the faulty block parameter	–	–
	During start-up, the system detects a syntax error in the user program.	131 _D	83 _H	Program address	–	–	–
	During start-up, the system detects that the historical value memory is too small.	132 _D	84 _H	–	–	–	–
	During start-up, the system detects that no cycle time has been set.	133 _D	85 _H	–	–	–	–
	During start-up, the system detects that there are bracketing errors in the user program.	134 _D	86 _H	Program address	–	–	–
	During start-up, the system detects that the target label for a conditional jump is missing.	135 _D	87 _H	Program address	–	–	–


Error class	Error description	Error identifier in MW 255,08 Dec Hex	Detailed info 1 in MW 255,09	Detailed info 2 in MW 255,10	Detailed info 3 in MW 255,11	Further detailed info in MW 255,12 : MW 255,15
FK4 Warning	Internal error (non-maskable internal interrupt has occurred)	136_D 88_H	–	–	–	–
	Internal error (an inhibited interrupt has occurred)	137_D 89_H	–	–	–	–
	The PLC program is not started because the number of remote modules which are adopted into the CS31 bus cycle is smaller than the number configured in KW 00,09.	138_D 8A_H	Configured number of remote modules (KW 00,09)	Actual number of modules connected to the CS31 bus cycle	–	–
	The PLC does not access the process inputs and outputs yet because the number of remote modules which are adopted into the CS31 bus cycle is smaller than the number configured in KW 00,09.	139_D 8B_H	Configured number of remote modules (KW 00,09)	Actual number of modules connected to the CS31 bus cycle	–	–

A4.11 Reaction on the bus master central unit and the remote modules in case of errors

No.	Error	Display/reaction of the bus master central unit	Display/reaction of the input/output remote modules	Display/reaction of the slave central units
1	Bus master central unit has failed, e.g. because of power failure	No display, all outputs are off.	LED ③ lights up. All the outputs are turned to 0.	07 KR 91 / 07 KT 92/93: – LED BA is on – LED RE flashes – Bit 1 = 0 in the status word EW 07,15
2	Bus master function of the central unit (Serial Unit) has failed, e.g. the bus processor is defective	Displays: FK2 = Serious error RE = Remote Unit Error SE = Serial Unit Error Flags: M 255,10 = 1 M 255,12 = 1 for further flags see A4.7		07 KR 31 / 07 KT 31: – Error LED flashes – Bit 1 = 0 in the status word EW 07,15
3a	CS31 system bus is disconnected (all the remote modules are disconnected)	Displays: FK3 = Light error BE = Bus Error RE = Remote Unit Error SE = Serial Unit Error		
3b	CS31 system bus is short-circuited	Flags: M 255,10 = 1 M 255,13 = 1 for further flags see A4.7		
4a	CS31 system bus is disconnected (the remote modules are only disconnected in part)	Displays: FK3 = Light error BE = Bus Error SE = Serial Unit Error	Remote modules without connection to the bus master central unit: same as 1	Slave central units without connection to the bus master central unit: same as 1
4b		Flags: M 255,10 = 1 M 255,13 = 1 for further flags see A4.7	Remote modules with connection to the bus master central unit: no display/reaction	Slave central units with connection to the bus master central unit: no display/reaction
5a	A remote module has been lost on the CS31 system bus. Cause:	Displays: RE = Remote Unit Error Flags: M 255,10 = 1 M 255,13 = 1 for further flags see A4.7	Remote modules with connection to the bus master central unit: no display/reaction	Slave central units with connection to the bus master central unit: no display/reaction
5b	No connection to the CS31 system bus		Remote modules without connection to the bus master central unit: same as 1	Slave central unit without connection to the bus master central unit: same as 1
5c	defective remote module		not clear	Error class FK1 / FK2, all outputs turn to 0.
5d	Power failure		all outputs turned to 0	all outputs turned to 0
6a	An error has occurred at the inputs or outputs of a remote module, e.g. a short circuit.	same as 5	Concerned remote module: LED ③ light up, the LEDs ① supply by means of the test button ④ detailed infos.	Concerned 07 KT 92/93: LED K = Short circuit 07 KT 31: Error LED is ON Flags (07 KT 92 / 07 KT 93/ 07 KT 31): M 255,10 = 1 M 255,14 = 1 for further flags see A4.7
6b			Not concerned remote modules: no display/reaction	Not concerned slave central units: no display/reaction

Reaction on the bus master central unit and the remote modules in case of errors (continued)

No.	Error	Display/reaction of the bus master central unit	Display/reaction of the input/output remote modules	Display/reaction of the slave central units
7a	Two remote input modules of the same type have been set to the same address.	The error is detected only when the signal statuses of the two modules become different. The message is faulty in this case, and the modules are considered to be disconnected. Display: RE = Remote Unit Error Flags: M 255,10 = 1 M 255,13 = 1 for other flags see A4.7 / A4.10	Concerned modules: same as 1 Other modules: no display/reaction	same as 1
7b	Two remote modules of the same type have been set to the same address.	No reaction, unless there is a large distance between the remote modules.	Faultless operation of the two modules, unless they are far apart from each other.	Not applicable because inputs and outputs are always present.
7c	Two remote modules of different types, but with overlapping ranges have been set to the same address, e.g. ICSI 16 D1 and ICSK 20 F1.	The error is already detected during the initialization. The two remote modules are not adopted into the bus cycle.	Concerned modules: same as 1 Other modules: no display/reaction	Concerned modules: same as 1 Other modules: no display/reaction
7d	Address 62 or 63 has been set to a binary remote module.	Is not detected.	– Output of the signals in parallel to the bus master – Input signals are ignored.	–
7e	An address higher than 5 has been set to an analog remote module.	Is not detected.	same as 1	–



- Creation of the user program using the programming languages
 - Extended instruction list (ext. IL)
 - Function block diagram (FBD) and
 - Ladder diagram (LD)

Test in ext. IL, FBD and LD (see 907 PC 331)
- Test in terminal mode, e.g. in the programming software 907 PC 331 (main menu "PLC commun. 2", submenu "Terminal emulation")
- Test

The terminal interface has to be set to 9600 baud, 8 data bits, no parity bit and 1 stop bit.
- Test

Press the following <keys> in order to activate the terminal mode:

<CR>, <1> for TERMINAL, <2> for CHAR. MODE and <N> for data rate unchanged.

For the interfacing to the 07 KR 91 / 07 KT 92/93 see the following.

In order to establish the connection between the programming and test tools *and* the central unit 07 KR 91 / 07 KT 92 / 07 KT 93, the serial interface COM1 of the central unit 07 KR 91 / 07 KT 92 / 07 KT 93 has to be set to "Active mode" in all cases, see chapter "Serial interface COM1" in the description of the central unit.

A7 Operands of 07 KR 91, 07 KT 92 and 07 KT 93 (variables and constants)

A7.1 Freely available variables and constants

Inputs

E 00,00...E 61,15	:	Binary inputs, CS31 remote modules
E 62,00...E 63,03	:	Binary inputs of the central unit 07 KR 91
E 62,00...E 62,11	:	Binary inputs of the central unit 07 KT 92
E 62,00...E 63,07	:	Binary inputs of the central unit 07 KT 93
E 63,14 and E 63,15	:	High-speed binary inputs ($T_D = 8 \mu s$), signal is identical to E 62,00 and E 62,01
E 63,13	:	High-speed counter, interrogation of "Zero crossing"

EW 00,00...EW 05,15	:	Analog inputs, CS31 remote modules
EW 06,00...EW 06,03	:	Analog inputs of the central unit 07 KT 92
EW 06,15	:	High-speed counter, interrogation of the counter content
EW 07,00...EW 07,07	:	reserved
EW 07,08...EW 07,14	:	Reading of the real-time clock
EW 07,15	:	Status for CS31 system bus, clock, battery

Outputs

A 00,00...A 61,15	:	Binary outputs, CS31 remote modules
A 62,00...A 62,11	:	Binary outputs of the central unit 07 KR 91
A 62,00...A 62,07	:	Binary outputs of the central unit 07 KT 92
A 62,00...A 62,15	:	Binary outputs of the central unit 07 KT 93
A 62,00	:	High-speed counter, direct output of "Counter zero crossing" after activation
A 63,13...A 63,15	:	High-speed counter, enabling, activation of E 62,01 and A 62,00, adoption of start value

AW 00,00...AW 05,15	:	Analog outputs, CS31 remote modules
AW 06,00...AW 06,01	:	Analog outputs of the central unit 07 KT 92 (-10V...+10V)
AW 06,15	:	High-speed counter, "Start value"

Internal operands

M 00,00...M 255,09	:	Binary flags
S 00,00...S 127,15	:	Steps
K 00,00...K 00,01	:	Binary constants
MW 00,00...MW 253,15	:	Word flags
KW 01,00...KW 39,15	:	Word constants
MD 00,00...MD 31,15	:	Double word flags
KD 00,01...KD 07,15	:	Double word constants

Time values for time functions

KD yy,xx	:	Time values for time functions such as ESV, ASV etc. are configured as <i>double word constants</i> or as
MD yy,xx	:	<i>double word flags</i> . Only integral multiples of 5 ms are permitted.

A7.2 System constants / diagnosis flags / CS31 status (overview)

Setting the operating modes

The constants KW 00,00...KW 00,15 are reserved as system constants. Even the constants KW 00,13...KW 00,15 which are not used yet may *under no circumstances* be used for other purposes.

KW 00,00	:	Setting the PLC operating modes, (Stand-alone PLC, Master PLC, Slave PLC)
KW 00,01	:	Initialization: bit flag area
KW 00,02	:	Initialization: word flag area
KW 00,03	:	Initialization: double word flag area
KW 00,04	:	Initialization: step chain flag area
KW 00,05	:	Initialization: historical values
KW 00,06	:	Application modes of the serial interface COM 1
KW 00,07	:	PLC reaction to class 3 errors

- KW 00,08 : PLC reaction to an overload/short-circuit at the transistor outputs A 62,00...A 62,07 (A 62,15) (07 KT 92 and 07 KT 93 only)
- KW 00,09 : Initialization of the CS31 system after power ON, warm start or cold start
- KW 00,10 : Size of the transmitting area of the slave PLC
- KW 00,11 : Size of the receiving area of the slave PLC
- KW 00,12 : Automatic warm start after an FK2 error

Setting the cycle time

KD 00,00 : The cycle time of the PLC program is preset with this constant. The cycle time is given in the unit of measurement milliseconds. Only integral multiples of 5 ms are permitted.

Error diagnosis

- Summation error display : M 255,10 indicates, that the PLC has detected an error
- Fatal error, FK1 : M 255,11 = 1 i.e. error detected, detailed information in MW 254,00...MW 254,07
- Serious error, FK2 : M 255,12 = 1 i.e. error detected, detailed information in MW 254,08...MW 254,15
- Light error, FK3 : M 255,13 = 1 i.e. error detected, detailed information in MW 255,00...MW 255,07
- Warning, FK4 : M 255,14 = 1 i.e. error detected, detailed information in MW 255,08...MW 255,15

First-cycle detection

M 255,15

This binary flag can be used for detection of the *first* program cycle after a program start. It is always set to "zero" after each program start, independent of the initialization instructions given by the system constants. If this flag is read by the user program and then set to "1", it can be found out whether or not the user program was started once more.

CS31 status word

EW 07,15

- Bit 0 = 1 : No class 2 error present.
- Bit 1 = 1 : PLC has been adopted into the CS31 bus cycle (only relevant if used as a slave).
- Bit 2 = 1 : Time and date are valid.
- Bit 3 = 1 : Battery is effective.
- Bit 4..7 : Not used.
- Bit 8..15 : Maximum number of modules on the CS31 system bus, found out until now (only relevant if used as a master).

A7.3 System constants / Setting of operating modes

● **Definitions**

Cold start

- All of the RAM memories are tested and deleted.
- If there is *no user program* in the Flash–EPROM, the default values are set to all of the system constants (identical to the factory settings).
- If there is *a user program* in the Flash–EPROM, this program is loaded into the RAM including the system constants.
- The operating modes given by the system constants are set.
- The CS31 system bus is initialized again(only when used as a master on the CS31 system bus).

Performing a cold start

- Power OFF/ON, if there is *no* backup battery or
- Command KALT <CR> in terminal mode (see volume 7.3) or
- Menu field "Cold start" in the programming system

Warm start

- All of the RAM memories, with the exception of the program memory and the operand memory (flags), are tested and deleted.
- If there is *a user program* in the Flash–EPROM, this program is loaded into the RAM including the system constants.
- The operating modes given by the system constants are set.
- The CS31 system bus is initialized again(only when used as a master on the CS31 system bus).

Performing a warm start

- Power OFF/ON, if there is a backup battery or
- Command WARM <CR> in terminal mode (see volume 7.3) or
- Menu field "Release PLC mode" in the programming system

● Operating mode: Master PLC, Slave PLC or Stand-alone PLC

- Absolute identifier: KW 00,00
- Symbolic identifier: MAST_SLV
- Meaning of the value of the constants:
 - Master PLC at the CS31 system bus -1 (FFFF_H)
 - Stand-alone PLC -2 (FFFE_H)
 - Slave PLC at the CS 31 system bus module address CS31 module addresses 0...61
- Range of values: -2, -1, 0...61
- Default value: -2 (Stand-alone)

Important!

The change of the PLC operation mode is carried out in three steps:

1. Change system constant KW 00,00 in the PLC
2. Save PLC program in the Flash EPROM
3. Activate new PLC operating mode with the following steps:
 - Call menu point "Release PLC mode" in the ABB programming and test system or
 - perform a warm start or
 - perform a cold start.

● Back-up of data areas

Back-up of data areas, i.e. saving of data during power OFF/ON, is only feasible with built-in battery. The following data can be backed, completely or partly:

- Binary flags
- Word flags
- Double word flags
- Step chains
- Historical values

In order to back-up certain data, they have to be excluded from initialization to 0.

● Initialization of data areas

During *program start*, that data areas are initialized to 0 partly or completely, that are defined by system constants. The initialization works as shown in the following table.

If no battery is effective or if the system constants are in their default values (factory settings), all of the above mentioned data areas are completely set to 0 after power OFF/ON.

Conditions, —> Action	Flags, step chains, and historical values which are initialized (set to 0)
No battery available, —> Power ON	all
Menu item —> Abort —> Cold start	all
Battery effective, RUN/STOP switch to RUN, —> Power ON	according to the values of the system constants (see below)
RUN/STOP switch, —> RUN	
Menu item —> Abort —> Start	

Initialization: Binary flags

- Absolute identifier: KW 00,01
- Symbolic identifier: INIT_M

Value n of the system constant KW 00,01	Binary flag areas which are initialized (set to 0)
n = 0 (default)	M 000,00...M 255,15
n = 1...255	M n,00...M 255,15
n < 0, n > 255	M 255,10...M 255,15

- Example: KW 00,01 = 52
 Initialized is: M 52,00...M 255,15
 Backed is: M 00,00...M 51,15
 Precondition: Battery is available

Initialization: Word flags

- Absolute identifier: KW 00,02
- Symbolic identifier: INIT_MW

Value n of the system constant KW 00,02	Word flag areas which are initialized (set to 0)
n = 0 (default)	MW 000,00...MW 253,15
n = 1...253	MW n,00...MW 253,15
n < 0, n > 253	no initialization

Initialization: Double word flags

- Absolute identifier: KW 00,03
- Symbolic identifier: INIT_MD

Value n of the system constant KW 00,03	Double word flag areas which are initialized (set to 0)
n = 0 (default)	MD 00,00...MD 31,15
n = 1...31	MD n,00...MD 31,15
n < 0, n > 31	no initialization

Initialization: Step chains

- Absolute identifier: KW 00,04
- Symbolic identifier: INIT_S

Value n of the system constant KW 00,04	Step chain areas which are initialized (set to 0)
n = 0 (default)	S 000,00...S 127,15
n = 1...127	S n,00...S 127,15
n < 0, n > 127	no initialization

Initialization: Historical values

- Absolute identifier: KW 00,05
- Symbolic identifier: INIT_VW

Value n of the system constant KW 00,05	Historical values which are initialized (set to 0)
n = 0 (default)	Initialization of all historical values
n < 0, n > 0	no initialization

Application mode: Serial interface COM1

- Absolute identifier: KW 00,06
- Symbolic identifier: MODE_SST
- Default value: 0

Table: Conditions for the settings of the operating modes of the COM1 interface

RUN/STOP switch	System constant KW00,06	System cable/device	Mode set by this
STOP	x	x	Active
RUN	1	x	Active
	2	x	Passive
	0, <0, >2	07 SK 90	Active
07 SK 91, TCZ		Passive	

x: without effect

- A change of this system constant becomes effective:
 - immediately

SPS reaction to class 3 errors

- Absolute identifier: KW 00,07
- Symbolic identifier: FK3_REAK
- Meaning of the value of the constant:
 - Just output error: 0
 - Output error and abort PLC program: <0, >0
- Range of values: <0, =0, >0
- Default value: 0
 - i.e. just output error
- A change of this system constant becomes effective:
 - immediately

PLC reaction to the occurrence of an overload/short circuit at the direct transistor outputs A 62,00...A 62,07...A 62,15 (07 KT 92 and 07 KT 93 only)

- Absolute identifier: KW 00,08
- Symbolic identifier: ÜLAST_REAK
- Meaning of the value of the constant:
 - Overloaded output is switched on again automatically: 0
 - Overloaded output is **not** switched on again automatically: 1
- If another value than 0 or 1 is given, the PLC selects the standard setting "automatic reset"

- Range of values: 0, 1
- Default value: 0
i.e. the overloaded output is switched on again automatically by the PLC.

Important!

The change of the PLC reaction on an overload/short-circuit is carried out in three steps:

1. Change system constant KW 00,08 in the PLC
2. Save PLC program in Flash EPROM
3. Activate new PLC operating mode with the following steps:
 - perform a warm start or
 - perform a cold start.

● Initialization of the CS31 system after power ON, warm start or cold start

- Absolute identifier: KW 00,09
- Symbolic identifier: HOCHFAHR
- This system constant is only effective if the central unit is configured as a bus master.
- Meaning of the value of the constants:

The user program is started.
The central unit takes no notice of initialization of the CS31 remote modules and their adoption into the CS31 bus cycle: =0

The user program is not started until at least n remote modules have been initialized and adopted into the CS31 bus cycle: =+n

The user program is started.
It does not handle the process inputs and outputs until at least n remote modules have been initialized and adopted into the CS31 bus cycle. However, the CS31 status information in EW 07,15 is available as early as with the program start. This is also valid for the dual port RAM image of the two high-speed inputs at terminals 02 and 03: =-n
- Range of values: -31...+31
- Default value: 0
i.e. the user program is started immediately.

A change of this system constant becomes effective:

- with the next warm start or
- with the next cold start.

● Size of the transmitting area of the slave PLC

- Absolute identifier: KW 00,10
- Symbolic identifier: SLV_SEND
- Meaning of the value of the constants:

The slave PLC can be used at the CS31 system bus *either* in the binary area *or* in the word area. The binary values are transferred byte by byte. It is possible to set the number of bytes (or words) which are to be sent from the slave PLC to the master PLC.

 - For use in the binary area:

Transmitting: 0...15 bytes	0...15
----------------------------	--------
 - For use in the word area:

Transmitting 0...8 words	100...108
--------------------------	-----------
- Default value: 0
- Range of values: 0...15 and 100...108

A change of this system constant becomes effective:

- with the next warm start or
- with the next cold start.

Note:

The default setting

- in the binary area is:
 - transmit 4 bytes and
 - receive 4 bytes.

This is defined by the default combination KW 00,10 = KW 00,11 = 0.

The configured combination KW 00,10 = KW 00,11 = 4 has the same result as the default combination.

The combination

KW 00,10 = KW 00,11 = 100

is inadmissible! It would mean:

Transmit 0 words and receive 0 words.

When employed in the word area, the unused higher 8 channels of the address can be used by an analog modul (no KR/KT).

● Size of the receiving area of the slave PLC

- Absolute identifier: KW 00,11
- Symbolic identifier: SLV_REC
- Meaning of the value of the constants:

The slave PLC can be used at the CS31 system bus *either* in the binary area *or* in the word area. It is possible to set the number of bytes (or words) which are to be received by the slave PLC from the master PLC.

 - For use in the binary area:

Receiving: 0...15 bytes	0...15
-------------------------	--------
 - For use in the word area:

Receiving: 0...8 words	100...108
------------------------	-----------

- Default value: 0
- Range of values: 0...15 and 100...108

A change of this system constant becomes effective:

- with the next warm start or
- with the next cold start.

Note:

The default setting

- in the binary area is:
 - transmit 4 bytes and
 - receive 4 bytes.

This is defined by the default combination KW 00,10 = KW 00,11 = 0.

The configured combination KW 00,10 = KW 00,11 = 4 has the same result as the default combination.

The combination

KW 00,10 = KW 00,11 = 100

is inadmissible! It would mean:

Transmit 0 words and receive 0 words.

When employed in the word area, the unused higher 8 channels of the address can be used by an analog modul (no KR/KT).

● **Automatic warm start after an FK2 error**
(only for 07 KT 92)

- Absolute identifier: KW 00,12
- Symbolic identifier: SYSTEM
- By means of the system constant KW 00,12 an automatic warm start can be configured after an FK2 error:

Bit 0 of KW 00,12 = 0: no automatic warm start

Bit 0 von Kw 00,12 = 1: automatic warm start

The bits 1...15 of KW 00,12 have to be 0.

In the default setting KW 00,12 = 0 the module 07 KT 92 **R202/262** has the same behaviour as the module 07 KT 92 **R101** (no warm start after an FK2 error).

A change of this system constant becomes effective:

- with the next warm start.

● **PLC cycle time**

- Absolute identifier: KD 00,00
- Symbolic identifier: ZYKL_ZEIT
- Meaning of the value of the constants:
The PLC program is processed cyclically in the time intervals stated by the set cycle time. The entries are made in the unit of measurement [ms]. The smallest cycle time that can be entered is 5 ms. Only integral multiples of 5 ms are permissible.
- Range of values: ≥ 5
- Default value: 10

A change of this system constant becomes effective:

- with the next program start.


A8 The ARCnet system (Attached Resource Computer Network)

- ARCnet is a system for data transmission in local networks
- The ARCnet protocol is based on the Token Passing principle.
- By passing an identifier (token) from station to station it is guaranteed, that only one station can start a data transmission (transmission without collisions).
- The order of sequence, in which the stations are accessed, is automatically adapted by the existing conditions in the network, i.e. that the network is re-configured automatically each time a station is added to the network or switched off.

A8.1 The networking configurations

Linear ARCnet

- In the Linear ARCnet configuration, the stations are connected to one another directly, i.e. without using any distribution units.
- Each station is inserted into the network by using a T connector.
- Both cable ends must be terminated by termination resistors.
- A maximum of 8 stations can be connected to one linear ARCnet.
- The maximum length of the network is 300 m.
- An additional segment can be connected at the end of the wired segment via an Active Hub (active distribution unit), see next page.



Linear ARCnet, expanded by active distribution units (Active Hubs)

- Active Hubs amplify the arriving signals. So they stabilize the network configuration and allow especially for high distances. The Active Hub decouples the station

connectors from one another. Therefore, the entire network does not fail if one of the connections fails.

- The maximum length of the network is 6 km.
- A maximum of 255 stations can be used.




Fig.: Linear ARCnet, expanded by active distribution units (Active Hubs)

A8.2 The features of the ARCnet system

- Data transmission rate 2.5 MBit/s
- Coaxial cable of type RG62/U, 93 Ω
- Maximum number of stations: 255

Maximum distances

- The maximum distance between two stations amounts to 6 km.
- The maximum distance between an Active Hub and an ARCnet station or between two Active Hubs amounts to 600 m.
- The maximum distance between a Passive Hub and an ARCnet station or between an Active Hub and a Passive Hub is 30 m. A Passive Hub works like a resistor network which carries out the cable termination at the stations.
- The maximum distance within a Linear ARCnet is 300 m. A maximum of 8 stations can be connected.

Vol.	Description	Page
5.1	Central processing units PCZB/CS 20	1 - 1
5.2	Central processing units UCZA/UCZB	1 - 1



- Documentations : Ref. FPTC 404368 P2001-Edition 07.92 c.p.u. "**PCZB/CS 20**"
Ref. FPTC 404366 P2001-Edition 07.92 c.p.u. "**UCZA/UCZB**"
are still in force but are no longer included in this present April '94 edition.

- If required, above the documentation in the April '94 edition can be separately supplied on your request :
please quote : Ref. FPTC 404368 P2001-a Edition 04.94 c.p.u. "**PCZB/CS 20**"
Ref. FPTC 404366 P2001-a Edition 04.94 c.p.u. "**UCZA/UCZB**"


Vol.	Description	Page
7.2	Handheld terminal TCZ	
7.3	Monitor	0 - 1
7.4	Software PC 29	



- Documentations : Ref. FPTC 404369 P2001-Edition 07.92 "**Handheld terminal TCZ**"
 Ref. FPTC 404370 P2001-Edition 06.92/09.92 "**Software PC 29**"
 are still in force but are no longer included in this present November '96 edition.

- If required, above the documentation in the November '96 edition can be separately supplied on your request :
 please quote : Ref. FPTC 404369 P2001-a Edition 04.94 "**Handheld terminal TCZ**"
 Ref. FPTC 404370 P2001-a Edition 04.94 "**Software PC 29**"

Monitor



Regulations Concerning the Setting up of Installations

Apart from the basic "Regulations for the Setting up of Power Installations" DIN VDE* 0100 and for "The Rating of Creepage Distances and Clearances" DIN VDE 0110 Part 1 and Part 2 the regulations "The Equipment of Power Installations with Electrical Components" DIN VDE 0160 in conjunction with DIN VDE 0660 Part 500 have to be taken into due consideration.

Further attention has to be paid to DIN VDE 0113 Part 1 and Part 200 in case of the control of working and processing machines. If operating elements are to be mounted near parts with dangerous contact voltage DIN VDE 0106 Part 100 is additionally relevant.

If the protection against direct contact according to DIN VDE 0160 is required, this has to be ensured by the user (e.g. by incorporating the elements in a switch-gear cabinet). The devices are designed for pollution severity 2 in accordance with DIN VDE 0110 Part 1. If higher pollution is expected, the devices must be installed in appropriate housings.

The user has to guarantee that the devices and the components belonging to them are mounted following these regulations. For operating the machines and installations, other national and international relevant regulations, concerning prevention of accidents and using technical working means, also have to be met.

The ABB Procontic devices are designed according to IEC 1131 Part 2. Meeting this regulation, they are classified in overvoltage category II which is in conformance with DIN VDE 0110 Part 2.

For the direct connection of ABB Procontic devices, which are powered with or coupled to AC line voltages of overvoltage category III, appropriate protection measures corresponding to overvoltage category II according to IEC-Report 664/1980 and DIN VDE 0110 Part 1 are to install.

Equivalent standards:

DIN VDE 0110 Part 1 \triangleq IEC 664

DIN VDE 0113 Part 1 \triangleq EN 60204 Part 1

DIN VDE 0660 Part 500 \triangleq EN 60439-1 \triangleq IEC 439-1

All rights reserved to change design, size, weight, etc.

* VDE stands for "Association of German Electrical Engineers".

ABB Schalt- und Steuerungstechnik GmbH Heidelberg

Table of Contents

1	Operating and test functions	1– 1
1.1	Commands for creating the user program	1– 3
1.2	Commands for testing the user program	1– 9
1.3	Commands for configuring	1–17
1.4	Texts in the instruction list	1–22
1.5	Syntax diagram for instruction list (IL)	1–24
1.5.1	Syntax diagram: BOOLEAN SENTENCE	1–24
1.5.2	Syntax diagram: ARITHMETIC SENTENCE	1–25
1.5.3	Syntax diagram: HYBRID SENTENCE	1–26
2	Monitor functions	2– 1
3	Memory overview	3– 1
3.1	Memory overview for 07 KR 91, 07 KT 92 and 07 KT 93	3– 1
3.1.1	User program RAM	3– 1
3.1.2	User program Flash–EPROM	3– 1
3.1.3	Operand memory	3– 2
3.1.4	Dual–port RAM	3– 2
3.2	Memory overview for 07 KR 31, and 07 KT 31	3– 3
3.2.1	System addressing (Mapping)	3– 3
3.2.2	Data addressing (Data mapping)	3– 3

1 Operating and test functions

The operating and test functions of the PLC can be used with the aid of a terminal, the TCZ service device or the ABB Procontic programming system.

Note:

If the user works with the ABB Procontic programming and test system, this provides him with a convenient operator interface. When communicating with the control system, the ABB Procontic programming and test system uses the operating and test functions described in this chapter.

The ABB Procontic programming and test system has its own operating instructions.

Operator control commands

The operator control commands can be subdivided into:


- Commands for creating and modifying user programs
- Commands for testing the user programs
- Commands for configuring the PLC

Notes:

- User entries require no "blanks". Any "blanks" entered are ignored.
- In order to provide greater clarity when describing the commands, the user entries
 - for keywords are shown in **UPPER-CASE LETTERS**
 - and other entries (addresses etc.) are shown in lower-case letters.
- Outputs generated by the PLC software on the monitor are shown in *lower-case italics*.

All available commands are displayed with the HELP command on the screen.

Help command



Function:
All available operator control and test functions are

displayed on the monitor. Use <CR> to scroll the HELP text.

Note on service device TCZ:

The four-line liquid-crystal display (LCD) of the service device TCZ does not suffice to display this command.

Commands for creating the user program (overview)

Command Function	Page
AEND Prepare a program change on a running PLC program	1- 3
AEND Reject a program change which has not yet been enabled	1- 3
ALT Reject an enabled program change on a running PLC program and reactivate the old program status	1- 3
AL Display PLC capacity utilization	1- 3
CROSS *) Display CROSS reference list	1- 4
D Display program	1- 5
DEEP Erase PLC program on Flash EPROM	1- 5
F*) Search for string in user program (Find)	1- 5
FREI Enable a program change on a running PLC program	1- 5
IDA Display program identification	1- 6
IDR Delete program identification	1- 6
IDS Enter program identification	1- 6
K Enter/edit values of indirect constants	1- 6
NOP Delete program part, i.e. overwrite program part with NOPs ...	1- 7
O Optimize program	1- 7
P Display free program memory area	1- 8
PA*) Program preparation	1- 8
S Enter/edit user program (Substitute)	1- 8
SO*) Enter/edit user program without echo	1- 9
SP Save PLC program in Flash EPROM	1- 9
V Move user program	1- 9

*) **not** with 07 KR 31 / 07 KT 31
) **only with 07 KR 31 / 07 KT 31

Commands for testing the user program (overview)

Command	Function	Page
A	Abort user program	1– 9
BA*)	Display breakpoints	1–10
BR*)	Reset breakpoints	1–10
BS*)	Set breakpoints	1–10
<CTRL>W*)	Change-over between operator control functions <—> monitor	1–10
EA*)	I/O test mode	1–11
EAA*)	Deactivate I/O test mode	1–11
ES*)	Single-step mode ON	1–11
ESA*)	Single-step mode OFF	1–11
EZ*)	Single-cycle mode ON	1–11
EZA*)	Single-cycle mode OFF	1–12
FEHLER	Display contents of the error register	1–12
FORC	Enter Force values	1–12
FORC A	Display Force value	1–13
FORC R	Delete Forcing	1–13
G	Start user program	1–13
KALT	Perform cold-start	1–14
WARM	Perform warm start	1–14
L*)	Continue user program	1–14
PS	Display program status	1–14
ST	Display PLC status	1–14
TRACE*)	TRACE mode	1–15
TRACE*)	Display TRACE memory	1–15
TRACE E*)	Activate TRACE mode	1–15
TRACE A*)	Deactivate TRACE mode	1–15
W*)	Stop user program	1–15
Y	Overwrite value of a variable with a value to be entered	1–15
Z	Display status of variables	1–15
ZZ	Display only the values of the variables	1–16
ZD	Display and continually update status of variables	1–16

Commands for configuring


Command	Function	Page
KONFS	Display/change operating modes	1–17
MAIL	Configuration of CS31 remote modules	1–17
PASS **)	Activate / deactivate the password ..	1–21
UHR	Display time and date	1–21
UHRS	Set time and date	1–22

*) **not** with 07 KR 31 / 07 KT 31
) **only with 07 KR 31 / 07 KT 31

1.1 Commands for creating the user program

Prepare a program change on a running PLC program

Command:



Function:

The command announces to the PLC that modifications are to be carried out on the running PLC program. After this command has been entered, the PLC is ready to accept the program and constant modifications.

When command AEND is entered, all currently active test functions are deactivated. However, Force values of I/O signals remain active.

The following commands for program modifications and operation of the PLC are permitted after entering command AEND:

AL, CROSS, D, F, IDA, IDR, IDS, K, N, NOP, O, P, PA, S, SO, V, CTRL W, FEHLER, LED.

Reject a program change which has not yet been enabled


Entering the AEND command again rejects all program modifications performed to date, and the PLC is ready to accept program modifications again.

The following commands are activated with the program **running, and also** reject the AEND command and, thus, all program modifications performed after entry of the AEND command:

A, BA, BR, BS, EA, EAA, ES, ESA, EZ, EZA, FORC, FORC A, FORC R, G, L, PS, ST, TRACE, TRACE E, W, Y. Command AEND must be entered again in order to permit you to perform program modifications again.

Reject an enabled program change on a running PLC program and reactivate the old program status

Command:



Function:


Modifications which have been performed on a running PLC program **and** which have been enabled are rejected again. In addition, the PLC restores the old program status. The old program status is the status of the program which existed before the program modification, i.e. before entry of command AEND in the PLC.

After command ALT is entered, the old program status is reactivated within approximately 1 ms without further intervention on the part of the user.

The command can be used if the user recognizes that the program modifications implemented do not achieve the intended result.

Display PLC capacity utilization

Command:



Function:

The PLC's present capacity utilization is displayed in percent. This display indicates to what extent the capacity of the PLC is being utilized owing to execution of the user program.


The processor capacity which corresponds to the difference between 100 % and the capacity utilization display is available for operation of the serial interfaces, i.e. for communication with the devices connected to the serial interfaces. The utilization should not be greater than 95 % for the longest program path so that communication is still possible via the serial interfaces. Note that the capacity utilization of the PLC is also determined by the current program branches (conditional branches and consecutive number blocks).

Note:

The capacity utilization display provides a correct indication of the utilization caused by the user program only if *no communication* is occurring via the serial interfaces at the instant of display.

Display CROSS reference list

Command:



Where:

- E: Abbreviation for input
- A: Abbreviation for output
- S: Abbreviation for step
- M: Abbreviation for flag
- K: Abbreviation for constant
- W: Abbreviation for word variable
- D: Abbreviation for double-word variable
- nr: Number of the operand

Function:

The cross-reference list is the assignment of operands to

the program memory addresses at which they occur. The cross-reference list can be output for


- D all operands occurring in the program, entry: CROSS <CR>
- D a specific operand type, entry, e.g.: CROSS E <CR>
- D a single operand, entry, e.g.: CROSS KD 00,12 <CR>

Note on service device TCZ:

The four-line liquid-crystal display (LCD) of the service device TCZ does not suffice to display this command.

Display program

Command:



aa: Start address as of which the program is to be displayed

ea: End address of the program part to be displayed

L: Length (keyword)

az: Number of program memory words to be displayed

Function:

The specified program part is displayed.

Example:

- D 0,20 <CR>

The user program is displayed from address 0 through to address 20 on the monitor.

- D 10 L 20 <CR>

20 program memory words are displayed, starting from address 10.

Display format in the case of sentences:

```
start address operator operand
      :
      :
```

Display format in the case of block calls:

```
address n      !ba number
address n+1 type
address n+2 content of addr n+2
```

Example:


```
0000 !E 00,00
0002 &E 00,01
0004 =A 00,00
0006 !BA001
0007 AWT
0008 A 00,00
0009 KW 00,00
0010 KW 00,01
0011 AW 00,00
```

Note on service device TCZ:

This command can be used only with the following restriction: A maximum of three instructions can be displayed on the liquid-crystal display.

Erase PLC program on Flash EPROM

Command:




Function:

A PLC program stored on the Flash EPROM is erased (rendered invalid).

Search for string in user program (Find)

Command:



adr: Start address as of which searching is to be carried out. If no start address is entered, searching is performed as of address 0.

string: Maximum 8 commands, i.e. 16 words of the intermediate code.

Function:

The user program memory is searched for the string entered by the user as of the entered start address through to the end of the user program memory. If the string is found, the address is displayed. If the string occurs several times in the program, the next program address which corresponds to the string is displayed in each case if you enter a semicolon (;).

Example:

```
F, E 0,0 & E 0,1 <CR>
```


The entered string is sought as of the program memory start address 0.

```
F 100, !BA1 <CR>
```

Block call 1 is sought as of the program memory start address 100.

Enable a program change on a running PLC program

Command:



Function:


The modifications on a running PLC program performed after entry of command AEND are enabled for execution.

Before entry of command FREI, the program modifications performed are not yet executed by the PLC.

After entry of command FREI, the modifications performed are executed by the PLC. Command ALT can be used to reactivate the old program status. The functionality of the PLC program can be further–modified by a further program modification.

Display program identification

Command:




Function:

The identification entered by the user for the user program is displayed. If no identification has been issued for the program, nothing is displayed either (see also command: IDS).

Delete program identification

Command:




Function:

The identification entered by the user for the user program is deleted.

Enter program identification

Command:



Program identification: These characters are assigned as the identification to the user program.


*) No program identification is entered for this path. An already existing program identification is deleted.

Function:

The identification entered by the user for the user program is stored in the program memory. The identification may comprise maximum 16 characters. It serves, for instance, to store the project name and the creation date of the program in the PLC.

Enter/edit values of indirect constants


Command:



W: Abbreviation for word constants

D: Abbreviation for double–word constants

nr: Entered number of the constant



constant No. old value:

Displayed number and value of the constant.

new value: The user can overwrite the value of the displayed constant by a new value. In the case of the word and double–word constants, a hexadecimal value may also be entered in place of a decimal value. An H is prefixed to the numerical value for this purpose.

Caution: Values H8000 and H8000 0000 are forbidden in two's–complement arithmetic (practical only in the case of masks for instance).

:: Entering a semicolon results in display of number and value of the constant with the next number up. If the semicolon is entered without entering a new value, the old value of the displayed constant is retained.

↑: Entering character "↑" results in display of number and value of the constant with the next number down. If character "↑" is entered without entering a new value, the old value of the displayed constant is retained. (Use character "^" on the PC keyboard.)

<CR>: The command is terminated by entering a <CR>.

Function:

The required numerical values are assigned to the indirect constants.

This value assignment can also be performed with the user program running. This means that time values of timers can be modified when the system is running for instance.

Cycle time:

The cycle time is set with the double-word constant KD 00,00. The set cycle time must be an integral multiple of the basic time of 5 ms, i.e. 5 ms, 10 ms, 15 ms etc.

Example:

K 0,0 <CR>

Output of the number and value of the binary constant K 00,00. This value can be overwritten if required. If a semicolon is entered, the number and value of the next binary constant (K 00,01) is output.

KW 0,4 <CR>


Output of the number and value of the word constant KW 00,04.

KD 0,0 <CR>

Output of the number and value of the double-word constant KD 00,00. The cycle time is preset with this constant.

Delete program part, i.e. overwrite program part with NOPs

Command:



aa: Start address of the program part to be deleted

ea: End address of the program part to be deleted

L: Length (keyword)

az: Number of program memory words to be deleted

Function:

The specified program part is deleted. A prompt is displayed in order to establish whether you really do want to delete this program part before deletion. The user must once again either confirm deletion with "J" or cancel deletion with "N".

Example:

NOP 0,20 <CR>


The user program is deleted from address 0 through to address 20.

NOP 10 L 20 <CR>

20 program memory words are deleted, as of address 10.

Optimize program

Command:



aa: Start address of the area as of which the program memory is to be optimized.

ea: End address of the area

L: Length (keyword)

az: Number of program memory words

Function:

All NOPs are removed and the program is compressed in the given program part.

Example:

O 0 <CR>

The entire program memory is optimized.

O 0,10 <CR>


The program memory is optimized as of address 0 through to address 10.

O 10 L 10 <CR>

The NOPs within the next 10 program memory words as of address 10 are removed and the program is compressed accordingly.

Display free program memory area

Command:




Function:

The program memory is searched for NOPs from the end. If a word which does not correspond to an NOP is found in the intermediate code, the number of NOPs found, i.e. the number of free program memory words, is displayed.

Program preparation

Command:




Function:

The I/O signals planned in the user program are enabled in the I/O configuration list of the PLC. In addition, a syntax check is conducted for the user program. In the case of sentences with relational operators using bracketed expressions, the RIGHT BRACKET in front of the binary assignment is stored by the translator as a binary RIGHT BRACKET in the intermediate code. This binary RIGHT BRACKET is corrected to form a word bracket by program preparation. PA computes the target addresses and the historical values to be skipped for the branch blocks and consecutive number blocks. The PA command is called automatically each time the program is started (G command).

Enter/edit user program (Substitute)

Command:



adr: Program memory address as of which the program is to be entered or modified in instruction list.

address: The program memory address whose content is to be modified is displayed by the PLC.

content: Applies to block calls only. The content of the program memory address, translated back, is displayed.

command: Applies to sentences and the block header (number and type). The command or block header, translated back, is displayed, always as an entire command, i.e. operand and operator or block call and block type. If an address which does not point to the start of a command or to a block call is entered, this is corrected to the start of the command by the PLC.

content new: New content of the user program.

:: Entering a semicolon displays the subsequent program memory address and its content, and this can be modified if required. If no new 'content' is entered before the semicolon, the old content of the displayed program memory address remains unchanged.

Function:

Entering or modifying the PLC program in instruction list. A program memory word is selected and displayed on the monitor as an instruction or operand. The displayed content can then be overwritten.


Note:

You will also find the following information for entering/modifying the instruction list with this command at the end of this Appendix:

- Syntactic structure of the instruction list
- Instructions on how texts for function blocks DRUCK/EMAS are entered and displayed.

Enter/edit user program without echo

Command:



adr: Program memory address as of which the program is to be entered or modified


content new: New content of the user program

Function:

The program memory address as of which the program is to be entered is preset. The program can then be entered consecutively. The PLC returns *no* echo of the entered program. However, in the event of an error, the PLC returns an error message (e.g. Incorrect Entry).

Save PLC program in Flash EPROM

Command:




Function:

The PLC program is transferred from the RAM to the Flash EPROM. Character <*> is displayed on the monitor at intervals of approximately 1 second during programming.

Move user program

Command:



aa: Start address of program part to be moved

ea: End address

L: Length (keyword)

az: Number of program memory words by which the program part is to be moved

Function:

The program is moved from address aa to address ea or from address aa by the specified number of program memory words. The gap which results is filled with NOPs. New program parts can be inserted in this gap. Moving is possible only if the required space is still available at the end of the user program. However, this is checked automatically.

Example:

V 0,10 <CR>

The program is moved from address 0 to address 10. NOPs are inserted from address 0 through to address 9.


V 10 L 20 <CR>

The program is moved from address 10 by 20 program memory words to address 30, and 20 NOPs are inserted.

1.2 Commands for testing the user program

Abort user program

Command:




Function:

Execution of the user program is aborted. All outputs (binary and word) are set to zero. The user program can be restarted by entering "G".

Timers which have been started continue to run independently of the program status in the operating system. They are aborted only by a cold-start or power OFF/ON.

Display breakpoints

Command:



Function:

All breakpoints of the program are displayed. The address of the start of the command and its content are displayed and not the breakpoint address when the command is issued.


Note on service device TCZ:

This command can be used only with the following restriction:

A maximum of three program memory points at which breakpoints are set can be displayed on the liquid-crystal display (LCD).

Reset breakpoints

Command:



adr: Address of the breakpoint to be reset

,: If only specific breakpoints are reset, the individual addresses must be separated by a comma when entering.

Function:


The breakpoints can be reset individually. Command

BR <CR>

resets all breakpoints of the program.

Set breakpoints

Command:



adr: Address of the breakpoint

,: If several breakpoints are set, the addresses must be separated by a comma when entering.

Breakpoints can be set:

- to the address of the operand *after* an assignment character
- to the address of a RIGHT BRACKET
- to the address of the last parameter of a block
- to the address of the end of the program

Function:

After the program start, the program stops at the first breakpoint. Breakpoints may also be entered with the program running. A maximum of 15 breakpoints may be set.


Advancing to the next breakpoint: If a *semicolon* is entered, the program runs to the next breakpoint after expiry of the cycle time and displays the program address and the command at this address. If the next breakpoint is *not* reached after a specific period, owing to a long cycle time, the display operation can be aborted by entering <CTRL>C if required.

If a breakpoint is set to a program point which is *not* executed, e.g. owing to a branch, the program continues its cycles but with four times the cycle time, which may have a disadvantageous effect on the functionality.

Change-over between operator control functions

←→ monitor

Command:




Function:

Pressing key <CTRL> and key W simultaneously takes you to the monitor program of the PLC. This makes available certain basic functions at the monitor level to the user. If you are in the monitor program, you can switch back to the operating program of the PLC by entering <CTRL> and W again (see also chapter Monitor functions)

I/O test mode

Command:



Function:

This mode permits the user to check the wiring of his I/O signals from the PLC through to the process in order to ensure that the wiring is correct.


After starting the user program, it is *not* executed. Only the I/O signals planned in the program are operated, i.e. the input signals are read in and the output signals are brought out.

By actuating limit switches etc., it is possible to check whether the signals arrive under the declared designation in the PLC. By setting outputs in targeted manner, it is possible to check whether the signals arrive at the correct point in the process. Command Z or ZD can be used to display the required I/O variables in the PLC.

Command "EA" can also be entered with the program running. In this case, the mode does not take effect until the start of the next program cycle.

Deactivate I/O test mode

Command:




Function:

Mode I/O test is deactivated with this command, i.e. the user program continues to run normally as of this point. It is advisable to abort the program before deactivating the I/O test.

Single-step mode ON

Command:



Function:

After starting the program, only one sentence or one block is executed and the program stops after each assignment, RIGHT BRACKET and at the end of each block.

Command Z can be used to display variable values.


Command "ES" can also be entered with the program running. In this case, the mode does not take effect until the start of the next program cycle.

Advancing by one step:

If you enter a *semicolon*, the program runs to the next breakpoint after expiry of the cycle time and displays the program address and the command at this address. If the next breakpoint is *not* reached after a specific period, owing to a long cycle time, the display operation can be aborted by entering <CTRL>C if required.

Single-step mode OFF

Command:




Function:

Single-step mode is deactivated, i.e. the user program continues to run normally as of the current breakpoint.

Single-cycle mode ON

Command:



Function:

When the program is started, the program stops at the end of the program. Command "EZ" can also be entered with the program running.


The mode does not come into effect until the start of the next program cycle.

Advancing by one program cycle:

If a *semicolon* is entered, the program is run through *once* after expiry of the cycle time and displays the program address and the command at this address (!PE). If the next breakpoint is *not* reached after a specific period, owing to a long cycle time, the display operation can be aborted by entering <CTRL>C if required.

Single-cycle mode OFF

Command:




Function:

Single-cycle mode is deactivated, i.e. the program is executed normally again.

Display contents of the error register

Command:



Function:

The error information stored in the PLC is output.

Enter Force values

On the PLC, the user can "force" input signals and output signals. This means that values are preset for I/O signals by the user. The PLC then operates with the force values instead of the real input signals. In turn, the PLC issues the force values to the output devices and not the output signals computed in the PLC program. The force values apply until forcing is cancelled for individual I/O signals or for all I/O signals. Both the values supplied by the input devices and the values assigned to outputs in the PLC program thus have *no effect* during forcing. Forcing can be applied both to binary I/O signals and to word I/O signals.

Maximum number of I/O signals to be forced:

- Binary inputs: 64
- Word inputs: 16
- Binary outputs: 64
- Word outputs: 16

Forcing is performed in the following way:

Forcing inputs

The PLC generates an image of the input signals planned in the PLC program at the start of each program cycle. If inputs are to be forced, their real values are replaced by the force values preset by the user after read-in. The PLC operates only with the modified input image during the program cycle, and, thus, signal changes on the input device during the program cycle are unimportant.

Forcing outputs

At the end of the program cycle, the PLC transfers the output image of the output signals planned in the PLC program to the output devices. If outputs are to be forced, their real values are replaced by the force values before they are output in the output image.

Behavior after power failure, RESET or warm-start

After a power failure, the PLC has "forgotten" the force job. The list of I/O signals to be forced, entered *before* the power failure, is, however, still present in the PLC and can also be displayed with command FORC A <CR>. The *overall force list* is reactivated and forcing is placed back into effect by entering a single signal to be forced.


The following commands are available for forcing I/O signals:

- FORC: Enter force value
- FORC A: Display force value
- FORC R: Delete forcing

Enter force value

The name of the I/O signal to be forced and the force value are entered with command FORC.

Command: FORC Enter force value



name: Name of the input or output signal to be forced

value: Force value for the input or output


:: A semicolon is used as the separator between the name and the force value. If several inputs/outputs are to be forced, they must also be separated by a semicolon.

Function:

Entering the I/O signals to be forced and their values. The list specifying which inputs/outputs are to be forced is stored power-fail-safe in the operand memory of the PLC (if a battery is fitted).

Display force value

Command:



Function:

- Displaying all inputs and outputs to be forced
- Displaying all inputs/outputs of a specific group of inputs/outputs to be forced


Note on service device TCZ:

This command can be used only with the following restriction:

A maximum of three I/O signals with related force values can be displayed on the liquid-crystal display (LCD).

Delete forcing

Command:



name: Name of the inputs/outputs for which forcing is to be terminated


:: If forcing is terminated only for specific inputs/outputs, the individual names must be separated by a semicolon when entering them.

Function:

- (1) Terminating forcing for all I/O signals
- (2) Terminating forcing for *single* I/O signals
- (3) Terminating forcing for *one* specific group of I/O signals

Start user program

Command:




Function:

The user program is started and the operands are initialized.

The operand areas are initialized in accordance with the corresponding system constant.

Perform cold-start

Command:



Function:

The cold-start command is only allowed, when the PLC program is "aborted".


- All RAM memories will be tested and deleted.
- If there is *no user program* in the Flash EPROM, the default values will be set to all system constants (same as factory setting).
- If there is *a user program* in the Flash EPROM, this will be stored in the RAM inclusive the system constants.
- The operating modes defined by the system constants will be adjusted.
- The CS31 system bus will be initialized again (only in case of CS31 system bus master)

Performing a cold start

- Command KALT <CR> in terminal mode or
- Voltage OFF/ON, when *no* battery is existing or
- menu item "Kaltstart" in the programming system

Perform warm start

Command:



Function:

The warm start command is only allowed, when the PLC program is "aborted".

Warm start


- All RAM memories will be tested and deleted with the exception of program memories and operand memories.
- If there is *a user program* in the Flash EPROM, this will be stored in the RAM inclusive the system constants.
- The operating modes defined by the system constants will be adjusted.
- The CS31 system bus will be initialized again (only in case of CS31 system bus master)

Performing a warm start

- Command WARM <CR> in terminal mode or
- Voltage OFF/ON, if a battery is existing or
- menu item "Enable PLC mode" in the programming system

Continue user program

Command:




Function:

The user program is continued after a preceding stop ("W"). When continuing, the flags and internal statuses have the same value as with program stop.

Timers which have started continue to run independently of the program status in the operating system. They are aborted only by a cold-start or power OFF/ON.

Display program status

Command:




Function:

The status (program at breakpoint, program aborted, program stopped, program running) of the user program is displayed.

Display PLC status

Command:




Function:

The entire PLC status is displayed as follows:


- Program identification
- Cycle time
- Program status
- Active test functions
- TRACE registers
- Error messages
- Capacity utilization

TRACE mode


Command: Display TRACE memory



Command: Activate TRACE mode



Command: Deactivate TRACE mode




Function:

In TRACE mode, the PLC notes the address of the block last executed or the address of the instruction last executed. After a system crash, the operator is thus provided with information as to how far the user program has been executed. The contents of the TRACE memory are retained in the event of a RESET.

Stop user program

Command:




Function:

The user program is stopped.

The values of the outputs and of the flags are retained. Timers which have been started continue to run independently of the program status in the operating system. They are aborted only by a cold-start or power OFF/ON.

Overwrite value of a variable with a value to be entered

Command:



var: Name of the variable or indirect constant

value: New value which is to be assigned to the variable

:: There must be a semicolon between the name and the value of the variable. If several variables are to be overwritten, these must also be separated by a semicolon.


Note:

If the variable is a step variable, it can only be set and not reset. When step variables are set, all other steps of the chain are automatically reset.

If an indirect constant is modified with this command, this modification is performed only in the operand memory and not in the program memory, i.e. this value is overwritten again by the value from the program memory with the next program start.

Display status of variables


Command:



var: Variable (flag, step, input, output, indirect constant) to be displayed

:: The individual variables must be separated by semicolons.

L number: Number of consecutively numbered variables as of the variable var which are to be displayed.
 Example: M 0,0 L 3
 The following are displayed:
 M 0,0 M 0,1 M 0,2



Z: The values of the variables (max. 22) are each updated when character Z <CR> is entered.

Function:

The variable names preset by the user are displayed on the monitor. The value of this variable is updated each time character Z <CR> is entered. The displayed variable values always originate from the same program cycle and represent a "snapshot" at the end of the cycle.

The number of variables to be displayed is restricted to 22 with this command since no more screen lines than this are available.

Note on service device TCZ:

This command can be used only with the following restriction: Only the status of one variable is displayed.

Computer connection instead of terminal

If a computer is connected instead of the terminal for evaluation of the status values, the following commands may also be used if required instead of Z (same syntax diagram as with command Z):

ZO: Number of possible variables maximum 120, otherwise as for command Z.


Screen control: In the case of commands Z, ZO and ZD, the following control characters are used by the PLC for screen control:

- Carriage return: <CR>
- Line feed: <LF>
- Clear screen: <ESC>[2J
- Position cursor: <ESC>[<line>;<column>H

ZZ: Number of possible variables maximum 120. The PLC sends no ESC sequences to the screen controller, but only the variable values, each followed by a <CR>. The variable values have the same order as the preset variable list, otherwise as with command Z.

Display and continually update status of variables

Command:




var: Variable (flag, input, output, indirect constant) to be displayed

:: The individual variables must be separated by semicolons.

L number: Number of consecutively numbered variables as of the variable var which are to be displayed.

Example: M 0,0 L 3

The following are displayed:
 M 0,0 M 0,1 M 0,2



Function:

The variable names preset by the user are displayed on the monitor. The related variable values are updated automatically. The displayed variable values always originate from the same program cycle and represent a "snapshot" at the end of the cycle.

The maximum number is 22. The command is terminated by a <CTRL>C.

If character Z <CR> or ZD <CR> is then entered, the status display is reactivated for the previously entered variables.

Note on service device TCZ:


This command can be used only with the following restriction:

Only the status of one variable is displayed.

1.3 Commands for configuring

Display/change operating modes

Command:



Function:

After command KONFS <CR> is entered, the set language is displayed on the monitor. If you press key <DELETE> (<CTRL> and the Backspace key on PCs), the language is switched over. The command is terminated by entering a <CR>.

Note:


The DELETE key is frequently not available on personal computers. The key code (7FH) of the DELETE key can be generated on such keyboards by pressing two keys. In general, these keys are keys <CTRL> and the Backspace key.

Note on service device TCZ:

On the servicing unit TCZ, you switch over by pressing keys <CTRL> and one after the other.

Configuration / interrogation of the configuration of CS31 remote modules (07 KR 91, 07 KT 92, 07 KT 93)

Command:



grn: Group number with which the local module is addressed by the PLC program

code: Job code

d1: 1st data byte of the job

: : :

d8: 8th data byte of the job

:: The individual values of the job must be separated by semicolons.

status: Status of the response:
51 (OK response)
170 (Not-OK response)

a1: 1st data byte of the response

: : :

a7: 7th data byte of the response

:: The individual values of the response are separated by semicolons.

Function:

The user has the option of configuring CS31 remote modules and interrogating the set configuration. The jobs are handled internally via a transmit mailbox (job) and receive mailbox (response).

List of jobs:

The OK responses are described for the relevant jobs.

The not-OK responses of the individual jobs are always as follows:

- **Not-OK response**

status: 170

- a1:* 1 = Unknown job code
 2 = Invalid parameter,
 e.g. group number
 3 = Remote module does not respond
 10 = Mail box not free within 3 sec.
 11 = Job has been aborted owing to
 actuation of the RUN/STOP switch
 12 = Job is not fetched within 6 sec.
 13 = No reply within 6 sec.

a2...a7: 0

- **Updating the maximum number of remote modules detected.**

The contents of the input word EW 07,15 include the maximum number of remote modules detected in the past. The current actual number of existing remote modules may be less than this.

This command updates this value. The existing modules are counted and the value is stored.

The user can interrogate this value in the PLC program (EW 07,15, bits 8...15).

- **Job**

grn: 255 (Master PLC with bus)
code: 132
d1...d8: Not used

- **OK response**

status: 51
a1...a7: 0

- **Interrogation whether open-circuit monitoring is activated or deactivated for an input**

- **Job**

grn: Group number 0...63
code: 32
d1: Channel number 0...15
d2...d8: Not used

- **OK response**

status: 51
a1: 47 = Open-circuit monitoring ON
 32 = Open-circuit monitoring OFF
a2...a7: 0

- **Interrogation whether open-circuit monitoring is activated or deactivated for an output**

- **Job**

grn: Group number 0...63
code: 33
d1: Channel number 0...15
d2...d8: Not used

- **OK response**

status: 51
a1: 47 = Open-circuit monitoring ON
 32 = Open-circuit monitoring OFF
a2...a7: 0

- **Activating or deactivating open-circuit monitoring of an input**

- **Job**

grn: Group number 0...63
code: 224 = Open-circuit monitoring ON
 160 = Open-circuit monitoring OFF
d1: Channel number 0...15
d2...d8: Not used

- **OK response**

status: 51
a1...a7: 0

- **Activating or deactivating open-circuit monitoring of an output**

- **Job**

grn: Group number 0...63
code: 225 = Open-circuit monitoring ON
 161 = Open-circuit monitoring OFF
d1: Channel number 0...15
d2...d8: Not used

- **OK response**

status: 51
a1...a7: 0

- **Interrogation whether a channel is configured as an input or as an input/output**

- **Job**

grn: Group number 0...63
code: 34
d1: Channel number 0...15
d2...d8: Not used

- **OK response**

status: 51
a1: 34 = Input
 35 = Input/output
a2...a7: 0

- **Configuration of a channel as an input or input/output**

- **Job**

grn: Group number 0...63
code: 162 = Input
 163 = Input/output
d1: Channel number 0...15
d2...d8: Not used

- **OK response**

status: 51
a1...a7: 0

- **Interrogation of the input delay of a channel**

- **Job**

- grn: Group number 0...63
 - code: 38
 - d1: Channel number 0...15
 - d2...d8: Not used

- **OK response**

- status:* 51
 - a1:* Input delay:
 - 2 = 2 ms
 - 4 = 4 ms
 - .
 - .
 - .
 - 30 = 30 ms
 - 32 = 32 ms
 - a2...a7:* 0

- **Setting the input delay of a channel**

- **Job**

- grn: Group number 0...63
 - code: 166
 - d1: Channel number 0...15
 - d2: Input delay
 - 2 = 2 ms
 - 4 = 4 ms
 - .
 - .
 - .
 - 30 = 30 ms
 - 32 = 32 ms
 - d3...d8: Not used

- **OK response**

- status:* 51
 - a1...a7:* 0

- **Acknowledging error on remote module**

This command resets the error messages registered on the selected remote module. The error messages can be reset only if the cause of the error has been remedied.

- **Job**

- grn: Group number 0...63
 - code: 232
 - d1: First channel number on the module:
 - 0 = First channel number on the module is 0 (≤ 7)
 - 8 = First channel number on the module is 8 (> 7)

- d2: Module type:
 - 0 = Binary input
 - 1 = Analog input
 - 2 = Binary output
 - 3 = Analog output
 - 4 = Binary input/output
 - 5 = Analog input/output

Note:

Bit: even number (0, 2, 4)
Word: odd number (1, 3, 5)

d3...d8: Not used

- **OK response**

- status:* 51
 - a1...a7:* 0

- **Acknowledging errors on remote module and resetting configuration values to default setting**

In addition to job "Acknowledging error on remote module", all configurable settings are reset to the default setting.

- **Job**

- grn: Group number 0...63
 - code: 233
 - d1: First channel number on the module:
 - 0 = First channel number on the module is 0 (≤ 7)
 - 8 = First channel number on the module is 8 (> 7)

- d2: Module type:
 - 0 = Binary input
 - 1 = Analog input
 - 2 = Binary output
 - 3 = Analog output
 - 4 = Binary input/output
 - 5 = Analog input/output

Note:

Bit: even number (0, 2, 4)
Word: odd number (1, 3, 5)

d3...d8: Not used

- **OK response**

- status:* 51
 - a1...a7:* 0

- **Interrogation of the configuration of an analog input**

- **Job**

- grn: Group number 0...63
 - code: 42
 - d1: Channel number 0...15
 - d2...d8: Not used

- **OK response**

- status:* 51
 - a1:* 50 = Input 0...20 mA
49 = Input 4...20 mA
 - a2...a7:* 0

- **Interrogation of the configuration of an analog output**

- **Job**

- grn: Group number 0...63
 - code: 43
 - d1: Channel number 0...15
 - d2...d8: Not used

- **OK response**
status: 51
a1: 50 = Output 0...20 mA
49 = Output 4...20 mA
51 = Output \pm 10V
a2...a7: 0
- **Configuration of an analog input**
 - **Job**
grn: Group number 0...63
code: 170
d1: Channel number 0...15
d2: 50 = Input 0...20 mA
49 = Input 4...20 mA
d3...d8: Not used
 - **OK response**
status: 51
a1...a7: 0
- **Configuration of an analog output**
 - **Job**
grn: Group number 0...63
code: 171
d1: Channel number 0...15
d2: 50 = Output 0...20 mA
49 = Output 4...20 mA
51 = Output \pm 10V
d3...d8: Not used
 - **OK response**
status: 51
a1...a7: 0
- **Interrogation of the bus configuration**
The bus interface of the Master PLC has a list which stores specific data of the remote modules. In this list, the remote modules are numbered in the order in which they are encountered on the CS31 bus. This command involves specifying the internal number of the modules. The response received is the group number stored under this number and the status information on the corresponding module.
 - **Job**
grn: 0 (is not evaluated)
code: 80
d1: Number from the module list (1...31)
d2...d8: Not used
 - **OK response**
status: 51
a1: Status of the remote module:
Bits 0...3: Number of process data bytes (binary module) or words (word module) sent by the module to the Master.
Bits 4...7: Number of process data bytes (binary module) or words (word module) sent by the Master to the module.
a2: Group number (0...63)
- **Reading 1...6 bytes (07 KR 91, 07 KT 92, 07 KT 93)**
 - **Job**
grn: Group number 0...63
code: 49 = Read 1 byte
50 = Read 2 bytes
51 = Read 3 bytes
52 = Read 4 bytes
53 = Read 5 bytes
54 = Read 6 bytes
d1: First channel number on the module:
0 = First channel number on the module is 0 (\leq 7)
8 = First channel number on the module is 8 ($>$ 7)
d2: Module type:
0 = Binary input
1 = Analog input
2 = Binary output
3 = Analog output
4 = Binary input/output
5 = Analog input/output
Note:
Bit: even number (0, 2, 4)
Word: odd number (1, 3, 5)
d3: Byte start address (low byte)
d4: Byte start address (high byte)
d5...d8: Not used
 - **OK response**
status: 51
a1: Value of the 1st byte
a2: Value of the 2nd byte or 0
a3: Value of the 3rd byte or 0
a4: Value of the 4th byte or 0
a5: Value of the 5th byte or 0
a6: Value of the 6th byte or 0
a7: 0
- **Reading 1 bit of 1 byte**
 - **Job**
grn: Group number 0...63
code: 63
d1: First channel number on the module:
0 = First channel number on the module is 0 (\leq 7)
8 = First channel number on the module is 8 ($>$ 7)
d2: Module type:
0 = Binary input
1 = Analog input
2 = Binary output
3 = Analog output
4 = Binary input/output
5 = Analog input/output

Note:
 Bit: even number (0, 2, 4)
 Word: odd number (1, 3, 5)

d3: Byte start address (low byte)
 d4: Byte start address (high byte)
 d5: Bit position within the byte 0...7
 d6...d8: Not used

• **OK response**

status: 51
a1: Bit value (0 or 1)
a2...a7: 0

• **Writing 1...4 bytes
 (07 KR 91, 07 KT 92, 07 KT 93)**

• **Job**

grn: Group number 0...63
code: 65 = Write 1 byte
 66 = Write 2 bytes
 67 = Write 3 bytes
 68 = Write 4 bytes

d1: First channel number on the module:
 0 = First channel number on the module is 0 (≤ 7)
 8 = First channel number on the module is 8 (> 7)

d2: Module type:
 0 = Binary input
 1 = Analog input
 2 = Binary output
 3 = Analog output
 4 = Binary input/output
 5 = Analog input/output

Note:
 Bit: even number (0, 2, 4)
 Word: odd number (1, 3, 5)

d3: Byte start address (low byte)
 d4: Byte start address (high byte)
 d5: Value of the 1st byte
 d6: Value of the 2nd byte or not used
 d7: Value of the 3rd byte or not used
 d8: Value of the 4th byte or not used

• **OK response**

status: 51
a1...a7: 0

• **Writing 1 bit of a byte**

• **Job**

grn: Group number 0...63
code: 79
 d1: First channel number on the module:
 0 = First channel number on the module is 0 (≤ 7)
 8 = First channel number on the module is 8 (> 7)

d2: Module type:
 0 = Binary input
 1 = Analog input
 2 = Binary output
 3 = Analog output
 4 = Binary input/output
 5 = Analog input/output

Note:
 Bit: even number (0, 2, 4)
 Word: odd number (1, 3, 5)


d3: Byte start address (low byte)
 d4: Byte start address (high byte)
 d5: Bit position within byte 0...7
 d6: Bit value (0 or 1)
 d7...d8: Not used

• **OK response**

status: 51
a1...a7: 0

Password (only with 07 KR 31 / 07 KT 31)

Command:



Function:

The command PASS value activates or deactivates the password. As a password, any 4-digit hexadecimal number (except 0000) can be used. If a password is activated, the following commands are disabled: AEND, D, DEEP, FREI, N, NOP, O, S, V.

Value: Any 4-digit hexadecimal number.


Caution: The value of 0000 has no effect.

status: The activation or deactivation of the password is displayed.

Display time and date

(07 KR 91, 07 KT 92, 07 KT 93)

Command:



Function:

The time and date are displayed on the monitor in the following form:

SYSTEM TIME : HH:MM:SS
 SYSTEM DATE : DAY OF WEEK TT.MM.JJ

where:


HH: Hours
 MM: Minutes
 SS: Seconds
 DAY OF WEEK: Name of the day of the week
 TT: Day
 MM: Month
 JJ: Year

Note on service device TCZ:

The four-line liquid-crystal display (LCD) of the servicing unit TCZ does not suffice to display this command.

Set time and date

Command:



Function:

Setting the time and date. For the day of the week, the clock manages a number between 1 and 7 internally. When converting the number to the name, it assumes that Monday is the first day of the week (number 1 →

Monday). If the clock is set with block UHR (see also Block catalog), a different number may then be assigned to Monday. In this case, the display of the day of the week no longer corresponds to the command UHR <CR> since the display function always assumes that Monday is assigned the number 1.

hh or *hh*: Hours
mm or *mm*: Minutes
ss or *ss*: Seconds
tt or *tt*: Day
mm or *mm*: Month
jj or *jj*: Year
day of week: Name of the day of the week
n: Enter for 'no'
j: Enter for 'yes'

1.4 Texts in the instruction list

Certain PLC blocks (DRUCK, EMAS) operate with texts stored in the user program.

Entering the texts in the user program

A text is entered with the terminal or service device TCZ embedded in the code characters #” and ”#. The key code character #” identifies the start of a text string and the key code character ”# identifies the end of a text string.

All ASCII characters between 0_H and 7F_H may be entered.

Storing the texts in the user program

Each text character entered occupies *one* word in the user program. The ASCII code of the text character is stored in the low byte and the prefix FA is stored in the high byte.

Example:

Text entry and storage as of address 100 in the PLC program:

Entry: S 100 <CR>
 00100 NOP
 #”ABB”#<CR>

Storage: 00100 FA41
 00101 FA42
 00102 FA42

Overview of the possible text characters, how they are entered and how they are displayed on a monitor

ASCII char-acter	Hex-value	User entry	Display	ASCII char-acter	Hex-value	User entry	Display	ASCII char-acter	Hex-value	User entry	Display
NUL	00	<CTRL><SP>	<NUL> *					b	62	b	b
SOH	01	<CTRL> A	<SOH>					c	63	c	c
STX	02	<CTRL> B	<STX>					d	64	d	d
ETX	03	<CTRL> C	<ETX>					e	65	e	e
EOT	04	<CTRL> D	<EOT>					f	66	f	f
ENQ	05	<CTRL> E	<ENQ>					g	67	g	g
ACK	06	<CTRL> F	<ACK>					h	68	h	h
BEL	07	<CTRL> G	<BEL>					i	69	i	i
BS	08	<CTRL> H	<BS>					j	6A	j	j
HT	09	<CTRL> I	<HT>	:	3A	:	:	k	6B	k	k
LF	0A	<CTRL> J	<LF>	;	3B	;	;	l	6C	l	l
VT	0B	<CTRL> K	<VT>	<	3C	<	<	m	6D	m	m
FF	0C	<CTRL> L	<FF>	=	3D	=	=	n	6E	n	n
CR	0D	<CTRL> M	<CR>	>	3E	>	>	o	6F	o	o
SO	0E	<CTRL> N	<SO>	?	3F	?	?	p	70	p	p
SI	0F	<CTRL> O	<SI>	@	40	@	@	q	71	q	q
DLE	10	<CTRL> P	<DLE>	A	41	A	A	r	72	r	r
DC1	11	<CTRL> Q	<DC1>	B	42	B	B	s	73	s	s
DC2	12	<CTRL> R	<DC2>	C	43	C	C	t	74	t	t
DC3	13	<CTRL> S	<DC3>	D	44	D	D	u	75	u	u
DC4	14	<CTRL> T	<DC4>	E	45	E	E	v	76	v	v
NAK	15	<CTRL> U	<NAK>	F	46	F	F	w	77	w	w
SYN	16	<CTRL> V	<SYN>	G	47	G	G	x	78	x	x
ETB	17	<CTRL> W	<ETB>	H	48	H	H	y	79	y	y
CAN	18	<CTRL> X	<CAN>	I	49	I	I	z	7A	z	z
EM	19	<CTRL> Y		J	4A	J	J	{	7B	{	{
SUB	1A	<CTRL> Z	<SUB>	K	4B	K	K		7C		
ESC	1B	<CTRL> [<ESC>	L	4C	L	L	}	7D	}	}
FS	1C	<CTRL> /	<FS>	M	4D	M	M	~	7E	~	~
GS	1D	<CTRL>]	<GS>	N	4E	N	N	DEL	7F		
RS	1E	<CTRL> ~	<RS> *	O	4F	O	O				
US	1F	<CTRL> ?	<US> *	P	50	P	P				
SP	20	<SP>	<SP> **	Q	51	Q	Q				
!	21	!	!	R	52	R	R				
"	22	"	"	S	53	S	S				
#	23	#	#	T	54	T	T				
\$	24	\$	\$	U	55	U	U				
%	25	%	%	V	56	V	V				
&	26	&	&	W	57	W	W				
'	27	'	'	X	58	X	X				
(28	((Y	59	Y	Y				
)	29))	Z	5A	Z	Z				
*	2A	*	*	[5B	[[
+	2B	+	+	\	5C	\	\				
,	2C	,	,]	5D]]				
-	2D	-	-	↑	5E	↑	↑				
.	2E	.	.	—	5F	—	—				
/	2F	/	/	'	60	'	'				
0	30	0	0	a	61	a	a				

* To older terminals applies:

NUL	0	<CTRL> @	<NUL>
RS	1E	<CTRL> ↑	<RS>
US	1F	<CTRL> _	<US>

** In the case of *text entry*, a SPACE is displayed as a blank. When *displaying* the user program, it is displayed as <SP> in order to permit it to be recognized easier.

Note:

Interrelationship between value and ASCII character

Binary value in the computer
1011 (0B_H, 11_{DEC})


Represented as:

- Decimal ASCII: 31_H, 31_H
- Hexadecimal ASCII: 42_H

Output by DRUCK as hexadecimal value: 1011

1.5 Syntax diagrams for instruction list (IL)

1.5.1 Syntax diagram: BOOLEAN SENTENCE




Signal flow: in the direction of arrow, otherwise from left to right.

Brackets: sum "LEFT BRACKET" = sum "RIGHT BRACKET", nesting depth: 15.

B-OPR: Binary operand (E, A, M, S, K)
Example: E 00,03 A 07,06 M 05,01 S 05,04 K 00,01

1.5.2 Syntax diagram: ARITHMETIC SENTENCE



Signal flow: in direction of arrow, otherwise from left to right.


Brackets: sum "LEFT BRACKET" = sum "RIGHT BRACKET", nesting depth: 15.

W-OPR: Word operand (EW, AW, MW, KW)

Example: EW 03,05 AW 11,12 MW 22,15 KW 09,06

1.5.3 Syntax diagram: HYBRID SENTENCE

See also chapter "Language repertoire", Relational operators



Signal flow: in direction of arrow, otherwise from left to right.

Brackets: sum "LEFT BRACKET" = sum "RIGHT BRACKET", nesting depth: 15.

W-OPR: Word operand (EW, AW, MW, KW)
Example: EW 03,05 AW 11,12 MW 22,15 KW 09,06

B-OPR: Binary operand (E, A, M, S, K)
Example: E 00,03 A 07,06 M 05,01


2 Monitor functions

The monitor program offers the specialist access at hexadecimal level to the entire address range of the PLC. Memory areas can be displayed and modified, and hardware tests can be conducted.

Monitor commands which change memory areas may endanger the functionality of the PLC. For this reason, take care when using the monitor functions.

Switchover Operator-control functions \longleftrightarrow Monitor functions

Command:



Not available in 07 KR 31 / 07 KT 31

Function:

By pressing key <CTRL> and key W simultaneously, you access the monitor program of the PLC. If you are in the monitor program, you can change back to the operator-control program of the PLC by entering <CTRL> and W again.

Explanation of the syntax:

- The monitor program responds with character * and waits for an entry.
- All numbers are hexadecimal numbers (leading zeroes may be omitted).
- If more digits than necessary are entered, only the last digits are valid (the last two digits in the case of byte commands and the last four digits in the case of word commands).
- The blank character (Space) is ignored and can be used for more clearly structured entries.
- Character CTRL C aborts the currently running operation.
- Every display on the monitor can be stopped with <CTRL>S (XOFF) and can be continued with <CTRL>Q (XON).
- If no segment is specified when entering an address, the working segment is used (see Y instruction).


Overview of the monitor functions

Function	Explanation	Page
H	Display help text / calculate hexadecimally	2-1
D	Display memory contents	2-2
I	Fill memory area with a value	2-2
M	Transfer memory areas	2-3
P	Read/write port	2-3
S	Display/edit memory contents	2-4
U/V	Edit address output format	2-4
Y	Display/edit working segment	2-4
ZA	Cyclic read and write	2-4
ZB	Cyclic read and write with waiting time	2-5
ZC	Read and write on keystroke	2-5
ZD	Cyclic write	2-5
ZE	Cyclic read	2-5
ZF	Cyclic write and read	2-5
ZG	Simultaneous output of 3 values	2-6
ZR	RAM test	2-6
ZZA	Output of 3 values after entering a semicolon (;)	2-7
ZZF	Search for string	2-7
ZZV	Compare memory areas word-serially	2-8
R	Read Intel HEX file	2-9
W	Write Intel HEX file	2-9

Display help text / calculate hexadecimally

When command H <CR> is entered, all available functions of the monitor are displayed on the screen. In addition, this command permits you to calculate simple hexadecimal arithmetic expressions.

Command:




hex: Hexadecimal number

Display memory contents

The memory contents can be displayed byte-serially or word-serially.

Command:



B: Byte-serially (keyword)
W: Word-serially (keyword)
aa: Start address as of which the memory contents are to be displayed
,: Keyword (separator)
ea: End address of the memory contents to be output
L: Length (keyword)
az: Number of bytes/words to be output

Example:

DB 0:0L2<CR> Display memory contents byte-serially


0000:0000 02 00 Monitor display

DW 0,2<CR> Display memory contents word-serially

0000:0000 0002 0000 Monitor display

Fill memory area with a value

Command:



B: Byte-serially (keyword)
W: Word-serially (keyword)
aa: Start address as of which the memory contents are to be filled with the specified value
,: Keyword (separator)
ea: End address of the memory area
L: Length (keyword)
az: Number of bytes/words to be filled
hex: Hexadecimal value with which the memory area is to be filled


Example:

IB 8000:80L3=FF<CR> The memory contents of 8000:80_H, 8000:81_H and 8000:82_H is overwritten with FF

Transfer memory areas

A memory area can be copied to another area. The data are transferred word-serially, but the number is specified in bytes when entering (i.e. one word is transferred in the case of az = 3).

Command:



aa: Start address as of which the memory contents are to be copied
,: Keyword (separator)
ea: End address of the memory area
L: Length (keyword)
az: Number of bytes to be copied
za: Target address of the memory area

Example:

M 8000:80L4,8000:90<CR> or M 8000:80,84,8000:90<CR>


The following are copied:

8000H:80H —> 8000H:90H
:81H —> :91H
:82H —> :92H
:83H —> :93H

Read/write port

A value from the I/O area is displayed and modified byte-serially.

Command:




adr: I/O address
value: Byte value to be written to the I/O address
=: Keyword

Display/edit memory contents

The memory contents can be displayed and modified byte-serially or word-serially.

Command:




- B: Byte-serially (keyword)
- W: Word-serially (keyword)
- aa: Start address as of which the memory contents are to be displayed/modified
- address: Address of the memory contents
- value: Value of the memory contents
- value new: New value of the memory contents (user entry)
- :: Entering a semicolon increments the address by 1 (command SB) or by 2 (command SW)
- ↑: Entering an "arrow up" (^ on the PC) decrements the address by 1 (command SB) or by 2 (command SW)

Edit address output format

The monitor program is set to SEGMENT:OFFSET address format when it is initialized, and this format is used for each address output. The address output format can be freely selected with the user commands U<CR> (Segment:Offset format) and V<CR> (Absolute format).


Command:



Display/edit working segment

If only an offset and no segment is specified when entering an address, the working segment Y is used as the segment. The default value of the working segment is zero.

Command:



- seg: New segment address of the working segment
- =: Keyword


Example:

Y <CR>	User command: Display working segment
Y 0000	Screen display
DB 0L2	Display memory contents byte-serially
0000:0000 02 00	Screen display
Y=8000<CR>	Modify working segment

Cyclic read and write

A value is read cyclically from a source address and written to a target address. The operation can be aborted with CTRL C.

Command:



- qa: Source address from which the value is read
- za: Target address to which the value is written
- ,: Keyword (separator)

Example:


ZA 1000:0, 1000:100 <CR>

A value is read cyclically from address 1000:0_H and written cyclically to address 1000:100_H.

Cyclic read and write with waiting time

A value is read cyclically from a source address and written cyclically to a target address. The operation can be aborted with CTRL C. The waiting time between two read cycles is approximately 1 ms.

Command:



qa: Source address from which the value is read
za: Target address to which the value is written
,: Keyword (separator)

Example:


ZA 1000:0, 1000:100 <CR>

A value is read cyclically from address 1000:0_H and written cyclically to address 1000:100_H.

Read and write on keystroke

After each keystroke, a value is read from the source address and written to a target address. The operation can be aborted with CTRL C.

Command:



qa: Source address from which the value is read
za: Target address to which the value is written
,: Keyword (separator)

Example:


ZC 1000:0, 1000:100 <CR>

With each keystroke, a value is read from address 1000:0_H and written to address 1000:100_H.

Cyclic write

The value of a counter is decremented and written to a target address. The operation can be aborted with CTRL C.

Command:



za: Target address to which the value is written

Example:


ZE 1000:100 <CR>

The value of a counter is written to 1000:100_H. The counter is decremented after each write operation.

Cyclic read

A source address is read cyclically. The operation can be aborted with CTRL C.

Command:



qa: Source address from which the value is read

Example:


ZE 1000:100 <CR>

The value of address 1000:100_H is read cyclically.

Cyclic write and read

The value of a counter is written cyclically to an address and then read again. The operation can be aborted with CTRL C.

Command:



adr: Address to which the value of the counter is written and from which the value is read

Example:


ZF 1000:0 <CR>

The value of a counter is written to address 1000:100_H. After each write operation, the value is read from address 1000:100_H and the counter is decremented.

Simultaneous output of 3 values

The ZG command permits the values of maximum 3 addresses to be displayed. Whenever the value of the first address changes, the values are updated on the monitor. The expression "expr" states how frequently updating of the values is to be suppressed.

Command:



- adr1: 1st address whose value is displayed on the monitor. If the value of adr1 changes, the values are updated on the monitor.
- adr2: 2nd address whose value is displayed on the monitor.
- adr3: 3rd address whose value is displayed on the monitor.
- expr: Number expressing how frequently updating of the values on the monitor is to be suppressed when the value of adr1 changes.
- ,: Keyword (separator)
- =: Keyword

Example:

ZG 1000:0, 1000:100 <CR>


The values of addresses 1000:0_H and 1000:100_H are displayed on the monitor. If the value of address 1000:0_H changes, the values of the two addresses are updated on the monitor.

RAM test

The specified area is written with a test pattern (FFFF, 5555, AAAA), and a check is then conducted in order to establish whether the test values have been stored correctly in the specified area. If an error is established, the address, actual value and required value are output. The test can be continued by pressing any key (apart from <SPACE>). CTRL C aborts the test.

3 test cycles are performed with test values whose order is reversed. The 4th test cycle consists of storing a counter at the start address, checking for correct storage and repeating the test with the decremented counter until it reaches value zero. The RAM test is then terminated with monitor message (*).

Command:



- aa: Start address of the RAM area
- ea: End address of the RAM area
- L: Length (keyword)
- az: Number of bytes of the RAM area
- ,: Keyword (separator)


Example:

ZR 1000:0L100<CR> RAM test over the specified memory area.

Output of 3 values after entering a semicolon (;)

Command ZZA permits you to display the values (byte or word) of maximum 3 addresses each time a semicolon (;) is entered. The command can be aborted with <CR>.

Command:



- B: Byte-serially (keyword)
- W: Word-serially (keyword)
- adr1: 1st address whose value is displayed on the monitor.
- adr2: 2nd address whose value is displayed on the monitor.
- adr3: 3rd address whose value is displayed on the monitor.
- ,: Keyword (separator)

Example:


ZZA 1000:0, 1000:100 <CR>

After entry of a semicolon (;), the values of addresses 1000:0_H and 1000:100_H are displayed on the monitor.

Search for string

Command ZZF can be used to search for a string with maximum 3 words in the specified memory area. If the string is found, the address is displayed on the monitor. The search is continued by entering a semicolon (;). If the string is not found, monitor message <#07> is displayed.

Command:



- aa: Start address of the memory area
- ea: End address of the memory area
- L: Length (keyword)
- az: Number of words in the memory area
- exp1: 1st word of the string
- exp2: 2nd word of the string
- exp3: 3rd word of the string
- ,: Keyword (separator)

Example:


ZZF 1000:0, 100 = AAAA, BBBB <CR>

The entered string (AAAA_H, BBBB_H) is sought in the area 1000:0_H to 1000:100_H.

Compare memory areas word–serially

Command ZZV is used to compare a memory area 1 word–serially with a memory area 2. If a difference is established, the address 1, the contents 1, the address 2 and the contents 2 are displayed on the monitor. The operation can be aborted with CTRL C.

Command:



aa1: Start address of the memory area 1
ea1: End address of the memory area 1
L: Length (keyword)
az1: Number of words in the memory area 1
aa2: Start address of the memory area 2
,: Keyword (separator)

Example:

ZZV A000:0 L 100, 8000:0 <CR>

Memory area 1 between A000:0_H and A000:100_H is compared with memory area 2 as of 8000:0_H.

Read Intel HEX file

Using the R command, it is possible to read in an INTEL HEX file via the COM2 serial interface of unit 07 KT 92 and to store the HEX file data in the PLC.

The following records are accepted in this case:

- address extension record
- data record
- end record


The following transfer format applies:

- 8 data bits
- no parity bit
- 1 stop bit

The data of the INTEL HEX file are stored in the PLC as of the following address:

- The segment address is determined by the address in the address extension record of the INTEL HEX file. If an offset is specified when entering the command, this offset is added to the segment address in the address extension record. This results in a new segment address as of which the data of the HEX file are stored. This permits the storage area for the HEX file data in the PLC to be preset.
- The offset address is determined by the address in the data record of the INTEL HEX file.

Command:



offset: Offset (by addition to the segment address of the address extension record, this results in the new segment address)

Example:

R <CR> The PLC is ready to receive an INTEL HEX file.

R 2F00 <CR> The PLC is ready to receive an INTEL HEX file. The HEX value 2F00_H is added to the segment address of the address extension record. The resultant new segment address is the address used for storing the HEX file data.

Write INTEL HEX file

The W command permits a data area of the PLC to be output as an INTEL HEX file via the serial interface COM2 of the unit 07 KT 92.


The following records are generated in this case:

- address extension record
- data record
- end record

The following transfer format applies:

- 8 data bits
- no parity bit
- 1 stop bit

Command:



area: Memory area to be output as an INTEL HEX file.

Example:

W 8000:0,FFFF <CR> The memory area from 8000:0_H up to and including 8000:FFFF_H is output as an INTEL HEX file via serial interface COM2 of the PLC.

W 8000:0LFFFF <CR> The memory area from 8000:0_H up to and including 8000:FFFE_H is output as an INTEL-HEX file via serial interface COM2 of the PLC.

3 Memory overview

3.1 Memory overview for 07 KR 91, 07 KT 92 and 07 KT 93

3.1.1 User program RAM

Not used	38C20 38C12
Constants for program 2 702 _H bytes	38510
Turbo RAM program 2 12EB0 _H bytes	25660
User program memory 2 7800 _H bytes	1DE60
Not used	1DE52
Constants for program 1 702 _H bytes	1D750
Turbo RAM program 1 12EB0 _H bytes	0A8A0
User program memory 1 7800 _H bytes	030A0
Not used	03080
Program identification	03070
Organizational directory for program 2	0305A
Organizational directory for program 1	03044
Organizational directory PLC-specific	03030
Control block 0...2	03000

Explanation of terms:

- Organizational directory
 - PLC-specific: This is used to store organizational data relating to the entire PLC.
 - for user program 1: This is used to store organizational data relating to program memory 1.
 - for user program 2: This is used to store organizational data relating to program memory 2.
- Program identification: 16 bytes for an identification, e.g. project name.

3.1.2 User program Flash-EPROM

Checksum	A7FFE
Not used 8C _H bytes	A7F72
User program 7800 _H bytes	A0772
Constants 702 _H bytes	A0070
Not used 20 _H bytes	A0050
Program identification	A0040
Organizational directory for program 2	A002A
Organizational directory for program 1	A0014
Organizational directory PLC-specific	A0000

- User program memory 1: Memory for the PLC program.
- Turbo RAM program 1: Machine code for user program memory 1.
- Constants for program 1: This area is used to store the indirect constants of the user program memory 1.
- User program memory 2: Memory for the PLC program.
- Turbo RAM program 2: Machine code for user program memory 2.
- Constants for program 2: This area is used to store the indirect constants of the user program memory 2.

3.1.3 Operand memory

40000		SEG:F3E0
3FFF0	not used 10 _H	SEG:F3D0
3FE60	I/O configuration list 2 190 _H	SEG:F240
3FCD0	I/O configuration list 1 190 _H	SEG:F0B0
3FCC8	Not used 8 _H	SEG:F0A8
3FA40	I/O force lists 288 _H	SEG:EE20
3FA30	Not used 10 _H	SEG:EE10
3F930	Stack 2 100 _H	SEG:ED10
3F830	ASAS 2 100 _H	SEG:EC10
3E030	VWS 1800 _H	SEG:D410
3D830	S 800 _H	SEG:CC10
3D030	MD 800 _H	SEG:C410
3B030	MW 2000 _H	SEG:A410
3A030	M 1000 _H	SEG:9410
39F30	AW 100 _H	SEG:9310
39B30	A 400 _H	SEG:8F10
39A30	EW 100 _H	SEG:8E10
39630	E 400 _H	SEG:8A10
39430	KD 200 _H	SEG:8810
38F30	KW 500 _H	SEG:8310
38F2E	K 2 _H	SEG:830E
38E20	Free Pool 10E _H	SEG:8200
38D20	Stack 1 100 _H	SEG:8100
38C20	ASAS 1 100 _H	SEG:8000
		SEG =30C2

Explanation of terms:

ASAS 1: Work memory program 1

Stack 1: Stack for program 1

K: Indirect constants BINARY

KW: Indirect constants WORD

KD: Indirect constants DOUBLE WORD

E: Process image of the inputs BINARY

EW: Process image of the inputs WORD

A: Process image of the outputs BINARY

AW: Process image of the outputs WORD

M: Flags BINARY

MW: Flags WORD

MD: Flags DOUBLE WORD

S: Step chains

VWS: Historical value memory

ASAS 2: Work memory for program 2

Stack 2: Stack for program 2

I/O force lists:

This is where the I/O signals to be forced and their force values are entered.

I/O configuration list 1:

This is where the I/O signals planned in program 1 are entered so that they are allowed for when generating and outputting the process image.

I/O configuration list 2:

This is where the I/O signals planned in program 2 are entered so that they are allowed for when generating and outputting the process image.

3.1.4 Dual-port RAM

CS31–status (EW 07,15)	C03FF C03FE C03FD
read real time clock EW 07,08...EW 07,14	C03F0 C03EF
spontaneous mail box (EW 07,04...EW 07,07)	C03E8 C03E7
receive mail box (EW 07,00...EW 07,03)	C03E0 C03DF
direct: EW 06,00...EW 06,15 CS31: EW 00,00...EW 05,15	C0300
reserved	C02FF
send mail box	C02FE C02F4 C02F3 C02E0 C02DF
reserved	
direct: AW 06,00...AW 06,15 CS31: AW 00,00...AW 05,15	C0200 C01FF
direct: E 62,00...E 63,15 CS31: E 00,00...E 61,15	C0180 C017F C0100 C00FF
reserved	
read/write permission read/write request	C00FE C00FD C0080 C007F
reserved	
direct: A 62,00...A 63,15 CS31: A 00,00...A 61,15	C0000

3.2 Memory overview for 07 KR 31 and 07 KT 31


3.2.2 Data addressing (Data mapping)

3.2.1 System addressing (Mapping)

FFF F D800 D7FF	Compiled program 1
B000 AFFF	Compiled program 2
AF00 AEFF	Reserved
AC00 ABFF	I/O data
A800 A7FF	Reserved
8981 8980	Micro code in RAM
8800 87FF	Constants
8000 7FFF	RAM non-safeguarded
5000 4FFF	Reserved
4000 3FFF	Data
2000 1FFF	UAR T
1000 0FFF	ASIC 2 – input ASIC
0000	ASIC 1 – output ASIC

AEFF	EW 15,15
AD00 ACFF	EW 00,00
AC80 AC7F	E 63,15
AC00	E 00,00
	A 63,15
	A 00,00
47D1	S 015,15
47B2	S 000,00
467F	MD 001,15
4600	MD 000,00
8980 897F	K 00,00; K 00,01
8900 88FF	KD 01,15
	KD 00,00
8800	KW 07,15
	KW 00,00
85FF	AW 07,15
8500	AW 00,00
4581	MW 255,15
4542 4541	MW 254,00
	MW 239,15
4402 4401	MW 230,00
	MW 005,15
4342 4341	MW 000,00
	M 255,15
4340 433F	M 255,00
	M 239,15
432C 432B	M 230,00
	M 021,15
4300 42FF	M 000,00
	Historical values
4100 40FF	
	Timers
4000	

Vol.	Description		Page
8.1	Communication Processor RCOM	07 KP 90	1
8.2	Communication Module	07 KP 92	1



Regulations Concerning the Setting up of Installations

Apart from the basic "Regulations for the Setting up of Power Installations" DIN VDE* 0100 and for "The Rating of Creepage Distances and Clearances" DIN VDE 0110 Part 1 and Part 2 the regulations "The Equipment of Power Installations with Electrical Components" DIN VDE 0160 in conjunction with DIN VDE 0660 Part 500 have to be taken into due consideration.

Further attention has to be paid to DIN VDE 0113 Part 1 and Part 200 in case of the control of working and processing machines. If operating elements are to be mounted near parts with dangerous contact voltage DIN VDE 0106 Part 100 is additionally relevant.

If the protection against direct contact according to DIN VDE 0160 is required, this has to be ensured by the user (e.g. by incorporating the elements in a switch-gear cabinet). The devices are designed for pollution severity 2 in accordance with DIN VDE 0110 Part 1. If higher pollution is expected, the devices must be installed in appropriate housings.

The user has to guarantee that the devices and the components belonging to them are mounted following these regulations. For operating the machines and installations, other national and international relevant regulations, concerning prevention of accidents and using technical working means, also have to be met.

The ABB Procontic devices are designed according to IEC 1131 Part 2. Meeting this regulation, they are classified in overvoltage category II which is in conformance with DIN VDE 0110 Part 2.

For the direct connection of ABB Procontic devices, which are powered with or coupled to AC line voltages of overvoltage category III, appropriate protection measures corresponding to overvoltage category II according to IEC-Report 664/1980 and DIN VDE 0110 Part 1 are to install.

Equivalent standards:

DIN VDE 0110 Part 1 \triangleq IEC 664

DIN VDE 0113 Part 1 \triangleq EN 60204 Part 1

DIN VDE 0660 Part 500 \triangleq EN 60439-1 \triangleq IEC 439-1

All rights reserved to change design, size, weight, etc.

* VDE stands for "Association of German Electrical Engineers".

ABB Schalt- und Steuerungstechnik GmbH Heidelberg

1 Communication module 07 KP 90 R202

Communication via RCOM protocol




Fig. 1: Communication module 07 KP 90 R202

Contents

1.1	Brief description	1
1.2	Features	1
1.3	Planning with the 907 KP 90 R202 software package	2
1.4	Structure of the front panel elements	3
1.5	Electrical connection	4
1.5.1	Application example	4
1.5.2	Connection of the supply voltage	6
1.5.3	Electrical isolation and earthing instructions	6
1.5.4	Serial interfaces	8
1.5.5	Networking interface	9
1.6	Diagnosis	10
1.7	Technical data	11
1.8	System cables and adaptors	14

1.1 Brief description

The 07 KP 90 R202 RCOM communication module can be connected as an expansion unit to basic units such as 07 KR 91 R252, 07 KT 92, 07 KT 93 of the decentralized automation system ABB Procontic CS31.

The 07 KP 90 R202 communication module permits communication via the RCOM protocol. Using this protocol it permits data exchange

- between ABB MasterPiece 200 control systems, ABB Procontic T200 systems and ABB Procontic CS31 systems or
- between ABB Procontic CS31 systems amongst themselves.

One advantage is that RCOM (Remote **COM**munication) permits large distances to be spanned.

Communication can be performed via various transmission media, such as:

- leased or private dedicated lines
- existing cable paths,
- telephone lines (dial-up connections).

Adaptation to the required transmission path can be performed by selection of various modems (e.g. VF or current loop modems, telephone modems, multidrop modems).

An RCOM network always consists of the master and one or more slaves, with the following data transmission options:

- Master transmits data to a slave,
- master reads data from a slave,
- event-driven transmission: a slave can store process events with a time stamp and transfer them to the master on request (event polling).

1.2 Features

- The RCOM 07 KP 90 R202 communication module can be planned as RCOM master or slave.
- A network may have up to 254 RCOM slaves (max. 8 slaves if using MasterPiece 200, max. 30 slaves in case of dial-up mode).

- The RCOM protocol is compatible with MP200/1 with DSCA 180A. All RCOM services are available (cold start, warm start, normalization, clock synchronization, write data, read data, event polling).
- The RCOM interface for connection of the modem complies with EIA RS–232. It can also be used as an EIA RS–485 interface.
- An additional operator interface (CONSOLE) complying with EIA RS–232 is provided as a commissioning aid (indication of the communication sequence, planning telephone numbers etc.)

- Software clock; time can be used in the PLC program.

1.3 Planning with the 907 KP 90 R202 software package

The communication sequence is planned with connection elements contained in the 907 KP 90 R202 documentation and software package (see also Ordering information). This package also contains the manual for the RCOM 07 KP 90 R202 communication module and planning examples.

1.4 Structure of the front panel elements





Fig. 2: Communication module 07 KP 90 R202 with reference points (see below for explanation)

- 1 Mounting the unit on a DIN rail
- 2 Mounting the unit with screws
- 3 6.3 mm Faston earthing terminal
- 4 24 V DC supply voltage
- 5 Serial interface CONSOLE
- 6 Serial interface RCOM
- 7 Networking interface to the ABB Procontic CS31 central unit
- 8 Switch



The switch has no function.

9 LED indicators see below

10 LED indicators see below

⑩	yellow	<input type="checkbox"/> RxD	07 KP 90 is receiving an RCOM telegram
	yellow	<input type="checkbox"/> TxD	07 KP 90 is transmitting data via the RCOM interface
	yellow	<input type="checkbox"/> BLK	Transmission of user data blocked as the result of communication error
⑨	green	<input type="checkbox"/> RUN	07 KP 90 R202 is ready for RCOM communication (running)
	red	<input type="checkbox"/> ERR	RCOM communication error
	green	<input type="checkbox"/> Supply	Supply voltage present

Refer to Section 1.6 Diagnosis for further information


11 Plastic film (detachable for labelling)

1.5 Electrical connection

1.5.1 Application example for connecting the inputs and outputs

The following illustration shows an application example with the 07 KT 93 which utilizes various possibilities for connecting inputs and outputs. Attention must be paid to the following in detail:

- The earthing measures
- Connection of the communication module 07 KP 90 R202
- Looping through the supply voltage (24 V DC) from the 07 KT 93 to the 07 KP 90 R202
- Earthing the switch cabinet mains socket
- Handling serial interfaces



- 1 Earth connection:
Use supplied parts (see Figure 6)
- 2 Supply voltage:
Short, direct connection between the modules,
wires 15 cm, 2.5 mm² (see Figure 6)
- 3 Cable shields:
In the case of permanent wiring at the switchgear cabinet
inlet, earth via clamps and do not put shield in the plug.
Otherwise, lay the cable shield in the plug to PGND.


Fig. 3: Application example:
Communication module 07 KP 90 R202 at central unit 07 KT 93
(Section 1.3 Electrical connection applies similarly to 07 KR 91 and 07 KT 92.)

1.5.2 Connecting the 24 V DC supply voltage

The supply voltage is fed in via a 5-pole detachable terminal block.

Important:


Plug and unplug terminal block only with power is off!



1.5.3 Electrical isolation and notes on earthing

The following illustration shows which circuit parts of the unit are electrically isolated from each other and which internal connections exist. Here, both the clearances and creepage distances and also the test voltages used correspond to DIN/VDE 0160.

The unit is connected via the 6.3 mm Faston terminal (bottom left) to the functional earth (switch cabinet earth) via a wire with a cross section of 6 mm² (also see Figure 6).






Fig. 6: Earthing connections and voltage supply for 07 KP 90 R202

1.5.4 Serial interfaces

Serial interface CONSOLE

A terminal (e.g. an IBM-PC with 907 PC 33 in Terminal mode) can be connected to the CONSOLE interface for commissioning. The CONSOLE interface can be used to

- configure the telephone directory or configuration data (only in the case of dial-up modems),


- follow the communication sequence (fault-finding during commissioning). This function can be deactivated after commissioning.

Serial interface RCOM

The RCOM network is connected to this interface. It is connected via a modem with standard interface.


Serial interface CONSOLE: Terminal assignment

Interface standard: EIA RS-232



Serial interface RCOM: Terminal assignment

Interface standard: EIA RS-232 or EIA RS-485



1.5.5 Networking Interface 7

The networking interface, a special parallel interface, allows the 07 KP 90 R202 communication module to be connected to ABB Procontic CS31 central units (such as 07 KR 91 R252, 07 KT 92, 07 KT 93). The housing of the communication module is connected to the housing of the

ABB Procontic CS31 basic unit by a snap-fit connection. The electrical connection is via a 40-pole ribbon cable with socket connector, soldered onto the 07 KP 92 R202 side.




Fig. 9: Example: Connecting 07 KP 90 R202 with 07 KT 93

Mounting the expansion housing

1. Detach the cover on unit 07 KT 93 from the networking interface.
2. Plug the socket strip of the 40-pole ribbon cable secured to the 07 KP 90 R202 onto the networking connector of the 07 KT 93.
3. Place both units on a level surface and slide them together so that they engage.
4. Slide in the connection part to fix the housing in position.

Note: Mounting of the 07 KP 90 R202 to 07 KR 91 / 07 KT 92 takes place in a similar way.

1.6 Diagnosis

LED displays for RCOM system messages

9

yellow RxD
yellow TxD
yellow BLK

RxD: 07 KP 90 is receiving an RCOM telegram.
TxD: 07 KP 90 is transmitting data via the RCOM interface
BLK: Transmission of user data blocked as the result of communication error. After normalization LED 'BLK' goes out again.

Fig. 10: LED displays for RCOM system messages

LED displays for RUN, ERR and Supply

10

green RUN
red ERR
green Supply

RUN: 07 KP 90 is ready for RCOM communication (running).
ERR: A RCOM communication error has occurred. In the case of recoverable errors the LED goes off again after a short time. In the case of fatal errors, the LED remains on continuously. The 'RUN' LED also goes off.
Supply: Supply voltage is present.

Fig. 11: LED displays for RUN, ERR and Supply

Operating states, error displays

RUN gn	RxD rd	TxD rd	BLK rd	Supply gn	ERR rd	Meaning	Remedy
<input type="checkbox"/>	Supply voltage not present.	<ul style="list-style-type: none"> Switch on supply voltage. Check supply voltage. 					
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	☆	<input type="checkbox"/>	Supply voltage present. 07 KP 90 R202 not ready for communication. <ul style="list-style-type: none"> during device reset or after fatal error 	<ul style="list-style-type: none"> Switch supply voltage of 07 KP 90 R202 and 07 KT 93 off and then on again.
☆	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	☆	<input type="checkbox"/>	The 07 KP 90 R202 is ready for communication.	—
☆	☆	<input type="checkbox"/>	<input type="checkbox"/>	☆	<input type="checkbox"/>	The 07 KP 90 R202 is receiving a data telegram.	—
☆	<input type="checkbox"/>	☆	<input type="checkbox"/>	☆	<input type="checkbox"/>	The 07 KP 90 R202 is transmitting a data telegram.	—
☆	X	X	<input type="checkbox"/>	☆	<input type="checkbox"/>	RCOM operation	—
☆	X	X	☆	☆	<input type="checkbox"/>	Transmission of user data not possible owing to the communication sequence.	<ul style="list-style-type: none"> Normalization.
☆	X	X	<input type="checkbox"/>	☆	☆	RCOM communication error.	<ul style="list-style-type: none"> The ERR LED goes out again automatically in the case of recoverable errors.
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	☆	☆	Fatal RCOM communication error.	<ul style="list-style-type: none"> Switch supply voltage of 07 KP 90 R202 and 07 KT 93 off and then on again.
X	☆	☆	☆	X	☆	Hardware error. (RAM, EPROM, DP-RAM error)	<ul style="list-style-type: none"> Switch supply voltage of 07 KP 90 R202 and 07 KT 93 off and then on again.

= LED off, ☆ = LED on, ☆* = LED blinks, X = LED on or off, gn = green, rd = red

Fig. 12: Signalling operating states and error display

1.7 Technical data

In general, the details in Section 1 "System data and system structure" of volume 2 of the system description "ABB Procontic CS31" apply as technical data. Supplementary and deviating data is listed below.

1.7.1 General data

Number of serial interfaces	2
Number of parallel interfaces	1 networking interface for connecting to the ABB Procontic CS31 central unit
Operating and error displays	6 LEDs: RUN, ERR, Supply, RxD, TxD, BLK
Conductor cross section for the removable terminal blocks	max. 2.5 mm ²

1.7.2 Supply voltage for 07 KP 90 R202

Rated supply voltage	24 V DC
Power dissipation	typ. 2.5 W
Max. current consumption	
with rated voltage	210 mA
with supply voltage 30 V	170 mA
Protection against reversed terminal connection	yes

1.7.3 Connection serial interface RCOM, CONSOLE

Interface standard	EIA RS-232 or EIA RS-485 (RCOM only)
Electrical isolation	yes, RCOM interface with respect to the rest of the unit (also see Figure 5)
Potential differences	So that no earthing potential differences arise between the 07 KP 90 R202 and the peripheral units connected to RCOM and CONSOLE, the latter are supplied from the switch cabinet mains socket (also see earthing connections in Figure 5).
Transmission speed (Baud rate)	
RCOM	300...19200 Baud
CONSOLE	9600 Baud
Terminal assignment and description of the interfaces RCOM, CONSOLE	See Page 8 onwards

1.7.4 LED displays

1.7.5 LED displays

LEDs for operating and error displays:	
– Supply voltage present (Supply)	1 green LED
– Fatal or serious error occurred (ERR)	1 red LED
– Ready for RCOM communication (running), (RUN)	1 green LED
– Interface signals RxD, TxD	2 yellow LEDs
– Protocol status BLK	1 yellow LED

1.7.6 Mechanical data

Mounting on DIN rail

in accordance with DIN EN 50022–35, 15 mm deep
The DIN rail is located in the middle between the upper and the lower edges of the module.

Fastening by screws

using 4 M4 screws.

Width x height x depth

140 x 120 x 85 mm

Wiring method


by removeable terminal blocks with screw–type terminals, max. 2.5 mm²

Weight

450 g

Dimensions for mounting

see the following drawing



All dimensions in mm.

The device is 85 mm deep. The interface connectors RCOM and CONSOLE are set deeper so that the mounting depth required does not become any larger even with detachable interface cables. If, however, a DIN rail is used, the mounting depth is increased by the overall depth of the rail.

Fig. 13: Dimensions of the Communications module 07 KP 90 R202, front view, **the dimensions for assembly bore holes are printed in bold**

1.7.7 Mounting hints

Mounting position

vertical, terminals above and below

Cooling

The natural convection cooling must not be hindered by cable ducts or other material mounted in the switch cabinet.

1.7.8 Ordering data

Communication module 07 KP 90 R202

Order No. GJR5 2510 00 R0202

Scope of delivery

Communication module 07 KP 90 R202
1 5pole terminal block (5.08 mm grid)
Cable including terminals for making the
earth connection
Earthing instructions enclosed

Further literature

System description ABB Procontic CS31, English

Order No. FPTN 4400 04 R2001

System description ABB Procontic T200, English

Order No. GATS 1314 99 R2001

System description ABB Procontic T300, English

Order No. GATS 1315 99 R2002

Operating manual 07 KR 91, English

Order No. GATS 1316 01 R2001

Operating manual 07 KT 92, English

Order No. GATS 1316 02 R2001

Operating manual 07 KT 93 R101, English

Order No. GATS 1316 12 R2001

System description ABB Procontic CS31, German

Order No. GATS 1316 99 R1002

System description ABB Procontic T200, German

Order No. GATS 1314 99 R1001

System description ABB Procontic T300, German

Order No. GATS 1315 99 R1002

Operating manual 07 KR 91, German

Order No. GATS 1316 01 R1001

Operating manual 07 KT 92, German

Order No. GATS 1316 02 R1001

Operating manual 07 KT 93 R101, German

Order No. GATS 1316 12 R1001

Software

907 KP 90 R202, English documentation,
CE library and example programs,


GJP5 2051 00 R0202

907 KP 90 R202, German documentation,
CE library and example programs,


GJP5 2052 00 R0202

1.8 System cables


1.8.1 CONSOLE to PC (25-pole) for commissioning




1.8.2 RCOM as EIA RS-232 to modem



1.8.3 RCOM as EIA RS-485



1.8.4 Adaptor 15-pole/9-pole






Printed on chlorine-free bleached paper

ABB Schalt- und Steuerungstechnik GmbH
Eppelheimer Straße 82 Postfach 10 50 09
D-69123 Heidelberg D-69040 Heidelberg
Telephone +49 6221 777-0
Telefax +49 6221 777-111

Printed in the Federal Republic of Germany (05.95 · 0.15 · AD)



Regulations Concerning the Setting up of Installations

Apart from the basic "Regulations for the Setting up of Power Installations" DIN VDE* 0100 and for "The Rating of Creepage Distances and Clearances" DIN VDE 0110 Part 1 and Part 2 the regulations "The Equipment of Power Installations with Electrical Components" DIN VDE 0160 in conjunction with DIN VDE 0660 Part 500 have to be taken into due consideration.

Further attention has to be paid to DIN VDE 0113 Part 1 and Part 200 in case of the control of working and processing machines. If operating elements are to be mounted near parts with dangerous contact voltage DIN VDE 0106 Part 100 is additionally relevant.

If the protection against direct contact according to DIN VDE 0160 is required, this has to be ensured by the user (e.g. by incorporating the elements in a switch-gear cabinet). The devices are designed for pollution severity 2 in accordance with DIN VDE 0110 Part 1. If higher pollution is expected, the devices must be installed in appropriate housings.

The user has to guarantee that the devices and the components belonging to them are mounted following these regulations. For operating the machines and installations, other national and international relevant regulations, concerning prevention of accidents and using technical working means, also have to be met.

The ABB Procontic devices are designed according to IEC 1131 Part 2. Meeting this regulation, they are classified in overvoltage category II which is in conformance with DIN VDE 0110 Part 2.

For the direct connection of ABB Procontic devices, which are powered with or coupled to AC line voltages of overvoltage category III, appropriate protection measures corresponding to overvoltage category II according to IEC-Report 664/1980 and DIN VDE 0110 Part 1 are to install.

Equivalent standards:

DIN VDE 0110 Part 1 \triangleq IEC 664

DIN VDE 0113 Part 1 \triangleq EN 60204 Part 1

DIN VDE 0660 Part 500 \triangleq EN 60439-1 \triangleq IEC 439-1

All rights reserved to change design, size, weight, etc.

* VDE stands for "Association of German Electrical Engineers".

ABB Schalt- und Steuerungstechnik GmbH Heidelberg

1 Communication module 07 KP 92 R101

Connecting external units




Fig. 1: Communication module 07 KP 92

Contents

1.1	Brief description	1
1.2	Structure of the front panel elements	2
1.3	Electrical connection	3
1.3.1	Application example	3
1.3.2	Connecting the supply voltage	5
1.3.3	Electrical isolation and earthing instructions	5
1.3.4	Serial interfaces	7
1.3.5	Networking interface	9
1.4	Diagnosis	10
1.5	Programming und test software 907 KP 92	10
1.6	Technical Data	11
1.7	System cables	14

1.1 Brief description

The 07 KP 92 R101 communication module is a freely programmable interface module with 2 serial interfaces.

The communication module allows external units to be connected to the ABB Procontic CS31 system via a serial interface.

The communications protocols and transmission types can be freely defined by the user.

Programming is performed on a PC with the programming and test software 907 KP 92.

The communication module is connected to ABB Procontic CS31 central units via the networking interface, e.g. 07 KR 91 (index h onwards), 07 KR 91 R252, 07 KT 92 (index i onwards) or 07 KT 93.

The most important features of the communication module are:

- 2 serial interfaces, optionally configurable in accordance with EIA RS-232 or EIA RS-422 or EIA RS-485 (COM3, COM4)
- Freely programmable with a comprehensive function library
- Communication with ABB Procontic CS31 central unit via connection elements
- Configurable LEDs for diagnosis
- Programming and testing on a PC via COM3 or COM4
- Saving applications in a Flash EPROM

Processing of the serial interfaces and the networking interface is provided for in an applications program.

Programming is in a language similar to the standard language "C". It provides elements for structuring and a comprehensive library for using the interfaces.

The exchange of data between the serial communication module and the ABB Procontic CS31 central unit is realized by connection elements in the central unit.

1.2 Structure of the front panel elements





Fig. 2: Communication module 07 KP 92 with reference (see below for explanation)

- 1 **Mounting the unit on a DIN rail**
- 2 **Mounting the unit with screws**
- 3 **6.3 mm Faston earthing terminal**
- 4 **24 V DC supply voltage**
- 5 **Configurable serial interface COM3**
- 6 **Configurable serial interface COM4**
- 7 **Networking interface for the ABB Procontic CS31 central unit**
- 8 **Switch for RUN/STOP operation**



The RUN/STOP switch controls the processing of the user application.

STOP → RUN

If the switch is switched from STOP to RUN, the user application is loaded into the main memory and processing of the application program is started.

The status of the application program is indicated by the LED RUN: The LED RUN lights up while the program is being pro-

cessed. If an error occurred during loading (e.g. program not present), the LED RUN remains OFF.

RUN → STOP

If the switch is switched from RUN to STOP, the program processing is aborted. The LED RUN goes out.

- 9 **LED displays for system messages**
- 10 **LED displays freely configurable**

10	yellow	<input type="checkbox"/>	LED1
	yellow	<input type="checkbox"/>	LED2
	yellow	<input type="checkbox"/>	LED3
	yellow	<input type="checkbox"/>	LED4
9	green	<input type="checkbox"/>	RUN
	red	<input type="checkbox"/>	ERR
	green	<input type="checkbox"/>	Supply

Application program is running
Fatal or serious error
Supply voltage present

Refer to Section 1.4 Diagnosis for further information


- 11 **Plastic sheet (detachable for labelling)**

1.3 Electrical connection

1.3.1 Application example for connecting the inputs and outputs

The following illustration shows an application example with the 07 KT 93 which utilizes various possibilities for connecting inputs and outputs. Attention must be paid to the following in detail:

- The earthing measures
- Connection of the 07 KP 92 communication module
- Looping through the supply voltage (24 V DC) from the 07 KT 93 to the 07 KP 92
- Earthing the switch cabinet mains socket
- Handling serial interfaces



- 1** Earth connection:
Use supplied parts (see Figure 6)
- 2** Supply voltage:
Short, direct connection between the modules,
wires 15 cm, 2.5 mm² (see Figure 6)
- 3** Cable shields:
In the case of permanent wiring at the switchgear cabinet
inlet, earth via clamps and do not put shield in the plug.
Otherwise, lay the cable shield in the plug to PGND.


Fig. 3: Application example:
Communication module 07 KP 92 at central unit 07 KT 93
(Section 1.3 Electrical connection applies similarly to 07 KR 91 and 07 KT 92.)

1.3.2 Connecting the 24 V DC supply voltage

The supply voltage is fed in via a 5-pole detachable terminal block.

Important:


Plug and unplug terminal block only with power is off!



1.3.3 Electrical isolation and notes on earthing

The following illustration shows which circuit parts of the unit are electrically isolated from each other and which internal connections exist. Here, both the clearances and creepage distances and also the test voltages used correspond to DIN/VDE 0160.

The unit is connected via the 6.3 mm Faston terminal (bottom left) to the functional earth (switch cabinet earth) via a wire with a cross section of 6 mm² (also see Figure 6).






Fig. 6: Earthing connections and voltage supply for 07 KP 92

Use

External units can be connected to the ABB Procontic CS31 system via the serial interfaces. The interfaces are independent of each other. They can be managed via freely definable protocols.

Scope of functions

The two serial interfaces can be configured independently of each other in the following scope of functions:

- Data format 7 or 8 bit
- Even, odd or no parity
- Discrete baud rates
from 300 Bd to 19200 Bd
- Automatic processing of the SW handshake (XON/XOFF)
- Automatic processing of the HW handshake (RTS/CTS)
- Error detection
(Parity, framing, overrun, break)

Interface standard

- EIA RS–232 or
- EIA RS–422 or
- EIA RS–485

Both interfaces can be run independently of each other in one of the interface standards each. Selection is by choosing the corresponding interface signals.

Mode

- Programming and test mode
- Application mode

In each case, one of the two interfaces can be used as a programming and test interface. This involves the mode being set at pin 6 of the interface connector by the signal status.

Electrical isolation


Both interfaces are electrically isolated.

Connection

Connection is via a 15–pole D–SUB connector (socket) in each case.


Serial interface COM3: Terminal designation

Interface standard: EIA RS-232, EIA RS-422, EIA RS-485



Serial interface COM4: Terminal designation


Interface standard: EIA RS-232, EIA RS-422, EIA RS-485



1.3.5 Networking interface 7

The networking interface, a special parallel interface, allows the 07 KP 92 communication module to be connected to ABB Procontic CS31 central units (such as 07 KR 91 R151, 07 KT 92, 07 KT 93). The housing of the

communication module is connected to the housing of the ABB Procontic CS31 basic unit by a snap-fit connection. The electrical connection is via a 40-pole ribbon cable with socket connector, soldered onto the 07 KP 92 side.



Mounting the expansion housing

1. Detach the cover on unit 07 KT 93 from the networking interface.
2. Plug the socket strip of the 40-pole ribbon cable secured to the 07 KP 92 onto the networking connector of the 07 KT 93.
3. Place both units on a level surface and slide them together so that they engage.
4. Slide in the connection part to fix the housing in position.

Note: Mounting of the 07 KP 92 to 07 KR 91 / 07 KT 92 takes place in a similar way.

1.4 Diagnosis

LED displays for system messages RUN, ERR, Supply

9

green	<input type="checkbox"/> RUN
red	<input type="checkbox"/> ERR
green	<input type="checkbox"/> Supply

The green LED "RUN" lights up when the user application is being processed.

The red LED "ERR" lights up when a fatal error (RAM error, DP-RAM error, EPROM error, Flash EPROM error) or a serious error is present.

The green LED "Supply" indicates the presence of the supply voltage.

Fig. 10: LED displays for system messages RUN, ERR, Supply

Freely configurable LED displays

The yellow LEDs "LED1...LED4" are configurable. They can be controlled in the applications program.

10

yellow	<input type="checkbox"/> LED1
yellow	<input type="checkbox"/> LED2
yellow	<input type="checkbox"/> LED3
yellow	<input type="checkbox"/> LED4

Fig. 11: LED displays, freely configurable

Operating states, error display

RUN ERR Supply	Meaning	Remedy
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	Supply voltage not present.	<ul style="list-style-type: none"> Switch on supply voltage. Check supply voltage.
<input type="checkbox"/> <input type="checkbox"/> ☆	Supply voltage present. 07 KP 92 is ready to process the user application.	
☆ <input type="checkbox"/> ☆	The user application is running.	
X ☆ ☆	A serious error is present which caused the user application to abort automatically.	<ul style="list-style-type: none"> Read out error and remedy if this is possible.
☆ ☆ ☆	Initialization phase. Voltage ON.	

= LED off, ☆ = LED on, X = LED on or off, gn = green, rd = red

Fig. 12: Signalling operating states and error display

1.5 Programming and test software 907 KP 92

The communication module is programmed with the programming and test software 907 KP 92. This software can be run on an IBM-compatible PC. The PC can be

connected to either interface COM3 or COM4 of the communication module.

In addition to the programming and test software, the package 907 KP 92 contains documentation of the communication module 07 KP 92, the CE library and configuration examples.

1.6 Technical data

In general, the details in Section 1 "System data and system structure" of volume 2 of the system description "ABB Procontic CS31" apply as technical data. Supplementary and deviating data is listed below.

1.6.1 General data

Number of serial interfaces	2
Number of parallel interfaces	1 networking interface for connecting to the ABB Procontic CS31 central unit
Built-in application software memory	Flash EPROM 32 kbytes
Diagnosis	4 configurable LEDs: LED1...4 (control led by the application program)
Operating and error displays	3 LEDs: RUN, ERR, Supply
Conductor cross section for the removable terminals	max. 2.5 mm ²

1.6.2 Supply voltage for 07 KP 92 R101

Rated supply voltage	24 V DC
Power dissipation	typ. 2.5 W
max. current consumption	
with rated voltage	210 mA
with supply voltage 30 V	170 mA
Protection against reversed terminal connection	yes

1.6.3 Connection serial interface COM3, COM4

Interface standard	EIA RS-232 or EIA RS-422 or EIA RS-485
Programming with 907 KP 92	via IBM-PC (or compatible)
Man-machine communication	yes, e.g. via ABB Procontic operating station 35 BS 40
Electrical isolation	yes, interfaces with respect to each other and with respect to the rest of the unit (also see Figure 5)
Potential differences	So that no earthing potential differences arise between the 07 KP 92 and the peripheral units connected to COM3 and COM4, the latter are supplied from the switch cabinet mains socket (also see earthing connections in Figure 5).
Terminal assignment and description of the interfaces COM3, COM4	See Page 7 onwards

1.6.4 LED displays

LEDs for operating and error displays:	
– Supply voltage present (Supply)	1 green LED
– Fatal or serious error occurred (ERR)	1 red LED
– Application program processing running (RUN)	1 green LED
Configurable LEDs for diagnosis: LED1...LED4	4 yellow LEDs

1.6.5 Mechanical data

Mounting on DIN rail

in accordance with DIN EN 50022–35, 15 mm deep
The DIN rail is located in the middle between the upper and the lower edges of the module.

Fastening by screws

using 4 M4 screws.

Width x height x depth

140 x 120 x 85 mm

Wiring method


by removeable terminal blocks with screw–type terminals, max. 2.5 mm²

Weight

450 g

Dimensions for mounting

see the following drawing



All dimensions in mm.

The device is 85 mm deep. The interface connectors COM3 and COM4 are set deeper so that the mounting depth required does not become any larger even with detachable interface cables. If, however, a DIN rail is used, the mounting depth is increased by the overall depth of the rail.

Fig. 13: Dimensions of the Communications module 07 KP 92, front view, **the dimensions for assembly bore holes are printed in bold**

1.6.6 Mounting hints

Mounting position

vertical, terminals above and below

Cooling

The natural convection cooling must not hindered by cable ducts or other material mounted in the switch cabinet.

1.6.7 Ordering data

Communication module 07 KP 92 R101

Order No. GJR5 2515 00 R0101

Scope of delivery

Communication module 07 KP 92 R101
1 5-pole terminal block (5.08 mm grid)
Cable including terminals for making the
earth connection
Earthing instructions enclosed

Further literature

System description ABB Procontic CS31, English

Order No. FPTN 4400 04 R2001

System description ABB Procontic T200, English

Order No. GATS 1314 99 R2001

System description ABB Procontic T300, English

Order No. GATS 1315 99 R2002

Operating manual 07 KR 91, English

Order No. GATS 1316 01 R2001

Operating manual 07 KT 92, English

Order No. GATS 1316 02 R2001

Operating manual 07 KT 93 R101, English

Order No. GATS 1316 12 R2001

System description ABB Procontic CS31, German

Order No. GATS 1316 99 R1002

System description ABB Procontic T200, German

Order No. GATS 1314 99 R1001

System description ABB Procontic T300, German

Order No. GATS 1315 99 R1002

Operating manual 07 KR 91, German

Order No. GATS 1316 01 R1001

Operating manual 07 KT 92, German

Order No. GATS 1316 02 R1001

Operating manual 07 KT 93 R101, German

Order No. GATS 1316 12 R1001

Software


Programming and test software 907 KP 92,
CE library and example programs,
German documentation

GJP5 2059 00 R0102


Programming and test software 907 KP 92,
CE library and example programs,
English documentation

GJP5 2060 00 R0102


1.7.3 COM3, COM4 as EIA RS-232 interface



1.7.4 COM3, COM4 as EIA RS-422 interface



1.7.5 COM3, COM4 as EIA RS-485 interface





Printed on chlorine-free bleached paper

ABB Schalt- und Steuerungstechnik GmbH
Eppelheimer Straße 82 Postfach 10 50 09
D-69123 Heidelberg D-69040 Heidelberg
Telephone +49 6221 777-0
Telefax +49 6221 777-111


Printed in the Federal Republic of Germany (02.95 · 0.30 · AD)

Chapter	Description	Page
1	Addresses of CS31 units	1
2	Overview Central Units	2.1
12	Bus - compatible units 12.1	
13.8	Interface Cables	13.9
14.6	Battery unit	14.11



- Enclosed pages bearing volume N° " **2** " are temporarily classified in Volume 9 of the present April'94 edition. In a next edition, these pages shall become part of volume N° " **2** ".

Notes




2 Overview Central Units

2.1	07 KR 31	Central unit for a user program containing typ. 2 k instructions
2.2	07 KT 31	Central unit for a user program containing typ. 2 k instructions
2.3	07 KR 91 R202 / R252	Central unit for a user program containing max. 28 kB of user program
2.4	07 KT 92 R202 / R262	Central unit for a user program containing max. 56 kB of user program + 30 kB user data
2.5	07 KT 93 R101 / R171	Central unit for a user program containing max. 56 kB of user program + 30 kB user data
2.6	07 GV 93 R101	Positioning module for 3 axes

2.1 Central Unit 07 KR 31

Central units for a user program containing max. 2 k of instructions



Central unit 07 KR 31

The comprehensive description for this central unit is located in part 3 of this volume.

Brief description

The central unit 07 KR 31 works either as

- **bus master** in the decentralized automation system ABB Procontic CS31 or as
- **intelligent I/O module** (slave remote processor) in the decentralized automation system ABB Procontic CS31 or as
- **stand-alone central unit.**

The module is supplied by 24 V DC or by 120 V AC or 230 V AC.


Main features

- 12 binary inputs
- 8 binary relay outputs
- 1 output with 24 V DC (regulated) for the 230-V-AC versions
- 1 counting input for counting frequencies up to 10 kHz
- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
 - can be set as a MODBUS interface: master and slave
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Mounting by insertion into the plug-in base ECZ. The plug-in base can either be snapped on a DIN rail or fastened by screws. Wiring over the plug-in base ECZ.
- Built-in lithium battery for back-up of the RAM contents, its lifetime is 10 years.
- Reading and writing protection of the user program by password
- Programming with the programming software 907 PC 331
- User program containing max. 2 k of instructions
- RUN/STOP switch for starting and aborting the program execution

- Extensive diagnosis functions
 - Self–diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

2.2 Central Unit 07 KT 31

Central units for a user program containing max. 2 k of instructions



Central unit 07 KT 31

The comprehensive description for this central unit is located in part 3 of this volume.

Brief description

The central unit 07 KT 31 works either as

- **bus master** in the decentralized automation system ABB Procontic CS31 or as
- **intelligent I/O module** (slave remote processor) in the decentralized automation system ABB Procontic CS31 or as
- **stand-alone central unit.**

The module is supplied by 24 V DC or by 120 V AC or 230 V AC.

Main features


- 12 binary inputs
- 8 binary transistor outputs
- 1 output with 24 V DC (regulated) for the 230-V-AC versions
- 1 counting input for counting frequencies up to 10 kHz
- 1 CS31 system bus interface for system expansion

- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
 - can be set as a MODBUS interface: master and slave
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Mounting by insertion into the plug-in base ECZ. The plug-in base can either be snapped on a DIN rail or fastened by screws. Wiring over the plug-in base ECZ.
- Built-in lithium battery for back-up of the RAM contents, its lifetime is 10 years.
- Reading and writing protection of the user program by password
- Programming with the programming software 907 PC 331
- User program containing max. 2 k of instructions
- RUN/STOP switch for starting and aborting the program execution

- Extensive diagnosis functions
 - Self–diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

2.3 Central Unit 07 KR 91 R202 and R252

Central unit for a user program containing max. 28 k of user program



The comprehensive description for this central unit is located in part 4 of this volume.

Brief description

The central unit 07 KR 91 works either as

- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit.

The module is provided in two versions with supply voltages of 24 V DC and 115/ 230 V AC:

07 KR 91 R202:

The device has a 115/230 V AC power supply voltage. It provides a 24 V output voltage for the supply of its own binary inputs.

07 KR 91 R252:

The device has a 24 V DC power supply voltage. It is provided with an additional interface for connecting communication modules (e.g. 07 KP 90).


Main features

- 20 binary inputs
- 12 binary relay outputs
- 1 counting input for counting frequencies up to 10 kHz

- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution
- Extensive diagnosis functions
 - Self-diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

2.4 Central Unit 07 KT 92 R202 and R262

Central unit for a user program containing max. 56 kB of user program
+ 30 kB user data



The comprehensive description for this central unit is located in part 4 of this volume.

Brief description

The central unit 07 KT 92 works either as

- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit.

The module is supplied by 24 V DC. It is provided with an additional interface for connecting communication modules (e.g. 07 KP 90).

The module 07 KT 92 **R262** is additionally provided with an **integrated ARCnet coupler** (and an ARCnet interface).

Main features


- 12 binary inputs
- 8 binary transistor outputs
- 4 analog inputs
- 2 analog output
- 1 counting input for counting frequencies up to 50 kHz

- 1 CS31 system bus interface for system expansion
- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
- Serial interface COM2 as an MMC interface
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution

- Extensive diagnosis functions
 - Self–diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

2.5 Central Unit 07 KT 93 R101 and R171

Central unit for a user program containing max. 56 kB of user program
+ 30 kB user data



The comprehensive description for this central unit is located in part 4 of this volume.

Brief description

The central unit 07 KT 93 works either as

- bus master in the decentralized automation system ABB Procontic CS31 or as
- slave (remote processor) in the decentralized automation system ABB Procontic CS31 or as
- stand-alone central unit.

The module is supplied by 24 V DC. It is provided with an additional interface for connecting communication modules (e.g. 07 KP 90).

The module 07 KT 93 **R171** is additionally provided with an **integrated ARCnet coupler** (and an ARCnet interface).


Main features

- 24 binary inputs
- 16 binary transistor outputs
- 1 counting input for counting frequencies up to 10 kHz
- 1 CS31 system bus interface for system expansion

- Serial interface COM1
 - is set as programming interface
 - can be set as an ASCII interface for connecting peripheral devices (e.g. MMC devices)
- Serial interface COM2 as an MMC interface
- ARCnet coupler / ARCnet interface (only R171)
- Additional interface for connecting communication modules (e.g. 07 KP 90)
- Real-time clock
- LEDs for displaying the binary input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail
- The lithium battery 07 LE 90 can be put into the battery compartment in order to
 - store and back-up the user program in the RAM
 - store and back-up data which is additionally contained in the RAM, e.g. the status of flags
 - back-up the time and date (real-time clock)
- RUN/STOP switch for starting and aborting the program execution

- Extensive diagnosis functions
 - Self–diagnosis of the central unit
 - Diagnosis of the ABB Procontic CS31 system bus and the connected modules

2.6 Positioning Module 07 GV 93 for 3 axes



The comprehensive description for the positioning module is located in the 07 GV 93 operating manual in DIN A5 format, order No. GATS 1316 07 R2001.

Brief description

The positioning module 07 GV 93 is a subsystem within the decentralized automation system ABB Procontic CS31. It moves and positions three independent axes. The move sequences are programmed in a simple way by means of sets. Machine parameters which can be freely chosen adapt the positioning module to the mechanical units of the machines or the installation.

When used as a stand-alone module, the 07 GV 93 positioning module automatically moves and positions the axes on the basis of the programmed positioning sets. Additional input/output modules, connected via the CS31 system bus, allow the external control of the positioning sets and positioning sequences programmed in 07 GV 93.

The positioning module 07 GV 93 can also be used as a slave on the CS31 system bus. In this case, the positioning sets and sequences programmed in 07 GV 93 are controlled by a central unit 07 KR 91 / 07 KT 92 / 07 KT 93. This configuration allows the connection of additional positioning modules, slave central units as well as input and output modules.

The main features of the 07 GV 93 positioning module are:

- 1...3 axes
- Speed setpoint ± 10 V DC
- Connection to incremental encoders
- High traversing speed of up to 100 m/min
- Position control cycle 4 ms
- Internal numerical representation 32 bits
- Adjustable ramps per axis for both traverse directions
- Encoder error detection
- Power supply 24 V DC
- LEDs for displaying the input and output signals as well as operating conditions and error messages
- Detachable screw-type terminal blocks
- Detachable plastic sheet on the front side of the device; can be labelled with the signal names in order to have the inputs and outputs directly assigned
- Fastening by screws or by snapping the device onto a DIN rail
- RUN/STOP switch for starting and aborting the program execution
- Diagnosis functions

Operating and programming

A means for operating and programming the positioning module 07 GV 93 is the operating station 35 BS 40. It is configured as a simple terminal when the power is switched on and no further programming is to be done. The control of the display which includes 2 lines of 40 characters each is performed completely by the module 07 GV 93. Entry is done via function keys and a numerical keypad.

The following functions are available for programming:

- Absolute and incremental dimensions
- Override 0...125 %
- 300 positioning sets per axis
- Machine data set for machine-specific parameters
- Software limit switches
- 1-, 2- and 4-fold evaluation of the positioning encoders
- Metric system
- Reference point drive
- Automatic single set and automatic next set
- Manual control (Feed, Jog, Pos)
- Error detection, diagnosis

12 Bus-compatible modules from external manufacturers

VIFB-02...FB5
IIFB-02...FB5

Valve island (Festo)
Installation island (Festo)

12.1 Valve island VIFB–02...FB5 (Festo)

4 to 10 valves, 24 V supply, with field bus nodes for ABB Procontic CS31 system bus

Size	No. of valve positions	Data length	Bus transfer time
4	4	2 Bytes	387 µs
6	6	2 Bytes	387 µs
8	8	2 Bytes	387 µs
10	10	4 Bytes	452 µs




Fig. 12.1–1: Valve island VIFB–02...FB5 (Festo)

The valve island comprises the following:

- Connection block for the valves (valves support with pneumatic connections)
- Valve coupling unit (with the electrical outputs for the valve solenoids). The signal statuses are displayed.
- Valves, mostly two–way valves, for travel cylinders with monostable and bistable versions
- Field bus nodes (connection for ABB Procontic CS31 system bus)

Manufacturer and source of supply: Festo KG, Esslingen.


Order No.: VIFB–02–x/x–x–FB5–x...

x: Pneumatic connection, No. of valves, valves type,...

The address of the field bus node on the system bus is set at the two–decade rotary switches after removing the front cover.

Upper switch → Units
Lower switch → Tens

The DIL switch must be set as follows:



Connections on the field bus node:




Fig. 12.1–2: Connections on the field bus node

Both socket-outlets are internally wired in parallel.

Connections for 24 V supply:




Fig.12.1–3: Connections for 24 V supply




Fig. 12.1–4: Example: 24 V supply connection

Address assignment

No. of valve positions	Valve No.	Output No.	Operands for the central units PCZB, 07 KR 91 and 07 KT 92	Operands for the coupler 07 CS 61 *)	Operands for the central unit UCZA
	0	O 0.00	A n , 00	A n , 00	A n , 00
	0	O 0.01	A n , 01	A n , 01	A n , 01
	1	O 0.02	A n , 02	A n , 02	A n , 02
	1	O 0.03	A n , 03	A n , 03	A n , 03
	2	O 0.04	A n , 04	A n , 04	A n , 04
	2	O 0.05	A n , 05	A n , 05	A n , 05
	3	O 0.06	A n , 06	A n , 06	A n , 06
	3	O 0.07	A n , 07	A n , 07	A n , 07
	4	O 0.08	A n , 08	A n , 08	A n+1 , 00
	4	O 0.09	A n , 09	A n , 09	A n+1 , 01
	5	O 0.10	A n , 10	A n , 10	A n+1 , 02
	5	O 0.11	A n , 11	A n , 11	A n+1 , 03
	6	O 0.12	A n , 12	A n , 12	A n+1 , 04
	6	O 0.13	A n , 13	A n , 13	A n+1 , 05
	7	O 0.14	A n , 14	A n , 14	A n+1 , 06
	7	O 0.15	A n , 15	A n , 15	A n+1 , 07
	8	O 1.00	A n+1 , 00	A n , 16	A n+2 , 00
	8	O 1.01	A n+1 , 01	A n , 17	A n+2 , 01
	9	O 1.02	A n+1 , 02	A n , 18	A n+2 , 02
	9	O 1.03	A n+1 , 03	A n , 19	A n+2 , 03
	O 1.04	A n+1 , 04	A n , 20	A n+2 , 04	
	O 1.05	A n+1 , 05	A n , 21	A n+2 , 05	
	O 1.06	A n+1 , 06	A n , 22	A n+2 , 06	
	O 1.07	A n+1 , 07	A n , 23	A n+2 , 07	
	O 1.08	A n+1 , 08	A n , 24	A n+3 , 00	
	O 1.09	A n+1 , 09	A n , 25	A n+3 , 01	
	O 1.10	A n+1 , 10	A n , 26	A n+3 , 02	
	O 1.11	A n+1 , 11	A n , 27	A n+3 , 03	
	O 1.12	A n+1 , 12	A n , 28	A n+3 , 04	
	O 1.13	A n+1 , 13	A n , 29	A n+3 , 05	
	O 1.14	A n+1 , 14	A n , 30	A n+3 , 06	
	O 1.15	A n+1 , 15	A n , 31	A n+3 , 07	
Permissible module addresses n for central unit or coupler: Values in brackets apply to valve island with 10 positions.			PCZB: 1...31 (30) 07 KR 91: 0...60 07 KT 92: 0...60	07 CS 61: 0... 8 (7) 10...18 (17) 20...28 (27) 30...38 (37) 40...48 (47) 50...58 (57) 60	UCZA: 0...60
Next higher address that can be set on another module			n+1 (n+2)	n+1	n+2 (n+4)

*) For the coupler 35 CS 91 (ABB Proconic T300), the assignment is freely programmable, see the description of the coupler 35 CS 91 (in preparation) in the system description ABB Protonic T300, order No. GATS131599R2002.

- The outputs 8 to 15 cannot be used with the valve island when operating with the UCZA. They are available on the bus for other CS31 modules.

- The setting for channel <7 or > 7 is omitted for the valve/installation island
- Error displays are automatically deleted after remedying the error
- Error displays on the device:
 - Green LED lights up: Operating voltage is present
 - Red LED lights up: Hardware error or short-circuit or voltage is too low.
 - Red LED flashes quickly: Baud rate or address is incorrect.
 - Red LED flashes slowly: Bus connection is not okay.

Technical data

See the device description in the Festo documents.

12.2 Installation island IIFB-02...FB5 (Festo)

4 to 10 valves, 24 V supply, with field bus nodes for ABB Procontic CS31 system bus

Size	No. of valve positions	Data length	Bus transfer time
4	4	2 Bytes / 2 Bytes	516 μ s
6	6	2 Bytes / 2 Bytes	516 μ s
8	8	4 Bytes / 4 Bytes	772 μ s
10	10	4 Bytes / 4 Bytes	772 μ s




Fig. 12.2-1: Installation island IIFB-02 (Festo)

The installation island comprises the following:

- Connection block for the valves (valve support with pneumatic connections)
- Valve/sensor coupling unit (with the electrical outputs for the valve solenoids, with 2 signal inputs for each valve position and with 2 additional signal inputs and 2 signal outputs 500 mA). All signals are displayed.
- Valves, mostly two-way valves, for travel cylinders with monostable and bistable versions
- Field bus nodes (connector for ABB Procontic CS31 system bus)


Manufacturer and source of supply: Festo KG, Esslingen.

Order No.: IIFB-02-x/x-x-FB5-x...
x: Pneumatic connection, No. of valves, valve type,...

The address of the field bus node on the system bus is set at the two-decade rotary switches after removing the front cover.

Upper switch → Units
Lower switch → Tens

The DIL switch must be set as follows:



Connection on the field bus node:




Fig. 12.2-2: Connection on the field bus node

Both socket-outlets are internally wired in parallel.

Connections for 24 V supply:




Fig. 12.2-3: Connections for 24 V supply

Connections for signal inputs and outputs

The socket-outlets are located at the top on the valve-sensor coupling unit.





Fig. 12.2-4: Connections for additional outputs





Fig.12.2-5: Connections for signal inputs




Fig.12.2-6: Signal inputs, internal connection

Address assignment for the installation islands sizes 4 and 6

Outputs

No. of valve positions	Output pair/valve No.	Installation island outputs *)	Operands for the central units PCZB, 07 KR 91 and 07 KT 92	Operands for the coupler 07 CS 61 **)	Operands for the central unit UCZA
	Additional outputs 0 0 1 1 2 2 3 3 4 4 5 5 Diagnosis bits	O 0.00 O 0.01 O 0.02 O 0.03 O 0.04 O 0.05 O 0.06 O 0.07 O 0.08 O 0.09 O 0.10 O 0.11 O 0.12 O 0.13 O 0.14 O 0.15	A n , 00 A n , 01 A n , 02 A n , 03 A n , 04 A n , 05 A n , 06 A n , 07 A n , 08 A n , 09 A n , 10 A n , 11 A n , 12 A n , 13 A n , 14 A n , 15	A n , 16 A n , 17 A n , 18 A n , 19 A n , 20 A n , 21 A n , 22 A n , 23 A n , 24 A n , 25 A n , 26 A n , 27 A n , 28 A n , 29 A n , 30 A n , 31	A n , 00 A n , 01 A n , 02 A n , 03 A n , 04 A n , 05 A n , 06 A n , 07 A n+1 , 00 A n+1 , 01 A n+1 , 02 A n+1 , 03 A n+1 , 04 A n+1 , 05 A n+1 , 06 A n+1 , 07
Permissible module addresses n for central unit or coupler:			PCZB: 1...31 07 KR 91: 0...60 07 KT 92: 0...60	07 CS 61: 0... 8 10...18 20...28 30...38 40...48 50...58 60	UCZA: 0...60
Next higher address that can be set on another module			n+1	n+1	n+2

**) For the coupler 35 CS 91 (ABB Procontic T300), the assignment is freely programmable, see the description of the coupler 35 CS 91 (in preparation) in the system description ABB Procontic T300, order No. GATS131599R2002.

- When operating with the UCZA, the channels 8 to 15 cannot be used with the CS31 designator with the valve/installation island. They are available for other CS31 modules.
- The setting for channel <7 or >7 is omitted for the valve / installation island.

- Error displays on the device:
 - Green LED lights up: Operating voltage is present
 - Red LED lights up: Hardware error or short-circuit or voltage is too low.
 - Red LED flashes quickly: Baud rate or address is incorrect.
 - Red LED flashes slowly: Bus connection is not okay.
- Error displays are automatically deleted after remedying the error.
- Note:
For T200 coupling: Configuration type EA16

Address assignment for the installation islands sizes 4 and 6

Outputs

No. of valve positions	Output pair/valve No.	Installation island outputs *)	Operands for the central units PCZB, 07 KR 91 and 07 KT 92	Operands for the coupler 07 CS 61 **)	Operands for the central unit UCZA
	Additional outputs 0 0 1 1 2 2 3 3 4 4 5 5 Diagnosis bits	O 0.00 O 0.01 O 0.02 O 0.03 O 0.04 O 0.05 O 0.06 O 0.07 O 0.08 O 0.09 O 0.10 O 0.11 O 0.12 O 0.13 O 0.14 O 0.15	A n , 00 A n , 01 A n , 02 A n , 03 A n , 04 A n , 05 A n , 06 A n , 07 A n , 08 A n , 09 A n , 10 A n , 11 A n , 12 A n , 13 A n , 14 A n , 15	A n , 16 A n , 17 A n , 18 A n , 19 A n , 20 A n , 21 A n , 22 A n , 23 A n , 24 A n , 25 A n , 26 A n , 27 A n , 28 A n , 29 A n , 30 A n , 31	A n , 00 A n , 01 A n , 02 A n , 03 A n , 04 A n , 05 A n , 06 A n , 07 A n+1 , 00 A n+1 , 01 A n+1 , 02 A n+1 , 03 A n+1 , 04 A n+1 , 05 A n+1 , 06 A n+1 , 07
Permissible module addresses n for central unit or coupler:			PCZB: 1...31 07 KR 91: 0...60 07 KT 92: 0...60	07 CS 61: 0... 8 10...18 20...28 30...38 40...48 50...58 60	UCZA: 0...60
Next higher address that can be set on another module			n+1	n+1	n+2

**) For the coupler 35 CS 91 (ABB Procontic T300), the assignment is freely programmable, see the description of the coupler 35 CS 91 (in preparation) in the system description ABB Procontic T300, order No. GATS131599R2002.

- When operating with the UCZA, the channels 8 to 15 cannot be used with the CS31 designator with the valve/installation island. They are available for other CS31 modules.
- The setting for channel <7 or >7 is omitted for the valve / installation island.

- Error displays on the device:
 - Green LED lights up: Operating voltage is present
 - Red LED lights up: Hardware error or short-circuit or voltage is too low.
 - Red LED flashes quickly: Baud rate or address is incorrect.
 - Red LED flashes slowly: Bus connection is not okay.
- Error displays are automatically deleted after remedying the error.
- Note:
For T200 coupling: Configuration type EA16

Inputs

No. of valves positions	Input pair/valve No.	Installation island inputs *)	Operands for the central units PCZB, 07 KR 91 and 07 KT 92	Operands for the coupler 07 CS 61	Operands for the central unit UCZA
	Additional inputs	I 0.00	E n , 00	E n , 00	E n , 00
	0	I 0.0	E n , 01	E n , 01	E n , 01
	0	I 0.02	E n , 02	E n , 02	E n , 02
	1	I 0.03	E n , 03	E n , 03	E n , 03
	1	I 0.04	E n , 04	E n , 04	E n , 04
	2	I 0.05	E n , 05	E n , 05	E n , 05
	2	I 0.06	E n , 06	E n , 06	E n , 06
	3	I 0.07	E n , 07	E n , 07	E n , 07
	3	I 0.08	E n , 08	E n , 08	E n+1 , 00
	4	I 0.09	E n , 09	E n , 09	E n+1 , 01
	4	I 0.10	E n , 10	E n , 10	E n+1 , 02
	5	I 0.11	E n , 11	E n , 11	E n+1 , 03
	5	I 0.12	E n , 12	E n , 12	E n+1 , 04
	6	I 0.13	E n , 13	E n , 13	E n+1 , 05
	6	I 0.14	E n , 14	E n , 14	E n+1 , 06
	6	I 0.15	E n , 15	E n , 15	E n+1 , 07
	7	I 1.00	E n+1 , 00	E n , 16	E n+2 , 00
	7	I 1.01	E n+1 , 01	E n , 17	E n+2 , 01
	8	I 1.02	E n+1 , 02	E n , 18	E n+2 , 02
	8	I 1.03	E n+1 , 03	E n , 19	E n+2 , 03
	9	I 1.04	E n+1 , 04	E n , 20	E n+2 , 04
	9	I 1.05	E n+1 , 05	E n , 21	E n+2 , 05
	Not used	I 1.06	E n+1 , 06	E n , 22	E n+2 , 06
		I 1.07	E n+1 , 07	E n , 23	E n+2 , 07
		I 1.08	E n+1 , 08	E n , 24	E n+3 , 00
		I 1.09	E n+1 , 09	E n , 25	E n+3 , 01
		I 1.10	E n+1 , 10	E n , 26	E n+3 , 02
		I 1.11	E n+1 , 11	E n , 27	E n+3 , 03
I 1.12		E n+1 , 12	E n , 28	E n+3 , 04	
Diagnosis bits	I 1.13	E n+1 , 13	E n , 29	E n+3 , 05	
	I 1.14	E n+1 , 14	E n , 30	E n+3 , 06	
	I 1.15	E n+1 , 15	E n , 31	E n+3 , 07	
Permissible module addresses n for the central unit or coupler:			PCZB: 1...30 07 KR 91: 0...60 07 KT 92: 0...60	07 CS 61: 0... 8 10...18 20...28 30...38 40...48 50...58 60	UCZA: 0...60
Next higher address which can be set on another module			n+2	n+1	n+4

- Note:
For T200 coupling: Configuration type EA32

Technical data

See the description in the Festo documentation.

Address assignment for the installation islands sizes 8 and 10

Outputs

No. of valve positions	Output pair/ valve No.	Installation island outputs	Operands for the central units PCZB, 07 KR 91 and 07 KT 92	Operands for the coupler 07 CS 61	Operands for the central unit UCZA	
	Additional outputs	O 0.00 O 0.01 O 0.02 O 0.03 O 0.04 O 0.05 O 0.06 O 0.07 O 0.08 O 0.09 O 0.10 O 0.11 O 0.12 O 0.13 O 0.14 O 0.15	A n , 00 A n , 01 A n , 02 A n , 03 A n , 04 A n , 05 A n , 06 A n , 07 A n , 08 A n , 09 A n , 10 A n , 11 A n , 12 A n , 13 A n , 14 A n , 15	A n , 32 A n , 33 A n , 34 A n , 35 A n , 36 A n , 37 A n , 38 A n , 39 A n , 40 A n , 41 A n , 42 A n , 43 A n , 44 A n , 45 A n , 46 A n , 47	A n , 00 A n , 01 A n , 02 A n , 03 A n , 04 A n , 05 A n , 06 A n , 07 A n+1 , 00 A n+1 , 01 A n+1 , 02 A n+1 , 03 A n+1 , 04 A n+1 , 05 A n+1 , 06 A n+1 , 07	
	7 7 8 8 9 9	O 1.00 O 1.01 O 1.02 O 1.03 O 1.04 O 1.05 O 1.06 O 1.07 O 1.08 O 1.09 O 1.10 O 1.11 O 1.12 O 1.13 O 1.14 O 1.15	A n+1 , 00 A n+1 , 01 A n+1 , 02 A n+1 , 03 A n+1 , 04 A n+1 , 05 A n+1 , 06 A n+1 , 07 A n+1 , 08 A n+1 , 09 A n+1 , 10 A n+1 , 11 A n+1 , 12 A n+1 , 13 A n+1 , 14 A n+1 , 15	A n , 48 A n , 49 A n , 50 A n , 51 A n , 52 A n , 53 A n , 54 A n , 55 A n , 56 A n , 57 A n , 58 A n , 59 A n , 60 A n , 61 A n , 62 A n , 63	A n+2 , 00 A n+2 , 01 A n+2 , 02 A n+2 , 03 A n+2 , 04 A n+2 , 05 A n+2 , 06 A n+2 , 07 A n+3 , 00 A n+3 , 01 A n+3 , 02 A n+3 , 03 A n+3 , 04 A n+3 , 05 A n+3 , 06 A n+3 , 07	
	Permissible module addresses for the central unit or coupler:			PCZB: 1...30 07 KR 91: 0...60 07 KT 92: 0...60	07 CS 61: 0... 8 10...18 20...28 30...38 40...48 50...58 60	UCZA: 0...60
	Next higher address which can be set on another module			n+2	n+1	n+4

- Note:
For T200 coupling: Configuration type EA32

Technical data

See the device description in the Festo documentation.

13.8 Interface Cables 07 SK 90 R1, 07 SK 91 R1 and 07 SK 92 R1

for connection of peripheral units to the 9-pole serial interfaces of the compact PLCs 07 KR 91, 07 KT 92 (ABB Procontic CS31) and the communication processors 07 KP 62, 07 KP 63 and 07 KP 64 (ABB Procontic T200) and 07 KP 90 (ABB Procontic CS31)


13.8.1 Survey table

The following table shows, which interface cables can be used for connections between the peripheral units and the 9-pole interfaces of the CS31 compact PLCs and the T200 communication processors. In order to connect

printers no definite cables can be proposed, because printers of different make have different interface pin assignments. However, under 13.8.5 a schematic diagram of a possible interface cable is proposed to connect the 07 DR 12 printer.

Connection from the processor unit, interface,	through the system cable (interface cable)	to the peripheral unit.
07 KR91 COM1 07 KT92 COM1 07 KP62 COM1	07 SK 90	Programming unit 07 PH 32 with 907 PC 331
07 KR91 COM1 07 KT92 COM1 07 KP62 COM1	07 SK 90	Operating station 35 BS 93 in active mode
07 KR91 COM1 07 KT92 COM1 07 KP62 COM1 07 KP63 COM1 07 KP64 CONSOLE 07 KP90 CONSOLE	07 SK 90	Terminal
07 KR91 COM1 07 KT92 COM1 07 KT92 COM2 07 KP62 COM1 07 KP62 COM2	07 SK 91	Operating station 35 BS 40
07 KR91 COM1 07 KT92 COM1 07 KT92 COM2 07 KP62 COM1 07 KP62 COM2	07 SK 91	Operating station 35 BS 93 in passive mode
07 KR91 COM1 07 KT92 COM1 07 KT92 COM2 07 KP62 COM1 07 KP62 COM2 07 KP64 RCOM 07 KP90 RCOM	07 SK 92	Modem with a standard interface, for signal names and pin assignment see 13.8.4
07 KR91 COM1 07 KT92 COM1 07 KT92 COM2 07 KP62 COM1 07 KP62 COM2	special printer cable, suitable for the used printer	Printer, under 13.8.5 a schematic diagram of an interface cable is proposed to connect the 07 DR 12 printer

13.8.2 Interface Cable 07 SK 90 R1 with adaptor



Intended Purpose

The cable 07 SK 90 is used to connect a 9-pole serial interface connector of CS31 compact PLCs or T200 communication processors with a peripheral unit in order to operate in programming or active mode (see 13.8.1 Survey table). If the peripheral unit has a 9-pole connector, the adaptor provided with (25-pole to 9-pole) can be employed for adaption.

Mechanical Design

Plug 1

SUB-D plug, 9-pole male, on the side of 07 KP 6x, 07 KR 91, 07 KT 92.

The housing is metal-plated, the shield is connected to the metal plate.

Plug 2

SUB-D plug, 25-pole female, on the side of the peripheral unit.

The plugs are mounted to both interfaces by means of screws.

Cable type

LICYCY 5 x 0.14/15

Adaptor provided

25-pole male/9-pole female for connection of peripheral units with 9-pole interfaces (male)

Technical Data

Length	5 m
Weight	220 g
Order number	GJR5 2502 00 R1





Fig. 13.8.2-2: Terminal assignment of the 07 SK 90 interface cable and the adaptor provided with

13.8.3 Interface Cable 07 SK 91 R1 with adaptor



Intended Purpose

The cable 07 SK 91 is used to connect a 9-pole serial interface connector of CS31 compact PLCs or T200 communication processors with a peripheral unit in order to operate in MMC mode or passive mode (see 13.8.1 Survey table). If the peripheral unit has a 9-pole connector, a commercially available adaptor (25-pole to 9-pole) has to be employed for adaption.

Mechanical Design

Plug 1

SUB-D plug, 9-pole male, on the side of 07 KP 6x, 07 KR 91, 07 KT 92.

The housing is metal-plated, the shield is connected to the metal plate.

Plug 2

SUB-D plug, 25-pole female, on the side of the peripheral unit.

The plugs are mounted to both interfaces by means of screws.

Cable type

LICYCY 5 x 0.14/15

Adaptor provided

25-pole male/25-pole male for connection of peripheral units with 25-pole interfaces (female)

Technical Data

Length	5 m
Weight	220 g
Order number	GJR5 2503 00 R1





Fig. 13.8.3-2: Terminal assignment of the 07 SK 91 interface cable and the adaptor provided with

13.8.4 Interface Cable 07 SK 92 R1



Intended Purpose

The cable 07 SK 92 is used to connect a 9-pole serial interface connector of CS31 compact PLCs or T200 communication processors with a modem with a standard interface (see 13.8.1 Survey table). If another modem has to be connected, the cable must be modified possibly.

Mechanical Design

Plug 1

SUB-D plug, 9-pole male, on the side of 07 KP 6x, 07 KR 91, 07 KT 92.

The housing is metal-plated, the shield is connected to the metal plate.

Plug 2

SUB-D plug, 25-pole male, on the side of the modem.

The plugs are mounted to both interfaces by means of screws.

Cable type

LICYCY 5 x 0.14/15

Technical Data

Length	5 m
Weight	220 g
Order number	GJR5 2504 00 R1





Fig. 13.8.4-2: Terminal assignment of 07 SK 92

13.8.5 Interface Cable for the 07 DR 12 printer (schematic diagram)



Intended Purpose

The shown cable can be used to connect a 9-pole serial interface connector of CS31 compact PLCs or T200 communication processors with the 07 DR 12 printer (EPSON FX 870, serial interface C823061) (see 13.8.1 Survey table). If another printer has to be connected, the cable must be modified possibly.

Mechanical Design

Plug 1

SUB-D plug, 9-pole male, on the side of 07 KP 6x, 07 KR 91, 07 KT 92.

The housing is metal-plated, the shield is connected to the metal plate.

Plug 2

SUB-D plug, 25-pole male, on the side of the printer.

The plugs are mounted to both interfaces by means of screws.

Usable cable type

LICYCY 5 x 0.14/15





Fig. 13.8.5-2: Schematic diagram of an interface cable for the 07 DR 12 printer

14.6 Lithium Battery Module 07 LE 90 R1

for data back-up in processor units of ABB Procontic systems



The 07 LE 90 R1 lithium battery module is used for RAM data back-up in several processor units of ABB Procontic programmable control systems. In order to change the

battery quickly, it is equipped with a 2-pole plug and two soldered wires.

The following handling advice has to be taken into due consideration:

- Use only genuine ABB lithium battery modules.
- Replace battery before it is fully exhausted.
- **Do not short-circuit battery!** It may cause overheating or explosion. Prevent accidental short-circuit. Therefore, do not put battery into metallic boxes or on metallic surfaces.
- **Do not try to charge battery!** It may cause overheating or explosion.
- **Replace battery only during the power is on.** Otherwise you can lose data.
- **Dispose of the battery ecologically!**
- **Pay attention to the battery monitoring facilities on the devices, e.g.,**

LED indications, whether the battery is exhausted or missing. The battery lifetime depends on the unit where it is installed.

Battery Lifetime

The value of the battery lifetime says how long the battery is able to back-up the stored data while the unit is not supplied by the internal voltages. If the internal voltages

are switched on, the battery is only discharged by its own leakage current.

Type of unit, where the battery is installed

Battery lifetime t (guaranteed values @ 25 °C)

07 KP 62 R101 (ABB Procontic T200)	min. 5 000 h
07 KP 63 R101 (ABB Procontic T200)	min. 5 000 h
07 KR 91 (ABB Procontic CS31)	min. 5 000 h
07 KT 92 (ABB Procontic CS31)	min. 5 000 h

Technical Data

Capacity	1000 mAh
Storage temperature	-10 °C...+75 °C
Operating temperature	0 °C...+55 °C
No-load voltage	3.6 V
Rated voltage	3.5 V
Temperature coefficient of rated voltage	ca. -1 mV/K
Temperature coefficient of capacity	≤ -1,5 % @ 0...70 °C
Self discharge	≤ 3.0 % per year @ 25 °C ≤ 6.0 % per year @ 40 °C ≤ 25.0 % per year @ 70 °C
Weight	20 g
Dimensions	18 mm x 53 mm
Order number	GJR5250700R1

